
YASKAWA

Σ -7-Series AC Servo Drive $\Sigma\text{-}7S$ SERVOPACK with 400 V-Input Power and MECHATROLINK-III **Communications References RJ-45** Connectors FT/EX Specification ZONE Outputs Product Manual

Model: SGD7S-DDD30BDDDF64



Copyright © 2016 YASKAWA ELECTRIC CORPORATION

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, or by any means, mechanical, electronic, photocopying, recording, or otherwise, without the prior written permission of Yaskawa. No patent liability is assumed with respect to the use of the information contained herein. Moreover, because Yaskawa is constantly striving to improve its high-quality products, the information contained in this manual is subject to change without notice. Every precaution has been taken in the preparation of this manual. Nevertheless, Yaskawa assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained in this publication.

About this Manual

This manual provides information required to select Σ -7S SERVOPACKs with MECHATROLINK-III Communications References and RJ-45 Connectors for Σ -7-Series AC Servo Drives, and to design, perform trial operation of, tune, operate, and maintain the Servo Drives.

Read and understand this manual to ensure correct usage of the Σ -7-Series AC Servo Drives.

Keep this manual in a safe place so that it can be referred to whenever necessary.

Outline of Manual


The contents of the chapters of this manual are described in the following table.

Refer to these chapters as required.

Chapter	Chapter Title	Contents
1	Basic Information on SERVOPACKs	Provides information required to select SERVOPACKs, such as SER- VOPACK models and combinations with Servomotors.
2	Selecting a SERVOPACK	Provides information required to select SERVOPACKs, such as specifi- cations, block diagrams, dimensional drawings, and connection exam- ples.
3	SERVOPACK Installation	Provides information on installing SERVOPACKs in the required loca- tions.
4	Wiring and Connecting SERVOPACKs	Provides information on wiring and connecting SERVOPACKs to power supplies and peripheral devices.
5	Wiring and Settings for the Dynamic Brake	Provides information about selecting the resistor, wiring, and parameter settings when using the dynamic brake.
6	Basic Functions That Require Set- ting before Operation	Describes the basic functions that must be set before you start Servo System operation. It also describes the setting methods.
7	Application Functions	Describes the application functions that you can set before you start Servo System operation. It also describes the setting methods.
8	Trial Operation and Actual Operation	Provides information on the flow and procedures for trial operation and convenient functions to use during trial operation.
9	Tuning	Provides information on the flow of tuning, details on tuning functions, and related operating procedures.
10	Monitoring	Provides information on monitoring SERVOPACK product information and SERVOPACK status.
11	Fully-Closed Loop Control	Provides detailed information on performing fully-closed loop control with the SERVOPACK.
12	Safety Functions	Provides detailed information on the safety functions of the SERVO- PACK.
13	Maintenance	Provides information on the meaning of, causes of, and corrections for alarms and warnings.
14	Parameter Lists	Provides information on the parameters.
15	Appendices	Provides information on interpreting panel displays and tables of corre- sponding SERVOPACK and SigmaWin+ function names.

Related Documents

The relationships between the documents that are related to the Servo Drives are shown in the following figure. The numbers in the figure correspond to the numbers in the table on the following pages. Refer to these documents as required.



Classification	Document Name	Document No.	Description
① Enclosed Document	Σ-7-Series AC Servo Drive Σ-7S and $Σ$ -7W SERVOPACK with 400 V-Input Power Safety Precautions	TOMP C710828 02	Provides detailed information for the safe usage of Σ -7-Series SERVOPACKs.
	Σ -7-Series AC Servo Drive Σ -7S SERVOPACK with 400 V-Input Power and EtherCAT (CoE) Communications References FT/EX Specification ZONE Outputs Product Manual	SIEP S800001 80	
② Σ-7-Series Σ-7S/Σ-7W	Σ -7-Series AC Servo Drive Σ -7S SERVOPACK with 400-V Input Power and MECHATROLINK-III Communications References RJ-45 Connectors FT/EX Specifi- cation ZONE Outputs Product Manual	This manual (SIEP S800002 14)	Provide detailed information on selecting Σ -7-Series SERVOPACKs and information on installing, connecting, setting, performing trial
SERVOPACK Product Manual	Σ -7-Series AC Servo Drive Σ -7W SERVOPACK with 400-V Input Power and EtherCAT (CoE) Communications References Product Manual	SIEP S800002 19	operation for, tuning, monitoring, and maintaining the Servo Drives.
	Σ -7-Series AC Servo Drive Σ -7W SERVOPACK with 400-V Input Power and MECHATROLINK-III Communications References RJ-45 Connectors Product Manual	CK with er and -III SIEP S800002 20 References	
 ③ Σ-7-Series Σ-7S/Σ-7W SERVOPACK FT/EX Product Manual 	$\begin{array}{l} \Sigma \text{-}7\text{-}\text{Series AC Servo Drive} \\ \Sigma \text{-}7\text{S SERVOPACK with} \\ 400\text{-}V \text{ Input Power and} \\ \text{EtherCAT (CoE) Communications} \\ \text{References} \\ \text{FT/EX Specification} \\ \text{for Advanced Safety Module} \\ \text{Product Manual} \end{array}$	SIEP S800002 30	Provide detailed information on the FT/EX Option for Σ -7-Series SERVOPACKs.
④ Enclosed Documents	AC Servo Drive Rotary Servomotor Safety Precautions	TOBP C230260 00	Provides detailed information for the safe usage of Σ -7-Series Rotary Servomotors and Direct Drive Servomotors.
Enclosed Documents	AC Servomotor Linear Σ Series Safety Precautions	TOBP C230800 00	Provides detailed information for the safe usage of Σ -7-Series Linear Servomotors.
© Σ-7-Series Rotary Servomotor Product Manual	Σ-7-Series AC Servo Drive Rotary Servomotor with 400 V-Input Power Product Manual	SIEP S800001 86	Provide detailed information on selecting, installing, and connecting
© Σ-7-Series Linear Servomotor Product Manual	Σ-7-Series AC Servo Drive Linear Servomotor with 400 V-Input Power Product Manual	SIEP S800001 81	the Σ -7-Series Servomotors.
⑦ Σ-7-Series	Σ-7-Series AC Servo Drive Digital Operator Operating Manual	SIEP S800001 33	Describes the operating proce- dures for a Digital Operator for a Σ -7-Series Servo System.
Operation Interface Operating Manuals	AC Servo Drive Engineering Tool SigmaWin+ Operation Manual	SIET S800001 34	Provides detailed operating proce- dures for the SigmaWin+ Engineer- ing Tool for a Σ -7-Series Servo System.

Using This Manual

◆ Technical Terms Used in This Manual

The following terms are used in this manual.

Term	Meaning
Servomotor	A Σ-7-Series Rotary Servomotor or Linear Servomotor.
Rotary Servomotor	A Σ-7-Series Rotary Servomotor (SGM7J, SGM7A, or SGM7G).
Linear Servomotor	A Σ -7-Series Linear Servomotor (SGLF or SGLT).
SERVOPACK	A Σ -7-Series Σ -7S servo amplifier with MECHATROLINK-III Communications References.
Servo Drive	The combination of a Servomotor and SERVOPACK.
Servo System	A servo control system that includes the combination of a Servo Drive with a host controller and peripheral devices.
servo ON	Supplying power to the motor.
servo OFF	Not supplying power to the motor.
base block (BB)	Shutting OFF the power supply to the motor by shutting OFF the base current to the power transistor in the SERVOPACK.
servo lock	A state in which the motor is stopped and is in a position loop with a position reference of 0.
Main Circuit Cable	One of the cables that connect to the main circuit terminals, including the Main Circuit Power Supply Cable, Control Power Supply Cable, and Servomotor Main Circuit Cable.
MECHATROLINK-III Communications Cable (RJ-45)	A MECHATROLINK-III Communications Cable for RJ-45 connectors.
SigmaWin+	The Engineering Tool for setting up and tuning Servo Drives or a computer in which the Engineering Tool is installed.

• Differences in Terms for Rotary Servomotors and Linear Servomotors

There are differences in the terms that are used for Rotary Servomotors and Linear Servomotors. This manual primarily describes Rotary Servomotors. If you are using a Linear Servomotor, you need to interpret the terms as given in the following table.

Rotary Servomotors	Linear Servomotors
torque	force
moment of inertia	mass
rotation	movement
forward rotation and reverse rotation	forward movement and reverse movement
CW and CCW pulse trains	forward and reverse pulse trains
rotary encoder	linear encoder
absolute rotary encoder	absolute linear encoder
incremental rotary encoder	incremental linear encoder
unit: min ⁻¹	unit: mm/s
unit: N·m	unit: N

Notation Used in this Manual

Notation for Reverse Signals

The names of reverse signals (i.e., ones that are valid when low) are written with a forward slash (/) before the signal abbreviation.


Notation Example

BK is written as /BK.

Notation for Parameters

The notation depends on whether the parameter requires a numeric setting (parameter for numeric setting) or requires the selection of a function (parameter for selecting functions).

Parameters for Numeric Settings



Notation Example

Notation Examples for Pn002

	Digit Notation			Numeric Value Notation
n.0000	Notation	Meaning	Notation	Meaning
	Pn002 = n.□□□X	Indicates the first digit from the right in Pn002.	Pn002 = n.□□□1	Indicates that the first digit from the right in Pn002 is set to 1.
	Pn002 = n.□□X□	Indicates the second digit from the right in Pn002.	Pn002 = n.□□1□	Indicates that the second digit from the right in Pn002 is set to 1.
	Pn002 = n.□X□□	Indicates the third digit from the right in Pn002.	Pn002 = n.⊡1⊡⊡	Indicates that the third digit from the right in Pn002 is set to 1.
►	Pn002 = n.X□□□	Indicates the fourth digit from the right in Pn002.	Pn002 = n.1□□□	Indicates that the fourth digit from the right in Pn002 is set to 1.

Engineering Tools Used in This Manual

This manual uses the interfaces of the SigmaWin+ for descriptions.

♦ Trademarks

- QR code is a trademark of Denso Wave Inc.
- MECHATROLINK is a trademark of the MECHATROLINK Members Association.
- Other product names and company names are the trademarks or registered trademarks of the respective company. "TM" and the R mark do not appear with product or company names in this manual.

Visual Aids

The following aids are used to indicate certain types of information for easier reference.



Indicates precautions or restrictions that must be observed. Also indicates alarm displays and other precautions that will not result in machine damage.



Indicates definitions of difficult terms or terms that have not been previously explained in this manual.



Indicates operating or setting examples.

Information Indicates supplemental information to deepen understanding or useful information.

Safety Precautions

♦ Safety Information

To prevent personal injury and equipment damage in advance, the following signal words are used to indicate safety precautions in this document. The signal words are used to classify the hazards and the degree of damage or injury that may occur if a product is used incorrectly. Information marked as shown below is important for safety. Always read this information and heed the precautions that are provided.

\Lambda DANGER

• Indicates precautions that, if not heeded, are likely to result in loss of life, serious injury, or fire.

• Indicates precautions that, if not heeded, could result in loss of life, serious injury, or fire.

• Indicates precautions that, if not heeded, could result in relatively serious or minor injury, or in fire.

NOTICE

• Indicates precautions that, if not heeded, could result in property damage.

Safety Precautions That Must Always Be Observed

General Precautions

- Read and understand this manual to ensure the safe usage of the product.
- Keep this manual in a safe, convenient place so that it can be referred to whenever necessary. Make sure that it is delivered to the final user of the product.
- Do not remove covers, cables, connectors, or optional devices while power is being supplied to the SERVOPACK.

There is a risk of electric shock, operational failure of the product, or burning.

- Use a power supply with specifications (number of phases, voltage, frequency, and AC/DC type) that are appropriate for the product. There is a risk of burning, electric shock, or fire.
- Connect the ground terminals on the SERVOPACK and Servomotor to ground poles according to local electrical codes. (Connect to 10 Ω or less.) There is a risk of electric shock or fire.
- Do not attempt to disassemble, repair, or modify the product. There is a risk of fire or failure. The warranty is void for the product if you disassemble, repair, or modify it.

- The SERVOPACK heat sinks, regenerative resistors, External Dynamic Brake Resistors, Servomotors, and other components can be very hot while power is ON or soon after the power is turned OFF. Implement safety measures, such as installing covers, so that hands and parts such as cables do not come into contact with hot components. There is a risk of burn injury.
- For a 24-VDC power supply, use a power supply device with double insulation or reinforced insulation.
 - There is a risk of electric shock.
- Do not damage, pull on, apply excessive force to, place heavy objects on, or pinch cables. There is a risk of failure, damage, or electric shock.
- The person who designs the system that uses the hard wire base block safety function must have a complete knowledge of the related safety standards and a complete understanding of the instructions in this document.
 - There is a risk of injury, product damage, or machine damage.
- Do not use the product in an environment that is subject to water, corrosive gases, or flammable gases, or near flammable materials.
 There is a risk of electric shock or fire.

- Do not attempt to use a SERVOPACK or Servomotor that is damaged or that has missing parts.
- Install external emergency stop circuits that shut OFF the power supply and stops operation immediately when an error occurs.
- In locations with poor power supply conditions, install the necessary protective devices (such as AC Reactors) to ensure that the input power is supplied within the specified voltage range. There is a risk of damage to the SERVOPACK.
- Use a Noise Filter to minimize the effects of electromagnetic interference. Electronic devices used near the SERVOPACK may be affected by electromagnetic interference.
- Always use a Servomotor and SERVOPACK in one of the specified combinations.
- Do not touch a SERVOPACK or Servomotor with wet hands. There is a risk of product failure.

Storage Precautions

• Do not place an excessive load on the product during storage. (Follow all instructions on the packages.)

There is a risk of injury or damage.

NOTICE

- Do not install or store the product in any of the following locations.
 - Locations that are subject to direct sunlight
 - · Locations that are subject to ambient temperatures that exceed product specifications
 - Locations that are subject to relative humidities that exceed product specifications
 - · Locations that are subject to condensation as the result of extreme changes in temperature
 - · Locations that are subject to corrosive or flammable gases
 - · Locations that are near flammable materials
 - · Locations that are subject to dust, salts, or iron powder
 - Locations that are subject to water, oil, or chemicals
 - · Locations that are subject to vibration or shock that exceeds product specifications
 - Locations that are subject to radiation
 - If you store or install the product in any of the above locations, the product may fail or be damaged.

Transportation Precautions

- Transport the product in a way that is suitable to the mass of the product.
- Do not use the eyebolts on a SERVOPACK or Servomotor to move the machine. There is a risk of damage or injury.
- When you handle a SERVOPACK or Servomotor, be careful of sharp parts, such as the corners. There is a risk of injury.
- Do not place an excessive load on the product during transportation. (Follow all instructions on the packages.)
 - There is a risk of injury or damage.

- Do not hold onto the front cover or connectors when you move a SERVOPACK. There is a risk of the SERVOPACK falling.
- A SERVOPACK or Servomotor is a precision device. Do not drop it or subject it to strong shock. There is a risk of failure or damage.
- Do not subject connectors to shock. There is a risk of faulty connections or damage.
- If disinfectants or insecticides must be used to treat packing materials such as wooden frames, plywood, or pallets, the packing materials must be treated before the product is packaged, and methods other than fumigation must be used.

Example: Heat treatment, where materials are kiln-dried to a core temperature of 56°C for 30 minutes or more.

If the electronic products, which include stand-alone products and products installed in machines, are packed with fumigated wooden materials, the electrical components may be greatly damaged by the gases or fumes resulting from the fumigation process. In particular, disinfectants containing halogen, which includes chlorine, fluorine, bromine, or iodine can contribute to the erosion of the capacitors.

• Do not overtighten the eyebolts on a SERVOPACK or Servomotor. If you use a tool to overtighten the eyebolts, the tapped holes may be damaged.

Installation Precautions

- Install the Servomotor or SERVOPACK in a way that will support the mass given in technical documents.
- Install SERVOPACKs, Servomotors, regenerative resistors, and External Dynamic Brake Resistors on nonflammable materials.

Installation directly onto or near flammable materials may result in fire.

- Provide the specified clearances between the SERVOPACK and the control panel as well as with other devices.
 - There is a risk of fire or failure.
- Install the SERVOPACK in the specified orientation. There is a risk of fire or failure.
- Do not step on or place a heavy object on the product. There is a risk of failure, damage, or injury.
- Do not allow any foreign matter to enter the SERVOPACK or Servomotor. There is a risk of failure or fire.

- Do not install or store the product in any of the following locations.
 - Locations that are subject to direct sunlight
 - · Locations that are subject to ambient temperatures that exceed product specifications
 - Locations that are subject to relative humidities that exceed product specifications
 - Locations that are subject to condensation as the result of extreme changes in temperature
 - · Locations that are subject to corrosive or flammable gases
 - · Locations that are near flammable materials
 - · Locations that are subject to dust, salts, or iron powder
 - Locations that are subject to water, oil, or chemicals
 - · Locations that are subject to vibration or shock that exceeds product specifications
 - Locations that are subject to radiation
 - If you store or install the product in any of the above locations, the product may fail or be damaged.
- Use the product in an environment that is appropriate for the product specifications. If you use the product in an environment that exceeds product specifications, the product may fail or be damaged.
- A SERVOPACK or Servomotor is a precision device. Do not drop it or subject it to strong shock. There is a risk of failure or damage.
- Always install a SERVOPACK in a control panel.
- Do not allow any foreign matter to enter a SERVOPACK or a Servomotor with a Cooling Fan and do not cover the outlet from the Servomotor's cooling fan. There is a risk of failure.

Wiring Precautions

A DANGER


• Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.

- Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.
- Check all wiring and power supplies carefully.

Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures. If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. This could damage the machine or cause an accident that may result in death or injury.

- Connect the AC and DC power supplies to the specified SERVOPACK terminals.
 - Connect an AC power supply to the L1, L2, and L3 terminals on the SERVOPACK.
 - Connect a DC power supply to the B1 and ⊖2 terminals and the 24 V and 0 V terminals on the SERVOPACK.

There is a risk of failure or fire.



- Whenever possible, use the Cables specified by Yaskawa. If you use any other cables, confirm the rated current and application environment of your model and use the wiring materials specified by Yaskawa or equivalent materials.
- Securely tighten connector screws and lock mechanisms. Insufficient tightening may result in connectors falling off during operation.
- Do not bundle power lines (e.g., the Main Circuit Cable) and low-current lines (e.g., the I/O Signal Cables or Encoder Cables) together or run them through the same duct. If you do not place power lines and low-current lines in separate ducts, separate them by at least 30 cm. If the cables are too close to each other, malfunctions may occur due to noise affecting the low-current lines.
- Install a battery at either the host controller or on the Encoder Cable. If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.
- When connecting a battery, connect the polarity correctly. There is a risk of battery rupture or encoder failure.
- If you use an External Regenerative Resistor or External Dynamic Brake Resistor, use cable ties, clamps, or other means to secure the resistor so that the connectors or terminal blocks inside the SERVOPACK will not be affected even if the resistor is subjected to vibration or shock. There is a risk of SERVOPACK damage.

Operation Precautions

WARNING

• Before starting operation with a machine connected, change the settings of the switches and parameters to match the machine.

Unexpected machine operation, failure, or personal injury may occur if operation is started before appropriate settings are made.

- Do not radically change the settings of the parameters. There is a risk of unstable operation, machine damage, or injury.
- Install limit switches or stoppers at the ends of the moving parts of the machine to prevent unexpected accidents.

There is a risk of machine damage or injury.

- For trial operation, securely mount the Servomotor and disconnect it from the machine. There is a risk of injury.
- Forcing the motor to stop for overtravel is disabled when the Jog, Origin Search, or Easy FFT utility function is executed. Take necessary precautions. There is a risk of machine damage or injury.
- When an alarm occurs, the motor will coast to a stop or stop with the dynamic brake according to a setting in the SERVOPACK. The coasting distance will change with the moment of inertia of the load. Check the coasting distance during trial operation and implement suitable safety measures on the machine.
- Do not enter the machine's range of motion during operation. There is a risk of injury.
- Do not touch the moving parts of the Servomotor or machine during operation. There is a risk of injury.

- Design the system to ensure safety even when problems, such as broken signal lines, occur. For example, the P-OT and N-OT signals are set in the default settings to operate on the safe side if a signal line breaks. Do not change the polarity of this type of signal.
- When overtravel occurs, the power supply to the motor is turned OFF and the brake is released. If you use the Servomotor to drive a vertical load, set the Servomotor to enter a zero-clamped state after the Servomotor stops. Also, install safety devices (such as an external brake or counterweight) to prevent the moving parts of the machine from falling.
- Always turn OFF the servo before you turn OFF the power supply. If you turn OFF the main circuit power supply or control power supply during operation before you turn OFF the servo, the Servomotor will stop as follows:
 - If you turn OFF the main circuit power supply during operation without turning OFF the servo, the Servomotor will stop abruptly with the dynamic brake.
 - If you turn OFF the control power supply without turning OFF the servo, the stopping method that is used by the Servomotor depends on the model of the SERVOPACK. For details, refer to the manual for the SERVOPACK.
 - If you use an External Dynamic Brake Resistor, the stopping method will be different from when you use built-in Dynamic Brake Resistor. For details, refer to the product manual for your SERVOPACK.
- Do not use the dynamic brake for any application other than an emergency stop. There is a risk of failure due to rapid deterioration of elements in the SERVOPACK and the risk of unexpected operation, machine damage, burning, or injury.

- When you adjust the gain during system commissioning, use a measuring instrument to monitor the torque waveform and speed waveform and confirm that there is no vibration. If a high gain causes vibration, the Servomotor will be damaged quickly.
- Do not frequently turn the power supply ON and OFF. After you have started actual operation, allow at least one hour between turning the power supply ON and OFF (as a guideline). Do not use the product in applications that require the power supply to be turned ON and OFF frequently.
 - The elements in the SERVOPACK will deteriorate quickly.
- An alarm or warning may occur if communications are performed with the host controller while the SigmaWin+ or Digital Operator is operating.
- If an alarm or warning occurs, it may interrupt the current process and stop the system.
- After you complete trial operation of the machine and facilities, use the SigmaWin+ to back up the settings of the SERVOPACK parameters. You can use them to reset the parameters after SERVOPACK replacement.

If you do not copy backed up parameter settings, normal operation may not be possible after a faulty SERVOPACK is replaced, possibly resulting in machine or equipment damage.

Maintenance and Inspection Precautions

🛕 DANGER

• Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.

• Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.

• Wait for at least six minutes after turning OFF the power supply (with a SERVOPACK for a 100-VAC input, wait for at least nine minutes) and then make sure that the CHARGE indicator is not lit before starting wiring or inspection work. Do not touch the power supply terminals while the CHARGE lamp is lit after turning OFF the power supply because high voltage may still remain in the SERVOPACK.

There is a risk of electric shock.

• Before you replace a SERVOPACK, back up the settings of the SERVOPACK parameters. Copy the backed up parameter settings to the new SERVOPACK and confirm that they were copied correctly.

If you do not copy backed up parameter settings or if the copy operation is not completed normally, normal operation may not be possible, possibly resulting in machine or equipment damage.

NOTICE

• Discharge all static electricity from your body before you operate any of the buttons or switches inside the front cover of the SERVOPACK. There is a risk of equipment damage.

Troubleshooting Precautions

• If the safety device (molded-case circuit breaker or fuse) installed in the power supply line operates, remove the cause before you supply power to the SERVOPACK again. If necessary, repair or replace the SERVOPACK, check the wiring, and remove the factor that caused the safety device to operate.

There is a risk of fire, electric shock, or injury.

• The product may suddenly start to operate when the power supply is recovered after a momentary power interruption. Design the machine to ensure human safety when operation restarts. There is a risk of injury.

- When an alarm occurs, remove the cause of the alarm and ensure safety. Then reset the alarm or turn the power supply OFF and ON again to restart operation. There is a risk of injury or machine damage.
- If the Servo ON signal is input to the SERVOPACK and an alarm is reset, the Servomotor may suddenly restart operation. Confirm that the servo is OFF and ensure safety before you reset an alarm.
 - There is a risk of injury or machine damage.
- Always insert a Magnetic Contactor in the line between the main circuit power supply and the main circuit power supply terminals on the SERVOPACK so that the power supply can be shut OFF at the main circuit power supply.
 If a Magnetic Contactor is not connected when the SERVOPACK fails, a large current may flow, possibly resulting in fire.
- If an alarm occurs, shut OFF the main circuit power supply. There is a risk of fire due to a Regenerative Resistor overheating as the result of regenerative transistor failure.
- Install a ground fault detector against overloads and short-circuiting or install a molded-case circuit breaker combined with a ground fault detector. There is a risk of SERVOPACK failure or fire if a ground fault occurs.
- The holding brake on a Servomotor will not ensure safety if there is the possibility that an external force (including gravity) may move the current position and create a hazardous situation when power is interrupted or an error occurs. If an external force may cause movement, install an external braking mechanism that ensures safety.

Disposal Precautions

• Correctly discard the product as stipulated by regional, local, and municipal laws and regulations. Be sure to include these contents in all labelling and warning notifications on the final product as necessary.



General Precautions

- Figures provided in this document are typical examples or conceptual representations. There may be differences between them and actual wiring, circuits, and products.
- The products shown in illustrations in this document are sometimes shown without covers or protective guards. Always replace all covers and protective guards before you use the product.
- If you need a new copy of this document because it has been lost or damaged, contact your nearest Yaskawa representative or one of the offices listed on the back of this document.
- This document is subject to change without notice for product improvements, specifications changes, and improvements to the manual itself.
 We will update the document number of the document and issue revisions when changes are made.
- Any and all quality guarantees provided by Yaskawa are null and void if the customer modifies the product in any way. Yaskawa disavows any responsibility for damages or losses that are caused by modified products.

Warranty

Details of Warranty

Warranty Period

The warranty period for a product that was purchased (hereinafter called the "delivered product") is one year from the time of delivery to the location specified by the customer or 18 months from the time of shipment from the Yaskawa factory, whichever is sooner.

Warranty Scope

Yaskawa shall replace or repair a defective product free of charge if a defect attributable to Yaskawa occurs during the above warranty period.

This warranty does not cover defects caused by the delivered product reaching the end of its service life and replacement of parts that require replacement or that have a limited service life.

This warranty does not cover failures that result from any of the following causes.

- Improper handling, abuse, or use in unsuitable conditions or in environments not described in product catalogs or manuals, or in any separately agreed-upon specifications
- · Causes not attributable to the delivered product itself
- Modifications or repairs not performed by Yaskawa
- Use of the delivered product in a manner in which it was not originally intended
- Causes that were not foreseeable with the scientific and technological understanding at the time
 of shipment from Yaskawa
- Events for which Yaskawa is not responsible, such as natural or human-made disasters

Limitations of Liability

- Yaskawa shall in no event be responsible for any damage or loss of opportunity to the customer that arises due to failure of the delivered product.
- Yaskawa shall not be responsible for any programs (including parameter settings) or the results of program execution of the programs provided by the user or by a third party for use with programmable Yaskawa products.
- The information described in product catalogs or manuals is provided for the purpose of the customer purchasing the appropriate product for the intended application. The use thereof does not guarantee that there are no infringements of intellectual property rights or other proprietary rights of Yaskawa or third parties, nor does it construe a license.
- Yaskawa shall not be responsible for any damage arising from infringements of intellectual property rights or other proprietary rights of third parties as a result of using the information described in catalogs or manuals.

Suitability for Use

- It is the customer's responsibility to confirm conformity with any standards, codes, or regulations that apply if the Yaskawa product is used in combination with any other products.
- The customer must confirm that the Yaskawa product is suitable for the systems, machines, and equipment used by the customer.
- Consult with Yaskawa to determine whether use in the following applications is acceptable. If use in the application is acceptable, use the product with extra allowance in ratings and specifications, and provide safety measures to minimize hazards in the event of failure.
 - Outdoor use, use involving potential chemical contamination or electrical interference, or use in conditions or environments not described in product catalogs or manuals
 - Nuclear energy control systems, combustion systems, railroad systems, aviation systems, vehicle systems, medical equipment, amusement machines, and installations subject to separate industry or government regulations
 - Systems, machines, and equipment that may present a risk to life or property
 - Systems that require a high degree of reliability, such as systems that supply gas, water, or electricity, or systems that operate continuously 24 hours a day
 - Other systems that require a similar high degree of safety
- Never use the product for an application involving serious risk to life or property without first ensuring that the system is designed to secure the required level of safety with risk warnings and redundancy, and that the Yaskawa product is properly rated and installed.
- The circuit examples and other application examples described in product catalogs and manuals are for reference. Check the functionality and safety of the actual devices and equipment to be used before using the product.
- Read and understand all use prohibitions and precautions, and operate the Yaskawa product correctly to prevent accidental harm to third parties.

Specifications Change

The names, specifications, appearance, and accessories of products in product catalogs and manuals may be changed at any time based on improvements and other reasons. The next editions of the revised catalogs or manuals will be published with updated code numbers. Consult with your Yaskawa representative to confirm the actual specifications before purchasing a product.

Compliance with UL Standards, EU Directives, and Other Safety Standards

Certification marks for the standards for which the product has been certified by certification bodies are shown on nameplate. Products that do not have the marks are not certified for the standards. Refer to the Servomotor manual for compliant standards of Servomotors.

North American Safety Standards (UL)



Product	Model	UL Standards (UL File No.)
SERVOPACKs	SGD7S	UL 61800-5-1 (E147823), CSA C22.2 No.274

European Directives

CE			
Product	Model	EU Directive	Harmonized Standards
	s SGD7S	Machinery Directive 2006/42/EC	EN ISO13849-1: 2015
SERVOPACKs		EMC Directive 2014/30/EU	EN 55011 group 1, class A EN 61000-6-2 EN 61000-6-4 EN 61800-3 (Category C2, Second environment)
		Low Voltage Directive 2014/35/EU	EN 50178 EN 61800-5-1
		RoHS Directive 2011/65/EU (EU)2015/863	EN IEC 63000

Note: 1. We declared the CE Marking based on the harmonized standards in the above table.

2. These products are for industrial use. In home environments, these products may cause electromagnetic interfer-

ence and additional noise reduction measures may be necessary.

Safety Standards

Product	Model	Safety Standards	Standards
		Safety of Machinery	EN ISO13849-1: 2015 IEC 60204-1
SERVOPACKs	SGD7S	Functional Safety	IEC 61508 series IEC 62061 IEC 61800-5-2
		EMC	IEC 61326-3-1

Safety Parameters

Item	Standards	Performa	ance Level
Sofoty Integrity Loyal	IEC 61508	SIL3	
Safety Integrity Level	IEC 62061	SILCL3	
Mission Time	IEC 61508	10 years	20 years
Probability of Dangerous Failure per Hour	IEC 61508 IEC 62061	$PFH = 4.60 \times 10^{-9} [1/h]$ (4.60% of SIL3)	$PFH = 4.62 \times 10^{-9} [1/h]$ (4.62% of SIL3)
Performance Level	EN ISO 13849-1	PLe (Category 3)	
Mean Time to Dangerous Failure of Each Channel	EN ISO 13849-1	MTTFd: High	
Average Diagnostic Coverage	EN ISO 13849-1	DCavg: Medium	
Stop Category	IEC 60204-1	Stop category 0	
Safety Function	IEC 61800-5-2	STO	
Hardware Fault Tolerance	IEC 61508	HFT = 1	
Subsystem	IEC 61508	В	

Contents

About this Manual		. iii
Outline of Manual		. iii
Related Documents		. iv
Using This Manual		. vi
Safety Precautions		.ix
Warranty	>	xix
Compliance with UL Standards, EU Directives, and Other Safety Standards .	>	xxi

Basic Information on SERVOPACKs

2

1.1	The Σ -7 Series	-2
1.2	nterpreting the Nameplate1	-3
1.3	Part Names1	-4
1.4	Model Designations 1- 1.4.1 Interpreting SERVOPACK Model Numbers 1	
	1.4.2 Interpreting Servomotor Model Numbers	-7
1.5	Combinations of SERVOPACKs and Servomotors 1	-8
	1.5.1Combinations of Rotary Servomotors and SERVOPACKs11.5.2Combinations of Linear Servomotors and SERVOPACKs1	
1.6	Functions	0

Selecting a SERVOPACK

2.1	Ratin	gs and Specifications 2-2
	2.1.1 2.1.2 2.1.3	Ratings2-2SERVOPACK Overload Protection Characteristics2-3Specifications2-4
2.2	Block	C Diagrams 2-7
	2.2.1 2.2.2	SERVOPACKs without Built-in Servomotor Brake Control
2.3	Exter	nal Dimensions
	2.3.1 2.3.2	Front Cover Dimensions and Connector Specifications2-13SERVOPACK External Dimensions2-15
2.4	Exampl	es of Standard Connections between SERVOPACKs and Peripheral Devices. 2-17

3 S	ERVOPACK Installation
3.1	Installation Precautions 3-2
3.2	Mounting Types and Orientation 3-3
3.3	Mounting Hole Dimensions 3-4
3.4	Mounting Interval 3-5
	3.4.1Installing One SERVOPACK in a Control Panel
3.5	Monitoring the Installation Environment
3.6	Derating Specifications 3-7
3.7	EMC Installation Conditions 3-8
4 ^v	Viring and Connecting SERVOPACKs
4.1	Wiring and Connecting SERVOPACKs 4-3
	4.1.1General Precautions4-34.1.2Countermeasures against Noise4-54.1.3Grounding4-8
4.2	Basic Wiring Diagrams 4-9
4.3	Wiring the Power Supply to the SERVOPACK 4-11
	4.3.1Terminal Symbols and Terminal Names4-114.3.2Connector Wiring Procedure4-134.3.3Power ON Sequence4-144.3.4Power Supply Wiring Diagrams4-154.3.5Wiring Regenerative Resistors4-184.3.6Wiring Reactors for Harmonic Suppression4-18
4.4	Wiring Servomotors 4-19
	4.4.1Terminal Symbols and Terminal Names4-194.4.2Pin Arrangement of Encoder Connector (CN2)4-194.4.3Wiring the SERVOPACK to the Encoder4-204.4.4Wiring the SERVOPACK to the Holding Brake4-27
4.5	I/O Signal Connections 4-29
	4.5.1I/O Signal Connector (CN1) Names and Functions4-294.5.2I/O Signal Connector (CN1) Pin Arrangement4-314.5.3I/O Signal Wiring Examples4-324.5.4I/O Circuits4-34
4.6	Connecting Safety Function Signals 4-36
	4.6.1 Pin Arrangement of Safety Function Signals (CN8)4-36 4.6.2 I/O Circuits4-36
4.7	Connecting MECHATROLINK-III Communications Cables (RJ-45) 4-38

4	4.8 Conr	necting the Other Connectors
_	4.8.1 4.8.2 4.8.3	Serial Communications Connector (CN3)4-39Computer Connector (CN7)4-39Analog Monitor Connector (CN5)4-39
5	Wiring	and Settings for the Dynamic Brake
5	5.1 Intro	duction to the Dynamic Brake 5-2
	5.1.1 5.1.2	SERVOPACK Models with a Built-In Dynamic Brake
5	5.2 SER	OPACK Models with a Built-In Dynamic Brake
_	5.2.1 5.2.2 5.2.3 5.2.4	Using the Dynamic Brake5-3Selecting the Dynamic Brake Resistor5-4Connecting Dynamic Brake Resistors5-7Setting the Energy Consumption and Resistance of5-9
5	5.3 SER\	/OPACK Models without a Built-In Dynamic Brake 5-10
_	5.3.1 5.3.2 5.3.3 5.3.4	Using the Dynamic Brake5-10Selecting the Devices Required for the Dynamic Brake Circuit5-12Wiring the Dynamic Brake Circuit5-15Parameter Settings for the Dynamic Brake Circuit5-16
5	5.4 Coas	ting Distances for Dynamic Braking
_	5.4.1 5.4.2	Coasting Distance during Dynamic Braking

7	
2	

Basic Functions That Require Setting before Operation

6.1	Mani	pulating Parameters (Pn□□□)	. 6-4
	6.1.1 6.1.2 6.1.3 6.1.4 6.1.5	Parameter Classification Notation for Parameters Parameter Setting Methods Write Prohibition Setting for Parameters Initializing Parameter Settings	6-5 6-6 6-7
6.2	MECH	HATROLINK-III Communications Settings	6-12
	6.2.1 6.2.2	Communications Settings	
6.3	Powe	er Supply Type Settings for the Main Circuit	6-13
6.4	Autor	matic Detection of Connected Motor	. 6-14
6.5	Moto	r Direction Setting	6-15
6.6	Settir	ng the Linear Encoder Pitch	. 6-16
6.7	Writin	ng Linear Servomotor Parameters	. 6-17
6.8	Selec	ting the Phase Sequence for a Linear Servomotor	6-21

6.9	Polar	ity Sensor Setting 6-23
6.10	6.10.1 6.10.2	ity Detection.6-24Restrictions
6.11	Overt	ravel and Related Settings 6-27
	6.11.2 6.11.3 6.11.4	Overtravel Signals
6.12	Holdi	ng Brake
	6.12.3 6.12.4	Brake Operating Sequence6-32/BK (Brake) Signal.6-33Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped.6-34Output Timing of /BK (Brake) Signal When the Servomotor Is Operating.6-34Built-in Brake Relay Usage Selection.6-36
6.13		r Stopping Methods for Servo OFF and Alarms 6-37
		Stopping Method for Servo OFF
6.14	Moto	r Overload Detection Level 6-40
		Detection Timing for Overload Warnings (A.910)
6.15	Electi	ronic Gear Settings 6-42
		Electronic Gear Ratio Settings
6.16	Reset	tting the Absolute Encoder 6-47
	6.16.2 6.16.3	Precautions on Resetting
6.17	Settin	ng the Origin of the Absolute Encoder 6-50
	6.17.1 6.17.2	Absolute Encoder Origin Offset
6.18	Settin	ng the Regenerative Resistor Capacity

Application Functions

7

7.1	I/O Si	ignal Allocations
	7.1.1 7.1.2 7.1.3 7.1.4 7.1.5 7.1.6 7.1.7 7.1.8 7.1.9 7.1.10	Input Signal Allocations7-4Output Signal Allocations7-6ALM (Servo Alarm) Signal7-7/WARN (Warning) Signal7-8/TGON (Rotation Detection) Signal7-8/S-RDY (Servo Ready) Signal7-9/V-CMP (Speed Coincidence Detection) Signal7-10/COIN (Positioning Completion) Signal7-11/NEAR (Near) Signal7-12Speed Limit during Torque Control7-13
7.2	Opera	ation for Momentary Power Interruptions
7.3	SEMI	F47 Function
7.4	Settin	ng the Motor Maximum Speed
7.5	Enco 7.5.1 7.5.2	der Divided Pulse Output 7-19 Encoder Divided Pulse Output Signals 7-19 Setting for the Encoder Divided Pulse Output 7-24
7.6	Softw	vare Limits
	7.6.1 7.6.2 7.6.3	Setting to Enable/Disable Software Limits 7-26 Setting the Software Limits 7-26 Software Limit Check for References 7-26
7.7	Selec	ting Torque Limits
	7.7.1 7.7.2 7.7.3	Internal Torque Limits7-27External Torque Limits7-28/CLT (Torque Limit Detection) Signal7-31
7.8	Abso	lute Encoders
	7.8.1 7.8.2 7.8.3 7.8.4 7.8.5 7.8.6 7.8.7 7.8.8 7.8.8 7.8.9	Connecting an Absolute Encoder7-32Structure of the Position Data of the Absolute Encoder7-33Output Ports for the Position Data from the Absolute Encoder7-33Reading the Position Data from the Absolute Encoder7-34Transmission Specifications7-35Calculating the Current Position in Machine Coordinates7-35Alarm Output from Output Ports for the Position Data from7-36Multiturn Limit Setting7-37Multiturn Limit Disagreement Alarm (A.CC0)7-38
7.9	Abso	lute Linear Encoders
	7.9.1 7.9.2 7.9.3 7.9.4 7.9.5 7.9.6 7.9.7	Connecting an Absolute Linear Encoder7-41Structure of the Position Data of the Absolute Linear Encoder7-41Output Ports for the Position Data from the Absolute Linear Encoder7-42Reading the Position Data from the Absolute Linear Encoder7-42Transmission Specifications7-43Calculating the Current Position in Machine Coordinates7-44Alarm Output from the Output Ports for the Position Data from7-45

	7.10	Softw	vare Reset	7-46
		7.10.2	Preparations	.7-46
	7.11	Initial	izing the Vibration Detection Level	7-49
		7.11.2 7.11.3	Preparations Applicable Tools Operating Procedure Related Parameters	.7-50 .7-50
	7.12	Adjus	ting the Motor Current Detection Signal Offset7	7-53
			Automatic Adjustment	
	7.13		ng the Motor to Stop	
		7.13.2	FSTP (Forced Stop Input) Signal Stopping Method Selection for Forced Stops Resetting Method for Forced Stops	.7-57
	7.14	ZONE	Outputs (FT64 Specification)	7-60
		7.14.2 7.14.3 7.14.4	ZONE Table and ZONE Signals. ZONE Table Settings ZONE Signals 1 to 4 Outputs (/ZONE0 to /ZONE3). nZONE Signal Output ZONE Output Application Example.	.7-62 .7-64 .7-65
	7.15	Overh	neat Protection	7-67
			Connecting the Overheat Protection Input (TH) Signal	
8	Tr	ial Op	peration and Actual Operation	
	8.1		of Trial Operation	
		8.1.1 8.1.2	Flow of Trial Operation for Rotary Servomotors	
	8.2	Inspe	ctions and Confirmations before Trial Operation	8-6
	8.3	Trial C	Operation for the Servomotor without a Load	8-7
		8.3.1	Preparations	8-7

8.4	Trial (Operation with MECHATROLINK-III Communications 8-10
	8.3.3	Operating Procedure
	8.3.2	Applicable Tools

8.5	Trial C	Operation with the Servomotor Connected to the Machine	8-12
	8.5.2	Precautions Preparations Operating Procedure	.8-12
8.6	Conv	enient Function to Use during Trial Operation	8-14
	8.6.1	Program Jogging	.8-14

8.6.2

8.6.3

8.7 Operation Using MECHATROLINK-III Commands 8-25

9 [—]	uning		
	•	·	0.4
9.1	9.1.1 9.1.2	/iew and Flow of Tuning Tuning Functions Diagnostic Tool	9-5
9.2	Monit	toring Methods	9-7
9.3	Preca	autions to Ensure Safe Tuning	9-8
	9.3.1 9.3.2 9.3.3 9.3.4 9.3.5	Overtravel Settings	9-8 9-8 9-10
9.4	Tunin	g-less Function	. 9-12
	9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6	Application Restrictions.Operating ProcedureTroubleshooting AlarmsParameters Disabled by Tuning-less FunctionAutomatically Adjusted Function SettingRelated Parameters	9-13 9-14 9-15 9-15
9.5	Estim	ating the Moment of Inertia	. 9-16
	9.5.1 9.5.2 9.5.3 9.5.4	Outline. Restrictions Restrictions Applicable Tools Operating Procedure Procedure	9-16 9-17
9.6	Autot	uning without Host Reference	. 9-24
	9.6.1 9.6.2 9.6.3 9.6.4 9.6.5 9.6.6 9.6.7	Outline. Restrictions. Replicable Tools Operating Procedure. Operating Procedure. Troubleshooting Problems in Autotuning without a Host Reference. Automatically Adjusted Function Settings Related Parameters.	9-25 9-26 9-26 9-30 9-32
9.7		uning with a Host Reference	
	9.7.1 9.7.2 9.7.3 9.7.4 9.7.5 9.7.6 9.7.7	Outline. Restrictions Restrictions Applicable Tools Operating Procedure Operating Procedure Troubleshooting Problems in Autotuning with a Host Reference Automatically Adjusted Function Settings Related Parameters Related Parameters	9-36 9-36 9-36 9-40 9-40

9.8	Custo	om Tuning	9-42
	9.8.1 9.8.2 9.8.3 9.8.4 9.8.5 9.8.6 9.8.7	Outline Preparations . Applicable Tools Operating Procedure Automatically Adjusted Function Settings Tuning Example for Tuning Mode 2 or 3 Related Parameters	.9-42 .9-43 .9-43 .9-49 .9-49
9.9	Anti-F	Resonance Control Adjustment	
	9.9.1 9.9.2 9.9.3 9.9.4 9.9.5 9.9.6	Outline Preparations Applicable Tools Operating Procedure Related Parameters Suppressing Different Vibration Frequencies with Anti-resonance Control	.9-51 .9-52 .9-52 .9-54
9.10	Vibrat	tion Suppression	9-56
	9.10.3 9.10.4 9.10.5 9.10.6	Preparations	.9-57 .9-57 .9-57 .9-59 .9-59
9.11	Speed	d Ripple Compensation	
		Outline	.9-60
9.12	Addit	ional Adjustment Functions	9-66
	9.12.3 9.12.4 9.12.5 9.12.6 9.12.7	Gain Switching Friction Compensation Gravity Compensation Current Control Mode Selection Current Gain Level Setting Speed Detection Method Selection Speed Feedback Filter Backlash Compensation	.9-70 .9-72 .9-74 .9-74 .9-75 .9-75
9.13	Manu	al Tuning	
	9.13.1 9.13.2	Tuning the Servo Gains. Compatible Adjustment Functions	
9.14	Diagn	nostic Tools	
	9.14.1 9.14.2	Mechanical Analysis	

	lonitoring
10.1	Monitoring Product Information 10-2 10.1.1 Items That You Can Monitor 10-2 10.1.2 Operating Procedures 10-2
10.2	Monitoring SERVOPACK Status10-310.2.1Servo Drive Status10-310.2.2Monitoring Operation, Status, and I/O10-310.2.3I/O Signals Status Monitor10-5
10.3	Monitoring Machine Operation Status and Signal Waveforms 10-710.3.1 Items That You Can Monitor
10.4	Monitoring Product Life 10-14 10.4.1 Items That You Can Monitor 10-14 10.4.2 Operating Procedure 10-15 10.4.3 Preventative Maintenance 10-15
10.5	Alarm Tracing10-1710.5.1 Data for Which Alarm Tracing Is Performed10-1710.5.2 Applicable Tools10-17
	ully-Closed Loop Control Fully-Closed System 11-2
11.2	SERVOPACK Commissioning Procedure
11.3	Parameter Settings for Fully-Closed Loop Control 11-5

11.3.5External Absolute Encoder Data Reception Sequence11-811.3.6Electronic Gear Setting11-811.3.7Alarm Detection Settings11-911.3.8Analog Monitor Signal Settings11-1011.3.9Setting to Use an External Encoder for Speed Feedback11-10


11.3.4 Setting the PAO, PBO, and PCO (Encoder Divided Pulse Output)

12 Safe	ety Functions	_
12	Itroduction to the Safety Functions 12 2.1.1 Safety Functions 12 2.1.2 Precautions for Safety Functions 12	2-2
12.2 Ha	ard Wire Base Block (HWBB)12	-3
12 12 12 12 12 12 12 12 12 12 12	2.2.1 Risk Assessment 12 2.2.2 Hard Wire Base Block (HWBB) State 12 2.2.3 Resetting the HWBB State 12 2.2.4 Related Commands 12 2.2.5 Detecting Errors in HWBB Signal 12 2.2.6 HWBB Input Signal Specifications 12 2.2.7 Operation without a Host Controller 12 2.2.8 /S-RDY (Servo Ready Output) Signal 12 2.2.9 /BK (Brake Output) Signal 12 2.2.10 Stopping Methods 12 2.2.11 ALM (Servo Alarm) Signal 12	2-5 2-6 2-7 2-7 2-7 2-7 2-8 2-8 2-8 2-9 2-9
12.3 EI	DM1 (External Device Monitor) 12- ⁻	10
12	2.3.1 EDM1 Output Signal Specifications	10
12.4 Ap	pplications Examples for Safety Functions 12- ⁻	11
12	2.4.1 Connection Example 12- 2.4.2 Failure Detection Method 12- 2.4.3 Procedure 12-	11
12.5 Va	alidating Safety Functions 12-	13
12.6 Co	onnecting a Safety Function Device	14

13

Maintenance

13.1	Inspe	ctions and Part Replacement 13-2
	13.1.1 13.1.2 13.1.3	Inspections13-2Guidelines for Part Replacement.13-2Replacing the Battery13-3
13.2	Alarm	Displays
	13.2.2 13.2.3 13.2.4	List of Alarms.13-5Troubleshooting Alarms.13-11Resetting Alarms.13-43Displaying the Alarm History.13-45Clearing the Alarm History.13-46Resetting Alarms Detected in Option Modules.13-47Resetting Motor Type Alarms.13-49
13.3	Warni	ng Displays
		List of Warnings
13.4	Monit	oring Communications Data during Alarms or Warnings 13-60
13.5	Trouble	shooting Based on the Operation and Conditions of the Servomotor 13-61



Index

Revision History

Basic Information on SERVOPACKs

This chapter provides information required to select SERVOPACKs, such as SERVOPACK models and combinations with Servomotors.

1.1	The S	C-7 Series1-2	
1.2	Interpreting the Nameplate1-3		
1.3	Part Names1-4		
1.4	Model Designations1-6		
	1.4.1 1.4.2	Interpreting SERVOPACK Model Numbers 1-6 Interpreting Servomotor Model Numbers 1-7	
1.5	Combinations of SERVOPACKs and Servomotors 1-8		
	1.5.1 1.5.2	Combinations of Rotary Servomotors and SERVOPACKs	
1.6	Functions		

1.1 The Σ -7 Series

The Σ -7-series SERVOPACKs are designed for applications that require frequent high-speed and high-precision positioning. The SERVOPACK will make the most of machine performance in the shortest time possible, thus contributing to improving productivity.

These SERVOPACKs support ZONE outputs.


ZONE outputs are used to output signals during preset ranges of positions. You can use the ZONE outputs as triggers for operations related to positioning.

Refer to the following chapter for details on ZONE outputs.

7.14 ZONE Outputs (FT64 Specification) on page 7-60


1.2 Interpreting the Nameplate

The following basic information is provided on the nameplate.



1

1.3 Part Names



No.	Name	Description	Reference
0	Front Cover	_	-
2	Model	The model of the SERVOPACK.	page 1-6
3	QR Code	The QR code that is used by the MechatroCloud service.	-
4	CHARGE	Lit while the main circuit power is being supplied. Note: Even if you turn OFF the main circuit power supply, this indicator will be lit as long as the internal capacitor remains charged. Do not touch the main circuit or motor terminals while this indicator is lit. Doing so may result in electric shock.	-
5	Main Circuit Terminals	The terminals depend on the main circuit power supply input specifications of the SERVOPACK.	page 4-11
6	DC Power Supply Terminals	_	page 4-11
Ø	Control Power Supply Termi- nals	The connection terminals for the control power supply.	page 4-11
8	Servomotor Terminals (U, V, and W) and Ground Terminal (PE)	The connection terminals for the Servomotor Main Circuit Cable (power line).	page 4-19
9	Dynamic Brake Terminals	The connection terminals for a dynamic brake resistor.	page 4-11
10	Ground Terminal (🔔)	The ground terminals to prevent electric shock. Always connect this terminal.	_
1	MECHATROLINK-III Com- munications Connector (CN6A and CN6B)	Connects to MECHATROLINK-III-compatible devices.	page 4-38
(12)	I/O Signal Connector (CN1)	Connects to sequence I/O signals.	page 4-29
(13)	Safety Connector (CN8)	Connects to a safety function device.	page 4-36
(4)	Encoder Connector (CN2)	 Rotary Servomotor: Connects to the encoder in the Servomotor. Linear Servomotor: Connects to a Serial Converter Unit or linear encoder. 	page 4-19
(15)	Computer Connector (CN7)	A USB connector to connect a computer.	page 4-39
16	Safety Option Module Con- nector	Connects to a Safety Option Module.	_
1	Feedback Option Module Connector	Connects to a Feedback Option Module.	_
18	Serial Communications Con- nector (CN3)	Connects to the Digital Operator.	page 4-39


Continued on next page.

Continued from previous page.

No.	Name	Description	Reference
19	Serial Number	_	-
20	DIP Switch (S3)	Used to set MECHATROLINK communications.	-
21)	Rotary Switches (S1 and S2)	Used to set the MECHATROLINK station address.	page 6-12
22	PWR	Lights when the control power is being supplied.	-
23	CN	Not used.	-
24)	L1 and L2	not useu.	_
25	Analog Monitor Connector (CN5)	You can use a special cable (peripheral device) to monitor the motor speed, torque reference, or other values.	page 4-39
26	Panel Display	Displays the servo status with a seven-segment display.	-
Ø	Servomotor Brake Power Supply Terminals (CN117)*	Connect to the power supply for the Servomotor brake.	_

* SERVOPACKs without built-in Servomotor brake control do not have these terminals.

1.4.1 Interpreting SERVOPACK Model Numbers



* The same SERVOPACKs are used for both Rotary Servomotors and Linear Servomotors.

1.4.2 Interpreting Servomotor Model Numbers

1.4.2 Interpreting Servomotor Model Numbers

This section outlines the model numbers of Σ -7-series Servomotors. Refer to the relevant manual in the following list for details.

Ω Σ-7-Series Rotary Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 86)

Ω-7-Series Linear Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 81)

Rotary Servomotors

SGM		D 7 F rd 4th digit digit	2 6th digit	7th digit		
Series	Σ-7-Series Servomotors	1st+2nd digits Rat	ed Output		5th digit	Design Revision Order
Code	Specifications	• SGM7J: 200 W to 1				
SGM7J	Medium inertia, high speed	SGM7A: 200 W to 7.0 kW SGM7G: 450 W to 15 kW Gth digit Shaft End Specificatio		Shaft End Specification		
SGM7A	Low inertia, high speed			 Straight v 	without key	
SGM7G	Medium inertia, low speed, high torque		3rd digit Power Supply Voltage		 Straight with key and tap 	
Medium inertia, high speed, high torque						
		4th digit Serial Enc	oder Specif	ication	7th digit	Options
		 24-bit absolute 24-bit incremental			With holdWith dus	0

Linear Servomotors



Series Σ-7-Series Servomotors

Servomotor Type

Specification

Models with F-type iron core

Models with T-type iron core

1st digit

Code

F

Т





Code	Specification	
W	Moving Coil	
W2	Moving Coil	
М	Magnetic Way	
M2	Magnetic Way	

3rd digit on

The specifications for the 3rd digit on depend on the Servomotor type.

1.5.1 Combinations of Rotary Servomotors and SERVOPACKs

1.5 Combinations of SERVOPACKs and Servomotors

1.5.1 Combinations of Rotary Servomotors and SERVOPACKs

		0	SERVOPACK Model
Rotary Servomo	tor Model	Capacity	SGD7S-
SGM7J Models	SGM7J-02D□F	200 W	1000
(Medium Inertia,	SGM7J-04D□F	400 W	- 1R9D
High Speed), Rated motor speed:	SGM7J-08D□F	750 W	3R5D
3,000 min ⁻¹	SGM7J-15D□F	1.5 kW	5R4D
	SGM7A-02D□F	200 W	1000
	SGM7A-04D□F	400 W	- 1R9D
	SGM7A-08D□F	750 W	3R5D
SGM7A Models	SGM7A-10D□F	1.0 kW	5R4D
(Low Inertia,	SGM7A-15D□F	1.5 kW	- JN4D
High Speed),	SGM7A-20D□F	2.0 kW	8R4D
Rated motor speed:	SGM7A-25D□F	2.5 kW	- 120D
3,000 min⁻¹	SGM7A-30D□F	3.0 kW	1200
	SGM7A-40D□F	4.0 kW	- 170D
	SGM7A-50D□F	5.0 kW	- 1700
	SGM7A-70D□F	7.0 kW	260D
	SGM7G-05D□F	450 W	1R9D
	SGM7G-09D□F	850 W	3R5D
SGM7G Models	SGM7G-13D□F	1.3 kW	5R4D
Standard Models	SGM7G-20D□F	1.8 kW	8R4D
(Medium Inertia, Low Speed,	SGM7G-30D□F	2.9 kW	120D
High Torque),	SGM7G-44D□F	4.4 kW	170D
Rated motor speed:	SGM7G-55D□F	5.5 kW	210D
1,500 min ⁻¹	SGM7G-75D□F	7.5 kW	260D
	SGM7G-1AD□F	11.0 kW	280D
	SGM7G-1ED□F	15.0 kW	370D
SGM7G Models	SGM7G-05D□R	450 W	3R5D
High-speed Models	SGM7G-09D□R	850 W	5R4D
(Medium Inertia, High	SGM7G-13D□R	1.3 kW	8R4D
Speed, High Torque)	SGM7G-20D□R	1.8 kW	120D
Rated motor speed:	SGM7G-30D□R	2.9 kW	170D
1,500 min⁻¹	SGM7G-44D□R	4.4 kW	210D

1.5.2 Combinations of Linear Servomotors and SERVOPACKs

1.5.2 Combinations of Linear Servomotors and SERVOPACKs

		Rated Force	Instantaneous	SERVOPACK Model
Linear Servomotor Model		[N]	Maximum Force [N]	SGD7S-
	SGLFW-35D120A	80	220	1R9D
	SGLFW-35D230A	160	440	1R9D
	SGLFW-50D200B	280	600	3R5D
	SGLFW-50D380B	EGO	1000	5040
	SGLFW-1ZD200B	560	1200	5R4D
	SGLFW-1ZD380B	1120	2400	120D
	SGLFW2-30D070A	45	135	1R9D
SGLF	SGLFW2-30D120A	90	270	1R9D
(Models with F-type Iron Cores)	SGLFW2-30D230A	180	540	1R9D
	SGLFW2-45D200A	280	840	3R5D
	SGLFW2-45D380A	- 560	1680	8R4D
	SGLFW2-90D200A			5R4D
	SGLFW2-90D380A	1120	3360	120D
	SGLFW2-90D560A	1680	5040	170D
	SGLFW2-1DD380A	1680	5040	170D
	SGLFW2-1DD560A	2520	7560	260D
	SGLTW-35D170H	300	600	3R5D
	SGLTW-35D320H	600	1200	8R4D
	SGLTW-40D400B	670	2600	120D
SGLT	SGLTW-40D600B	1000	4000	170D
(Models with T-type Iron Cores)	SGLTW-50D170H	450	900	3R5D
	SGLTW-50D320H	900	1800	8R4D
	SGLTW-80D400B	1300	5000	170D
	SGLTW-80D600B	2000	7500	260D

1.6 Functions

This section lists the functions provided by SERVOPACKs. Refer to the reference pages for details on the functions.

· Functions Related to the Machine

Function	Reference
Power Supply Type Settings for the Main Circuit and Control Circuit	page 6-13
Automatic Detection of Connected Motor	page 6-14
Motor Direction Setting	page 6-15
Linear Encoder Pitch Setting	page 6-16
Writing Linear Servomotor Parameters	page 6-17
Selecting the Phase Sequence for a Linear Servomotor	page 6-21
Polarity Sensor Setting	page 6-23
Polarity Detection	page 6-24
Overtravel Function and Settings	page 6-27
Holding Brake	page 6-32
Motor Stopping Methods for Servo OFF and Alarms	page 6-37
Resetting the Absolute Encoder	page 6-47
Setting the Origin of the Absolute Encoder	page 6-50
Setting the Regenerative Resistor Capacity	page 6-53
Operation for Momentary Power Interruptions	page 7-15
SEMI F47 Function	page 7-16
Setting the Motor Maximum Speed	page 7-18
Software Limits and Settings	page 7-26
Multiturn Limit Setting	page 7-37
Adjustment of Motor Current Detection Signal Offset	page 7-53
Forcing the Motor to Stop	page 7-57
Overheat Protection	page 7-67
Speed Ripple Compensation	page 9-60
Current Control Mode Selection	page 9-74
Current Gain Level Setting	page 9-74
Speed Detection Method Selection	page 9-75
Fully-Closed Loop Control	page 11-1
Safety Functions	page 12-1
External Latches	_

Function	Reference
Electronic Gear Settings	page 6-42
I/O Signal Allocations	page 7-4
ALM (Servo Alarm) Signal	page 7-7
/WARN (Warning) Signal	page 7-8
/TGON (Rotation Detection) Signal	page 7-8
/S-RDY (Servo Ready) Signal	page 7-9
/V-CMP (Speed Coincidence Detection) Signal	page 7-10
/COIN (Positioning Completion) Signal	page 7-11
/NEAR (Near) Signal	page 7-12
Speed Limit during Torque Control	page 7-13
/VLT (Speed Limit Detection) Signal	page 7-13
Encoder Divided Pulse Output	page 7-19
Selecting Torque Limits	page 7-27
Vibration Detection Level Initialization	page 7-49
Alarm Reset	page 13-43
Replacing the Battery	page 13-3
Setting the Position Deviation Overflow Alarm Level	page 9-8

· Functions Related to the Host Controller

Functions to Achieve Optimum Motions

Function	Reference
Tuning-less Function	page 9-12
Autotuning without a Host Reference	page 9-24
Autotuning with a Host Reference	page 9-35
Custom Tuning	page 9-42
Anti-Resonance Control Adjustment	page 9-51
Vibration Suppression	page 9-56
Gain Selection	page 9-66
Friction Compensation	page 9-70
Gravity Compensation	page 9-72
Backlash Compensation	page 9-75
Model Following Control	page 9-90
Compatible Adjustment Functions	page 9-93
Mechanical Analysis	page 9-97
Easy FFT	page 9-99

• Functions for Trial Operation during Setup

Function	Reference
Software Reset	page 7-46
Trial Operation for the Servomotor without a Load	page 8-7
Program Jogging	page 8-14
Origin Search	page 8-18
Test without a Motor	page 8-20
Monitoring Machine Operation Status and Signal Waveforms	page 10-7

Function	Reference
Write Prohibition Setting for Parameters	page 6-7
Initializing Parameter Settings	page 6-10
Automatic Detection of Connected Motor	page 6-14
Monitoring Product Information	page 10-2
Monitoring Product Life	page 10-2
Alarm History Display	page 13-45
Alarm Tracing	page 10-17

• Functions for Inspection and Maintenance

Selecting a SERVOPACK

This chapter provides information required to select SERVOPACKs, such as specifications, block diagrams, dimensional drawings, and connection examples.

2.1	Rating	gs and Specifications
	2.1.1 2.1.2	Ratings2-2SERVOPACK Overload ProtectionCharacteristics2-3
	2.1.3	Specifications
2.2	Block	Diagrams 2-7
	2.2.1 2.2.2	SERVOPACKs without Built-in Servomotor Brake Control
2.3	Exter	nal Dimensions2-13
	2.3.1	Front Cover Dimensions and Connector
	2.3.2	Specifications
2.4	Examples	of Standard Connections between SERVOPACKs and Peripheral Devices2-17

2.1.1 Ratings

2.1 Ratings and Specifications

This section gives the ratings and specifications of SERVOPACKs.

2.1.1 Ratings

Three-Phase, 400 VAC

Ν	/lodel SGD7S	;-	1R9D	3R5D	5R4D	8R4D	120D	170D	210D	260D	280D	370D
Maximum Applicable Motor Capacity [kW]			0.5	1	1.5	2	3	5	6	7.5	11	15
Continuous (Output Currer	nt [Arms]	1.9	3.5	5.4	8.4	11.9	16	20.8	25.7	28.1	37.2
Instantaneou rent [Arms]	is Maximum (Output Cur-	5.5	8.5	14	21	28	42	55	65	70	85
Main Circuit	Power Supp	ly		Three-phase, 380 VAC to 480 VAC, -15% to +10%, 50 Hz/60 Hz								
	Input Curren	it [Arms]*	1.4	2.9	4.3	5.8	8.6	14.5	17.4	21.7	31.8	43.4
Control	Power Supp	ly					24 VDC	C±15%)			
Control	Input Curren	1.2						1.4		1.7		
Power Supp	ly Capacity [k'	1.1	2.3	3.5	4.5	7.1	11.7	12.4	14.4	21.9	30.6	
	Main Circuit Power Loss [W]		19.4	30.3	62.8	90.1	137.7	188.7	188.4	228.5	278.2	389.8
Power	Control Circuit Power Loss [W]		21				22	28		32		
Loss*	Built-in Regenerative Resistor Power Loss [W]		14	14	28	28	28	36	(18	80)*	(24	0)*
	Total Power	Loss [W]	54.4	65.3	111.8	139.1	186.7	246.7	216.4	256.5	310.2	389.8
Regenera- tive Resis- tor	Built-In Resistance Regenera- [Ω]		75	75	75	43	43	27	_			
	tive Resis- tor	Capacity [W]	70	70	140	140	140	180	_			
	Minimum Allowable External Resistance $[\Omega]$		75	75	75	43	43	27	18	18	14.25	14.25
Overvoltage Category												

* This is the net value at the rated load.

540 VDC

Model SGD7S-			3R5D	5R4D	8R4D	120D	170D	210D	260D	280D	370D
Maximum Applicable Motor Capacity [kW]			1	1.5	2	3	5	6	7.5	11	15
Continuous (Output Current [Arms]	1.9	3.5	5.4	8.4	11.9	16	20.8	25.7	28.1	37.2
Instantaneous Maximum Output Cur- rent [Arms]			8.5	14	21	28	42	55	65	70	85
Main Circuit	Power Supply		513 VDC to 648 VDC, -15% to +10%								
Main Circuit	Input Current [Arms]*	2	3.3	5.5	6.8	11	18	19.6	26.2	38.3	47.6
Control	Power Supply	24 VDC ±15%									
Control	Input Current [Arms]*	1.2						1.4		1.7	
Power Supp	ly Capacity [kVA]*	1.1	2.3	3.5	4.5	7.1	11.7	12.4	14.4	21.9	30.6
	Main Circuit Power Loss [W]	16.4	24.4	48.5	73.7	110.4	144.5	188.4	228.5	278.2	389.8
Power Loss*	Control Circuit Power Loss [W]			21			22	28		3	2
	Total Power Loss [W]	37.4	45.4	69.5	94.7	131.4	166.5	216.4	228.5	310.2	389.8
Overvoltage	III										

* This is the net value at the rated load.

2.1.2 SERVOPACK Overload Protection Characteristics


2.1.2 SERVOPACK Overload Protection Characteristics

The overload detection level is set for hot start conditions with a SERVOPACK surrounding air temperature of 55°C.

An overload alarm (A.710 or A.720) will occur if overload operation that exceeds the overload protection characteristics shown in the following diagram (i.e., operation on the right side of the applicable line) is performed.

The actual overload detection level will be the detection level of the connected SERVOPACK or Servomotor that has the lower overload protection characteristics.

In most cases, that will be the overload protection characteristics of the Servomotor.



Note: The above overload protection characteristics do not mean that you can perform continuous duty operation with an output of 100% or higher.

For a Yaskawa-specified combination of SERVOPACK and Servomotor, maintain the effective torque within the continuous duty zone of the torque-motor speed characteristic of the Servomotor.

2.1.3 Specifications

2.1.3 Specifications

	Item	Specification						
Drive Method		IGBT-based PWM control, sine wave current drive						
Feedback	With Rotary Servomotor	Serial encoder: 24 bits (incremental encoder/absolute encoder)						
	With Linear Servomotor	 Absolute linear encoder (The signal resolution depends on the absolute linear encoder.) Incremental linear encoder (The signal resolution depends on the incremental linear encoder or Serial Converter Unit.) 						
	Surrounding Air Tem- perature ^{*1}	-5°C to 55°C However, the range for the SGD7S-370D is -5°C to 40°C. (With derating, usage is possible between 55°C and 60°C. For the SGD7S-370D, however, usage is possible between 40°C to 60°C.) Refer to the following section for derating specifications. 3.6 Derating Specifications on page 3-7						
	Storage Temperature	-20°C to 85°C						
	Surrounding Air Humidity	95% relative humidity max. (with no freezing or condensation)						
	Storage Humidity	95% relative humidity max. (with no freezing or condensation)						
- ·	Vibration Resistance	4.9 m/s ²						
Environ- mental	Shock Resistance	19.6 m/s ²						
Conditions	Degree of Protection	IP10						
	Pollution Degree	 2 Must be no corrosive or flammable gases. Must be no exposure to water, oil, or chemicals. Must be no dust, salts, or iron dust. 						
	Altitude	1,000 m max. (With derating, usage is possible between 1,000 m and 2,000 m.) Refer to the following section for derating specifications. 3.6 Derating Specifications on page 3-7						
	Others	Do not use the SERVOPACK in the following locations: Locations sub- ject to static electricity, noise, strong electromagnetic/magnetic fields, or radioactivity						
Compliant S	tandards	Refer to the following section for details. Compliance with UL Standards, EU Directives, and Other Safety Stan- dards on page xxi						
Mounting		Base-mounted						
· · · · ·	Speed Control Range	1:5000 (At the rated torque, the lower limit of the speed control range must not cause the Servomotor to stop.)						
		$\pm 0.01\%$ of rated speed max. (for a load fluctuation of 0% to 100%)						
	Coefficient of Speed	0% of rated speed max. (for a voltage fluctuation of $\pm 10\%$)						
Perfor- mance	Fluctuation ^{*2}	\pm 0.1% of rated speed max. (for a temperature fluctuation of 25°C \pm 25°C)						
	Torque Control Preci- sion (Repeatability)	±1%						
	Soft Start Time Setting	0 s to 10 s (Can be set separately for acceleration and deceleration.)						

Continued on next page.

2.1.3 Specifications

Continued from previous page.

	Item		Specification
	Encoder Div Pulse Outpu		Phase A, phase B, phase C: Line-driver output Number of divided output pulses: Any setting is allowed.
	Overheat Pi Input	rotection	Number of input points: 1 Input voltage range: 0 V to +5 V
	Sequence	Input Signals	 Allowable voltage range: 24 VDC ±20% Number of input points: 7 (Input method: Sink inputs or source inputs) Input Signals /DEC (Origin Return Deceleration Switch) signal /EXT1 to /EXT3 (External Latch Input 1 to 3) signals P-OT (Forward Drive Prohibit) and N-OT (Reverse Drive Prohibit) sig-
	Input Signals	That Can Be Allo- cated	 refer to the referred billing of the referred
I/O Signals		Fixed Output	Allowable voltage range: 5 VDC to 30 VDC Number of output points: 1 (A photocoupler output (isolated) is used.) Output signal: ALM (Servo Alarm) signal Allowable voltage range: 5 VDC to 30 VDC Number of output points: 5
	Sequence Output Signals	Output Signals That Can Be Allo- cated	 (A photocoupler output (isolated) is used.) Output Signals /COIN (Positioning Completion) signal /V-CMP (Speed Coincidence Detection) signal /TGON (Rotation Detection) signal /S-RDY (Servo Ready) signal /CLT (Torque Limit Detection) signal /VLT (Speed Limit Detection) signal /VLT (Speed Limit Detection) signal /WARN (Warning) signal /WARN (Warning) signal /DBON (Dynamic Brake Operation Request) signal^{*3*4} /ZONE0 (ZONE Signal 1 Output) signal /ZONE1 (ZONE Signal 2 Output) signal /ZONE2 (ZONE Signal 4 Output) signal /ZONE3 (ZONE Output) signal
	RS-422A Communi-	faces 1:N Commu-	Digital Operator (JUSP-OP05A-1-E) Up to N = 15 stations possible for RS-422A port
Communi- cations	cations (CN3)	nications Axis Address Setting	Set with parameters.
	USB Communi- cations (CN7)	Interface Commu- nications	Personal computer (with SigmaWin+) The software version of the SigmaWin+ must be version 7.11 or highe Conforms to USB2.0 standard (12 Mbps).
Displays/Indicators			CHARGE, PWR, CN, L1, and L2 indicators, and one-digit seven-seg-

2.1.3 Specifications

Continued from previous page.

MECHATR OLINK-III Communications Pro- tocol MECHATROLINK-III Settings O3h to EFh (maximum number of slaves: 62) The rotary switches (S1 and S2) are used to set the station address. Transmission Speed 100 Mbps Transmission Cycle 125 µs, 250 µs, 500 µs, 750 µs, 1.0 ms to 4.0 ms (multiples of 0.5 ms) Number of Transmis- sion Bytes 32 or 48 bytes/station A DIP switch (S3) is used to select the number of transmission bytes. Reference Method Performance Position, speed, or torque control with MECHATROLINK-III communi- cations Reference Input MECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.) Profile MECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.) Profile MECHATROLINK-III commands (sequence, motion, data setting, data access, the points: 2 Analog Monitor (CN5) Rotary switch (S1 and S2) positions: 16 Number of points: 2 Analog Monitor (CN5) Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF. Regenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal		ltom	Specification					
tocol MECHATR Settings MECHATR The rotary switches (S1 and S2) are used to set the station address. MECHATR OLINK-III Communi- cations Transmission Speed 100 Mbps Transmission Cycle 125 µs, 250 µs, 500 µs, 750 µs, 1.0 ms to 4.0 ms (multiples of 0.5 ms) Number of Transmis- sion Bytes 32 or 48 bytes/station A DIP switch (S3) is used to select the number of transmission bytes. Reference Method Performance Position, speed, or torque control with MECHATROLINK-III communi- cations Reference Input MECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.) Profile MECHATROLINK-III communica- tions Setting Switches Analog Monitor (CN5) Rotary switch (S1 and S2) positions: 16 Number of DIP switch (S3) pins: 4 Analog Monitor (CN5) Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF. Regenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal Protective Functions Qai adjustment, alarm history, jogging, origin search, etc. Hitty Function- Functions Gai adjustment, alarm history, jogging, origin search, etc. <th></th> <th>Item</th> <th>Specification</th>		Item	Specification					
MECHATR OLINK-III cations Settings The rotary switches (S1 and S2) are used to set the station address. MECHATR OLINK-III cations Transmission Speed 100 Mbps Transmission Cycle 125 µs, 250 µs, 500 µs, 750 µs, 1.0 ms to 4.0 ms (multiples of 0.5 ms) Number of Transmis- sion Bytes 32 or 48 bytes/station A DIP switch (S3) is used to select the number of transmission bytes. Reference Method Performance Position, speed, or torque control with MECHATROLINK-III communi- cations Reference Input MECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.) Profile MECHATROLINK-III communica- tions Setting Switches Number of DiP switch (S3) positions: 16 Number of DIP switch (S3) pins: 4 Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ) Dynamic Brake (DB)*5 Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF. Regenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal Protective Functions Overcurrent			MECHATROLINK-III					
Communi- cations Transmission Speed Tot Mops Transmission Cycle 125 µs, 250 µs, 500 µs, 750 µs, 1.0 ms to 4.0 ms (multiples of 0.5 ms) Number of Transmis- sion Bytes 32 or 48 bytes/station A DIP switch (S3) is used to select the number of transmission bytes. Reference Performance Position, speed, or torque control with MECHATROLINK-III communi- cations Reference Input MECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.) Profile MECHATROLINK-III commands MECHATROLINK-III Communica- tions Setting Switches Rotary switch (S1 and S2) positions: 16 Number of DIP switch (S3) pins: 4 Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ) Dynamic Brake (DB)*5 Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF. Regenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjust	MECHATR							
cations Transmission Cycle 125 µs, 250 µs, 10 ms (x 0, 0 ms (multiples of 0.5 ms) Number of Transmission Bytes A DIP switch (S3) is used to select the number of transmission bytes. Reference Performance Position, speed, or torque control with MECHATROLINK-III communications. Reference Method Performance Position, speed, or torque control with MECHATROLINK-III communications. MECHATROLINK-III Communications Setting Switches MECHATROLINK-III standard servo profile MECHATROLINK-III Communications Setting Switches Rotary switch (S1 and S2) positions: 16 Number of DIP switch (S3) pins: 4 Number of DIP switch (S3) pins: 4 Analog Monitor (CN5) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Setting time (±1%): 1.2 ms (Typ) Dynamic Brake (DB)*5 Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjustment, alarn history, jogging, origin search, etc. Vertility Functions Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Functi	-	Transmission Speed	100 Mbps					
sion BytesA DIP switch (S3) is used to select the number of transmission bytes.Reference MethodPerformancePosition, speed, or torque control with MECHATROLINK-III communi- cationsReference MethodReference InputMECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.)ProfileMECHATROLINK-III standard servo profileMECHATROLINK-III Communica- tions Setting SwitchesRotary switch (S1 and S2) positions: 16Mumber of DIP switch (S3) pins: 4Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ)Dynamic Brake (DB)*5Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF.Regenerative ProcessingBuilt-in Refer to the catalog for details.Overtravel (OT) PreventionStopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signalProtective FunctionsOvercurrent, overvoltage, low voltage, overload, regeneration error, etc.Utility FunctionsGain adjustment, alarm history, jogging, origin search, etc.Safety FunctionsOutputEDM1: Monitors the status of built-in safety circuit (fixed output).Compliant standards*6ISO13849-1 PLe (category 3), IEC61508 SIL3	cations	Transmission Cycle						
Performance cations Reference Method Reference Input MECHATROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.) Profile MECHATROLINK-III communica- tions Setting Switches Rotary switch (S1 and S2) positions: 16 MECHATROLINK-III Communica- tions Setting Switches Rotary switch (S3) pins: 4 Number of DIP switch (S3) pins: 4 Analog Monitor (CN5) Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ) Dynamic Brake (DB)*5 Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF. Begenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjustment, alarm history, jogging, origin search, etc. Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Functions Output EDM1: Monitors the status of built-in safety circuit (fixed output).								
Method Reference Input MECHAIROLINK-III commands (sequence, motion, data setting, data access, monitoring, adjustment, etc.) Profile MECHAIROLINK-III communications Setting Switches MECHAIROLINK-III standard servo profile MECHAIROLINK-III communications Setting Switches Rotary switch (S1 and S2) positions: 16 Number of DIP switch (S3) pins: 4 Number of DIP switch (S3) pins: 4 Analog Monitor (CN5) Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ) Dynamic Brake (DB)*5 Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF. Regenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjustment, alarm history, jogging, origin search, etc. Safety Functions Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Functions Sot13849-1 PLe (category 3), IEC61508 SIL3	D. (Performance						
MECHATROLINK-III Communications Setting Switches Rotary switch (S1 and S2) positions: 16 Number of DIP switch (S3) pins: 4 Number of DIP switch (S3) pins: 4 Analog Monitor (CN5) Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ) Dynamic Brake (DB)*5 Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF. Regenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjustment, alarm history, jogging, origin search, etc. Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Functions EDM1: Monitors the status of built-in safety circuit (fixed output). Compliant Standards**6 ISO13849-1 PLe (category 3), IEC61508 SIL3	Reference Method	Reference Input						
tions Setting Switches Number of DIP switch (S3) pins: 4 Analog Monitor (CN5) Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ) Dynamic Brake (DB)*5 Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF. Regenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjustment, alarm history, jogging, origin search, etc. Safety Functions Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Functions Output EDM1: Monitors the status of built-in safety circuit (fixed output). Compliant Standards**6 ISO13849-1 PLe (category 3), IEC61508 SIL3		Profile	MECHATROLINK-III standard servo profile					
Analog Monitor (CN5) Number of points: 2 Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ) Dynamic Brake (DB)*5 Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF. Regenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjustment, alarm history, jogging, origin search, etc. MumBB1 and /HWBB2: Base block signals for Power Modules Output Safety Functions Output EDM1: Monitors the status of built-in safety circuit (fixed output). Compliant Standards*6 ISO13849-1 PLe (category 3), IEC61508 SIL3	MECHATROLINK-III Communica-		Rotary switch (S1 and S2) positions: 16					
Analog Monitor (CN5)Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA Settling time (±1%): 1.2 ms (Typ)Dynamic Brake (DB)*5Activated when a servo alarm or overtravel (OT) occurs, or when the power supply to the main circuit or servo is OFF.Regenerative ProcessingBuilt-in Refer to the catalog for details.Overtravel (OT) PreventionStopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signalProtective FunctionsOvercurrent, overvoltage, low voltage, overload, regeneration error, etc.Utility FunctionsGain adjustment, alarm history, jogging, origin search, etc.Inputs/HWBB1 and /HWBB2: Base block signals for Power ModulesOutputEDM1: Monitors the status of built-in safety circuit (fixed output).Compliant Standards*6ISO13849-1 PLe (category 3), IEC61508 SIL3	tions Setting	Switches	Number of DIP switch (S3) pins: 4					
Dynamic Brake (DB) power supply to the main circuit or servo is OFF. Regenerative Processing Built-in Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro- hibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjustment, alarm history, jogging, origin search, etc. Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Functions Output EDM1: Monitors the status of built-in safety circuit (fixed output). Compliant Standards*6 ISO13849-1 PLe (category 3), IEC61508 SIL3	Analog Monitor (CN5)		Output voltage range: ±10 VDC (effective linearity range: ±8 V) Resolution: 16 bits Accuracy: ±20 mV (Typ) Maximum output current: ±10 mA					
Regenerative Processing Refer to the catalog for details. Overtravel (OT) Prevention Stopping with dynamic brake, deceleration to a stop, or coasting to a stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjustment, alarm history, jogging, origin search, etc. Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Output EDM1: Monitors the status of built-in safety circuit (fixed output). Compliant ISO13849-1 PLe (category 3), IEC61508 SIL3	Dynamic Bra	ake (DB) ^{*5}						
Overtravel (OT) Prevention stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal Protective Functions Overcurrent, overvoltage, low voltage, overload, regeneration error, etc. Utility Functions Gain adjustment, alarm history, jogging, origin search, etc. Villity Functions Inputs Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Output Functions EDM1: Monitors the status of built-in safety circuit (fixed output). Compliant ISO13849-1 PLe (category 3), IEC61508 SIL3	Regenerative	e Processing						
Utility Functions Gain adjustment, alarm history, jogging, origin search, etc. Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Output EDM1: Monitors the status of built-in safety circuit (fixed output). Functions Compliant Standards*6 ISO13849-1 PLe (category 3), IEC61508 SIL3	Overtravel (OT) Prevention		stop for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Pro-					
Inputs /HWBB1 and /HWBB2: Base block signals for Power Modules Safety Output EDM1: Monitors the status of built-in safety circuit (fixed output). Functions Compliant Standards*6 ISO13849-1 PLe (category 3), IEC61508 SIL3	Protective Functions		Overcurrent, overvoltage, low voltage, overload, regeneration error, etc.					
Safety Output EDM1: Monitors the status of built-in safety circuit (fixed output). Functions Compliant Standards*6 ISO13849-1 PLe (category 3), IEC61508 SIL3	Utility Functions		Gain adjustment, alarm history, jogging, origin search, etc.					
Functions Compliant Standards*6 ISO13849-1 PLe (category 3), IEC61508 SIL3		Inputs	/HWBB1 and /HWBB2: Base block signals for Power Modules					
Standards ^{*6} ISO13849-1 PLe (category 3), IEC61508 SIL3	Safety	Output	EDM1: Monitors the status of built-in safety circuit (fixed output).					
Applicable Option Modules Fully-closed Modules	Functions		ISO13849-1 PLe (category 3), IEC61508 SIL3					
	Applicable C	ption Modules	Fully-closed Modules					

*1. The applicable surrounding range cannot be increased by derating.

*2. The coefficient of speed fluctuation for load fluctuation is defined as follows:

Coefficient of speed fluctuation = $\frac{\text{No-load motor speed} - \text{Total-load motor speed}}{\text{Rated motor speed}} \times 100\%$

*3. Usable only with SGD7S-210D, -260D, -280D, -370D SERVOPACKs.

*4. The /DBON signal can be used as positive logic.

*5. The SGD7S-210D, -260D, -280D, and -370D do not have a dynamic brake (DB). If a dynamic brake is necessary, create an external dynamic brake circuit.
 Refer to the following chapter for details on the dynamic brake.
 Chapter 5 Wiring and Settings for the Dynamic Brake


*6. Always perform risk assessment for the system and confirm that the safety requirements are met.

2.2.1 SERVOPACKs without Built-in Servomotor Brake Control

2.2 Block Diagrams

This section provides a block diagram of the interior of the SERVOPACKs.


2.2.1 SERVOPACKs without Built-in Servomotor Brake Control



SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, and -170D


* If using these terminals, contact your YASKAWA representative.

2.2.1 SERVOPACKs without Built-in Servomotor Brake Control



* If using these terminals, contact your YASKAWA representative.


2.2.1 SERVOPACKs without Built-in Servomotor Brake Control



* If using these terminals, contact your YASKAWA representative.

2.2.2 SERVOPACKs with Built-in Servomotor Brake Control


2.2.2 SERVOPACKs with Built-in Servomotor Brake Control



SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, and -170D


* If using these terminals, contact your YASKAWA representative.

2.2.2 SERVOPACKs with Built-in Servomotor Brake Control



* If using these terminals, contact your YASKAWA representative.

2.2.2 SERVOPACKs with Built-in Servomotor Brake Control



* If using these terminals, contact your YASKAWA representative.


2.3.1 Front Cover Dimensions and Connector Specifications

2.3 External Dimensions

2.3.1 Front Cover Dimensions and Connector Specifications

The front cover dimensions and panel connector section are the same for all models. Refer to the following figures and table.

Front Cover Dimensions and Connectors



Connector Specifications

Connector No.	Connector Model	Number of Pins	Manufacturer	SERVOPACK Model
CN1	DMC 1.5/15-G1F-3.5-LR-BK	30	Phoenix Contact	All models
CN2	3E106-0220KV	6	3M Japan Limited	All models
CN3	HDR-EC14LFDTN-SLD+	14	Honda Tsushin Kogyo Co., Ltd.	All models
CN6A/B	1-1734579-4	8	Tyco Electronics Japan G.K.	All models
CN7	2172034-1	5	Tyco Electronics Japan G.K.	All models
CN8	1903815-1	8	Tyco Electronics Japan G.K.	All models
CN101	BLZ 7.62HP/08/180LR SN BK BX PRT	8	Weidmüller Interface	SGD7S-1R9D to -170D
	BUZ 10.16HP/07/180F AG BK BX LPR	0	GmbH & Co. KG	SGD7S-210D to -370D

Continued on next page.

2.3.1 Front Cover Dimensions and Connector Specifications

			Continued from	previous page.
Connector No.	Connector Model	Number of Pins	Manufacturer	SERVOPACK Model
CN102	BLZ 7.62IT/04/180MF4 SN BK BX PRT	4	Weidmüller Interface	SGD7S-1R9D to -170D
GINTOZ	BUZ 10.16IT/04/180MF4 AG BK BX LPR	4	GmbH & Co. KG	SGD7S-210D to -370D
CN103*	BVZ 7.62IT/04/180MF3 SN BK BX PRT	4	Weidmüller Interface	SGD7S-1R9D to -170D
CINTUS	BUZ 10.16IT/04/180MF3 AG BK BX LPR	4	GmbH & Co. KG	SGD7S-210D to -370D
CN115	BLZ 7.62IT/03/180MF2 SN BK BX PRT	3	Weidmüller Interface	SGD7S-1R9D to -170D
CIVI15	None	5	GmbH & Co. KG	SGD7S-210D to -370D
CN201	BLF 5.08HC/04/180LR SN OR BX SO	4	Weidmüller Interface GmbH & Co. KG	All models

* If using these terminals, contact your YASKAWA representative.


Note: The above connectors or their equivalents are used for the SERVOPACKs.


2.3.2 SERVOPACK External Dimensions

2.3.2 SERVOPACK External Dimensions

Base-mounted SERVOPACKs

• Three-Phase, 400 VAC: SGD7S-1R9D, -3R5D, -5R4D, -8R4D, and -120D







Approx. mass: SGD7S-1R9D, -3R5D, or -5R4D: 3.4 kg SGD7S-8R4D or -120D: 3.7 kg Unit: mm

Three-Phase, 400 VAC: SGD7S-170D

330






Approx. mass: 5.5 kg Unit: mm


2.3.2 SERVOPACK External Dimensions


• Three-Phase, 400 VAC: SGD7S-210D and -260D



Approx. mass: 7.0 kg Unit: mm

• Three-Phase, 400 VAC: SGD7S-280D and -370D






Approx. mass: 13.5 kg Unit: mm

Examples of Standard Connections between SERVOPACKs and Peripheral Devices 2.4






* The power supply for the holding brake is not provided by Yaskawa. Select a power supply based on the holding

If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.

Linear Servomotors



SERVOPACK Installation

This chapter provides information on installing SERVO-PACKs in the required locations.

3.1	Installation Precautions						
3.2	Mounting Types and Orientation						
3.3	Mounting Hole Dimensions						
3.4	Mour	nting Interval					
	3.4.1 3.4.2	Installing One SERVOPACK in a Control Panel3-5 Installing More Than One SERVOPACK in a Control Panel					
3.5	Moni	toring the Installation Environment 3-6					
3.6	Derat	ting Specifications					
3.7	EMC	Installation Conditions3-8					

3.1 Installation Precautions

Refer to the following section for the ambient installation conditions. (2) 2.1.3 Specifications on page 2-4

Installation Near Sources of Heat

Implement measures to prevent temperature increases caused by radiant or convection heat from heat sources so that the ambient temperature of the SERVOPACK meets the ambient conditions.

■ Installation Near Sources of Vibration

Install a vibration absorber on the mounting surface of the SERVOPACK so that the SERVO-PACK will not be subjected to vibration.

Other Precautions


Do not install the SERVOPACK in a location subject to high temperatures, high humidity, water drops, cutting oil, excessive dust, excessive dirt, excessive iron powder, corrosive gasses, or radioactivity.

3.2 Mounting Types and Orientation

Only base-mounted SERVOPACKs are available. Mount the SERVOPACK vertically, as shown in the following figures.

Also, mount the SERVOPACK so that the front panel is facing toward the operator.


Note: Prepare four mounting holes for the SERVOPACK and mount it securely in the mounting holes. (The number of mounting holes depends on the capacity of the SERVOPACK.)



3.3 Mounting Hole Dimensions

Use mounting holes to securely mount the SERVOPACK to the mounting surface.

Note: To mount the SERVOPACK, you will need to prepare a screwdriver that is longer than the depth of the SER-VOPACK.



Mounting Hole Dimensions


SERVOPACK Model				Screw	Number						
		А	В	С	D	Е	F	G	н	Size	of Screws
	1R9D, 3R5D, 5R4D, 8R4D, 120D	330	7.5	315±0.5	80	10	60±0.5	10	60±0.5	M5	4
SGD7S-	170D	330	7.5	315±0.5	100	10	80±0.5	10	80±0.5	M5	4
	210D, 260D	380	7.5	365±0.5	100	10	80±0.5	10	80±0.5	M5	4
	280D, 370D	380	6.5	367±0.5	180	12.5	155±0.5	12.5	155±0.5	M6	4

3.4.1 Installing One SERVOPACK in a Control Panel

3.4 Mounting Interval

3.4.1 Installing One SERVOPACK in a Control Panel


Provide the following spaces around the SERVOPACK.



* For this dimension, ignore items protruding from the main body of the SERVOPACK.

3.4.2 Installing More Than One SERVOPACK in a Control Panel

When multiple SERVOPACKs are installed close together in an enclosed space, natural convection may provide insufficient air circulation to distribute heat uniformly through the space, resulting in the air surrounding the SERVOPACKs to locally exceed the surrounding air temperature range. In this case, you must take measures to disperse the localized hot spots, such as by using fans. When using fans, install them as shown below.



QE	RVOPACK model	Cooling Fan Installation Conditions				
36	INVOFACIN MODEL	10 mm above SERVOPACK's Top Surface				
	1R9D, 3R5D, 5R4D, 8R4D, 120D, 170D, 210D, 260D, 280D, 370D	Air speed: 1.0 m/s min.				

Note: When option modules are mounted on SERVOPACKs, the SERVOPACK installation conditions will depend on the option modules that are mounted. For details, refer to the manual for option module.

3.5 Monitoring the Installation Environment

You can use the SERVOPACK Installation Environment Monitor parameter to check the operating conditions of the SERVOPACK in the installation environment.

You can check the SERVOPACK installation environment monitor with either of the following methods.

- Using the SigmaWin+: Life Monitor Installation Environment Monitor SERVOPACK
- Panel Operator or Digital Operator: Un025 (Installation Environment Monitor [%])

Implement one or more of the following actions if the monitor value exceeds 100%.

- Lower the surrounding temperature.
- Decrease the load.

Information The value of the SERVOPACK Installation Environment Monitor parameter will increase by about 10% for each 10°C increase in the ambient temperature.




Always observe the surrounding air temperature given in the SERVOPACK environment conditions. Even if the monitor value is 100% or lower, you cannot use a SERVOPACK in a location that exceeds the specified surrounding air temperature.

3.6 Derating Specifications

If you use the SERVOPACK at a surrounding air temperature of 55°C to 60°C or at an altitude of 1,000 m to 2,000 m, you must apply the derating rates given in the following graphs.

• SGD7S-1R9D, 3R5D, 5R4D, 8R4D, 120D, 170D, 210D, 260D, and 280D



3.7 EMC Installation Conditions

This section gives the recommended installation conditions that were used for EMC certification testing.

The EMC installation conditions that are given here are the conditions that were used to pass testing criteria at Yaskawa. The EMC level may change under other conditions, such as the actual installation structure and wiring conditions. These Yaskawa products are designed to be built into equipment. Therefore, you must implement EMC measures and confirm compliance for the final equipment.


The compliant standards are EN 55011 group 1 class A, EN 61000-6-2, EN 61000-6-4, and EN 61800-3 (category C2, second environment).



• In a domestic environment, this product may cause radio interference in which case supplementary mitigation measures may be required.

• This equipment is not intended for use in residential environments and may not provide adequate protection to radio reception in such environments.

• Three-Phase, 400 VAC



Wiring and Connecting SERVOPACKs

This chapter provides information on wiring and connecting SERVOPACKs to power supplies and peripheral devices.

4.1	Wiring	g and Connecting SERVOPACKs 4-3
	4.1.1 4.1.2 4.1.3	General Precautions4-3Countermeasures against Noise4-5Grounding4-8
4.2	Basic	Wiring Diagrams
4.3	Wiring	the Power Supply to the SERVOPACK 4-11
	4.3.1 4.3.2 4.3.3 4.3.4 4.3.5 4.3.6	Terminal Symbols and Terminal Names4-11Connector Wiring Procedure4-13Power ON Sequence4-14Power Supply Wiring Diagrams4-15Wiring Regenerative Resistors4-18Wiring Reactors for Harmonic Suppression4-18
4.4	Wiring	g Servomotors 4-19
	4.4.1 4.4.2	Terminal Symbols and Terminal Names4-19Pin Arrangement of Encoder Connector(CN2)
	4.4.3 4.4.4	Wiring the SERVOPACK to the Encoder 4-20 Wiring the SERVOPACK to the Holding Brake 4-27

4.5	I/O Si	gnal Connections4-29
	4.5.1	I/O Signal Connector (CN1) Names and Functions
	4.5.2 4.5.3	I/O Signal Connector (CN1) Pin Arrangement4-31 I/O Signal Wiring Examples
	4.5.4	I/O Circuits
4.6	Conn	ecting Safety Function Signals4-36
	4.6.1 4.6.2	Pin Arrangement of Safety Function Signals (CN8) 4-36 I/O Circuits
4.7	Connect	ing MECHATROLINK-III Communications Cables (RJ-45) 4-38
4.8	Conn	ecting the Other Connectors4-39
	4.8.1 4.8.2 4.8.3	Serial Communications Connector (CN3)4-39Computer Connector (CN7)4-39Analog Monitor Connector (CN5)4-39

4.1.1 General Precautions


4.1 Wiring and Connecting SERVOPACKs

4.1.1 General Precautions

<u> DANGER</u>

• Do not change any wiring while power is being supplied. There is a risk of electric shock or injury.


- Wiring and inspections must be performed only by qualified engineers. There is a risk of electric shock or product failure.
- Check all wiring and power supplies carefully. Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures. If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. This could damage the machine or cause an accident that may result in death or injury.
- Connect the AC and DC power supplies to the specified SERVOPACK terminals.
 - Connect an AC power supply to the L1, L2, and L3 terminals on the SERVOPACK.
 Connect a DC power supply to the B1 and C 2 terminals and the 24 V and C V terminals
 - Connect a DC power supply to the B1 and \ominus 2 terminals and the 24 V and 0 V terminals on the SERVOPACK.



Continued on next page.

4.1.1 General Precautions

Continued from previous page.



- short-circuiting, or install a ground fault detector combined with a molded-case circuit breaker. • Do not turn the power supply ON and OFF more than necessary. Do not use the SERVOPACK for applications that require the power supply to turn ON and
 - OFF frequently. Such applications will cause elements in the SERVOPACK to deteriorate. After you have started actual operation, allow at least one hour between turning the power
 - supply ON and OFF (as a guideline).

To ensure safe, stable application of the Servo System, observe the following precautions when wiring.

- Use the Cables specified by Yaskawa. Design and arrange the system so that each cable is as short as possible.
 - Refer to the catalog for information on the specified cables.
- The signal cable conductors are as thin as 0.2 mm² or 0.3 mm². Do not subject them to excessive bending stress or tension.

4.1.2 Countermeasures against Noise

4.1.2 Countermeasures against Noise

The SERVOPACK is designed as an industrial device. It therefore provides no measures to prevent radio interference. The SERVOPACK uses high-speed switching elements in the main circuit. Therefore peripheral devices may be affected by switching noise.

If the equipment is to be used near private houses or if radio interference is a problem, take countermeasures against noise.

The SERVOPACK uses microprocessors. Therefore, it may be affected by switching noise from peripheral devices.

To prevent the noise from the SERVOPACK or the peripheral devices from causing malfunctions of any devices, take the following countermeasures against noise as required.

- Install the input reference device and Noise Filter as close to the SERVOPACK as possible.
- Always install a Surge Absorber for relays, solenoids, and Magnetic Contactor coils.
- Do not place the following cables in the same duct or bundle them together. Also, separate the cables from each other by at least 30 cm.

•Main Circuit Cables and I/O Signal Cables

- •Main Circuit Cables and Encoder Cables
- Do not share the power supply with an electric welder or electrical discharge machine. If the SERVOPACK is placed near a high-frequency generator, install Noise Filters on the input side on the Main Circuit Power Supply Cable and Control Power Supply Cable even if the same power supply is not shared with the high-frequency generator. Refer to the following section for information on connecting Noise Filters.
 - Noise Filters on page 4-6
- Implement suitable grounding measures. Refer to the following section for information on grounding measures.


4.1.3 Grounding on page 4-8

Δ

4.1.2 Countermeasures against Noise

Noise Filters

You must attach Noise Filters in appropriate places to protect the SERVOPACK from the adverse effects of noise. The following is an example of wiring for countermeasures against noise.




- *1. For the ground wire, use a wire with a thickness of at least 2.0 mm² (preferably, flat braided copper wire).
- *2. Whenever possible, use twisted-pair wires to wire all connections marked with \perp .
- *3. Refer to the following section for precautions when using Noise Filters. *Noise Filter Wiring and Connection Precautions* on page 4-7

4.1.2 Countermeasures against Noise


Noise Filter Wiring and Connection Precautions

Always observe the following precautions when wiring or connecting Noise Filters.


• Separate input lines from output lines. Do not place input lines and output lines in the same duct or bundle them together.



• Separate the Noise Filter ground wire from the output lines. Do not place the Noise Filter ground wire, output lines, and other signal lines in the same duct or bundle them together.




• Connect the Noise Filter ground wire directly to the grounding plate. Do not connect the Noise Filter ground wire to other ground wires.



Λ

4.1.3 Grounding

• If a Noise Filter is located inside a control panel, first connect the Noise Filter ground wire and the ground wires from other devices inside the control panel to the grounding plate for the control panel, then ground the plate.



4.1.3 Grounding

Implement grounding measures as described in this section. Implementing suitable grounding measures will also help prevent malfunctions, which can be caused by noise.

Observe the following precautions when wiring the ground cable.

- Ground the SERVOPACK to a resistance of 10 Ω or less.
- Be sure to ground at one point only.
- Ground the Servomotor directly if the Servomotor is insulated from the machine.

Motor Frame Ground or Motor Ground

If you ground the Servomotor through the machine, a current resulting from switching noise can flow from the main circuit of the SERVOPACK through the stray capacitance of the Servomotor. To prevent this, always connect the FG terminal of the Servomotor Main Circuit Cable connected to the Servomotor to the ground terminal) on the SERVOPACK. Also be sure to ground the ground terminal). Always connect the shield wire of the Encoder Cable connected to the Servomotor to the connector case (shell).


Ground both the Moving Coil and Magnetic Way of a Linear Servomotor.

Noise on I/O Signal Cables

If noise enters the I/O Signal Cable, ground the shield of the I/O Signal Cable using a clamp or other means. If the Servomotor Main Circuit Cable is placed in a metal conduit, ground the conduit and its junction box. For all grounding, ground at one point only.

4.2 Basic Wiring Diagrams

This section provide the basic wiring diagrams. Refer to the reference sections given in the diagrams for details.



*1. \checkmark represents twisted-pair wires.

- *2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
- *3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- *4. Refer to the following chapter if you use a safety function device.
 Chapter 12 Safety Functions
 If you do not use the safety function, insert the Safety Jumper Connector (provided as an accessory) into CN8 when you use the SERVOPACK.
- *5. Always use line receivers to receive the output signals.
- *6. Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals.
- *7. The CN117 connector is used for SERVOPACKs with built-in Servomotor brake control. SERVOPACKs without built-in Servomotor brake control do not have the CN117 connector.
- *8. If using these terminals, contact your YASKAWA representative.
- Note: 1. You can use parameters to change the functions allocated to the /DEC, P-OT, N-OT, /EXT1, /EXT2, and / EXT3 input signals and the /SO1, /SO2, /SO3, /SO4, and /SO5 output signals. Refer to the following section for details.

7.1 I/O Signal Allocations on page 7-4

- If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.
- 3. Default settings are given in parentheses.

4.3.1 Terminal Symbols and Terminal Names

4.3 Wiring the Power Supply to the SERVOPACK

Refer to the catalog for information on cables and peripheral devices.

4.3.1 Terminal Symbols and Terminal Names

Use the main circuit connector on the SERVOPACK to wire the main circuit power supply and control circuit power supply to the SERVOPACK.

• Wire all connections correctly according to the following table and specified reference information. There is a risk of SERVOPACK failure or fire if incorrect wiring is performed.

The SERVOPACKs have the following two types of main circuit power supply input specifications.

• Three-Phase, 400-VAC Power Supply Input

Terminal Symbols	Terminal Name	Specifications and Reference
L1, L2, L3	Main circuit power sup- ply input terminals for AC power supply input	Three-phase, 380 VAC to 480 VAC, -15% to +10%, 50 Hz/60 Hz
24 V	Control power supply	24 VDC, -15% to +15%
0 V	terminals ^{*1}	0 VDC
		4.3.5 Wiring Regenerative Resistors on page 4-18
B1, B2, B3 ^{*2}	Regenerative Resistor terminal	If the internal Regenerative Resistor is insufficient, remove the lead or short bar between B2 and B3 and connect an External Regen- erative Resistor between B1 and B2. The External Regenerative Resistor is not included. Obtain it sepa- rately.
	DC Reactor terminals for	3.3.6 Wiring Reactors for Harmonic Suppression on page 4-18
⊖1, ⊖2	power supply harmonic suppression	These terminals are used to connect a DC Reactor for power supply harmonic suppression.
⊖, ⊕	-	None. (Do not connect anything to this terminal.)
U, V, W, PE	Servomotor terminals	These are the Σ-7S connection terminals for the Servomotor Main Circuit Cable (power line). Note: Do not connect the PE terminal to anything other than a ground ter- minal.
D1, D2, D3 ^{*3}	Dynamic Brake Resistor terminals	 In the following cases, remove the lead or short bar between D2 and D3 and connect a Dynamic Brake Resistor between D1 and D2. To specify the brake torque when stopping with the dynamic brake To use a larger load moment of inertia than in the standard specifications The Dynamic Brake Resistor is not included. Obtain it separately.
DC+*5	Servomotor brake power	24 VDC
DC-*5	supply terminals ^{*4}	0 VDC
BK+, BK- ^{*5}	Servomotor brake termi- nals	Connect these terminals to the Servomotor's holding brake termi- nals. The holding brake terminals on the Servomotor do not have any polarity.
	Ground terminal	The ground terminals to prevent electric shock. Always connect this terminal.

*1. Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals.

*2. With the SGD7S-210D, -260D, -280D, or -370D, connect an External Regenerative Resistor between B1 and B2.

*3. The SGD7S-210D, -260D, -280D, and -370D do not have the D1, D2, and D3 terminals.

*4. Make sure you check the brake specifications of the Servomotor for the 24-VDC power supply input to the Servomotor brake power supply terminals.

*5. SERVOPACKs without built-in Servomotor brake control do not have these terminals.

4.3.1 Terminal Symbols and Terminal Names

• DC Power Supply Input

Terminal Symbols	Terminal Name	Specifications and Reference	
24 V	Control power supply termi-	24 VDC, -15% to +15%	
0 V	nals ^{*1}	0 VDC	
B1 ^{*2}	Main circuit power supply	513 VDC to 648 VDC, -15% to +10%	
$\ominus 2^{*2}$	input terminals for DC power supply input	0 VDC	
L1, L2, L3, B2, B3, ⊖1, ⊖, ⊕	-	None. (Do not connect anything to these terminals.) Note: The SGD7S-210D to -370D do not have B3 terminal.	
U, V, W, PE	Servomotor terminals	These are the Σ-7S connection terminals for the Servomotor Main Circuit Cable (power line). Note: Do not connect the PE terminal to anything other than a ground terminal.	
D1, D2, D3 ^{*3}	Dynamic Brake Resistor ter- minals	 In the following cases, remove the lead or short bar between D2 and D3 and connect a Dynamic Brake Resistor between D1 and D2. To specify the brake torque when stopping with the dynamic brake To use a larger load moment of inertia than in the standard specifications The Dynamic Brake Resistor is not included. Obtain it separately. 	
DC+*5	Servomotor brake power	24 VDC	
DC-*5	supply terminals ^{*4}	0 VDC	
BK+, BK- ^{*5}	Servomotor brake terminals	Connect these terminals to the Servomotor's holding brake terminals. The holding brake terminals on the Servomotor do not have any polarity.	
	Ground terminal	This is the ground terminal to prevent electric shock. Always connect this terminal.	

*1. Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals.

*2. If using these terminals, contact your YASKAWA representative.

*3. The SGD7S-210D, -260D, -280D, and -370D do not have the D1, D2, and D3 terminals.

*4. Make sure you check the brake specifications of the Servomotor for the 24-VDC power supply input to the Servomotor brake power supply terminals.

*5. SERVOPACKs without built-in Servomotor brake control do not have these terminals.

If you use a DC power supply input to the SERVOPACK, make sure to set parameter Pn001 to $n.\Box 1 \Box \Box$ (DC power supply input supported) before inputting the power supply. Refer to the following section for details.

6.3 Power Supply Type Settings for the Main Circuit on page 6-13

4.3.2 Connector Wiring Procedure

4.3.2 Connector Wiring Procedure


- Screwdriver End SERVOPACK model Screwdriver Dimensions Wire Stripping **Terminal Symbols** SGD7S-Thickness × Width Length [mm] Туре [mm] L1, L2, L3, B1, B2, B3, -1, -2 Flat-blade 7 1R9D, 3R5D, 5R4D, Phillips or U, V, W, PE 0.6×3.5 7 8R4D, 120D, 170D flat-blade 24 V, 0 V Flat-blade 10 Phillips or L1, L2, L3, B1, B2, B3, -1, -2 12 flat-blade 210D, 260D, 280D, Phillips or 1.0×5.5 370D U, V, W, PE 12 flat-blade 24 V, 0 V Flat-blade 10
- Required Items: Phillips or flat-blade screwdriver

- 1. Prepare the connector that was provided with the SERVOPACK.
- 2. Remove the sheath from the wire to connect.

3. Open the wire insertion hole on the terminal connector with the screwdriver.

Main Circuit Terminals and Motor Terminals	Control Power Supply Terminals
Insert the conductor of the wire into the wire inser- tion hole, insert the screwdriver into the screwdriver insertion hole, and tighten the screw.	Press the lever with a screwdriver or your fingertip and insert the conductor of the wire into the wire insertion hole. After you insert conductor, release the screwdriver or your fingertip.
Wire	Wire

- 4. Make all other connections in the same way.
- 5. When you have completed wiring, attach the connector to the SERVOPACK.
- 6. Press the connector all the way to the back and lock it with the lock lever.



4.3.3 Power ON Sequence

4.3.3 Power ON Sequence

Consider the following points when you design the power ON sequence.

• The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON. Take this into consideration when you design the power ON sequence, and turn ON the main circuit power supply to the SERVOPACK when the ALM signal is OFF (alarm cleared).

	Power ON	
	Ļ	
Control power supply	OFF ON	
ALM (Servo Alarm) signal	Alarm	Alarm cleared.
Main circuit power supply	OFF	ON
/S_RDY (Servo Ready) signal	OFF	ON
SV_ON (Servo ON) command	Servo OFF	Servo ON
Motor power status	Power not supplied	. Power supplied.

- Information If the servo ON state cannot be achieved by inputting the Servo ON command (Enable Operation command), the /S_RDY signal is not ON. Check the status of the /S_RDY signal. Refer to the following section for details.
- Design the power ON sequence so that main circuit power supply is turned OFF when an ALM (Servo Alarm) signal is output.
- Make sure that the power supply specifications of all parts are suitable for the input power supply.
- Allow at least 1 s after the power supply is turned OFF before you turn it ON again.



Turn ON the control power supply and the main circuit power supply at the same time or turn ON the control power supply before the main circuit power supply. Turn OFF the main circuit power supply first, and then turn OFF the control power supply.


• Even after you turn OFF the power supply, a high residual voltage may still remain in the SERVOPACK. To prevent electric shock, do not touch the power supply terminals after you turn OFF the power. When the voltage is discharged, the CHARGE indicator will turn OFF. Make sure the CHARGE indicator is OFF before you start wiring or inspection work.

4.3.4 Power Supply Wiring Diagrams


4.3.4 Power Supply Wiring Diagrams

Using Only One SERVOPACK

• Wiring Example for Three-Phase, 400-VAC Power Supply Input: SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, and -170D




• Wiring Example for Three-Phase, 400-VAC Power Supply Input: SGD7S-210D, -260D, -280D, and -370D




4.3.4 Power Supply Wiring Diagrams

 Wiring Example for DC Power Supply Input: SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, and -170D



• Wiring Example for DC Power Supply Input: SGD7S-210D, -260D, -280D, and -370D



4.3.4 Power Supply Wiring Diagrams


Using More Than One SERVOPACK

Connect the ALM (Servo Alarm) output for these SERVOPACKs in series to operate the alarm detection relay (1RY).

When a SERVOPACK alarm is activated, the ALM output signal transistor turns OFF.

The following diagram shows the wiring to stop all of the Servomotors when there is an alarm for any one SERVOPACK.

More than one SERVOPACK can share a single Noise Filter. However, always select a Noise Filter that has a large enough capacity to handle the total power supply capacity of all the SERVOPACKs. Be sure to consider the load conditions.



To comply with UL/cUL standards, you must install a branch circuit protective device at the power supply input section to each SERVOPACK. Refer to the following document for details. Ω Σ-7-Series Σ-7S and Σ-7W SERVOPACK with 400 V-Input Power Safety Precautions (Manual No.: TOMP C710828 02)

4.3.5 Wiring Regenerative Resistors

4.3.5 Wiring Regenerative Resistors

This section describes how to connect External Regenerative Resistors.


Refer to the catalog to select External Regenerative Resistors.




● Be sure to wire Regenerative Resistors correctly. Do not connect B1/⊕ and B2. Doing so may result in fire or damage to the Regenerative Resistor or SERVOPACK.

Connecting Regenerative Resistors

1. Remove the wire connected between the B2 and B3 terminals.




2. Connect the External Regenerative Resistor between the B1 and B2 terminals on the SERVOPACK.



 Set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistor Resistance). Refer to the following section for details on the settings.
 6.18 Setting the Regenerative Resistor Capacity on page 6-53

4.3.6 Wiring Reactors for Harmonic Suppression

You can connect a reactor for harmonic suppression to the SERVOPACK when power supply harmonic suppression is required. Connection terminals $\ominus 1$ and $\ominus 2$ for a DC Reactor are connected when the SERVOPACK is shipped. Remove the lead wire and connect a DC Reactor as shown in the following diagram.



4.4.1 Terminal Symbols and Terminal Names

4.4 Wiring Servomotors

4.4.1 Terminal Symbols and Terminal Names

The SERVOPACK terminals or connectors that are required to connect the SERVOPACK to a Servomotor are given below.

Terminal/Connector Symbols	Terminal/Connector Name	Remarks
U, V, and W	Servomotor terminals	Refer to the following section for the wiring proce- dure. (2) 4.3.2 Connector Wiring Procedure on page 4-13
PE	Ground terminal	-
CN2	Encoder connector	-

4.4.2 Pin Arrangement of Encoder Connector (CN2)

Pin No.	Signal	Function		
1	PG5V	Encoder power supply +5 V		
2	PG0V	Encoder power supply 0 V		
3	BAT (+)*	Battery for absolute encoder (+)		
4	BAT (-)*	Battery for absolute encoder (-)		
5	PS	Serial data (+)		
6	/PS	Serial data (-)		
Shell	Shield	-		

• When Using a Rotary Servomotor

* You do not need to wire these pins for an incremental encoder.

• When Using a Linear Servomotor

Pin No.	Signal	Function	
1	PG5V	Linear encoder power supply +5 V	
2	PG0V	Linear encoder power supply 0 V	
3	-	– (Do not use.)	
4	-	– (Do not use.)	
5	PS	Serial data (+)	
6	/PS	Serial data (-)	
Shell	Shield	-	


4.4.3 Wiring the SERVOPACK to the Encoder

When Using an Absolute Encoder


If you use an absolute encoder, use an Encoder Cable with a JUSP-BA01-E Battery Case or install a battery on the host controller.

Refer to the following section for the battery replacement procedure. *13.1.3 Replacing the Battery* on page 13-3


• Wiring Example When Using an Encoder Cable with a Battery Case




- *1. The absolute encoder pin numbers for wiring the connector depend on the Servomotor that you use.
- *2. represents a shielded twisted-pair cable.
- Wiring Example When Installing a Battery on the Host Controller




*1. The absolute encoder pin numbers for wiring the connector depend on the Servomotor that you use.





When Using an Incremental Encoder



*1. The incremental encoder pin numbers for wiring the connector depend on the Servomotor that you use.




When Using an Absolute Linear Encoder

The wiring depends on the manufacturer of the linear encoder.

Connections to Linear Encoder from Dr. JOHANNES HEIDENHAIN GmbH


■ LIC4100 Series, LIC2100 Series, LC115, and LC415




represents a shielded twisted-pair cable.

Information

n Sales of the interface unit EIB3391Y with the LIC4100, and LIC2100 series have ended due to the release of the LIC4190, LIC3190, and LIC2190 series.





Connections to Linear Encoder from RSF Elektronik GmbH Absolute linear encoder




represents a shielded twisted-pair cable.

Connections to Linear Encoder from Mitutoyo Corporation






Connections to Absolute Linear Encoder from Renishaw PLC




• Connections to Absolute Linear Encoder from Canon Precision Inc.




When Using an Incremental Linear Encoder

The wiring depends on the manufacturer of the linear encoder.





Connections to Linear Encoder from Renishaw PLC




* represents a shielded twisted-pair cable.

◆ Connections to Linear Encoder from Magnescale Co., Ltd.

If you use a linear encoder from Magnescale Co., Ltd., the wiring will depend on the model of the linear encoder.

■ SR75 and SR85




* represents a shielded twisted-pair cable.

- SL700, SL710, SL720, SL730, and SQ10
- PL101-RY, MQ10-FLA, or MQ10-GLA Interpolator
 - The following table gives the linear encoder and Interpolator combinations.

÷.		
	Linear Encoder Model	Interpolator Model
	SL700, SL710, SL720, and SL730	PL101-RY ^{*1}
	SQ10	MQ10-FLA*2
	3010	MQ10-GLA ^{*2}


- *1. This is the model of the Head with Interpolator.
- *2. This is the model of the Interpolator.



* $\overbrace{t'}^{\uparrow}$ represents a shielded twisted-pair cable.


■ SL700, SL710, SL720, and SL730

MJ620-T13 Interpolator
 Linear encoder




represents a shielded twisted-pair cable.

Connections to Linear Encoder from Canon Precision Inc.




4.4.4 Wiring the SERVOPACK to the Holding Brake

4.4.4 Wiring the SERVOPACK to the Holding Brake



SERVOPACKs without Built-in Servomotor Brake Control

A wiring example for SERVOPACKs without built-in Servomotor brake control is provided below.



1D: Flywheel diode


* Install the Surge Absorber near the brake terminals on the Servomotor.

4.4.4 Wiring the SERVOPACK to the Holding Brake

SERVOPACKs with Built-in Servomotor Brake Control

SERVOPACKs with built-in brake control contain a brake relay.

The wiring is different because of the built-in brake relays. The following figure shows a wiring example.



Connector Specifications

Connector No.	Model	Number of Pins	Manufacturer
CN117	BLF 5.08HC/04/180LR SN BK BX SO	4	Weidmüller Interface GmbH & Co. KG

Built-in Brake Relay Specifications

The specifications of the built-in brake relay are as follows:

• Service life (number of operations): 30,000 operations

• Allowable number of operations: 30 operations per minute max.

4.5.1 I/O Signal Connector (CN1) Names and Functions

4.5 I/O Signal Connections

4.5.1 I/O Signal Connector (CN1) Names and Functions

The following table gives the pin numbers, names, and functions the I/O signal pins for the default settings.

Input Signals

Default settings are given in parentheses.

Signal	Pin No.	Name	Function	Reference
/SI1* (P-OT)	7	General-purpose Sequence Input 1 (For- ward Drive Prohibit Input)	You can allocate the input signal to use with a parameter. (Stops Servomotor drive (to prevent over-	
/SI2* (N-OT)	8	General-purpose Sequence Input 2 (Reverse Drive Prohibit Input)	travel) when the moving part of the machine exceeds the range of move- ment.)	page 6-27
/SI3* (/DEC)	9	General-purpose Sequence Input 3 (Ori- gin Return Deceleration Switch Input)	You can allocate the input signal to use with a parameter. (Connects the deceleration limit switch for origin return.)	_
/SI4* (/EXT1)	10	General-purpose Sequence Input 4 (Exter- nal Latch Input 1)		
/SI5* (/EXT2)	11	General-purpose Sequence Input 5 (Exter- nal Latch Input 2)	You can allocate the input signals to use with parameters. (Connect the external signals that latch the current feedback pulse counter.)	-
/SI6* (/EXT3)	12	General-purpose Sequence Input 6 (Exter- nal Latch Input 3)		
/SI0*	13	General-purpose Sequence Input 0	You can allocate the input signal to use with a parameter. (Used for general-purpose input. You can monitor this signal in the I/O monitor field of MECHATROLINK.)	_
+24VIN	6	Sequence Input Signal Power Supply Input	Inputs the sequence input signal power supply. Allowable voltage range: 24 VDC ±20% The 24-VDC power supply is not provided by Yaskawa.	_
BAT+	14	Battery for Absolute Encoder (+)	These are the pins to connect the abso- lute encoder backup battery.	
BAT-	15	Battery for Absolute Encoder (-)	Do not connect these pins if you use the Encoder Cable with a Battery Case.	_
ТН	5	Overheat Protection Input	Inputs the overheat protection signal from a Linear Servomotor or from a sensor attached to the machine	page 7-67

* You can change the allocations. Refer to the following section for details.

7.1.1 Input Signal Allocations on page 7-4

Note: If forward drive prohibition or reverse drive prohibition is used, the SERVOPACK is stopped by software controls. If the application does not satisfy the safety requirements, add external safety circuits as required.

4.5.1 I/O Signal Connector (CN1) Names and Functions

Output Signals

Default settings are given in parentheses.

Signal	Pin No.	Name	Function	Reference	
ALM+	3	Servo Alarm Output	Turne OFF (apape) when an error is detected		
ALM-	4	Servo Alarm Output	Turns OFF (opens) when an error is detected.	page 7-7	
/SO1+* (/BK+)	1	General-purpose Sequence Output 1	You can allocate the output signal to use with a parameter.	page 6-32	
/SO1-* (/BK-)	2	(Brake Output)	(Controls the brake. The brake is released when the signal turns ON (closes).)		
/SO2+*	23	General-purpose		_	
/SO2-*	24	Sequence Output 2			
/SO3+*	25	General-purpose			
/SO3-*	26	Sequence Output 3	Used for general-purpose outputs.		
/SO4+*	27	General-purpose	Set the parameters to allocate functions.		
/SO4-*	28	Sequence Output 4			
/SO5+*	29	General-purpose			
/SO5-*	30	Sequence Output 5			
PAO	17	Encoder Divided Pulse		page 7-32 page 7-41	
/PAO	18	Output, Phase A	Output the encoder divided pulse output sig-		
PBO	19	Encoder Divided Pulse	nals with a 90° phase differential.		
/PBO	20	Output, Phase B			
PCO	21	Encoder Divided Pulse	Outputs the origin signal once every encoder		
/PCO	22	Output, Phase C	rotation.		
SG	16	Signal ground	This is the 0-V signal for the control circuits.	_	

You can change the allocations. Refer to the following section for details.
 7.1.2 Output Signal Allocations on page 7-6

4.5.2 I/O Signal Connector (CN1) Pin Arrangement

4.5.2 I/O Signal Connector (CN1) Pin Arrangement


The following figure gives the pin arrangement of the of the I/O signal connector (CN1) for the default settings.

	No	Signal	Specification	No	Signal	Specification
Pin 15 200 Pin 30	15	PG BAT-	Battery for absolute encoder (-)	30	/SO5-	General-purpose sequence output 5
	14	PG BAT+	Battery for absolute encoder (+)	29	/SO5+	General-purpose sequence output 5
1001 1001 1001 Pin 1001 Pin	13	/SI0	General-purpose sequence input 0	28	/SO4-	General-purpose sequence output 4
2 100 17 1001 Pin	12	/SI6 (/EXT3)	General-purpose sequence input 6	27	/SO4+	General-purpose sequence output 4
1 16 Top View of I/O Signal Connector	11	/SI5 (/EXT2)	General-purpose sequence input 5	26	/SO3-	General-purpose sequence output 3
	10	/SI4 (/EXT1)	General-purpose sequence input 4	25	/SO3+	General-purpose sequence output 3
	9	/SI3 (/DEC)	General-purpose sequence input 3	24	/SO2-	General-purpose sequence output 2
Side View of I/O	8	/SI2 (N-OT)	General-purpose sequence input 2	23	/SO2+	General-purpose sequence output 2
Signal Connector	7	/SI1 (P-OT)	General-purpose sequence input 1	22	/PCO	Encoder divided pulse output, phase C
	6	+24VIN	Sequence input signal power supply input	21	PCO	Encoder divided pulse output, phase C
	5	ТН	Overheat protection input	20	/PBO	Encoder divided pulse output, phase B
	4	ALM-	Servo alarm output	19	РВО	Encoder divided pulse output, phase B
	3	ALM+	Servo alarm output	18	/PAO	Encoder divided pulse output, phase A
	2	/SO1- (/BK-)	General-purpose sequence output 1	17	PAO	Encoder divided pulse output, phase A
	1	/SO1+ (/BK+)	General-purpose sequence output 1	16	SG	Signal ground

4.5.3 I/O Signal Wiring Examples

4.5.3 I/O Signal Wiring Examples


Using a Rotary Servomotor



- *1. Frepresents twisted-pair wires.
- *2. Connect these when using an absolute encoder. If the Encoder Cable with a Battery Case is connected, do not connect a backup battery.
- *3. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.
- *4. Always use line receivers to receive the output signals.
- Note: 1. You can use parameters to change the functions allocated to the /DEC, P-OT, N-OT, /EXT1, /EXT2, and /EXT3 input signals and the /SO1, /SO2, /SO3, /SO4, and /SO5 output signals. Refer to the following section for details.
 - 7.1 I/O Signal Allocations on page 7-4
 - 2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.

4.5.3 I/O Signal Wiring Examples

Using a Linear Servomotor



*1. / represents twisted-pair wires.

*2. The 24-VDC power supply is not provided by Yaskawa. Use a 24-VDC power supply with double insulation or reinforced insulation.

*3. Always use line receivers to receive the output signals.

Note: 1. You can use parameters to change the functions allocated to the /DEC, P-OT, N-OT, /EXT1, /EXT2, and /EXT3 input signals and the /SO1, /SO2, /SO3, /SO4, and /SO5 output signals. Refer to the following section for details.

To Signal Allocations on page 7-4

2. If you use a 24-V brake, install a separate power supply for the 24-VDC power supply from other power supplies, such as the one for the I/O signals of the CN1 connector. If the power supply is shared, the I/O signals may malfunction.


4.5.4 I/O Circuits

4.5.4 I/O Circuits

Sequence Input Circuits

Photocoupler Input Circuits


This section describes CN1 connector terminals 6 to 13.



Note: The 24-VDC external power supply capacity must be 50 mA minimum.

The SERVOPACK input circuits use bidirectional photocouplers. Select either a sink circuit or source circuit according to the specifications required by the machine.

Note: The connection examples in 4.5.3 I/O Signal Wiring Examples on page 4-32 are for sink circuit connections.



4.5.4 I/O Circuits


Sequence Output Circuits

Incorrect wiring or incorrect voltage application to the output circuits may cause short-circuit failures.

If a short-circuit failure occurs as a result of any of these causes, the holding brake will not work. Important This could damage the machine or cause an accident that may result in death or injury.

Photocoupler Output Circuits

Photocoupler output circuits are used for the ALM (Servo Alarm), /S-RDY (Servo Ready), and other sequence output signals. Connect a photocoupler output circuit to a relay or line-receiver circuit.




Note: The maximum allowable voltage and current range for photocoupler output circuits are as follows:

- Maximum allowable voltage: 30 VDC
- Current range: 5 mA to 50 mA DC

◆ Line-Driver Output Circuits

This section describes CN1 connector terminals 17-18 (Phase-A Signal), 19-20 (Phase-B Signal), and 21-22 (Phase-C Signal).

The serial data from the encoder is converted to two-phase (phases A and B) pulses. The resulting output signals (PAO, /PAO and PBO, /PBO), origin pulse signal (PCO and /PCO), and the absolute encoder position output signals (PSO and /PSO) are output with line-driver output circuits. Connect the line-driver output circuits to line-receiver circuits at the host controller.



4.6.1 Pin Arrangement of Safety Function Signals (CN8)

4.6 Connecting Safety Function Signals

This section describes the wiring required to use a safety function. Refer to the following chapter for details on the safety function. *Chapter 12 Safety Functions*

4.6.1 Pin Arrangement of Safety Function Signals (CN8)

Pin No.	Signal	Name	Function		
1	-	(Do not use these pips because they	are connected to internal circuits.)		
2	-	- (Do not use these pins because they			
3	/HWBB1-	Hard Wire Base Block Input 1	For a hard wire base block input. The base block (motor power turned OFF) is in effect when the signal is OFF.		
4	/HWBB1+	Hard whe base block input i			
5	/HWBB2-	Hard Wire Rose Pleak Input 2			
6	/HWBB2+	Hard Wire Base Block Input 2			
7	EDM1-	External Device Monitor Output	Turns ON when the /HWBB1 and the /HWBB2 signals are input and the SER-		
8	EDM1+		VOPACK enters a base block state.		

4.6.2 I/O Circuits

For safety function signal connections, the input signal is the 0-V common and the output signal is a source output. This is opposite to other signals described in this manual.


To avoid confusion, the ON and OFF status of signals for the safety function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

Safety Input Circuits

Use a 0-V common to connect the safety function signals. You must connect redundant input signals.



4.6.2 I/O Circuits

Туре	Signal	Connector Pin No.	Status	Meaning
Inputs	/HWBB1	CN8-4 CN8-3	ON (closed)	Does not activate the HWBB (normal operation).
			OFF (open)	Activates the HWBB (motor current shut-OFF request).
		CN8-6	ON (closed)	Does not activate the HWBB (normal operation).
		/HWBB2	CN8-5	OFF (open)


◆ Input (HWBB) Signal Specifications

The input (HWBB) signals have the following electrical characteristics.

Item	Characteristics	Remarks
Internal Impedance	4.7 kΩ	-
Operating Voltage Range	+24 V ±20%	-
Maximum Delay Time	8 ms	Time from /HWBB1 and /HWBB2 signals turning OFF until HWBB is activated

Diagnostic Output Circuits

The EDM1 output signal uses a source circuit. The following figure shows a connection example.



EDM1 Output Signal Specifications


Туре	Signal	Pin No.	Output Status	Meaning
Output	EDM1	CN8-8 CN8-7	ON	Both the /HWBB1 and /HWBB2 signals are operat- ing normally.
			OFF	The /HWBB1 signal, the /HWBB2 signal, or both are not operating.

The electrical characteristics of the EDM1 signal are as follows:

Item	Characteristics	Remarks
Maximum Allowable Voltage	30 VDC	-
Maximum Allowable Current	50 mA DC	-
Maximum ON Voltage Drop	1.0 V	Voltage between EDM1+ and EDM1- when current is 50 mA
Maximum Delay Time	8 ms	Time from a change in /HWBB1 or /HWBB2 until a change in EDM1

4.7 Connecting MECHATROLINK-III Communications Cables (RJ-45)

Connect the MECHATROLINK-III Communications Cables to the CN6A and CN6B connectors.



Note: The length of the cable between stations (L1, L2, ... Ln) must be 50 m or less. Use the cables specified in the selection table for the MECHATROLINK-III Communications Cables (RJ-45). The maximum cable lengths are as follows:

- Cables with Connectors on Both Ends and No Ferrite Cores: 30 m
- Cables with Connectors on Both Ends and Ferrite Cores: 50 m

Selection Table

Contact your Yaskawa representative for details.

Туре	Length (L)	Order Number*
Cables with Connectors on Both Ends and No Ferrite Cores	0.2 m, 0.5 m, 1 m, 2 m, 3 m, 4 m, 5 m, 10 m, 20 m, and 30 m	JZSP-CM3RR00-□□-E (□□: 00P2/00P5/01/02/03/04/05/10/20/30)
Cables with Connectors on Both Ends and Ferrite Cores	10 m, 20 m, 30 m, and 50 m	JZSP-CM3RR01-ПП-Е (ПП: 10/20/30/50)

* Replace the boxes ($\Box\Box$) in the order number with the code for the cable length.

External Dimensions



4.8.1 Serial Communications Connector (CN3)

4.8 Connecting the Other Connectors

4.8.1 Serial Communications Connector (CN3)

To use a Digital Operator or to connect a computer with an RS-422 cable, connect CN3 on the SERVOPACK.

Refer to the following manual for the operating procedures for the Digital Operator. $\square \Sigma$ -7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

4.8.2 Computer Connector (CN7)

To use the SigmaWin+ Engineering Tool, connect the computer on which the SigmaWin+ is installed to CN7 on the SERVOPACK.

Refer to the following manual for the operating procedures for the SigmaWin+.




Use the Yaskawa-specified cables. Operation will not be dependable due to low noise resistance with any other cable.

Refer to the catalog for details on the Computer Cable.

4.8.3 Analog Monitor Connector (CN5)

To use an analog monitor, connect CN5 on the SERVOPACK.

• Wiring Example



* The measuring instrument is not provided by Yaskawa.

Refer to the following section for information on the monitoring methods for an analog monitor. 10.3 Monitoring Machine Operation Status and Signal Waveforms on page 10-7

Wiring and Settings for the Dynamic Brake

5

This chapter provides information on wiring and settings when using a dynamic brake with the SERVOPACK.

5.1	Introd	luction to the Dynamic Brake5-2
	5.1.1 5.1.2	SERVOPACK Models with a Built-In Dynamic Brake
5.2	SERVO	PACK Models with a Built-In Dynamic Brake5-3
	5.2.1 5.2.2 5.2.3 5.2.4	Using the Dynamic Brake
5.3	SERVO	PACK Models without a Built-In Dynamic Brake 5-10
	5.3.1 5.3.2 5.3.3 5.3.4	Using the Dynamic Brake
5.4	Coast	ing Distances for Dynamic Braking 5-18
	5.4.1 5.4.2	Coasting Distance during Dynamic Braking 5-18 Data for Calculating Coasting Distance 5-19

5.1.1 SERVOPACK Models with a Built-In Dynamic Brake

5.1 Introduction to the Dynamic Brake

Dynamic braking is a method in which the kinetic energy of the Servomotor is converted to electrical energy, and then this energy is consumed as thermal energy with a resistor to brake the motor.

The smaller the resistance of the Dynamic Brake Resistor, the faster the Servomotor can be stopped and the shorter the coasting distance will be. However, the larger the resistance of the Dynamic Brake Resistor, the more time will be required to stop the Servomotor and the longer the coasting distance will be.

Refer to the following section for details on the coasting distance. 5.4 Coasting Distances for Dynamic Braking on page 5-18



Coasting Distance

During dynamic braking, the Servomotor rotates due to inertia until the electrical energy is consumed. The travel distance at this time is called the coasting distance.

Dynamic braking can be used when an alarm occurs, when the servo is turned OFF, during an emergency stop, and when overtravel occurs by setting $Pn001 = n.\Box\Box\BoxX$ (Motor Stopping Method for Servo OFF and Group 1 Alarms) to 0 or 1.

Parameter		Meaning	When Enabled	Classification
	n.□□□0 (default setting)	Stop the motor by applying the dynamic brake.		
Pn001	n.0001	Stop the motor by the applying dynamic brake and then release the dynamic brake.	After restart	Setup
n.□□□2		Coast the motor to a stop without the dynamic brake.		

SERVOPACKs are available as models with a built-in dynamic brake (SGD7S-1R9D to 170D) and models without a built-in dynamic brake (SGD7S-210D to 370D).

5.1.1 SERVOPACK Models with a Built-In Dynamic Brake

SGD7S-1R9D to 170D SERVOPACKs are equipped with the built-in circuit required to use the dynamic brake. A Dynamic Brake Resistor is not required when operating the SERVOPACK within its rated range. However, an External Dynamic Brake Resistor must be connected to the SERVOPACK to operate the SERVOPACK in the following manner.

- When specifying the brake torque when stopping with the dynamic brake.
- When operating with a load moment of inertia that exceeds the rating.

Refer to the following section for how to connect the Dynamic Brake Resistor to the SERVO-PACK.

5.2.3 Connecting Dynamic Brake Resistors on page 5-7

5.1.2 SERVOPACK Models without a Built-In Dynamic Brake

SGD7S-210D to 370D SERVOPACKs are not equipped with a built-in dynamic brake.

To use dynamic braking, you must select the Resistor, create the circuit, and set the parameters.

Refer to the following section for details on the dynamic brake circuit.

5.3.3 Wiring the Dynamic Brake Circuit on page 5-15

Refer to the following section for details on selecting the Dynamic Brake Resistor.

5.3.2 Selecting the Devices Required for the Dynamic Brake Circuit on page 5-12

Refer to the following section for details on parameter settings for the dynamic brake. 5.3.4 Parameter Settings for the Dynamic Brake Circuit on page 5-16


5.2.1 Using the Dynamic Brake

5.2 SERVOPACK Models with a Built-In Dynamic Brake

This section describes how to use the SERVOPACKs (SGD7S-1R9D to 170D) equipped with a built-in dynamic brake.

5.2.1 Using the Dynamic Brake

When using the SGD7S-1R9D to 170D, set up the SERVOPACK according to the following flowchart.



5.2.2 Selecting the Dynamic Brake Resistor

Setting When Not Using Dynamic Braking

When not using dynamic braking, set $Pn001 = n.\Box\Box\BoxX$ (Motor Stopping Method for Servo OFF and Group 1 Alarms) to 2.

Parameter		Meaning	When Enabled	Classification
	n.□□□0 (default setting)	Stop the motor by applying the dynamic brake.	After restart	Setup
Pn001	n.0001	Stop the motor by the applying dynamic brake and then release the dynamic brake.		
	n.0002	Coast the motor to a stop without the dynamic brake.		

Setting When Using Dynamic Braking

When using dynamic braking, set $Pn001 = n.\Box\Box\BoxX$ (Motor Stopping Method for Servo OFF and Group 1 Alarms) to 0 or 1.

You must complete the following items to use the dynamic brake.

- Selecting the Dynamic Brake Resistor 5.2.2 Selecting the Dynamic Brake Resistor on page 5-4
- Connecting the Dynamic Brake Resistor [] 5.2.3 Connecting Dynamic Brake Resistors on page 5-7
- Parameter Settings for the Dynamic Brake

 5.2.4 Setting the Energy Consumption and Resistance of the Dynamic Brake Resistor on page 5-9

Note: When using the dynamic brake built into the SERVOPACK, you do not need to connect a Dynamic Brake Resistor.

5.2.2 Selecting the Dynamic Brake Resistor

This section describes the selection of the Dynamic Brake Resistor.

To select the Dynamic Brake Resistor, you must calculate the resistance and energy consumption for the specifications of the machine.

- Do not use dynamic braking for any application other than an emergency stop. There is a risk of failure due to rapid deterioration of elements in the SERVOPACK and the risk of unexpected operation, machine damage, burning, or injury.
- Use a Dynamic Brake Resistor matched to the specifications of the machine. There is a risk of unexpected operation, machine damage, burning, or injury.
- When using dynamic braking, implement suitable safety measures on the machine. There is a risk of unexpected operation, machine damage, burning, or injury.
- In situation where the motor will be rotated from the machine after it has been stopped, set the SERVOPACK to coast to stop instead of using dynamic braking. There is a risk of burning in the equipment, damage to the machine, or injury.

Resistance

Based on the characteristic graphs of the Servomotor that will be used, you must determine the resistance that can satisfy the limit of instantaneous maximum brake torque.

• Do not select a resistor with resistance less than the minimum allowable resistance. There is a risk of burning in the SERVOPACK or Servomotor, damage to the machine, or injury.


5.2.2 Selecting the Dynamic Brake Resistor

If it is not necessary to reduce the brake torque, select a Dynamic Brake Resistor with the following resistance.


Model		Minimum Allowable Resis- tance (±5%)
	-1R9D, -3R5D	30 Ω
SGD7S	-5R4D	20 Ω
5100	-8R4D, -120D	7.8 Ω
	-170D	6.6 Ω

If it is necessary to reduce the brake torque, determine the resistance based on the characteristic graphs.

The following graphs show the relationship between the instantaneous maximum brake torque of the Servomotor and the resistance of the dynamic brake.



5.2.2 Selecting the Dynamic Brake Resistor



Energy Consumption of the Dynamic Brake Resistor

Calculate the energy consumption required to stop the Servomotor using the Dynamic Brake Resistor.

To simplify the calculation of energy consumption, assume that all kinetic energy until the Servomotor stops is consumed by the Dynamic Brake Resistor and calculate energy consumption with the following formula.

Calculate energy consumption at the maximum value of kinetic energy of the Servomotor out of all anticipated operation patterns.

Rotary Servomotors

Energy consumption of Dynamic Brake Resistor: ${\ensuremath{\scriptscriptstyle \mathsf{E}_{\mathsf{DB}}}}\left[J\right]$

Motor moment of inertia: J_M [kg·m²]

Load moment of inertia: JL [kg·m²]

Motor speed before dynamic braking: N [min⁻¹]

 $E_{DB} = 1/2 \times (J_M + J_L) \times (2\pi N/60)^2$

Note: Refer to the catalog or product manual of the Servomotor for details on the motor moment of inertia.

5.2.3 Connecting Dynamic Brake Resistors

Linear Servomotors

Energy consumption of Dynamic Brake Resistor: ${\ensuremath{\mathtt{E}_{DB}}}\left[J\right]$

Moving Coil mass: M_M [kg]

Load mass: M_L [kg]

Movement speed before dynamic braking: V [m/s]

 $E_{DB} = 1/2 \times (M_M + M_L) \times V^2$

Note: Refer to the catalog or product manual of the Servomotor for details on the Moving Coil mass.

Specifications of the Dynamic Brake Resistor

Have the following specifications ready when purchasing the Dynamic Brake Resistor. In the blank cells of the table, write down the specifications of the Dynamic Brake Resistor that you are considering for purchase, and confirm these specifications with the manufacturer of the Resistor.

Item	Specification
Resistance (Ω)	
Energy consumption of resistor from dynamic braking (J)	
Number of operations of the dynamic brake (Number of times the dynamic brake will be used in the service life of the machine (reference data))	
Wire size	AWG14 (2.0 mm ²) to AWG18 (0.9 mm ²)

5.2.3 Connecting Dynamic Brake Resistors

A connector or terminal block is used to wire a Dynamic Brake Resistor.

This section describes the connection of the Dynamic Brake Resistor to a SERVOPACK with a built-in dynamic brake (SGD7S-1R9D to 170D).

Terminal Symbols and Terminal Names

• Wire all connections correctly according to the following table.

There is a risk of SERVOPACK failure or fire if incorrect wiring is performed.

SERVOPACK Model	Terminal Symbols	Terminal Name	Specification
SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, -170D	D1, D2	Dynamic Brake Resis- tor terminals	These terminals are connected to an External Dynamic Brake Resistor.

Note: The SGD7S-210D to 370D are not equipped with a connection terminal for a Dynamic Brake Resistor.

Connecting a Dynamic Brake Resistor



• Wire the Dynamic Brake Resistor correctly. Do not connect the following terminals directly to each other: D1 and D2.

There is a risk of burning in the SERVOPACK or Servomotor, damage to the machine, or injury.


5.2.3 Connecting Dynamic Brake Resistors




· Required Items

Required Item	Remarks
Phillips or flat-blade	Commercially available screwdriver with a tip thickness of 0.6 mm and tip width of
screwdriver	3.5 mm


- 1. Prepare the connector that is provided with the SERVOPACK.
- 2. Remove the lead wire from between D2 and D3.




3. Remove the sheath from the wire to connect.



- 4. Open the wire insertion hole on the terminal connector with the screwdriver.
- 5. Insert the conductor of the wire into the wire insertion hole. After you insert the conductor, remove the screwdriver.



- 6. Connect the Dynamic Brake Resistor to the D1 and D2 terminals on the SERVOPACK.
 - Note: 1. The D1 and D2 are in the locations shown in the following figure. Do not connect anything to the D3 terminal.
 - 2. Terminal labels (D1 and D2) are provided on the Dynamic Brake Resistor connector.



5.2.4 Setting the Energy Consumption and Resistance of the Dynamic Brake Resistor

7. Set Pn601 (Dynamic Brake Resistor Allowable Energy Consumption) and Pn604 (Dynamic Brake Resistance).

Refer to the following section for details on the settings.

🕼 5.2.4 Setting the Energy Consumption and Resistance of the Dynamic Brake Resistor on page 5-9

5.2.4 Setting the Energy Consumption and Resistance of the Dynamic Brake Resistor

If an External Dynamic Brake Resistor is connected, you must set Pn601 (Dynamic Brake Resistor Allowable Energy Consumption) and Pn604 (Dynamic Brake Resistance).

- If you connect an External Dynamic Brake Resistor, set Pn601 and Pn604 to suitable values. Failure to set these parameters will cause an A.730 alarm (Dynamic Brake Overload) to be detected incorrectly and can destroy the External Dynamic Brake Resistor, cause unintended operation during an emergency stop, cause damage to the machine, and cause burning or injury.
- When you select an External Dynamic Brake Resistor, make sure that it has a suitable energy consumption and resistance. There is a risk of personal injury or fire.

 Mount Dynamic Brake Resistors only on nonflammable materials. Do not mount them on or near any flammable material.

There is a risk of fire.

	Dynamic Brake Res	sistor Allowable Ene	Speed Position Torque		
Pn601*1	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535 10 J		0	After restart	Setup
	Dynamic Brake Res	sistance	Speed Position Torque		
Pn604*2	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	10 mΩ	0	After restart	Setup

*1. SGD7S-210D to 370D SERVOPACKs require three Dynamic Brake Resistors. For this parameter setting, enter the total value of resistor capacity of the three resistors.

*2. SGD7S-210D to 370D SERVOPACKs require three Dynamic Brake Resistors. For this parameter setting, enter the resistance of one Dynamic Brake Resistor multiplied by $\sqrt{3}$.

Set Pn601 to the capacity of the Dynamic Brake Resistor that you calculated when selecting the connected External Dynamic Brake Resistor or the capacity of the Resistor as reported by the manufacturer.

Refer to the following section for details on the energy consumption of the Dynamic Brake Resistor.

→ Energy Consumption of the Dynamic Brake Resistor on page 5-6

5.3.1 Using the Dynamic Brake


5.3 SERVOPACK Models without a Built-In Dynamic Brake

This section describes how to use the SERVOPACKs (SGD7S-210D to 370D) that are not equipped with a built-in dynamic brake.

5.3.1 Using the Dynamic Brake

The SGD7S-210D to 370D are not equipped with a built-in dynamic brake. When using the SGD7S-210D to 370D, set up the SERVOPACK according to the following flowchart.

With the SGD7S-210D to 370D, A.042 (Parameter Combination Error) will always occur when the power supply is first turned ON. This alarm occurs because the settings for the dynamic brake have not been configured. After you set the parameters according to the following flow-chart, the A.042 alarm will be reset when the power supply is turned OFF and ON again.



5.3.1 Using the Dynamic Brake

Setting When Not Using Dynamic Braking

When not using dynamic braking, set $Pn001 = n.\Box\Box\BoxX$ (Motor Stopping Method for Servo OFF and Group 1 Alarms) to 2.

The A.042 (Parameter Combination Error) alarm will be reset when you set $Pn001 = n.\Box\Box\Box2$ (Coast to a stop) and turn the power supply OFF and ON again.

F	Parameter	Meaning	When Enabled	Classification	
	n.ロロロ0 (default setting)	Stop the motor by applying the dynamic brake.			
Pn001	n.0001	Stop the motor by the applying dynamic brake and then release the dynamic brake.	After restart	Setup	
	n.0002	Coast the motor to a stop without the dynamic brake.			

Setting When Using Dynamic Braking

When using dynamic braking, set $Pn001 = n.\Box\Box\BoxX$ (Motor Stopping Method for Servo OFF and Group 1 Alarms) to 0 or 1.

You must also create the dynamic brake circuit in order to perform dynamic braking. The A.042 (Parameter Combination Error) alarm will be reset when you turn the power supply OFF and ON again after the parameters for the dynamic brake circuit and stopping the Servomotor have been set.

You must complete the following items to use the dynamic brake.

- Selecting the Dynamic Brake Resistor 5.3.2 Selecting the Devices Required for the Dynamic Brake Circuit on page 5-12
- Creating the Dynamic Brake Circuit 5.3.3 Wiring the Dynamic Brake Circuit on page 5-15


5.3.2 Selecting the Devices Required for the Dynamic Brake Circuit

5.3.2 Selecting the Devices Required for the Dynamic Brake Circuit

You must select the resistor, Magnetic Contactor, and relay to create the dynamic brake circuit.

Selecting the Dynamic Brake Resistor

To select the Dynamic Brake Resistor, you must calculate the resistance and energy consumption for the specifications of the machine.



Resistance

Based on the characteristic graphs of the Servomotor that will be used, you must determine the resistance that can satisfy the limit of instantaneous maximum brake torque.



• Do not select a resistor with resistance less than the minimum allowable resistance. There is a risk of burning in the SERVOPACK or Servomotor, damage to the machine, or injury.


If it is not necessary to reduce the brake torque, select a Dynamic Brake Resistor with the following resistance. SGD7S-210D to 370D SERVOPACKs differ from SGD7S-1R9D to 170D in that three Dynamic Brake Resistors are required. Use resistors with the same resistance and capacity for the three Dynamic Brake Resistors. The following table gives the resistance per resistor.

Mo	Minimum Allowable Resis- tance (±5%)	
SGD7S	-210D, -260D	1.1 Ω
30073	-280D, -370D	0.95 Ω

If it is necessary to reduce the brake torque, determine the resistance based on the characteristic graphs.


The following graphs show the relationship between the instantaneous maximum brake torque of the Servomotor and the resistance of the Dynamic Brake.

5.3.2 Selecting the Devices Required for the Dynamic Brake Circuit



Rotary Servomotors





Energy Consumption of the Dynamic Brake Resistor

Calculate the energy consumption required to stop the Servomotor using the Dynamic Brake Resistor.

To simplify the calculation of energy consumption, assume that all kinetic energy until the Servomotor stops is consumed by the Dynamic Brake Resistor and calculate energy consumption with the following formula.

Calculate energy consumption at the maximum value of kinetic energy of the Servomotor out of all anticipated operation patterns.

Rotary Servomotors

Energy consumption of Dynamic Brake Resistor: ${\ensuremath{\scriptscriptstyle \mathsf{E}_{\mathsf{DB}}}}\left[J\right]$

Motor moment of inertia: J_M [kg·m²]

Load moment of inertia: J_L [kg·m²]

Motor speed before dynamic braking: N [min⁻¹]

 $E_{DB} = 1/2 \times (J_M + J_L) \times (2\pi N/60)^2$

Note: Refer to the catalog or product manual of the Servomotor for details on the motor moment of inertia.

5.3.2 Selecting the Devices Required for the Dynamic Brake Circuit

Linear Servomotors

Energy consumption of Dynamic Brake Resistor: ${\ensuremath{\scriptscriptstyle\mathsf{E}_{DB}}}[J]$

Moving Coil mass: M_M [kg]

Load mass: M_L [kg]

Movement speed before dynamic braking: V [m/s]

 $E_{DB}=1/2\times(M_M+M_L)\times V^2$

Note: Refer to the catalog or product manual of the Servomotor for details on Moving Coil mass.

Specifications of the Dynamic Brake Resistor

Have the following specifications ready when purchasing the Dynamic Brake Resistor. In the blank cells of the table, write down the specifications of the Dynamic Brake Resistor that you are considering for purchase, and confirm these specifications with the manufacturer of the Resistor.

Item	Specification
Resistance (Ω)	
Energy consumption of resistor from dynamic braking (J)*	
Number of operations of the dynamic brake (Number of times the dynamic brake will be used in the service life of the machine (reference data))	
Wire size	AWG14 (2.0 mm ²) to AWG18 (0.9 mm ²)

* SGD7S-210D to 370D SERVOPACKs require three Dynamic Brake Resistors. Therefore, the energy consumption required for one resistor will be one-third of the electrical energy that was calculated from the kinetic energy of the Servomotor.

Selecting the Magnetic Contactor and Relay

The following table gives the Magnetic Contactor and relay that must be used to create the dynamic brake circuit.

SERVOPACK Model SGD7S-	Part	Manufacturer	Manufacturer Model No.
	Magnetic Contactor	Mitsubishi Electric Cor- poration	BD-N65 (24 VDC)
210D, 260D, 280D, and	Relay	OMRON Corporation	G6B-4BND
370D		Panasonic Corporation	ERZV09D390
	Surge Absorber	Okaya Electric Indus- tries Co., Ltd.	XEB01010


5.3.3 Wiring the Dynamic Brake Circuit

5.3.3 Wiring the Dynamic Brake Circuit

This section shows how to wire the dynamic brake based on a wiring example that uses the recommended parts from the following section.

Selecting the Magnetic Contactor and Relay on page 5-14

The /DBON (Dynamic Brake Operation Request Output) and /DBANS (Dynamic Brake Answer Input) signals must be allocated to sequence I/O signal terminals.



- Note: 1. Separate the 24-VDC power supply for the Magnetic Contactor from the power supply for the I/O signals (CN1). If the same power supply is used, the I/O signals may malfunction.
 - 2. The recommended relay (G6B-4BND) is a terminal relay equipped with four mini-relays. A single relay can be used for Relay1 and Relay2 in the above diagram.

5.3.4 Parameter Settings for the Dynamic Brake Circuit

5.3.4 Parameter Settings for the Dynamic Brake Circuit

You must set the following parameters to create the dynamic brake circuit.

Item to Set	Parameter	Reference
Allocation of /DBON (Dynamic Brake Operation Request Output) signal	Pn51A = n.□□X□	page 5-16
Allocation of /DBANS (Dynamic Brake Answer Input) signal	Pn515 = n.□X□□	page 5-16
Selection of motor stopping method	Pn001	page 5-2
Energy consumption of the Dynamic Brake Resistor	Pn601	2000 E 0
Resistance of Dynamic Brake Resistor	Pn604	page 5-9

/DBON (Dynamic Brake Operation Request Output) Signal

The /DBON signal is the trigger signal for executing dynamic braking.

Create the sequence so that the Magnetic Contactor in the dynamic brake circuit is excited when the /DBON signal is turned ON.

If you allocate more than one signal to the same output connector pin, a logical OR of the signals is output. Set the /DBON signal so that it is not allocated to the same terminal as another output signal.
 If the /DBON signal is allocated to the same terminal as another output signal.

 If the /DBON signal is allocated to the same terminal as another output signal, the A.F32 (Dynamic Brake Operation Request Output Signal Setting Error) alarm will occur to prevent unexpected operation.

The /DBON signal is required to execute dynamic braking on SGD7S-210D to 370D SERVO-PACKs. On SERVOPACKs other than SGD7S-210D to 370D, the /DBON signal cannot be allocated.

Туре	Signal	Connector Pin No.	Signal Status Meaning	
Output	Output /DBON	Must be allocated.	ON (closed)	Do not execute dynamic braking.
	Must be allocated.	OFF (open)	Execute dynamic braking.	

Note: Use $Pn51A = n.\square\squareX\square$ (/DBON (Dynamic Brake Operation Request Output) Signal Allocation) to allocate the /DBON signal to a connector pin. Refer to the following section for details.

7.1.2 Output Signal Allocations on page 7-6

/DBANS (Dynamic Brake Answer Input) Signal

The /DBANS signal is used to check the operating status of the Magnetic Contactor in the dynamic brake circuit.

Туре	Signal	Connector Pin No.	Signal Status	Meaning	
Input /DBANS			ON (closed)	Dynamic braking is not being executed.	
	/DBANS Must be allocated.	OFF (open)	Dynamic braking is being executed.		

Note: Use Pn515 = n. $\Box X \Box \Box$ (/DBANS (Dynamic Brake Answer Input) Signal Allocation) to allocate the /DBANS signal to a connector pin. Refer to the following section for details.

7.1.1 Input Signal Allocations on page 7-4

Always configure the parameter settings for the /DBANS and /DBON signals when using the External Dynamic Brake Resistor.

5.3.4 Parameter Settings for the Dynamic Brake Circuit

Operating Time of the Dynamic Brake

The operating time of the dynamic brake is the total value of the operating times of the relay and Magnetic Contactor.

The operating times of the selected parts are given in the following table.

Part	Model	Manufac- turer	Operating Time*	Sym- bol
Relay		OMRON Corpora- tion	Operating time: 10 ms or less (actual value: approx. 3 ms)	T _{R11}
(DBRy1)	G6B-4BND		Operating time: 15 ms or less (actual value: approx. 4 ms)	T _{R12}
Relay			Operating time: 10 ms or less (actual value: approx. 3 ms)	T _{R21}
(DBRy2)			Operating time: 15 ms or less (actual value: approx. 4 ms)	T _{R22}
Magnetic	BD-N65	Mitsubi- shi Elec-	Time from coil ON to main contact (normally closed) OFF: 68 ms to 92 ms	T _{C1}
Contactor (DBKM)	(24 VDC)	tric Corpora- tion	Time from coil OFF to main contact (normally closed) ON: 13 ms to 29 ms	T _{C2}

Operating Times of Selected Parts


* The operating time values are those listed in the manufacturers' catalogs. Refer to the materials from the manufacturers for details on the operating conditions.

■ Dynamic Brake Operating Time

Sym- bol	Description	Operating Time
T _{D1}	Time from when the /DBON signal is turned ON to when the Magnetic Contactor operates.	$T_{D1} = T_{R11} + T_{C2}$
T _{D2}	Time from when the /DBON signal is turned OFF to when the Magnetic Contactor opens.	$T_{D2} = T_{R12} + T_{C1}$
T _{D3}	Time from when the /DBON signal is turned ON to when the /DBANS signal turns ON.	$T_{D3} = T_{D1} + T_{R21}$
T _{D4}	Time from when the /DBON signal is turned OFF to when the /DBANS signal turns OFF.	$T_{D4} = T_{D2} + T_{R22}$

Timing Chart

The SERVOPACK monitors the status of the /DBON and /DBANS signals. The A.F30 (Dynamic Brake Circuit Error) alarm will occur if a disagreement in the status of the /DBON and /DBANS signals occurs for 0.14 s or longer.



5.4.1 Coasting Distance during Dynamic Braking

5.4 Coasting Distances for Dynamic Braking

During dynamic braking, the motor rotates due to inertia until the electrical energy is consumed. The travel distance at this time is called the coasting distance.

This section provides a method for calculating the coasting distance.

5.4.1 Coasting Distance during Dynamic Braking

• There will be a margin of error between the value calculated for the coasting distance and the actual distance. Therefore, evaluate the operation of the dynamic brake with the actual equipment or machine and confirm that the coasting distance is acceptable. There is a risk of machine damage or injury.

The coasting distance must be checked with the actual equipment, but it can be approximated with the following formulas.

Rotary Servomotors

The coasting distance can be calculated with the following formula.

 $\theta = J\{\alpha(R_D + Zm)Nm_0 + (\beta \times N^3m_0) / (R_D + Zm)\} + (Nm_0/60) \times T_{D1} \times 360 \text{ [deg]}$

Calculate the coasting distance using the above formula based on the following conditions.

- θ [deg]: Coasting distance (mechanical angle)
- J [kgm²]: Moment of inertia (motor moment of inertia + load moment of inertia)
- R_D [Ω]: Resistance of Dynamic Brake Resistor
- Nm₀ [min⁻¹]: Motor speed before starting dynamic braking
- α, β: Coasting distance coefficients^{*1}
- Zm: Characteristic impedance^{*1}
- T_{D1} [s]: Dynamic brake operating time^{*2}
- *1. Refer to the following section for details on the coasting distance coefficients and characteristic impedance. 5.4.2 Data for Calculating Coasting Distance on page 5-19
- *2. Refer to the following section for details on the dynamic brake operating time.

 G → Operating Time of the Dynamic Brake on page 5-17

Linear Servomotors

The coasting distance can be calculated with the following formula.

 $Lm = M\{\alpha(R_{D} + Zm)Vm_{0} + (\beta \times V^{3}m_{0}) / (R_{D} + Zm)\} + Vm_{0} \times T_{D1} [m]$

Calculate the coasting distance using the above formula based on the following conditions.

- Lm [m]: Coasting distance
- M [kg]: Conveyed mass (Moving Coil mass + load mass)
- $R_D [\Omega]$: Resistance of Dynamic Brake Resistor
- Vm₀ [m/s]: Movement speed before starting dynamic braking
- α, β: Coasting distance coefficients^{*1}
- Zm: Characteristic impedance*1
- T_{D1} [s]: Dynamic brake operating time^{*2}
- *1. Refer to the following section for details on the coasting distance coefficients and characteristic impedance. 5.4.2 Data for Calculating Coasting Distance on page 5-19
- *2. Refer to the following section for details on the dynamic brake operating time.

 → Operating Time of the Dynamic Brake on page 5-17

5.4.2 Data for Calculating Coasting Distance

This section provides the coasting distance coefficients and characteristic impedance required to calculate the coasting distance.

Coasting Distance Coefficients

The following tables give the relationship between the Servomotor and coasting distance coefficients α and $\beta.$

Motor Type	SERVOPACK Model	Servomotor Model) Distance icients
			α	β [×10 ⁻⁶]
		SGM7G-03D □ F	4.31	2027.37
		SGM7G-05D □ F	3.56	980.46
		SGM7J-02D□F	48.85	588.19
	SGD7-1R9D	SGM7J-04D□F	11.15	317.05
		SGM7A-02DDF	33.65	2531.91
		SGM7A-04DDF	8.50	2710.91
		SGM7G-09D□F	3.52	366.36
		SGM7J-08D □ F	7.61	244.05
	SGD7-3R5D	SGM7A-08DDF	7.68	520.12
		SGM7G-05D □ R	8.12	429.13
		SGM7A-15DDF	6.85	301.37
	SGD7S-5R4D	SGM7G-13D□F	3.27	133.17
		SGM7A-10DDF	9.05	168.32
		SGM7J-15D D F	8.07	143.11
		SGM7G-09D □ R	8.24	146.05
Datan Can amatara	SGD7S-8R4D	SGM7A-20DDF	7.46	153.86
Rotary Servomotors		SGM7G-20D□F	4.65	55.13
		SGM7G-13D □ R	8.72	53.98
	00070 1000	SGM7A-25DDF	7.87	92.05
		SGM7A-30DDF	7.68	56.19
	SGD7S-120D	SGM7G-30D□F	3.61	23.52
		SGM7G-20D □ R	6.51	40.29
		SGM7A-40DDF	9.25	34.78
	SGD7S-170D	SGM7A-50D □ F	7.11	26.74
	30073-1700	SGM7G-44D □ F	2.80	11.68
		SGM7G-30D □ R	6.91	14.88
	SGD7S-210D	SGM7G-55D □ F	3.20	5.21
	3-2100	SGM7G-44D □ R	4.79	7.04
		SGM7G-75D□F	2.83	2.59
	SGD7S-260D	SGM7A-70D □ F	7.11	26.74
	SGD7S-280D	SGM7G-1AD □ F	1.36	2.22
	SGD7S-370D	SGM7G-1ED □ F	1.27	1.49

Continued on next page.

Continued from previou				
Motor Type	SERVOPACK Model	Servomotor Model	Coasting Distance Coefficients	
			α	β [×10 ⁻⁶]
		SGLFW-35D120A	0.94	544.23
		SGLFW-35D230A	0.94	132.48
	SGD7-1R9D	SGLFW2-30D070A	15.62	487.67
		SGLFW2-30D120A	4.16	313.30
		SGLFW2-30D230A	1.04	313.30
		SGLFW-50D200B	0.95	183.90
	SGD7-3R5D	SGLTW-35D170H	1.75	100.60
		SGLTW-50D170H	0.74	87.00
	SGD7S-5R4D	SGLFW-50D380B	0.95	45.53
		SGLFW-1ZD200B	1.15	37.13
		SGLFW2-90D200A	0.73	49.83
Linear Servomotors	SGD7S-8R4D	SGLFW2-45D380A	0.93	38.73
		SGLTW-35D320H	1.75	25.57
		SGLTW-50D320H	0.74	22.18
		SGLFW-1ZD380B	1.15	9.28
	SGD7S-120D	SGLFW2-90D380A	0.73	12.46
		SGLTW-40D400B	0.45	34.53
		SGLFW2-90D560A	0.73	5.52
	SGD7S-170D	SGLFW2-1DD380A	0.65	6.18
	50073-1700	SGLTW-40D600B	0.45	15.86
		SGLTW-80D400B	0.46	9.17
	SGD7S-260D	SGLTW-80A600B	0.65	2.72
	5GD7 5-200D	SGLFW2-1DD560A	0.46	4.20


.. . . . ~


Characteristic Impedance


The following graphs give the relationship between the characteristic impedance and speed of the Servomotors.


Refer to the graph of the Servomotor that will be used, and use characteristic impedance Zm from the speed before starting dynamic braking.

















Basic Functions That Require Setting before Operation

6

This chapter describes the basic functions that must be set before you start Servo System operation. It also describes the setting methods.

6.1	Manipulating Parameters (PnDDD)6-4					
	6.1.1Parameter Classification6-46.1.2Notation for Parameters6-56.1.3Parameter Setting Methods6-66.1.4Write Prohibition Setting for Parameters6-76.1.5Initializing Parameter Settings6-10					
6.2	MECHATROLINK-III Communications Settings6-12					
	6.2.1Communications Settings6-126.2.2Setting the Station Address6-12					
6.3	Power Supply Type Settings for the Main Circuit6-13					
6.4	Automatic Detection of Connected Motor6-14					
6.5	Motor Direction Setting6-15					
6.6	Setting the Linear Encoder Pitch6-16					
6.7	Writing Linear Servomotor Parameters 6-17					
6.8	Selecting the Phase Sequence for a Linear Servomotor 6-21					
6.9	Polarity Sensor Setting6-23					

6.10	Polarity Detection6-24					
	6.10.1 6.10.2	Restrictions Using the SV_ON (Servo ON) Command to Perform Polarity Detection				
	6.10.3	Using a Tool Function to Perform Polarity Detection				
6.11	Overt	ravel and Related Settings6	6-27			
	6.11.1 6.11.2 6.11.3 6.11.4 6.11.5	Overtravel Signals Setting to Enable/Disable Overtravel Motor Stopping Method for Overtravel Overtravel Warnings Overtravel Release Method Selection	6-28 6-28 6-30			
6.12	Holdi	ng Brake6	6-32			
	6.12.1 6.12.2 6.12.3	Brake Operating Sequence	.6-33			
	6.12.4	the Servomotor Is Stopped Output Timing of /BK (Brake) Signal When the				
	6.12.5	Servomotor Is Operating Built-in Brake Relay Usage Selection				
6.13	Motor	Stopping Methods for Servo OFF and Alarms $$.6-37			
	6.13.1 6.13.2	Stopping Method for Servo OFF				
6.14	Motor	r Overload Detection Level6	6-40			
	6.14.1	Detection Timing for Overload Warnings (A.910)	6 40			
	6.14.2	Detection Timing for Overload Alarms (A.720)				
6.15		ronic Gear Settings6	6-42			
		Electronic Gear Ratio Settings	.6-43 .6-46			
6.16	Resetting the Absolute Encoder6-47					
	6.16.1 6.16.2 6.16.3 6.16.4	Precautions on Resetting	6-47 6-48			
6.17	Settin	g the Origin of the Absolute Encoder	6-50			
	6.17.1 6.17.2	Absolute Encoder Origin Offset				

6.18 Setting the Regenerative Resistor Capacity ... 6-53

6.1.1 Parameter Classification

6.1 Manipulating Parameters (Pn

This section describes the classifications, notation, and setting methods for the parameters given in this manual.

6.1.1 Parameter Classification

There are the following two types of SERVOPACK parameters.

Classification	Meaning
Setup Parameters	Parameters for the basic settings that are required for operation.
Tuning Parameters	Parameters that are used to adjust servo performance.

When you edit parameters with the SigmaWin+, setup parameters and tuning parameters are displayed. When you edit parameters with a Digital Operator, only setup parameters are displayed by default. To edit tuning parameters, set Pn00B to n. DDD1 (Display all parameters).					
Parameter		Meaning	When Enabled	Classification	
Pn00B	n.□□□0 (default setting)	Display only setup parameters.	After restart	Setup	
	n.0001	Display all parameters.			

The setting method for each type of parameter is described below.

Setup Parameters

You can use the Digital Operator or SigmaWin+ to set the setup parameters individually.

Information We recommend that you use the Setup Wizard of the SigmaWin+ to easily set the required setup parameters by setting the operating methods, machine specifications, and I/O signals according to on-screen Wizard instructions.

Setup Wizard AXIS#00	
SGD7S-R90A00A (100W)	Setting terms
Encoder Selection Encoder Selection : 24bit absolute Fully-closed encoder : Do not use	Servopack Selection / III Encoder Selection Servopack and motor selection: Confirm your motor model and Servopack model. In Online mode (when the Servopack is connected), the models are automatically displayed. In Offline mode (when the Servopack is disconnected), the model numbers must be set manually.
Control Mode Selection Position control with pulse train references	Control Mode Selection Control Mode Selecton: Select a control mode such as Speed Control that uses analog vottage reference and Position Control that uses pulse-train reference.
Reference Input Setting Reference Pulse Configuration : Sign + Pulse Electronic gear ratio : 64 / 1 Positioning Completed Width : 7 [reference u	Reference Input Setting Setthe reference input specifications and other items in accordance with the connected machine and host controller.
Motor Encoder Setting	All Motor Encoder Setting Configure the settings for the motor and encoder you use, such as encoder type, encoder output from the Servopack (encoder dividing pulse).
Absolute Encoder Usage : Üses absolute en Rotation (movement) direction setting : Stanc	Motor Stop Method Selection Set the motor stop method and whether or not to use brake at occurrence of alarm when the servo is off (motor power is off) or the when the overtravel limit is used (movable machine parts exceed the allowable range of moton and turn ON a limit switch).
Servo OFF, G1 alarm : Stop the motor by ap; Overtravel : Apply the dynamic brake or coa G2 alarm : Stops the motor by setting the sp W VO Signal Setting	Ho Signal Setting The VO signal allocations for specified terminal numbers of the CN-1 connector can be changed from the standard allocation. VO signal forced input and output are provided to check the wiring.
Input signal setting : Customize the allocation Output signal setting : Use the standard alloc	Check the allocated signals, and save the parameters in a file.
	Close

6.1.2 Notation for Parameters

Tuning Parameters

Normally the user does not need to set the tuning parameters individually.

Use the various SigmaWin+ tuning functions to set the related tuning parameters to increase the response even further for the conditions of your machine. Refer to the following sections for details.

- 9.6 Autotuning without Host Reference on page 9-24
- 9.7 Autotuning with a Host Reference on page 9-35

3.8 Custom Tuning on page 9-42


You can also set the tuning parameters individually to make adjustments. Refer to the following section for details.

3.13 Manual Tuning on page 9-82

6.1.2 Notation for Parameters

There are two types of notation used for parameters that depend on whether the parameter requires a numeric setting (parameter for numeric setting) or requires the selection of a function (parameter for selecting a function).

Parameters for Numeric Settings



6.1.3 Parameter Setting Methods

6.1.3 Parameter Setting Methods

You can use the SigmaWin+ or a Digital Operator to set parameters. Use the following procedure to set the parameters.

Setting Parameters with the SigmaWin+

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Edit Parameters in the Menu Dialog Box. The Parameter Editing Dialog Box will be displayed.
- **3.** Click the cell of the parameter to edit.

If the parameter to edit is not displayed in the Parameter Editing Dialog Box, click the a or stutter Button to display the parameter to edit.

A			YASKAWA SigmaWin+ Ver.	7		- 6 ×
	Edit Parameters	_				- û ×
001-SG075 -R90A00A HBB P-0T TOWER ESTP N-07	Category	SERVOPACK				۵
	All constant number Function Selection(Pn0xx-) Gain(Pn1xx-) Position(Pn2xc-) Speed(Pn3xx-) Torque(Pn4xx-)	Edited Parameters P Read from	arameters Parameters Parameters		Apport Save to Read from Project Function	Compare Servo from List Display
	Sequence(Pn5xx-)				■ 001-SGD75-R90	
	I/O Sign	No.	Name	Unit	Axis A	
	Display Settings	Pn000.0	Direction Selection	-	0 : Use CCW as t···	
	Hierarchy:	Pn000.1	Control Method Selection	-	1 : Position contr···	
	Descriptions:	Pn000.2	Reserved parameter (Do not chang	-	0 : Reserved para…	
		Pn000.3	Rotary/Linear Startup Selection Wh	-	0 : Start as a rota····	
		Pn001.0	Servo OFF or Alarm Group 1 Stoppi	-	0 : Stop the moto	
		Pn001.1	Overtravel Stopping Method	-	0 : Apply the dyn…	
		Pn001.2	Main Circuit Power Supply AC/DC Ir	-	0 : Input AC pow…	
		Pn001.3	Warning Code Output Selection	-	0 : Output only al···	
		Pn002.0	Speed/Position Control Option (T-R	-	0 : Do not use T-···	
		Pn002.1	Torque Control Option (V-REF Input	-	0 : Do not use V-···	
		Pn002.2	Absolute Encoder Usage	-	2 : Uses absolute…	
		Pn002.3	External Encoder Usage	-	0 : Do not use an…	
		Pn006.0+1	Analog Monitor 1 Signal Selection	-	02 : Torque refer…	
		Pn006.2	Reserved parameter (Do not chang	-	0 : Reserved para…	
		Pn006.3	Reserved parameter (Do not chang	-	0 : Reserved para…	
		Pn007.0-1	Analog Monitor 2 Signal Selection	-	00 : Motor speed…	
		Pn007.2	Reserved parameter (Do not chang	-	0 : Reserved para…	
		Pn007.3	Reserved parameter (Do not chang	-	0 : Reserved para…	
		Pn008.0	Low Battery Voltage Alarm/Warning		0 : Output alarm…	
		Pn008.1	Function Selection for Undervoltage	-	0 : Do not detect…	
		Pn008.2	Warning Detection Selection	-	0 : Detect warnin…	
0- Ø-		Pn008.3	Reserved parameter (Do not chang		0 : Reserved para…	
o ₁ . ⊠₁		Pn009.0	Reserved parameter (Do not chang	-	0 : Reserved para…	

4. Change the setting of the parameter.


Information

- 1. For a parameter for a numeric setting, input the numeric setting.
- 2. If the parameter requires selection of a function, select the function from the list of selections.

5. Press the Enter Key.


The background of the edited parameter cell will change to green.

6.1.4 Write Prohibition Setting for Parameters



6. Select Edited Parameters in the Write to Servo Group.

- The edited parameters are written to the SERVOPACK and the backgrounds of the cells change to white.
- 7. Click the OK Button.



8. To enable changes to the settings, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to set the parameters.

Setting Parameters with a Digital Operator

Refer to the following manual for information on setting the parameters with a Digital Operator. $\square \Sigma$ -7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

6.1.4 Write Prohibition Setting for Parameters

You can prohibit writing parameters from the Digital Operator. Even if you do, you will still be able to change parameter settings from the SigmaWin+.

Preparations

No preparations are required.

6.1.4 Write Prohibition Setting for Parameters

Applicable Tools

The following table lists the tools that you can use to change the write prohibition setting.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn010	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Others – Write Prohibited Setting	Gerating Procedure on page 6-8

Operating Procedure

Use the following procedure to prohibit or permit writing parameter settings.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Write Prohibition Setting in the Menu Dialog Box. The Write Prohibition Setting Dialog Box will be displayed.
- **3.** Press the ▼ or ▲ for the rightmost digit and set one of the following. 0000: Writing is permitted (default setting). 0001: Writing is prohibited.




4. Click the Setting Button.



5. Click the OK Button.

The setting will be written to the SERVOPACK.



6. To enable the new setting, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to prohibit or permit writing parameter settings.

6.1.4 Write Prohibition Setting for Parameters

Restrictions

If you prohibit writing parameter settings, you will no longer be able to execute some functions. Refer to the following table.

	SigmaWin+		Digital Operator			
Button in Menu Dialog Box	SigmaWin+ Function Name	Fn No.	Utility Function Name	When Writ- ing Is Pro- hibited	Reference	
	Initialize *1	Fn005	Initializing Parameters	Cannot be executed.	page 6-10	
	Software Reset	Fn030	Software Reset	Can be executed.	page 7-46	
Basic Func-		Fn011	Display Servomotor Model	Can be executed.		
tions	Product Information	Fn012	Display Software Version	Can be executed.	page 10-2	
		Fn01E	Display SERVOPACK and Servomotor IDs	Can be executed.		
		Fn01F	Display Servomotor ID from Feedback Option Module	Can be executed.		
	Absolute Encoder Reset	Fn008	Reset Absolute Encoder	Cannot be executed.	page 6-47	
Freedor	Multi-turn Limit Setup	Fn013	Multiturn Limit Setting after Multiturn Limit Disagreement Alarm	Cannot be executed.	page 7-38	
Encoder Setting	Search Origin ^{*2}	Fn003	Origin Search	Cannot be executed.	page 8-18	
	Zero Point Position Setting	Fn020	Set Absolute Linear Encoder Origin	Cannot be executed.	page 6-50	
	Polarity Detection	Fn080	Polarity Detection	Cannot be executed.	page 6-26	
		Fn000	Display Alarm History	Can be executed.	page 13-45	
Trouble-	Display Alarm	Fn006	Clear Alarm History	Cannot be executed.	page 13-46	
shooting		Fn014	Reset Option Module Config- uration Error	Cannot be executed.	page 13-47	
	Reset Motor Type Alarm	Fn021	Reset Motor Type Alarm	Cannot be executed.	page 13-49	
Operation	Jog	Fn002	Jog	Cannot be executed.	page 8-7	
Operation	Program JOG Operation	Fn004	Jog Program	Cannot be executed.	page 8-14	
	Tuning - Autotuning without Host Reference	Fn201	Advanced Autotuning with- out Reference	Cannot be executed.	page 9-24	
	Tuning - Autotuning with Host Ref- erence	Fn202	Advanced Autotuning with Reference	Cannot be executed.	page 9-35	
Tuning	Tuning - Custom Tuning	Fn203	One-Parameter Tuning	Cannot be executed.	page 9-42	
	Tuning - Custom Tuning - Adjust Anti-resonance Control	Fn204	Adjust Anti-resonance Con- trol	Cannot be executed.	page 9-51	
	Tuning - Custom Tuning - Vibration Suppression	Fn205	Vibration Suppression	Cannot be executed.	page 9-56	
	Response Level Setting	Fn200	Tuning-less Level Setting	Cannot be executed.	page 9-12	
Diagnostic	Easy FFT	Fn206	Easy FFT	Cannot be executed.	page 9-99	

6

Continued on next page.

6.1.5 Initializing Parameter Settings

		Cont	inued from pr	evious page.	
	SigmaWin+		Digital Operator	When Writ-	
Button in Menu Dialog Box	SigmaWin+ Function Name	Fn No.	Utility Function Name	ing Is Pro-	Reference
	Adjust the Analog Monitor	Fn00C	Adjust Analog Monitor Output Offset	Cannot be executed.	page 10.0
	Output	Fn00D	Adjust Analog Monitor Output Gain	Cannot be executed.	page 10-9
Others	Adjust the Motor Current Detection Offsets	Fn00E	Autotune Motor Current Detection Signal Offset	Cannot be executed.	D000 7 52
Others		Fn00F	Manually Adjust Motor Cur- rent Detection Signal Offset	Cannot be executed.	page 7-53
	Initialize Vibration Detection Level	Fn01B	Initialize Vibration Detection Level	Cannot be executed.	page 7-49
	Write Prohibited Setting	Fn010	Write Prohibition Setting	Can be executed.	page 6-7

*1. An Initialize Button will be displayed in the Parameter Editing Dialog Box.

*2. Cannot be used when connecting a Linear Servomotor.

6.1.5 **Initializing Parameter Settings**

You can return the parameters to their default settings.

This function will not initialize the settings of the parameters that are adjusted for the Fn00C, Fn00D, Fn00E, and Fn00F utility functions.



To enable the new settings, turn the power supply to the SERVOPACK OFF and ON again after you complete the operation.

Preparations

Always check the following before you initialize the parameter settings.

- The parameters must not be write prohibited.
- The servo must be OFF.

Applicable Tools

The following table lists the tools that you can use to initialize the parameter settings.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn005	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Basic Functions – Edit Parameters	G Operating Procedure on page 6-11

6.1.5 Initializing Parameter Settings

Operating Procedure

Use the following procedure to initialize the parameter settings.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Edit Parameters in the Menu Dialog Box. The Parameter Editing Dialog Box will be displayed.
- 3. Select any parameter of the axis to initialize.
- 4. Click the Initialize Button.

a		YASKAWA S	igmaWin+ Ver.7				- 5 ×
	Edit Parameters						• 9 ×
		OPACK					۵
0001-SV2 -020L2 HBB P-0T HBB P-0T ESTP TI-0T	Speed(Pn3xx-)	ed All Ed eters Parameters Param	ted All	import Exp	Save to Rei Project P Project	ad from troject	Display
	Sequence(Pn5xx-) I/O Sign Mechatrolink/Pn8xx-)	Name		Unit	0001-SV2-020L2 Axis A		Ċ.
	Common Parameters(PnAxx-) Pn000.	0 Direction Selec	tion	-	0 : Use CCW as t…		
	Display Settings	1 Reserved para	meter (Do not chang	-	0 : Reserved para…		
	Hierarchy: ott Pn000	2 Reserved para	meter (Do not chang	-	0 : Reserved para…		
	Descriptions: Pn000	3 Rotary/Linear	Startup Selection Wh	-	0 : Start as a rota…		
	Pn001		larm Group 1 Stoppi		0 : Stop the moto…		
	< Pn001	1 Overtravel Sto	oping Method	-	1 : Decelerate the…		
	Pn001	2 Main Circuit Po	wer Supply AC/DC II	-	0 : Input AC pow…		
	Pn001	3 Reserved para	meter (Do not chang	-	0 : Reserved para…		
	Pn002	0 MECHATROLIN	K Command Position	-	1 : Use TLIM as t…		
	Pn002	1 Torque Control	Option		1 : Use the speed…		
	Pn002	2 Absolute Encod	ler Usage	-	1 : Use the absol…		
	Pn002	3 External Encod	er Usage	-	0 : Do not use an…		
	Pn006	0-1 Analog Monito	1 Signal Selection	-	02 : Torque refer…		
	Pn006	2 Reserved para	meter (Do not chang	-	0 : Reserved para…		
	Pn006	.3 Reserved para	meter (Do not chang	-	0 : Reserved para…		
	Pn007	0-1 Analog Monitor	2 Signal Selection	-	00 : Motor speed…		
	Pn007		meter (Do not chang	-	0 : Reserved para…		
•	Pn007	3 Reserved para	meter (Do not chang	-	0 : Reserved para…		-

5. Click the OK Button.



Click the **Cancel** Button to cancel initialization. The Parameter Editing Dialog Box will return.

6. Click the OK Button.

YASKAWA SigmaWin+ Ver.7	
Cautior	
Turn OFF the power supply. The settings will be applied the next time the power supply is turned ON.	
ОК)

7. Turn the power supply to the SERVOPACK OFF and ON again after the parameter settings have been initialized.

This concludes the procedure to initialize the parameter settings.


6

6-11

6.2.1 Communications Settings

6.2 MECHATROLINK-III Communications Settings

The settings for MECHATROLINK-III communications are made with the DIP switch (S3). The station address is set using the rotary switches (S1 and S2).



6.2.1 Communications Settings

Use the DIP switch (S3) to make the communications settings.

Pin No.	Function		Default		
FIII NO.	Function	1	2	Description	Setting
1.0	Sets the number of transmission bytes.	OFF	OFF	Reserved. (Do not change.)	
		ON	OFF	32 bytes	1: OFF
1, 2		OFF	ON	48 bytes	2: ON
		ON	ON	Reserved. (Do not change.)	-
3	Reserved. (Do not change.)				OFF
4	4 Reserved. (Do not change.)				
					·



• If you will use the MECHATROLINK-III standard servo profile, set the number of transmission bytes to either 32 or 48.

• To enable the new setting, turn the power supply to the SERVOPACK OFF and ON again after you change the communications switches (S1, S2, and S3).

6.2.2 Setting the Station Address

Use the rotary switches (S1 and S2) to set the station address.

Station Address	S1	S2
00h to 02h: Disabled (Do not set.)	0	0 to 2
03h (default setting)	0	3
04h	0	4
:	:	:
EFh	E	F
F0h to FFh: Disabled (Do not set.)	F	0 to F

6.3 Power Supply Type Settings for the Main Circuit

A SERVOPACK can operate on either an AC power supply input or DC power supply input to the main circuits. This section describes the settings related to the power supply.

Set Pn001 = $n.\Box X \Box \Box$ (Main Circuit Power Supply AC/DC Input Selection) to specify whether to use an AC or DC power supply input for the main circuit power supply to the SERVOPACK.

If the setting of $Pn001 = n.\Box X \Box \Box$ does not agree with the actual power supply input, an A.330 alarm (Main Circuit Power Supply Wiring Error) will occur.

Examples of When an A.330 Alarm (Main Circuit Power Supply Wiring Error) Occurs

Example

- A DC power supply is connected between the B1 and ⊝2 terminals, but an AC power supply input is specified (Pn001 = n.□0□□).
 - An AC power supply is input to the L1, L2, and L3 terminals, but a DC power supply is specified (Pn001 = n.□1□□).

Parameter		Meaning	When Enabled	Classification				
Pp001	n.□0□□ (default set- ting)	Use an AC power supply input.	After restart	Setup				
r	n.0100	Use a DC power supply input.						
 Cor Cor SEF There Alway the m If you n.□11 equip With a suppl powe Instal The S with a suith a su	 Connect the AC or DC power supplies to the specified SERVOPACK terminals. Connect an AC power supply to the L1, L2, and L3 terminals on the SERVOPACK. Connect a DC power supply to the B1 and ⊖2 terminals and the 24 V and 0 V terminals on the SERVOPACK. There is a risk of failure or fire. Always specify a DC power supply input (Pn001 = n.□1□□) before you input DC power for the main circuit power supply. If you input DC power without specifying a DC power supply input (i.e., without setting Pn001 to n.□1□□), the SERVOPACK's internal elements may burn and may cause fire or damage to the equipment. With a DC power supply input, time is required to discharge electricity after the main power supply is turned OFF. A high residual voltage may remain in the SERVOPACK after the power supply is turned OFF. Be careful not to get an electric shock. Install fuses on the power supply line if you use DC power. The Servomotor returns regenerative energy to the power supply. If you use a SERVOPACK with a DC power supply input, regenerative energy is not processed. Process the regenerative energy at the power supply. 							

Refer to the following section for information on wiring the SERVOPACK. *4.3.4 Power Supply Wiring Diagrams* on page 4-15

6.4 Automatic Detection of Connected Motor

You can use a SERVOPACK to operate either a Rotary Servomotor or a Linear Servomotor.

If you connect the Servomotor encoder to the CN2 connector on the SERVOPACK, the SER-VOPACK will automatically determine which type of Servomotor is connected. Therefore, you normally do not need to specify the Servomotor type.

Information If an encoder is not connected, e.g., for a test without a motor, you can specify a Rotary Servomotor or a Linear Servomotor in Pn000 = n.X□□□ (Rotary/Linear Servomotor Startup Selection When Encoder Is Not Connected). If you specify either a Rotary or Linear Servomotor, only the parameters, monitors, alarms, and functions for the specified motor type will be enabled.

Parameter		Meaning	When Enabled	Classification	
Pn000	n.0□□□ (default setting)	When an encoder is not connected, start as SERVOPACK for Rotary Servo- motor.	After restart	Catura	
	n.1000	When an encoder is not connected, start as SERVOPACK for Linear Servo- motor.	Alter restart	Setup	

6.5 Motor Direction Setting

You can reverse the direction of Servomotor rotation by changing the setting of $Pn000 = n.\Box\Box\BoxX$ (Direction Selection) without changing the polarity of the speed or position reference. This causes the rotation direction of the Servomotor to change, but the polarity of the signals, such as encoder output pulses, output from the SERVOPACK do not change. Set the appropriate direction for your system.

Refer to the following section for details on the encoder divided pulse output. 7.5 Encoder Divided Pulse Output on page 7-19

Rotary Servomotors

The default setting for forward rotation is counterclockwise (CCW) as viewed from the load end of the Servomotor.

	Parameter	Forward/Reverse Reference	Motor Direction and Encoder Div	Applicable Overtravel Signal (OT)	
Pn000	n.□□□0 Use CCW as	Forward reference	CCW Hotor speed PBO	ivided Pulse Outputs	P-OT (For- ward Drive Prohibit) signal
	the forward direction. (default setting)	Reverse reference	Time PAO CW Motor speed PBO	ivided Pulse Outputs	N-OT (Reverse Drive Prohibit)signal
	n.□□□1 Use CW as the forward direc- tion. (Reverse Rota- tion Mode)	Forward reference	Torque reference Encoder D Time PAO CW Motor speed PBO	ivided Pulse Outputs	P-OT (For- ward Drive Prohibit)signal
		Reverse reference	Time PAO Motor speed PBO	ivided Pulse Outputs	N-OT (Reverse Drive Prohibit)signal

Note: The trace waveforms of the SigmaWin+ are shown in the above table for the torque reference and motor speed diagrams. If you measure them on a measuring instrument, e.g., with an analog monitor, the polarity will be reversed.

• Linear Servomotors

Before you set this parameter, make sure that $Pn080 = n.\Box\Box X\Box$ (Motor Phase Sequence Selection) is set correctly.

Ī	F	Parameter	Forward/Reverse Reference	Motor Moving Direction and Encoder Divided Pulse Outputs	Applicable Overtravel Signal (OT)
		n.□□□0 Use the direc- tion in which the linear encoder counts up as the for- ward direction. (default setting)	Forward reference	Moves in the count-up direction. Force reference Encoder Divided Pulse Outputs Moves in the count-up direction. PAO PAO	P-OT (For- ward Drive Prohibit) signal
			Reverse reference	Moves in the count-down direction. Hore and the cou	N-OT (Reverse Drive Prohibit) signal
	Pn000	n.□□□1 Use the direc- tion in which the linear encoder counts down as the forward direc- tion.	Forward reference	+ Force reference Encoder Divided Pulse Outputs Moves in the count-down direction. Motor speed PAO	P-OT (For- ward Drive Prohibit)signal
			Reverse reference	+ Force reference Encoder Divided Pulse Outputs Moves in the count-up direction. Motor speed PAO	N-OT (Reverse Drive Prohibit) signal

Note: The trace waveforms of the SigmaWin+ are shown in the above table for the force reference and motor speed diagrams. If you measure them on a measuring instrument, e.g., with an analog monitor, the polarity will be reversed.

Term

6.6 Setting the Linear Encoder Pitch

If you connect a linear encoder to the SERVOPACK through a Serial Converter Unit, you must set the scale pitch of the linear encoder in Pn282.

If a Serial Converter Unit is not connected, the setting of the Pn282 is disabled.

Serial Converter Unit

The Serial Converter Unit converts the signal from the linear encoder into a form that can be read by the SERVOPACK.

Scale Pitch

A linear encoder has a scale for measuring lengths (positions). The length of one division on this scale is the scale pitch.

	Linear Encoder Sc	ale Pitch	Speed Po	osition Force	
Pn282	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 6,553,600	0.01 µm	0	After restart	Setup

You will not be able to control the Linear Servomotor if Pn282 is not set correctly. Check the above table and always set the correct value before you operate the Linear Servomotor.

Type of Linear Encoder	Manufacturer	Model	Serial Converter Unit Model	Linear Encoder Pitch [µm]
			JZDP-H003-DDD-E	20
	Dr. JOHANNES HEIDENHAIN GmbH Renishaw PLC	LIDA48	JZDP-J003-DD-E	20
Incremental		LIF480	JZDP-H003-DD-E	4
Incremental			JZDP-J003-DD-E	
		RGH22B	JZDP-H005-DDD-E	20
	Henishaw PLC		JZDP-J005-DDD-E	20

The first time you supply power to the SERVOPACK, the panel display on the front of the Servomotor will display an A.080 alarm (Linear Encoder Pitch Setting Error). The A.080 alarm is displayed because the setting of Pn282 has not been changed. The A.080 alarm will be cleared when you change the setting of Pn282 and then turn the power supply OFF and ON again.


Information

Linear Encoder Pitch

If you do not use a Serial Converter Unit, the linear encoder pitch is automatically set and the setting of the Pn282 is disabled. Refer to the following section for details. Feedback Resolution of Linear Encoder on page 6-44

Writing Linear Servomotor Parameters

If you connect a linear encoder to the SERVOPACK without going through a Serial Converter Unit, you must use the SigmaWin+ to write the motor parameters to the linear encoder. The motor parameters contain the information that is required by the SERVOPACK to operate the Linear Servomotor.



Serial number information is not included in the motor parameters. You cannot use the monitor functions of the SERVOPACK to monitor the serial number. If you attempt to monitor the serial number, ******** will be displayed. Important

Precautions

- If the encoder parameters are not written to the linear encoder, an A.CAO alarm (Encoder Parameter Error) will occur. Consult the manufacturer of the linear encoder.
- If the motor parameters are not written to the linear encoder, an A.CAO alarm (Encoder Parameter Error) will not occur, but the following alarms will occur.
 - A.040 (Parameter Setting Error), A.041 (Encoder Output Pulse Setting Error),
 - A.050 (Combination Error), A.051 (Unsupported Device Alarm),
 - A.550 (Maximum Speed Setting Error), A.710 (Instantaneous Overload),
 - A.720 (Continuous Overload), and A.C90 (Encoder Communications Error)

Applicable Tools

The following table lists the tools that you can use to write the parameters to the Linear Servomotor.

Tool	Fn No./Function Name	Reference	
Digital Operator	You cannot write Linear Servomotor parameters from the Digital Operator.		
SigmaWin+	Encoder Setting – Motor Parameter Scale Write	Gerating Procedure on page 6-18	

Operating Procedure

Use the following procedure to write the motor parameters to the linear encoder.

- 1. Prepare the motor parameter file to write to the linear encoder.
- 2. Click the <u>J</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Motor Parameter Scale Write in the Menu Dialog Box. The Motor Parameter Scale Write Dialog Box will be displayed.
- 4. Click the OK Button.

Motor parameter scale write
This function rewrites data in the scale. If the data which does not suit the connected motor is rewritten, the motor may not work normally, resulting in motor overrun, etc., and it is very dangerous. Be sure that the data written in the scale suits the connected motor.
OK Cacnel

Click the **Cancel** Button to cancel writing the motor parameters to the linear encoder. The Main Window will return.

If the write is completed normally, the Motor Parameter Scale Write - File Select Dialog Box will be displayed.


5. Click the Ref. Button.

otor Parameter File	
	Ref.
Motor parameter file information	
-1	

6. Select the motor parameter file that you prepared and click the Open Button.

Open		- 2
Organize New folder	jii • 🛄	4
Favorites	Date modified Type	
Desktop	f 5/13/2015 7:39 PM MCF File	
Ubraries Ubraries Ubraries Music Pictures Videos		
P Computer		
Win7_JPN (D:)		
File game: 014_SGLTW-35A170AP.mcf	• Motor parameter file(*.mcf) Open Cancel	•

7. Confirm that the motor parameter file information that is displayed is suitable for your Servomotor, and then click the **Next** Button.




Click the **Cancel** Button to cancel writing the motor parameters to the linear encoder. The Main Window will return.

8. Click the Write Button.

Motor parameter scale write - Scale write					
The motor parameter is written in the scale. Please confirm the motor which connects is corresponding to the following information.					
Motor paran	neter file information				
SGLTW	/-35A170AP				
State Con	Outline ContForce 220 [N]				
	A	ContCurrent 3.3 PeakForce	[Arms]		
	C. J	660 PeakCurrent 11.3	[N] [Arms]		
<u>Т</u> уре:	Iron-core ,sW The Iron-core TW linear motors are com	posed	* *		
<u>A</u> spect:	EYaskawa's unique construction princip @the TW linear motors negate the effect		* •		
<u>R</u> emarks:			*		
	< <u>B</u> ack	Complete	Cancel		

9. Click the Yes Button.




Click the No Button to cancel writing the motor parameters to the linear encoder.

If you click the Yes Button, writing the motor parameter scale will start.

10. Click the Complete Button.

Motor parameter scale write - Scale write The motor parameter is written in the scale. Please confirm the motor which connects is corresponding to the following information.				
Motor para	meter file information			
SGLTW	/-35A170AP			
and the second s		Outline ContForce 220 ContCurrent 3.3 PeakForce 660 PeakCurrent 11.3	[N] [Arms] [N] [Arms]	
<u>Т</u> уре:	Iron-core ,sW The Iron-core TW linear motors are com	posed	*	
<u>A</u> spect:	EYaskawa's unique construction princip @the TW linear motors negate the effect		*	
<u>R</u> emarks:			*	
	< <u>B</u> ack	Complete	Cancel	

11. Click the OK Button.



12. Turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to write the motor parameters.

Confirming If the Motor Parameters Have Been Written

After you write the motor parameters, you can use a monitor function to confirm that the motor parameters are in the encoder.

If the motor parameters have not been written, no information on the Servomotor will be displayed.

10.1 Monitoring Product Information on page 10-2

6.8 Selecting the Phase Sequence for a Linear Servomotor

You must select the phase sequence of the Linear Servomotor so that the forward direction of the Linear Servomotor is the same as the encoder's count-up direction.

Before you set the Linear Servomotor phase sequence (Pn080 = $n.\Box\Box X\Box$), check the following items.

- Confirm that the signal from the linear encoder is being received normally.
- Make sure that the forward direction of the Linear Servomotor and the count-up direction of the linear encoder are in the same direction.



If you do not confirm the above items before you attempt to operate the Servomotor, the Servomotor may not operate or it may run out of control. Always confirm these items before you operate the motor.

Related Parameters

Parameter Meaning		Meaning	When Enabled	Classification
Pn080	n.□□0□ (default setting)	Set a phase-A lead as a phase sequence of U, V, and W.	After restart	Setup
	n.□□1□ Set a phase-B lead as a phase sequ			

Operating Procedure

Use the following procedure to select the phase sequence for a Linear Servomotor.


- **1.** Set Pn000 to n. $\Box\Box\Box$ (Set a phase-A lead as a phase sequence of U, V, and W). This setting is to make following confirmation work easier to understand.
- 2. Select Monitor in the Menu Dialog Box.

The Operation Pane will be displayed so that you can check the feedback pulse counter. To check the feedback pulse counter with the Digital Operator, use Un00D (Feedback Pulse Counter).

3. Manually move the Moving Coil from one end to the other of the stroke and confirm that only the correct number of feedback pulses is returned.

If the correct number and only the correct number of pulses is returned, the signal is being received correctly from the linear encoder.

Example In this example, assume that a linear encoder with a scale pitch of 20 μ m and a resolution of 256 is used. If you manually move the Moving Coil 1 cm in the count-up direction of the linear encoder, the number of feedback pulses would be as follows: 1 cm/(20 μ m/256) = 128,000 pulses



you have completed the confirmation.

Note: The actual monitor display will be offset by the error in the travel distance. There is no problem as long as the above value is close to the calculated value.


Information

If the correct value is not displayed for the feedback pulse counter, the following conditions may exist. Check the situation and correct any problems.

- The linear encoder pitch is not correct.
- If the scale pitch that is set in Pn282 does not agree with the actual scale pitch, the expected number of feedback pulses will not be returned. Check the specifications of the linear encoder.
- The linear encoder is not adjusted properly.
 If the linear encoder is not adjusted properly, the output signal level from the linear encoder will drop and the correct number of pulses will not be counted. Check the adjustment of the linear encoder. Contact the manufacturer of the linear encoder for details.
- There is a mistake in the wiring between the linear encoder and the Serial Converter Unit.

If the wiring is not correct, the correct number of pulses will not be counted. Correct the wiring.

4. Manually move the Moving Coil in the direction of the cable and check the value of the feedback pulse counter in the Operation Pane to confirm that it is counting up.



Manually move the Moving Coil in the direction of the cable.

- 5. If the feedback pulse counter counts up, set a phase-A lead as a phase sequence of U, V, and W (Pn080 = n.□□0□).
 If the feedback pulse counter counts down, set a phase-B lead as a phase sequence of U, V, and W (Pn080 = n.□□1□).
- 6. Turn the power supply to the SERVOPACK OFF and ON again.
- 7. If necessary, return $Pn000 = n.\Box\Box\BoxX$ (Direction Selection) to its original setting.

This concludes the procedure to set the phase sequence of the Linear Servomotor.

6.9 Polarity Sensor Setting

The polarity sensor detects the polarity of the Servomotor. You must set a parameter to specify whether the Linear Servomotor that is connected to the SERVOPACK has a polarity sensor. Specify whether there is a polarity sensor in Pn080 = $n.\square\square\squareX$ (Polarity Sensor Selection).

If the Linear Servomotor has a polarity sensor, set Pn080 to n. $\Box\Box\Box$ (Use polarity sensor) (default setting).

If the Linear Servomotor does not have a polarity sensor, set Pn080 to n. $\Box\Box\Box$ 1 (Do not use polarity sensor). Turn the power supply OFF and ON again to enable the new setting.

Parameter		Meaning	When Enabled	Classification
Pn080	n.□□□0 (default setting)	Use polarity sensor.	After restart	Setup
	n.0001	Do not use polarity sensor.		

6.10.1 Restrictions

6.10 Polarity Detection

If you use a Linear Servomotor that does not have a polarity sensor, then you must detect the polarity.

Detecting the polarity means that the position of the electrical angle phase on the electrical angle coordinates of the Servomotor is detected. The SERVOPACK cannot control the Servomotor correctly unless it accurately knows the position of the electrical angle coordinate of the Servomotor.

The execution timing and execution method for polarity detection depend on the encoder specification as described in the following table.

Encoder Specification	Polarity Detection Execution Timing	Polarity Detection Execution Method
	Each time the control power supply to the SERVOPACK is turned ON	 Use the SV_ON (Servo ON) com- mand.
Incremental encoder	(Even after you execute polarity detec- tion, the position of the polarity will be lost the next time the control power supply to the SERVOPACK is turned OFF.)	 Use the polarity detection function of the SigmaWin+. Execute the Fn080 (Polarity Detection) utility function from the Digital Opera- tor.
	Only for initial setup, or after the SER- VOPACK, linear encoder, or Servomotor has been replaced	 Use the polarity detection function of the SigmaWin+. Execute the Fn080 (Polarity Detection) utility function from the Digital Opera-
Absolute encoder	(The results of polarity detection is stored in the absolute encoder, so the polarity position is not lost when the control power supply is turned OFF.)	 tor. Use Pn587 (Polarity Detection Execution Selection for Absolute Linear Encoder).

Information If you use a Linear Servomotor that does not have a polarity sensor, you will not be able to turn ON the servo until polarity detection has been completed.

6.10.1 Restrictions

Assumed Conditions

The Servomotor will move when you execute polarity detection. The following conditions must be met before you start.

- It must be OK to move the Moving Coil about 10 mm.
- (If polarity detection fails, the Moving Coil may move approximately 5 cm. The amount of movement depends on conditions.)
- The linear encoder pitch must be 100 μm or less. (We recommend a pitch of 40 μm or less for an incremental encoder.)
- As much as possible, the motor must not be subjected to an imbalanced external force. (We recommend 5% or less of the rated force.)
- The mass ratio must be 50x or less.
- The axis must be horizontal.
- There must be friction equivalent to a few percent of the rated force applied to the guides. (Air sliders cannot be used.)

Preparations

Always check the following before you execute polarity detection.

- Not using a polarity sensor must be specified (Pn080 = $n.\Box\Box\Box$ 1).
- The servo must be OFF.
- The main circuit power supply must be ON.
- There must be no hard wire base block (HWBB).
- There must be no alarms except for an A.C22 alarm (Phase Information Disagreement).
- The parameters must not be write prohibited. (This item applies only when using the SigmaWin+ or Digital Operator.)
- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).
- There must be no overtravel.
- If the motor parameters have been written or the origin of the absolute linear encoder has been set, the power supply to the SERVOPACK must be turned OFF and ON again after completion of the writing or setting operation.



1. Power is supplied to the Servomotor during polarity detection. Be careful not to get an electric shock. Also, the Moving Coil of the Linear Servomotor may greatly move during detection. Do not approach the moving parts of the Servomotor.


Polarity detection is affected by many factors.
 For example, polarity detection may fail if the mass ratio or friction is too large or the cable tension is too strong.

6.10.2 Using the SV_ON (Servo ON) Command to Perform Polarity Detection

You can use the SV_ON (Servo ON) command to perform polarity detection only with an incremental linear encoder.

Polarity detection will be performed when you turn the control power supply to the SERVO-PACK OFF and then ON again, and then send the SV_ON (Servo ON) command. As soon as polarity detection is completed, the /S-RDY (Servo Ready) signal will turn ON.

Polarity detection will start simultaneously with execution of the SV_ON (Servo ON) command. As soon as polarity detection is completed, the /S-RDY will turn ON and the servo will remain ON.



6.10.3 Using a Tool Function to Perform Polarity Detection

6.10.3 Using a Tool Function to Perform Polarity Detection

Applicable Tools


The following table lists the tools that you can use to perform polarity detection.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn080	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Encoder Setting – Polarity Detection	J Operating Procedure on page 6-26

Operating Procedure

Use the following procedure to perform polarity detection.


- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Polarity Detection in the Menu Dialog Box. The Polarity Detection Dialog Box will be displayed.
- 3. Click the Continue Button.



Click the Cancel Button to cancel polarity detection. The Main Window will return.

4. Click the Start Button.

Polarity detection will be executed.



This concludes the polarity detection procedure.

6.11.1 Overtravel Signals


6.11 Overtravel and Related Settings

Overtravel is a function of the SERVOPACK that forces the Servomotor to stop in response to a signal input from a limit switch that is activated when a moving part of the machine exceeds the safe range of movement.

The overtravel signals include the P-OT (Forward Drive Prohibit) and the N-OT (Reverse Drive Prohibit) signals.


You use the P-OT and N-OT signals to stop the machine by installing limit switches at the positions where you want to stop the machine that is operated by the Servomotor.

A SERVOPACK wiring example is provided below.



Using the overtravel function is not necessary for rotating applications such as rotary tables and conveyors. No wiring for overtravel input signals is required.

This section describes the parameters settings related to overtravel.



6.11.1 Overtravel Signals

The overtravel signals include the P-OT (Forward Drive Prohibit) and the N-OT (Reverse Drive Prohibit) signals.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
	Dut P-OT CN1-7		ON	Forward drive is enabled (actual operation).
loout		OFF	Forward drive is prohibited (forward overtravel).	
input		0	ON	Reverse drive is enabled (actual operation).
		CN1-8	OFF	Reverse drive is prohibited (reverse overtravel).

You can operate the Servomotor in the opposite direction during overtravel by inputting a reference.

6.11.2 Setting to Enable/Disable Overtravel

6.11.2 Setting to Enable/Disable Overtravel

You can use $Pn50A = n.X \square \square \square$ (P-OT (Forward Drive Prohibit) Signal Allocation) and $Pn50B = n.\square \square \square X$ (N-OT (Reverse Drive Prohibit) Signal Allocation) to enable and disable the overtravel function.

You do not need to wire the overtravel input signals if you are not going to use the overtravel function.

Parameter		Meaning	When Enabled	Classification
Pn50A	n.1□□□ (default setting)	The forward overtravel function is enabled and the P-OT (Forward Drive Prohibit) signal is input from CN1-7.		Setup
	n.8000	The reverse overtravel function is disabled. Forward drive is always enabled.	After restart	
Pn50B	n.□□□2 (default setting)	The reverse overtravel function is enabled and the N-OT (Reverse Drive Prohibit) signal is input from CN1-8.	Aller Testart	
	n.□□□8	The reverse overtravel function is disabled. Reverse drive is always enabled.		

You can allocate the P-OT and N-OT signals to other connector pins. Refer to the following section for details.

7.1.1 Input Signal Allocations on page 7-4

6.11.3 Motor Stopping Method for Overtravel

You can set the stopping method of the Servomotor when overtravel occurs in Pn001 = $n.\square\squareXX$ (Motor Stopping Method for Servo OFF and Group 1 Alarms and Overtravel Stopping Method).

Parameter		Motor Stopping Method [*]	Status after Stopping	When Enabled	Classification	
	n.□□00 (default setting)	Dynamic brake				
n.□□01		5	Coasting			
	n.□□02	Coasting		After restart	Setup	
Pn001	n.0010	Deceleration	Zero clamp			
	n.0020	according to setting of Pn406	Coasting			
-	n.🗆 🗆 3 🗆	Deceleration	Zero clamp			
	n.0040	according to setting of Pn30A	Coasting			

* You cannot decelerate a Servomotor to a stop during torque control. For torque control, the Servomotor will be stopped with the dynamic braking or coast to a stop (according to the setting of Pn001 = n.□□□X (Motor Stopping Method for Servo OFF and Group 1 Alarms)), and then the Servomotor will enter a coasting state.

Refer to the following section for information on stopping methods other than those for overtravel.

6.13.1 Stopping Method for Servo OFF on page 6-38

6.11.3 Motor Stopping Method for Overtravel

Stopping the Servomotor by Setting Emergency Stop Torque

To stop the Servomotor by setting emergency stop torque, set Pn406 (Emergency Stop Torque).

If $Pn001 = n.\Box\BoxX\Box$ is set to 1 or 2, the Servomotor will be decelerated to a stop using the torque set in Pn406 as the maximum torque.

The default setting is 800%. This setting is large enough to allow you to operate the Servomotor at the maximum torque. However, the maximum emergency stop torque that you can actually use is the maximum torque of the Servomotor.

	Emergency Stop To	rque	Speed Positio	n	
Pn406	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup

* Set a percentage of the motor rated torque.


Stopping the Servomotor by Setting the Deceleration Time

To specify the Servomotor deceleration time and use it to stop the Servomotor, set Pn30A (Deceleration Time for Servo OFF and Forced Stops).

	Deceleration Time f	or Servo OFF and Fo	Speed Position	١	
Pn30A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup

If you set Pn30A to 0, the Servomotor will be stopped with a zero speed.

The deceleration time that you set in Pn30A is the time to decelerate the Servomotor from the maximum motor speed.



Important

6.11.4 Overtravel Warnings

6.11.4 Overtravel Warnings

You can set the system to detect an A.9A0 warning (Overtravel) if overtravel occurs while the servo is ON. This allows the SERVOPACK to notify the host controller with a warning even when the overtravel signal is input only momentarily. An alarm occurs only if overtravel occurs while the servo is ON. An overtravel warning will not be detected when the servo is OFF, even if overtravel occurs.

1. The occurrence of an A.9A0 warning will not stop the motor or have any affect on host controller motion operations. The next step (e.g., the next motion or command) can be executed even if an overtravel warning exists.


However, depending on the processing specifications and programming for warnings in the host controller, operation may be affected when an overtravel warning occurs (e.g., motion may stop or not stop). Confirm the specifications and programming in the host controller.

2. When overtravel occurs, the SERVOPACK will perform stop processing for overtravel. Therefore, when an A.9A0 warning occurs, the Servomotor may not reach the target position specified by the host controller. Check the feedback position to make sure that the axis is stopped at a safe position.

The following parameter is set for this function.

P	arameter	Meaning	When Enabled	Classification	
Pn00D	n.0□□□ (default setting)	Do not detect overtravel warnings.	Immediately	Setup	
	n.1000	Detect overtravel warnings.			

A timing chart for warning detection is provided below.



Information

- 1. Warnings are detected for overtravel in the same direction as the reference.
 - 2. Warnings are not detected for overtravel in the opposite direction from the reference. Example: A warning will not be output for a forward reference even if the N-OT signal turns ON.
 - 3. A warning can be detected in either the forward or reverse direction if there is no reference.
 - 4. A warning will not be detected when the servo is turned ON even if overtravel status exists.
 - 5. You can use the ALM_CLR (Clear Alarms and Warnings) command to clear the warning regardless of the servo ON/OFF status and overtravel signal status.
 - 6. If you clear the warning with the ALM_CLR (Clear Alarms and Warnings) command during overtravel status, a warning will not be detected again until the overtravel status is left.
 - 7. An overtravel warning will be detected even when the software limit has been detected.

6.11.5 Overtravel Release Method Selection


6.11.5 Overtravel Release Method Selection

You can set $Pn022 = n.\Box\Box\BoxX$ (Overtravel Release Method Selection) to release overtravel. The motor will not be driven if there is overtravel in the same direction as the reference.

Parameter		Meaning	When Enabled	Classification
	n.□□□0 (default setting)	Overtravel exists while the P-OT or N-OT signal is being input.		
Pn022	n.0001	Overtravel exists while the P-OT or N-OT signal is input and the current position of the workpiece is separated* from the P-OT signal or N-OT signal.	After restart	Setup

* Here, "separated" means a position that is further in the positive direction than the P-OT signal or a position that is further in the negative direction than the N-OT signal.

When Pn022 Is Set to n. DDD0



When Pn022 Is Set to n.DDD1


	 			ı 	1
	јш <u>с</u>	! .		<u> </u> ,	
Machine coordinate	-2	-1	0		2
P-OT signal		 	Inactive	Active	Inactive
N-OT signal	Inactive	Active	Inactive	• 	
Ū				' 	
SV_ON (Servo ON command) Servo	OFF	Servo ON	Servo OFF	
Motor status	Only forward operation		Normal operation OK	Only reverse operation	1

6.12.1 Brake Operating Sequence

6.12 Holding Brake

A holding brake is used to hold the position of the moving part of the machine when the SER-VOPACK is turned OFF so that moving part does not move due to gravity or an external force. You can use the brake that is built into a Servomotor with a Brake, or you can provide one on the machine.

The holding brake is used in the following cases.





The brake built into a Servomotor with a Brake is a de-energization brake. It is used only to hold the Servomotor and cannot be used for braking. Use the holding brake only to hold a Servomotor that is already stopped.

6.12.1 Brake Operating Sequence

You must consider the brake release delay time and the brake operation delay time to determine the brake operation timing, as described below.




Brake Release Delay Time

The time from when the /BK (Brake) signal is turned ON until the brake is actually released.

Brake Operation Delay Time

The time from when the /BK (Brake) signal is turned OFF until the brake actually operates.



*1. Rotary Servomotors: The brake delay times for Servomotors with Holding Brakes are given in the following table. The operation delay times in the following table are examples for when the power supply is switched on the DC side. You must evaluate the actual brake delay times on the actual equipment before using the application.

6.12.2 /BK (Brake) Signal

Model	Voltage	Brake Release Delay Time [ms]	Brake Operation Delay Time [ms]	
SGM7J-02, -04		60		
SGM7J-08, -15		80	100	
SGM7A-02, -04	24 VDC	60	100	
SGM7A-08, -10		80		
SGM7A-15 to -25	24 VDC	170		
SGM7A-30 to -50		100	80	
SGM7G-05 to -20		100		
SGM7G-30, -44		170	100	

Linear Servomotors: The brake delay times depend on the brake that you use. Set the parameters related to /BK signal output timing according to the delay times for the brake that you will actually use.

- *2. Before you output a reference from the host controller to the SERVOPACK, wait for at least 50 ms plus the brake release delay time after you send the SV_ON command.
- *3. Use the following parameters to set the timing of when the brake will operate and when the servo will be turned OFF.
 - Rotary Servomotors: Pn506 (Brake Reference-Servo OFF Delay Time), Pn507 (Brake Reference Output Speed Level), and Pn508 (Servo OFF-Brake Command Waiting Time) Linear Servomotors: Pn506 (Brake Reference-Servo OFF Delay Time), Pn508 (Servo OFF-Brake Command
 - Waiting Time), and Pn583 (Brake Reference Output Speed Level)
- Note: The brake operation delay time on SERVOPACKs with built-in Servomotor brake control is somewhat longer than the time required on SERVOPACKs without built-in Servomotor brake control. Consider the brake operation delay time when you design the system.

Connection Examples

Refer to the following section for information on brake wiring. (3 4.4.4 Wiring the SERVOPACK to the Holding Brake on page 4-27

6.12.2 /BK (Brake) Signal

The following settings are for the output signal that controls the brake. You can change the connector pin that is allocated. For details, refer to Allocating the /BK (Brake) Signal. The /BK signal is turned OFF (to operate the brake) when the servo is turned OFF or when an alarm is detected. You can adjust the timing of brake operation (i.e., the timing of turning OFF the /BK signal) with the servo OFF delay time (Pn506).

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output	/BK	CN1-1, CN1-2	ON (closed)	Releases the brake.
			OFF (open)	Activates the brake.

Information The /BK signal will remain ON during overtravel. The brake will not be applied.

Allocating the /BK (Brake) Signal

Set the allocation for the /BK signal in Pn50F = $n.\Box X \Box \Box$ (/BK (Brake Output) Signal Allocation).

Parameter		Connector Pin No.		Meaning	When	Classification
	Parameter		- Pin	wearing	Enabled	Classification
	n.0000	-	_	The /BK signal is not used.		Setup
	n.□1□□ (default setting)	CN1-1	CN1-2	The /BK signal is output from CN1-1 and CN1-2.		
Pn50F	n.0200	CN1-23	CN1-24	The /BK signal is output from CN1-23 and CN1-24.	After restart	
	n.¤3¤¤	CN1-25	CN1-26	The /BK signal is output from CN1-25 and CN1-26.		

6.12.3 Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped



If you allocate more than one signal to the same output connector pin, a logical OR of the signals is output. Allocate the /BK signal to its own output connector pin, i.e., do not use the same output terminal for another signal.

For example, never allocate the /TGON (Rotation Detection) signal and /BK signal to the same output connector pin. If you did so, the /TGON signal would be turned ON by the falling speed on a vertical axis, and the brake would not operate.


6.12.3 Output Timing of /BK (Brake) Signal When the Servomotor Is Stopped

When the Servomotor is stopped, the /BK signal turns OFF as soon as the SV_OFF (Servo OFF) command is received. Use the servo OFF delay time (Pn506) to change the timing to turn OFF power supply to the motor after the SV_OFF command is input.

	Brake Reference-Se	ervo OFF Delay Time	Speed Position	on Torque	
Pn506	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 50	10 ms	0*	Immediately	Setup

* The default setting is 32 for a SERVOPACK with built-in Servomotor brake control.

• When the Servomotor is used to control a vertical axis, the machine moving part may move slightly due to gravity or an external force. You can eliminate this slight motion by setting the servo OFF delay time (Pn506) so that power supply to the motor is stopped after the brake is applied.



 This parameter sets the timing of stopping power supply to the Servomotor while the Servomotor is stopped.

Power supply to the Servomotor will be stopped immediately when an alarm occurs, regardless of the setting of this parameter. The machine moving part may move due to gravity or an external force before the brake is applied.

6.12.4 Output Timing of /BK (Brake) Signal When the Servomotor Is Operating

If an alarm occurs while the Servomotor is operating, the Servomotor will start stopping and the /BK signal will be turned OFF. You can adjust the timing of /BK signal output by setting the brake reference output speed level (Rotary Servomotors: Pn507, Linear Servomotors: Pn583) and the Servo OFF-Brake Command Waiting Time (Pn508).

Note: If zero-speed stopping is set as the stopping method for alarms, the setting of Pn506 (Brake Reference-Servo OFF Delay Time) is used after the motor stops.

Rotary Servomotors

	Brake Reference O	utput Speed Level	Speed Positi	on Torque	
Pn507	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 min ⁻¹	100	Immediately	Setup
	Servo OFF-Brake C	ommand Waiting Ti	Speed Positi	on Torque	
Pn508	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 100	10 ms	50	Immediately	Setup


6.12.4 Output Timing of /BK (Brake) Signal When the Servomotor Is Operating

• Linear Servomotors


	Brake Reference Output Speed Level			Speed Position Force		
Pn583	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 mm/s	10	Immediately	Setup	
	Servo OFF-Brake Command Waiting Time			Speed Positi	on Force	
Pn508	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 100	10 ms	50	Immediately	Setup	

The brake operates when either of the following conditions is satisfied:

• When the Motor Speed Goes below the Level Set in Pn507 for a Rotary Servomotor or in Pn583 for a Linear Servomotor after the Power Supply to the Motor Is Stopped



• When the Time Set In Pn508 Elapses after the Power Supply to the Motor Is Stopped





The Servomotor will be limited to its maximum speed even if the brake reference output speed level (Rotary Servomotor: Pn507, Linear Servomotor: Pn583) is higher than the maximum speed.

6.12.5 Built-in Brake Relay Usage Selection

6.12.5 Built-in Brake Relay Usage Selection

SERVOPACKs with built-in brake control contain a brake relay.

Set Pn023 = $n.\Box\Box\BoxX$ (Built-in Brake Relay Usage Selection) to specify whether to use the built-in brake relays.

Para	ameter	Description		Classification
Pn023	n.□□□0 (default setting)	Use the built-in brake relays.	After restart	Setup
	n.0001	Do not use the built-in brake relays.		

You can use $Pn023 = n.\Box\BoxX\Box$ (Built-in Brake Relay Life Alarm Enable Selection) to select whether to detect or not detect the built-in brake relay life alarm (alarm number: A.232). Refer to the following section for details.

10.4.3 Preventative Maintenance on page 10-15

6.13 Motor Stopping Methods for Servo OFF and Alarms

You can use the following methods to stop the Servomotor when the servo is turned OFF or an alarm occurs.

There are the following four stopping methods.

Motor Stopping Method	Meaning
Stopping by Applying the Dynamic Brake	The electric circuits are internally connected to stop the Servomotor quickly.
Coasting to a Stop	The motor stops naturally due to friction during operation.
Zero Clamping	The speed reference is set to 0 to stop the Servomotor quickly.
Decelerating to a Stop	Emergency stop torque is used to decelerate the motor to a stop.

There are the following three conditions after stopping.

Status after Stopping	Meaning
Dynamic Brake Applied	The electric circuits are internally connected to hold the Servomotor.
Coasting	The SERVOPACK does not control the Servomotor. (The machine will move in response to a force from the load.)
Zero Clamping	A position loop is created and the Servomotor remains stopped at a position reference of 0. (The current stop position is held.)

• The dynamic brake is used for emergency stops. The dynamic brake circuit will operate frequently if the power supply is turned ON and OFF or the servo is turned ON and OFF while a reference input is applied to start and stop the Servomotor. This may result in deterioration of the internal elements in the SERVOPACK. Use speed input references or position references to start and stop the Servomotor.

 If you turn OFF the main circuit power supply or control power supply during operation before you turn OFF the servo, the Servomotor stopping method depends on the SERVOPACK model as shown in the following table.

	Servomotor Stopping Method			
Condition	SGD7S-1R9D, -3R5D, -5R4D, -8R4D, -120D, or -170D	SGD7S-210D, -260D, -280D, or -370D		
Main circuit power supply turned OFF before turning OFF the servo	Stopping with dynamic brake	Consting to a stop		
Control power supply turned OFF before turning OFF the servo	Stopping with dynamic brake	Coasting to a stop		

Note: The SGD7S-210D, -260D, -280D, and -370D do not have a built-in dynamic brake. They will always coast to a stop. To perform dynamic braking, you must create the dynamic brake circuit. Refer to the following chapter for details on the dynamic brake circuit.

Chapter 5 Wiring and Settings for the Dynamic Brake

- If the Servomotor must be stopped by coasting rather than with the dynamic brake when the main circuit power supply or the control power supply is turned OFF before the servo is turned OFF, use a Servomotor that has the dynamic brake option.
- To minimize the coasting distance of the Servomotor to come to a stop when an alarm occurs, zero-speed stopping is the default method for alarms to which it is applicable. However, depending on the application, stopping with the dynamic brake may be more suitable than zero-speed stopping.

For example, when coupling two shafts (twin-drive operation), machine damage may occur if a zero-speed stopping alarm occurs for one of the coupled shafts and the other shaft stops with a dynamic brake. In such cases, change the stopping method to the dynamic brake.

6.13.1 Stopping Method for Servo OFF

6.13.1 Stopping Method for Servo OFF

Set the stopping method for when the servo is turned OFF in Pn001 = $n.\Box\Box\BoxX$ (Motor Stopping Method for Servo OFF and Group 1 Alarms).

	Parameter	Servomotor Stop- ping Method	Status after Servo- motor Stops	When Enabled	Classifi- cation
n.□□□0 (default setting)		Dynamic brake *	Dynamic brake *	After restart	Catura
Pn001	n.0001		Coasting	After restart	Setup
	n.□□□2	Coasting	Coasting		

* The Servomotor will coast to a stop when the SERVOPACK is not equipped with a built-in Dynamic Brake Resistor or an External Dynamic Brake Resistor is not connected.

Note: If Pn001 is set to n. DDD0 (Stop the motor by applying the dynamic brake) and the Servomotor is stopped or operates at a low speed, braking force may not be generated, just like it is not generated for coasting to a stop.



When connecting an external dynamic brake circuit to SGD7S-210D, -260D, -280D, and -370D SERVOPACKs, set the /DBANS (Dynamic Brake Answer Input) and /DBON (Dynamic Brake Operation Request Output) signals regardless of the setting of Pn001 = n. \Box \Box \Box X. The A.F30 (Dynamic Brake Circuit Error) alarm will occur if the /DBANS and /DBON signals are not connected to I/O signal terminals.

6.13.2 Servomotor Stopping Method for Alarms

There are two types of alarms, group 1 (Gr. 1) alarms and group 2 (Gr. 2) alarms. A different parameter is used to set the stopping method for alarms for each alarm type.

Refer to the following section to see which alarms are in group 1 and which are in group 2. (7) 13.2.1 List of Alarms on page 13-5

Motor Stopping Method for Group 1 Alarms

When a group 1 alarm occurs, the Servomotor will stop according to the setting of $Pn001 = n.\Box\Box\BoxX$. The default setting is to stop by applying the dynamic brake.

Refer to the following section for details. 6.13.1 Stopping Method for Servo OFF on page 6-38

6.13.2 Servomotor Stopping Method for Alarms

Motor Stopping Method for Group 2 Alarms

When a group 2 alarm occurs, the Servomotor will stop according to the settings of the following three parameters. The default setting is for zero clamping.

- Pn001 = n. DDX (Motor Stopping Method for Servo OFF and Group 1 Alarms)
- Pn00A = n. DDDX (Motor Stopping Method for Group 2 Alarms)
- Pn00B = n. DDXD (Motor Stopping Method for Group 2 Alarms)

However, during torque control, the group 1 stopping method is always used. If you set Pn00B to n. DD1D (Apply dynamic brake or coast Servomotor to a stop), you can

use the same stopping method as group 1. If you are coordinating a number of Servomotors, you can use this stopping method to prevent machine damage that may result because of differences in the stopping method.

The following table shows the combinations of the parameter settings and the resulting stopping methods.

	Paramete	er	Servomotor	Status after	When	Classification
Pn00B	Pn00A	Pn001	Stopping Method	Servomotor Stops	Enabled	
n.□□0□		n.□□□0 (default setting)	Zero-speed stop-	Dynamic brake	_	
(default setting)	-	n.0001	ping	Coasting		
		n.0002		oodotiing	-	
n.0010		n.□□□0 (default setting)	Dynamic brake	Dynamic brake		
	_	n.0001		Coasting		
		n.0002	Coasting	Coasting	4	
	n.□□□0	n.□□□0 (default setting)	Dynamic brake	Dynamic brake	- After restart	Setup
		n.🗆 🗆 🗆 1		Coasting		
		n.0002	Coasting			
	n.□□□1 (default setting)	n.□□□0 (default setting)		Dynamic brake		
		n.🗆 🗆 🗆 1	Motor is deceler-	Coasting		
		n.0002	ated using the torque set in			
~ 0000	~ 0000	n.□□□0 (default setting)	Pn406 as the maximum torque.			
n.0020	n.□□□2	n.🗆 🗆 🗆 1		Coasting		
		n.0002				
		n.□□□0 (default setting)		Dynamic brake	_	
	n.□□□3	n.0001		Coasting		
		n.🗆 🗆 🗠 2	Motor is deceler- ated according to	Coasting		
	4	n.□□□0 (default setting)	setting of Pn30A.	Coosting		
	n.0004	n.□□□1		Coasting		
		n.□□□2				

Note: 1. The setting of Pn00A is ignored if Pn00B is set to n. DD0 or n. DD1.

2. The setting of Pn00A = n. \Box X is enabled for position control and speed control. During torque control, the setting of Pn00A = n. \Box X will be ignored and only the setting of Pn001 = n. \Box X will be used.

3. Refer to the following section for details on Pn406 (Emergency Stop Torque). Stopping the Servomotor by Setting Emergency Stop Torque on page 6-29

4. Refer to the following section for details on Pn30A (Deceleration Time for Servo OFF and Forced Stops).

Stopping the Servomotor by Setting the Deceleration Time on page 6-29

6.14.1 Detection Timing for Overload Warnings (A.910)

6.14 Motor Overload Detection Level

The motor overload detection level is the threshold used to detect overload alarms and overload warnings when the Servomotor is subjected to a continuous load that exceeds the Servomotor ratings.


It is designed to prevent Servomotor overheating.

You can change the detection timing for A.910 warnings (Overload) and A.720 alarms (Continuous Overload). You cannot change the detection level for A.710 alarms (Instantaneous Overload).

6.14.1 Detection Timing for Overload Warnings (A.910)

With the default setting for overload warnings, an overload warning is detected in 20% of the time required to detect an overload alarm. You can change the time required to detect an overload warning by changing the setting of the overload warning level (Pn52B). You can increase safety by using overload warning detection as an overload protection function matched to the system.

The following graph shows an example of the detection of overload warnings when the overload warning level (Pn52B) is changed from 20% to 50%. An overload warning is detected in half of the time required to detect an overload alarm.



	Overload Warning Level			Speed Position	n Torque
Pn52B	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 100	1%	20	Immediately	Setup

6.14.2 Detection Timing for Overload Alarms (A.720)


6.14.2 Detection Timing for Overload Alarms (A.720)

If Servomotor heat dissipation is insufficient (e.g., if the heat sink is too small), you can lower the overload alarm detection level to help prevent overheating.

To reduce the overload alarm detection level, change the setting of Pn52C (Base Current Derating at Motor Overload Detection).

	Base Current Derati	ng at Motor Overloa	Speed Position	n Torque	
Pn52C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 100	1%	100	After restart	Setup

An A.720 alarm (Continuous Overload) can be detected earlier to protect the Servomotor from overloading.



Note: The gray areas in the above graph show where A.710 and A.720 alarms occur.

Refer to the relevant manual given below for a diagram that shows the relationships between the Servomotor heat dissipation conditions (heat sink size, surrounding air temperature, and derating). You can protect the Servomotor from overloads more effectively by setting this derating value in Pn52C.

Ω Σ-7-Series Rotary Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 86)

Ω Σ-7-Series Linear Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 81)

6.15 Electronic Gear Settings

The minimum unit of the position data that is used to move a load is called the reference unit. The reference unit is used to give travel amounts, not in pulses, but rather in distances or other physical units (such as μm or °) that are easier to understand.

The electronic gear is used to convert the travel distances that are specified in reference units to pulses, which are required for actual movements.


With the electronic gear, one reference unit is equal to the workpiece travel distance per reference pulse input to the SERVOPACK. In other words, if you use the SERVOPACK's electronic gear, pulses can be read as reference units.

Note: If you set an electronic gear in the host controller, normally set the electronic gear ratio in the SERVOPACK to 1:1.


The difference between using and not using the electronic gear is shown below.


Rotary Servomotors

In this example, the following machine configuration is used to move the workpiece 10 mm.



When the Electronic Gear Is Not Used






When the Electronic Gear Is Used

If you use reference units to move the workpiece when one reference unit is set to 1 μ m, the travel distance is 1 μ m per pulse. To move the workpiece 10 mm (10,000 μ m), 10,000 ÷ 1 = 10,000 pulses, so 10,000 pulses would be input.

Calculating the number of reference pulses for each reference is not necessary.

Linear Servomotors

In this example, the following machine configuration is used to move the load 10 mm. We'll assume that the resolution of the Serial Converter Unit is 256 and that the linear encoder pitch is 20 μ m.



When the Electronic Gear Is Not Used

To move the load 10 mm: $10 \times 1000 \div 20 \times 256 = 128,000$ pulses, so 128,000 pulses are input as the reference.

Calculating the number of reference pulses for each reference is trouble-some.

When the Electronic Gear Is Used

To use reference units to move the load 10 mm: If we set the reference unit to 1 μ m, the travel distance is 1 μ m per pulse. To move the load 10 mm (10,000 μ m), 10,000/1 = 10,000 pulses, so 10,000 pulses would be input as the reference.

Calculating the number of reference pulses for each reference is not necessary.

6.15.1 Electronic Gear Ratio Settings

6.15.1 Electronic Gear Ratio Settings

Set the electronic gear ratio using Pn20E and Pn210.

	Electronic Gear Rati	ctronic Gear Ratio (Numerator)			Position		
Pn20E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	1 to 1,073,741,824	1	16	After restart	Setup		
	Electronic Gear Ratio (Denominator)			Position			
Pn210	Setting Range	Setting Unit	Default Setting	When Enabled	Classification		
	1 to 1,073,741,824	1	1	After restart	Setup		

Calculating the Settings for the Electronic Gear Ratio

Rotary Servomotors

If the gear ratio between the Servomotor shaft and the load is given as n/m, where n is the number of load rotations for m Servomotor shaft rotations, the settings for the electronic gear ratio can be calculated as follows:

Electronic gear ratio $\frac{B}{A} = \frac{Pn20E}{Pn210} = \frac{Encoder resolution}{Travel distance per load shaft revolution (reference units)} \times \frac{m}{n}$

Encoder Resolution

You can check the encoder resolution in the Servomotor model number.

SGM7J, SGM7A, or SGM7G -

 Code	Specification	Encoder Resolution
7	24-bit multiturn absolute encoder	16,777,216
F	24-bit incremental encoder	16,777,216

6.15.1 Electronic Gear Ratio Settings

Linear Servomotors

You can calculate the settings for the electronic gear ratio with the following equation: When Not Using a Serial Converter Unit

Use the following formula if the linear encoder and SERVOPACK are connected directly or if a linear encoder that does not require a Serial Converter Unit is used.

Electronic gear ratio $\frac{B}{A} = \frac{Pn20E}{Pn210} = \frac{Travel distance per reference unit (reference units) × Linear encoder resolution Linear encoder pitch (the value from the following table)$

When Using a Serial Converter Unit

Electronic gear ratio $\frac{B}{A} = \frac{Pn20E}{Pn210} = \frac{Travel distance per reference unit (reference units) × Resolution of the Serial Converter Unit Linear encoder pitch (setting of Pn282)$

■ Feedback Resolution of Linear Encoder

The linear encoder pitches and resolutions are given in the following table. Calculate the electronic gear ratio using the values in the following table.

Type of Linear Encoder	Manufacturer	Linear Encoder Model	Linear Encoder Pitch [µm] ^{*1}	Relay Device Model between SERVOPACK and Linear Encoder	Resolution	Resolution
Incre- mental	Dr. JOHANNES HEIDENHAIN GmbH	LIDA480	20	JZDP-H003- DD -E*2	256	0.078 µm
				JZDP-J003- DD -E ^{*2}	4,096	0.0049 μm
		LIF48D	4	JZDP-H003- DD -E*2	256	0.016 µm
				JZDP-J003- DD -E ^{*2}	4,096	0.00098 µm
	Renishaw PLC	RGH22B	20	JZDP-H005- DDD -E ^{*2}	256	0.078 µm
				JZDP-J005- DDD -E ^{*2}	4,096	0.0049 µm
	Magnescale Co., Ltd.	SR75-0000LF*3	80	_	8,192	0.0098 µm
		SR75-DDDDDMF	80	_	1,024	0.078 µm
		SR85-0000LF*3	80	-	8,192	0.0098 µm
		SR85-DDDDDMF	80	-	1,024	0.078 µm
		SL700 ^{*3} , SL710 ^{*3} , SL720 ^{*3,} SL730 ^{*3}	800	PL101-RY ^{*4} MJ620-T13 ^{*5}	8,192	0.0977 μm
		SQ10	400	MQ10-FLA*5	8,192	0.0488 μm
				MQ10-GLA*5		
	Canon Precision Inc.	PH03-36110	128	_	2,048	0.0625 μm
		PH03-36120	128	_	2,048	0.0625 μm
Absolute	Dr. JOHANNES HEIDENHAIN GmbH	LIC4100 Series ^{*6}	20.48	EIB3391Y*7	4,096	0.005 µm
		LIC2100 Series ^{*6}	204.8	EIB3391Y*7	4,096	0.05 μm
			409.6	EIB3391Y*7	4,096	0.1 µm
		LIC4190 Series	40.96	-	4,096	0.01 µm
			20.48	-	4,096	0.005 µm
			4.096	_	4,096	0.001 µm
		LIC3190 Series	40.96	_	4,096	0.01 µm
		LIC2190 Series	409.6	-	4,096	0.1 µm
			204.8	-	4,096	0.05 µm
		LC115	40.96	EIB3391Y ^{*7}	4,096	0.01 µm
		LC415	40.96	EIB3391Y ^{*7}	4,096	0.01 µm
	RSF Elektronik GmbH	MC15Y Series	409.6	-	4,096	0.1 µm
			204.8	_	4,096	0.05 µm

Continued on next page.

6.15.1 Electronic Gear Ratio Settings

Continued from previous page.

					nued from pre	evious page.
Type of Linear Encoder	Manufacturer	Linear Encoder Model	Linear Encoder Pitch [µm] ^{*1}	Relay Device Model between SERVOPACK and Linear Encoder	Resolution	Resolution
		ST781A/ST781AL	256	_	512	0.5 μm
		ST782A/ST782AL	256	_	512	0.5 μm
		ST783/ST783AL	51.2	_	512	0.1 μm
	Mitutoyo	ST784/ST784AL	51.2	_	512	0.1 µm
	Corporation	ST788A/ST788AL	51.2	_	512	0.1 μm
		ST789A/ST789AL	25.6	_	512	0.05 μm
		ST1381	5.12	_	512	0.01 µm
		ST1382	0.512	_	512	0.001 µm
		EL36Y DD 050F DDD	12.8	_	256	0.05 μm
			25.6	_	256	0.1 µm
	Renishaw PLC		128	_	256	0.5 µm
	FLG	RL36Y00000000	12.8	_	256	0.05 μm
		RL36Y0001000	0.256	_	256	0.001 μm
			2,000	_	2,048	•
	RLS d.o.o.	LA11YA Series	2,000	_	4,096	
			2,000	_	8,192	0.2441 μm
		SR77-0000LF*3	80	_	8,192	
		SR77-DDDDDMF	80	_	1,024	-
		SR87-0000LF*3	80	_	8,192	-
Absolute		SR87-DDDDDMF	80	_	1,024	-
	Magnescale Co., Ltd.	SQ47/SQ57- 0000SF000 SQ47/SQ57- 0000TF000	20.48	_	4,096	 0.01 μm 0.05 μm 0.1 μm 0.5 μm 0.05 μm 0.05 μm 0.05 μm 0.001 μm 0.9765 μm 0.4882 μm 0.2441 μm 0.0098 μm 0.078 μm 0.005 μm 0.005 μm 0.005 μm 0.078 μm 0.0098 μm 0.0098 μm 0.0098 μm 0.0098 μm 0.0098 μm
		SQ47/SQ57- DDDDDAFDDD SQ47/SQ57- DDDDDFFDDD	40.96	_	4,096	
		L2AK208	20	_	256	0.078 μm
		L2AK211	20	_	2,048	0.0098 µm
		LAK209	40	_	512	0.078 µm
	Fagor	LAK212	40	_	4,096	0.0098 µm
		S2AK208	20	_	256	0.078 μm
	Automation S. Coop.	SV2AK208	20	_	256	0.078 μm
		G2AK208	20	_	256	0.078 µm
		S2AK211	20	_	2,048	0.0098 µm
		SV2AK211	20	_	2,048	0.0098 µm
		G2AK211	20	_	2,048	0.0098 µm
	Canon Precision Inc.	PH03-36E00	128	_	2,048	0.0625 µm

*1. These are reference values for setting SERVOPACK parameters. Contact the manufacturer for actual linear encoder scale pitches.

*2. This is the model of the Serial Converter Unit.

*3. If you use an encoder pulse output with this linear encoder, the setting range of the encoder output resolution (Pn281) is restricted. Refer to the following section for details on the encoder output resolution (Pn281).
 7.5.2 Setting for the Encoder Divided Pulse Output on page 7-24

- *4. This is the model of the Head with Interpolator.
- *5. This is the model of the Interpolator.
- *6. Sales of the interface unit EIB3391Y with the LIC4100 and LIC2100 series have ended due to the release of the LIC4190, LIC3190, and LIC2190 series.
- *7. This is the model of the Interface Unit.

6.15.2 Electronic Gear Ratio Setting Examples


Information Resolution

You can calculate the resolution that is used inside the SERVOPACK (i.e., the travel distance per feedback pulse) with the following formula.

Resolution (travel distance per feedback pulse) =

Linear encoder pitch

The SERVOPACK uses feedback pulses as the unit to control a Servomotor.



Linear encoder pitch =Distance for one cycle of the analog voltage feedback signal from the linear encoder

Linear encoder pitch

6.15.2 Electronic Gear Ratio Setting Examples

Setting examples are provided in this section.

Rotary Servomotors

		Machine Configuration			
	Description	Ball Screw	Rotary Table	Belt and Pulley	
Step		Reference unit: 0.001 mm Load shaft Load shaft Encoder: Ball screw lead: 24 bits 6 mm	Reference unit: 0.01° Gear ratio: 1/100 Load shaft Encoder: 24 bits	Gear ratio: 1/50 Reference unit: 0.005 mm Load shaft Pulley dia.: 100 mm Encoder: 24 bits	
1	Machine Specifications	Ball screw lead: 6 mmGear ratio: 1/1	 Rotation angle per revolution: 360° Gear ratio: 1/100 	 Pulley dia.: 100 mm (Pulley circumference: 314 mm) Gear ratio: 1/50 	
2	Encoder Resolution	16,777,216 (24 bits)	16,777,216 (24 bits)	16,777,216 (24 bits)	
3	Reference Unit	0.001 mm (1 μm)	0.01°	0.005 mm (5 μm)	
4	Travel Distance per Load Shaft Revolution (Reference Units)	6 mm/0.001 mm = 6,000	360°/0.01° = 36,000	314 mm/0.005 mm = 62,800	
5	Electronic Gear Ratio	$\frac{B}{A} = \frac{16,777,216}{6,000} \times \frac{1}{1}$	$\frac{B}{A} = \frac{16,777,216}{36,000} \times \frac{100}{1}$	$\frac{B}{A} = \frac{16,777,216}{62,800} \times \frac{50}{1}$	
6	Parameters	Pn20E: 16,777,216	Pn20E: 167,772,160	Pn20E: 838,860,800	
0		Pn210: 6,000	Pn210: 3,600	Pn210: 62,800	

· Linear Servomotors

A setting example for a Serial Converter Unit resolution of 256 is given below.

		Machine Configuration	
Step	Description	Reference unit: 0.02 mm (20 μm) Forward direction	
1	Linear encoder pitch	0.02 mm (20 μm)	
2	Reference Unit	0.001 mm (1 μm)	
3	Electronic Gear Ratio	$\frac{B}{A} = \frac{1 (\mu m)}{20 (\mu m)} \times 256$	
4	Setting Parameters	Pn20E: 256	
4		Pn210: 20	

6.16.1 Precautions on Resetting

6.16 Resetting the Absolute Encoder

In a system that uses an absolute encoder, the multiturn data must be reset at startup. An alarm related to the absolute encoder (A.810 or A.820) will occur when the absolute encoder must be reset, such as when the power supply is turned ON.

When you reset the absolute encoder, the multiturn data is reset and any alarms related to the absolute encoder are cleared.

Reset the absolute encoder in the following cases.

- When an A.810 alarm (Encoder Backup Alarm) occurs
- When an A.820 alarm (Encoder Checksum Alarm) occurs
- When starting the system for the first time
- · When you want to reset the multiturn data in the absolute encoder
- When the Servomotor has been replaced

CAUTION

• The multiturn data will be reset to a value between -2 and +2 rotations when the absolute encoder is reset. The reference position of the machine system will change. Adjust the reference position in the host controller to the position that results from resetting the absolute encoder.

If the machine is started without adjusting the position in the host controller, unexpected operation may cause personal injury or damage to the machine.

Information

- The multiturn data will always be zero in the following cases. It is never necessary to reset the absolute encoder in these cases. An alarm related to the absolute encoder (A.810 or A.820) will not occur.
 - · When you use a single-turn absolute encoder
 - When the encoder is set to be used as a single-turn absolute encoder (Pn002 = $n.\Box 2\Box \Box$)

6.16.1 Precautions on Resetting

- You cannot use the ALM_CLR (Clear Alarm) command from the SERVOPACK to clear the A.810 alarm (Encoder Backup Alarm) or the A.820 alarm (Encoder Checksum Alarm). Always use the operation to reset the absolute encoder to clear these alarms.
- If an A.8 arm (Internal Encoder Monitoring Alarm) occurs, turn OFF the power supply to reset the alarm.

6.16.2 Preparations

Always check the following before you reset an absolute encoder.

- The parameters must not be write prohibited.
- The servo must be OFF.

6.16.3 Applicable Tools

6.16.3 Applicable Tools

The following table lists the tools that you can use to reset the absolute encoder.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn008	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Encoder Setting – Reset Absolute Encoder	6.16.4 Operating Procedure on page 6-48

Information You can reset the absolute encoder using the MEM_WR (Write Memory) command. Refer to the following manual for information on the MEM_WR (Write Memory) command. $\square \Sigma$ -7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Man-

6.16.4 Operating Procedure

Use the following procedure to reset the absolute encoder.

- **1.** Confirm that the servo is OFF.
- 2. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Reset Absolute Encoder in the Menu Dialog Box. The Absolute Encoder Reset Dialog Box will be displayed.
- 4. Click the Continue Button.

Absolute Encoder Warning
The Setup Absolute Encoder resets the multiturn amount of the connected serial-type absolute encoder as well as encoder alarms from the PC.
Upon resetting the absolute encoder multiturn to "0", the mechanical system will go to a position data system differing from that used until now.
Operating the machine in this state is extremely dangerous(In the worst case, my lead to injury to person or damage to machine). Be sure to reset the zero point of the machine after completing this process.
Continue absolute encoder setup processing?
Continue

Click the Cancel Button to cancel resetting the absolute encoder. The Main Window will return.

5. Click the Execute setting Button.

Absolute encoder - Setup AXIS#00	×
Perform absolute encoder setup under the following circumstances: 1. At first start-up of the machine 2. When an "encoder backup alarm" has been generated 3. After the Servopack power has been turned OFF and the encoder cable removed	
Absolute encoder setup can only be performed with the Restart power after setup processing is complete.	
Alarm name A.810 : Encoder Backup Alarm	
Execute setting	

The current alarm code and name will be displayed in the Alarm name Box.

6. Click the Continue Button.

ual No.: SIEP S800001 31)

6.16.4 Operating Procedure

Setup Verification
Upon execution of processing, the multiturn data within the absolute encoder is reset to "0" and the mechanical system will go to a position data system different from that used until now.
Continue processing?
Continue

Click the **Cancel** Button to cancel resetting the absolute encoder. The previous dialog box will return.

7. Click the OK Button.

The absolute encoder will be reset.

When Resetting Fails

If you attempted to reset the absolute encoder when the servo was ON in the SERVOPACK, the following dialog box will be displayed and processing will be canceled.

Absolute (encoder reset conditions error
4	Servo ON now. Tum the Servo OFF when resetting the absolute encoder.
	ОК

Click the **OK** Button. The Main Window will return. Turn OFF the servo and repeat the procedure from step 1.

When Resetting Is Successful

The following dialog box will be displayed when the absolute encoder has been reset.

Completion Warning Message
Absolute Encoder reset processing has been performed. The Multiurn amount in the absolute encoder has been to "0". Be sure to reset the mechanical system to "0" after restarting power.
ОК

The Main Window will return.

8. To enable the change to the settings, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to reset the absolute encoder.

6.17.1 Absolute Encoder Origin Offset

6.17 Setting the Origin of the Absolute Encoder

6.17.1 Absolute Encoder Origin Offset


The origin offset of the absolute encoder is a correction that is used to set the origin of the machine coordinate system in addition to the origin of the absolute encoder. Set the offset between the absolute encoder origin and the machine coordinate system origin in Pn808 (Absolute Encoder Origin Offset).

After the SENS_ON (Absolute Data Request) command is received, the position in the machine coordinate system (APOS) is set based on the absolute encoder position data and the setting of Pn808.

	Absolute Encoder C	rigin Offset	Position		
Pn808	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
1 11000	-1,073,741,823 to 1,073,741,823	1 reference unit	0	Immediately	Setup

Example

If the encoder position (X) is at the origin of the machine coordinate system (0), then Pn808 would be set to -X.



6.17.2 Setting the Origin of the Absolute Linear Encoder

You can set any position as the origin in the following Linear Encoders.

- Dr. JOHANNES HEIDENHAIN GmbH LIC4190, LIC3190, or LIC2190 Series
- RSF Elektronik GmbH MC15Y Series
- Mitutoyo Corporation ABS ST780A Series or ST1300 Series Models: ABS ST78□A/ST78□AL/ST13□□
- Renishaw PLC EVOLUTE Series Models: EL36Y
- Renishaw PLC RESOLUTE Series Models: RL36Y
- Canon Precision Inc. Model: PH03-36E00



1. After you set the origin, the /S-RDY (Servo Ready) signal will become inactive because the system position data was changed. Always turn the SERVOPACK power supply OFF and ON again.

^{20rtant} 2. After you set the origin, the Servomotor phase data in the SERVOPACK will be discarded. If you are using a Linear Servomotor without a Polarity Sensor, execute polarity detection again to save the Servomotor phase data in the SERVOPACK.

6.17.2 Setting the Origin of the Absolute Linear Encoder

Preparations

Always check the following before you set the origin of an absolute encoder.

- The parameters must not be write prohibited.
- The servo must be OFF.

Applicable Tools

The following table lists the tools that you can use to set the origin of the absolute linear encoder.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn020	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Encoder Setting – Zero Point Position Setting	Gerating Procedure on page 6-51

Operating Procedure

Use the following procedure to set the origin of an absolute linear encoder.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Zero Point Position Setting in the Menu Dialog Box. The Set Origin Dialog Box will be displayed.
- 3. Click the Continue Button.


Set Origin
The set origin sets the current position to the connected absolute linear scale as the zero-point position.
Always refer to the user's manual before executing this function. Note the following points:
1.Always make the settings for the mechanical system again after the set origin.
The absolute position of the connected absolute linear scale is cleared to 0 and the previously defined mechanical system will change to a different coordinate system. Operating the machine in this state is extremely dangerous. Failure to observe this warning may result in personal injury and/or damage to the machine. Be sure to reset the zero point for the mechanical system after the set origin.
2.Satisfy the following conditions before executing this function:
The following conditions must be satisfied to execute the set origin: a. Servo OFF b. The polarity detection has been completed. Check the SERVOPACK status.
3.Always turn the SERVOPACK power OFF then ON again after the set origin.
The set zero point position will be valid after turning OFF the power then ON again. Always turn OFF the SERVOPACK power then ON again after the set origin.
Do you want to continue the set origin?
Continue Cancel

4. Click the Execute Button.

<u> </u>	Set Origin AXIS#00
E	xecute the set origin in the following cases:
2	I. At initial machine startup 2. When the SERVOPACK power has been turned OFF, and the encoder able removed
	he set origin is enabled only while the servo is OFF. urn OFF the power then ON again after the set origin.
	Execute

6.17.2 Setting the Origin of the Absolute Linear Encoder

5. Click the Continue Button.



Click the **Cancel** Button to cancel setting the origin of the absolute linear encoder. The previous dialog box will return.

6. Click the OK Button.

Set Origin
Zero-point position setting has been executed. The movement amount saved in the encoder has been reset to 0 (zero). Always turn the power to the Servopack off and then on again after execution of this function.
When using a linear motor without a hall sensor, execute polarity detection after turning the power off and then on again
ОК

- 7. Turn the power supply to the SERVOPACK OFF and ON again.
- 8. If you use a Linear Servomotor that does not have a polarity sensor, perform polarity detection.

Refer to the following section for details on the polarity detection.

This concludes the procedure to set the origin of the absolute linear encoder.

6.18 Setting the Regenerative Resistor Capacity

The Regenerative Resistor consumes regenerative energy that is generated by the Servomotor, e.g., when the Servomotor decelerates.

If an External Regenerative Resistor is connected, you must set Pn600 (Regenerative Resistor Capacity) and Pn603 (Regenerative Resistance).

Note: When using the SERVOPACK's built-in regenerative resistor (not using an External Regenerative Resistor), use the default setting of 0 for Pn600 and Pn603.



- If you connect an External Regenerative Resistor, set Pn600 and Pn603 to suitable values. If a suitable value is not set, A.320 alarms (Regenerative Overload) will not be detected correctly, and the External Regenerative Resistor may be damaged or personal injury or fire may result.
- When you select an External Regenerative Resistor, make sure that it has a suitable capacity.

	Regenerative Resiste	or Capacity	Speed Position Torque		
Pn600	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to SERVOPACK's maximum applica- ble motor capacity	10 W	0	Immediately	Setup
	Regenerative Resistance Speed Position Torce				
Pn603	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	10 mΩ	0	Immediately	Setup

There is a risk of personal injury or fire.

Set the Regenerative Resistor capacity to a value that is consistent with the allowable capacity of the External Regenerative Resistor. The setting depends on the cooling conditions of the External Regenerative Resistor.

- For self-cooling (natural convection cooling): Set the parameter to a maximum 20% of the capacity (W) of the actually installed Regenerative Resistor.
- For forced-air cooling: Set the parameter to a maximum 50% of the capacity (W) of the actually installed Regenerative Resistor.

Example For a self-cooling 100-W External Regenerative Resistor, set Pn600 to 2 (×10 W) (100 W × 20% = 20 W).

Note: An A.320 alarm will be displayed if the setting is not suitable.



1. When an External Regenerative Resistor is used at the normal rated load ratio, the resistor temperature increases to between 200°C and 300°C. Always apply derating. Consult the manufacturer for the resistor's load characteristics.

^t 2. For safety, use an External Regenerative Resistor with a thermoswitch.

Application Functions

This chapter describes the application functions that you can set before you start Servo System operation. It also describes the setting methods.

7.1 7.1.1 7.1.2 7.1.3 7.1.4 7.1.5 7.1.6 7.1.7 /V-CMP (Speed Coincidence Detection) 7.1.8 7.1.9 /NEAR (Near) Signal7-12 Operation for Momentary Power Interruptions ...7-15 79 7.3 Setting the Motor Maximum Speed7-18 .4 7.5 Encoder Divided Pulse Output Signals7-19 7.5.1 7.5.2 Setting for the Encoder Divided Pulse Output . . 7-24 Software Limits7-26 7.6 7.6.1 Setting to Enable/Disable Software Limits 7-26 7.6.2 Setting the Software Limits7-26 7.6.3

7.7	Selecting Torque Limits7-27					
	7.7.1 7.7.2 7.7.3	Internal Torque Limits				
7.8	Absol	ute Encoders7-32				
	7.8.1 7.8.2	Connecting an Absolute Encoder				
	7.8.3 7.8.4	Output Ports for the Position Data from the Absolute Encoder				
	7.8.5 7.8.6	Encoder				
	7.8.7	Coordinates				
	7.8.8 7.8.9	Multiturn Limit Disagreement Alarm (A.CC0)				
7.9	Absolute Linear Encoders7					
	7.9.1 7.9.2	Connecting an Absolute Linear Encoder7-41 Structure of the Position Data of the Absolute Linear Encoder				
	7.9.3	Output Ports for the Position Data from the Absolute Linear Encoder				
	7.9.4	Reading the Position Data from the Absolute Linear Encoder				
	7.9.5 7.9.6	Transmission Specifications				
	7.9.7	Alarm Output from the Output Ports for the Position Data from the Absolute Linear Encoder				
7.10	Softw	are Reset7-46				
	7.10.1 7.10.2 7.10.3	Preparations				
7.11	Initializing the Vibration Detection Level 7-49					
	7.11.1 7.11.2 7.11.3 7.11.4	Preparations.7-49Applicable Tools.7-50Operating Procedure.7-50Related Parameters.7-52				
7.12	Adjusti	ng the Motor Current Detection Signal Offset7-53				
	7.12.1 7.12.2	Automatic Adjustment				

7.13	Forcir	ng the Motor to Stop
	7.13.1 7.13.2 7.13.3	FSTP (Forced Stop Input) Signal
7.14	ZONE	Outputs (FT64 Specification)7-60
	7.14.1	ZONE Table and ZONE Signals
	7.14.2	ZONE Table Settings
	7.14.3	ZONE Signals 1 to 4 Outputs
		(/ZONE0 to /ZONE3)
	7.14.4	nZONE Signal Output7-65
	7.14.5	ZONE Output Application Example
7.15	Overh	eat Protection
	7.15.1	Connecting the Overheat Protection Input (TH) Signal
	7.15.2	Overheat Protection Selections

7.1.1 Input Signal Allocations

7.1 I/O Signal Allocations

Functions are allocated to the pins on the I/O signal connector (CN1) in advance. You can change the allocations and the polarity for some of the connector pins. Function allocations and polarity settings are made with parameters.

This section describes the I/O signal allocations.

7.1.1 Input Signal Allocations



 If you change the default polarity settings for the P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal, the overtravel function will not operate if there are signal line disconnections or other problems. If you must change the polarity of one of these signals, verify operation and make sure that no safety problems will exist.

• If you allocate two or more signals to the same input circuit, a logical OR of the inputs will be used and all of the allocated signals will operate accordingly. This may result in unexpected operation.

The input signals that you can allocate to the pins on the I/O signal connector (CN1) and the related parameters are given in the following table.

Input Signal	Input Signal Name	Parameter
P-OT	Forward Drive Prohibit	Pn50A = n.X□□□
N-OT	Reverse Drive Prohibit	Pn50B = n.□□□X
/P-CL	Forward External Torque Limit	Pn50B = n.□X□□
/N-CL	Reverse External Torque Limit	Pn50B = n.X□□□
/DEC	Origin Return Deceleration Switch Input	Pn511 = n.□□□X
/EXT1	External Latch Input 1	Pn511 = n.□□X□
/EXT2	External Latch Input 2	Pn511 = n.□X□□
/EXT3	External Latch Input 3	Pn511 = n.X□□□
/DBANS	Dynamic Brake Answer Input	Pn515 = n.□X□□
FSTP Forced Stop		Pn516 = n.□□□X

7.1.1 Input Signal Allocations

Relationship between Parameter Settings, Allocated Pins, and Polarities

The following table shows the relationship between the input signal parameter settings, the pins on the I/O signal connector (CN1), and polarities.

Parameter Setting	Pin No.	Description		
0	13			
1	7			
2	8			
3	9	A reverse signal (a signal with "/" before the signal abbreviation, such as the /		
4	10	P-CL signal) is active when the contacts are ON (closed).		
5	11	A signal that does not have "/" before the signal abbreviation (such as the P- OT signal) is active when the contacts are OFF (open).		
6	12			
7	_	The input signal is not allocated to a connector pin and it is always active. If the signal is processed on a signal edge, then it is always inactive.		
8	_	The input signal is not allocated to a connector pin and it is always inactive. Set the parameter to 8 if the signal is not used.		
9	13			
A	7			
В	8			
С	9	A reverse signal (a signal with "/" before the signal abbreviation, such as the /		
D	10	P-CL signal) is active when the contacts are OFF (open). A signal that does not have "/" before the signal abbreviation (such as the F OT signal) is active when the contacts are ON (closed).		
E	11			
F	12			

Note: 1. You cannot allocate the /EXT1 to /EXT3 (External Latch Inputs 1 to 3) signals to pins 10 to 12 on the I/O signal connector (CN1).

2. Refer to the following section for details on input signal parameter settings.

14.1.2 List of Servo Parameters on page 14-3

Example of Changing Input Signal Allocations

The following example shows reversing the P-OT (Forward Drive Prohibit) signal allocated to CN1-7 and the /DEC (Origin Return Deceleration Switch) signal allocated to CN1-9.

Pn50A = n.1□□1	Pn511 = n.□□□3	Before change

 $Pn50A = n.3 \square \square 1$ $Pn511 = n. \square \square \square \square 1$ After change

 \downarrow

Refer to the following section for the parameter setting procedure. 6.1.3 Parameter Setting Methods on page 6-6

Ţ

Confirming the Allocation Status of Input Signals

You can confirm the allocation status of input signals with the I/O Signal Allocations Window of the SigmaWin+. Refer to the following section for details.

7.1.2 Output Signal Allocations

 $(\mathbf{0})$

7.1.2 Output Signal Allocations

You can allocate the desired output signals to pins 1, 2, and 23 to 30 on the I/O signal connector (CN1). You set the allocations in the following parameters: Pn50E, Pn50F, Pn510, Pn514, Pn51A, Pn53C, and Pn53D.

- The signals that are not detected are considered to be OFF. For example, the /COIN (Positioning Completion) signal is considered to be OFF during speed control.
- Reversing the polarity of the /BK (Brake) signal, i.e., changing it to positive logic, will prevent the holding brake from operating if its signal line is disconnected. If you must change the polarity of this signal, verify operation and make sure that no safety problems will exist.
 - If you allocate more than one signal to the same output circuit, a logical OR of the signals will be output.

The following table shows the relationship between the parameters and the output signals that can be allocated to the pins on the I/O signal connector (CN1).

Output Signals	Output Signal Name	Parameter
/COIN	Positioning Completion	Pn50E = n.□□□X
/V-CMP	Speed Coincidence Detection	$Pn50E = n.\Box\Box X\Box$
/TGON	Rotation Detection	Pn50E = n.□X□□
/S-RDY	Servo Ready	$Pn50E = n.X \square \square \square$
/CLT	Torque Limit Detection	$Pn50F = n.\Box\Box\BoxX$
/VLT	Speed Limit Detection	$Pn50F = n.\Box\Box X\Box$
/BK	Brake	$Pn50F = n.\Box X \Box \Box$
/WARN	Warning	$Pn50F = n.X \square \square \square$
/NEAR	Near	Pn510 = n.□□□X
/PM	Preventative Maintenance	Pn514 = n.□X□□
/DBON	Dynamic Brake Operation Request	$Pn51A = n.\Box\Box X\Box$
/ZONE0	ZONE Table Entry 1	$Pn53C = n.\Box\Box\BoxX$
/ZONE1	ZONE Table Entry 2	$Pn53C = n.\Box\Box X\Box$
/ZONE2	ZONE Table Entry 3	$Pn53C = n.\Box X \Box \Box$
/ZONE3	ZONE Table Entry 4	$Pn53C = n.X \square \square \square$
/nZONE ZONE n Signal		$Pn53D = n.\square\square\squareX$

• Relationship between Parameter Settings and Allocated Pin Numbers

The following table shows the relationship between the output signal parameter settings and the pin numbers on the I/O signal connector (CN1).

Parameter Setting Pin No.		Description	
0	—	Disable (signal output is not used)	
1	1 or 2	Output the allocated signal from the CN1-1 or CN1-2 output terminal.	
2	23 or 24	Output the allocated signal from the CN1-23 or CN1-24 output terminal.	
3	25 or 26	Output the allocated signal from the CN1-25 or CN1-26 output terminal.	
4	27 or 28	Output the allocated signal from the CN1-27 or CN1-28 output terminal.	
5	29 or 30	Output the allocated signal from the CN1-29 or CN1-30 output terminal.	
6	_	Reserved parameter (Do not change.)	

7.1.3 ALM (Servo Alarm) Signal

Output Signal Polarity Switching

The polarity of output signals is switched using Pn512 and Pn513.

Parameter		Pin No.	Description	
Parameter No. Setting Value		FILINO.		
	n. DDD X	0	1 or 2	The signal is not inverted.
		1	1012	The signal is inverted.
	n.🗆🗆 X 🗆	0	23 or 24	The signal is not inverted.
Pn512		1		The signal is inverted.
FIIJIZ	n.🗆X🗆 🗆	0	25 or 26	The signal is not inverted.
		1		The signal is inverted.
	n.XDDD	0	27 or 28	The signal is not inverted.
		1		The signal is inverted.
Pn513	n.🗆 🗆 🗆 X	0	29 or 30	The signal is not inverted.
F1013		1		The signal is inverted.

Example of Changing Output Signal Allocations

The following example shows disabling the /COIN (Positioning Completion) signal allocated to CN1-25 and CN1-26 and allocating the /SRDY (Servo Ready) signal.

 $Pn50E = n.0 \square \square 3$ Before change

 \downarrow

 $Pn50E = n.3 \square \square 0$ After change

Refer to the following section for the parameter setting procedure. *6.1.3 Parameter Setting Methods* on page 6-6

Confirming the Allocation Status of Output Signals

You can confirm the allocation status of output signals with the I/O Signal Allocations Window of the SigmaWin+. Refer to the following section for details. 10.2.3 I/O Signals Status Monitor on page 10-5

7.1.3 ALM (Servo Alarm) Signal

This signal is output when the SERVOPACK detects an error.

Configure an external circuit so that this alarm output turns OFF the main circuit power supply to the SERVOPACK whenever an error occurs.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output AL		CNI1 2 and CNI1 4	ON (closed)	Normal SERVOPACK status
		OFF (open)	SERVOPACK alarm	

Alarm Reset Methods

Refer to the following section for information on the alarm reset methods. (3.2.3 Resetting Alarms on page 13-43

7.1.4 /WARN (Warning) Signal

7.1.4 /WARN (Warning) Signal

Both alarms and warnings are generated by the SERVOPACK. Alarms indicate errors in the SERVOPACK for which operation must be stopped immediately. Warnings indicate situations that may results in alarms but for which stopping operation is not yet necessary.

The /WARN (Warning) signal indicates that a condition exists that may result in an alarm.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output /WA		Must be allocated.	ON (closed)	Warning
			OFF (open)	Normal status

Note: You must allocate the /WARN signal to use it. Use Pn50F = n.X□□□ (/WARN (Warning Output) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

7.1.2 Output Signal Allocations on page 7-6

7.1.5 /TGON (Rotation Detection) Signal

The /TGON signal indicates that the Servomotor is operating.

This signal is output when the shaft of the Servomotor rotates at the setting of Pn502 (Rotation Detection Level) or faster or the setting of Pn581 (Zero Speed Level) or faster.

Туре	Signal	Connector Pin No.	Signal Status	Servomotor	Meaning
Output /TGO		N Must be allocated. OFF (open)		Rotary Servomotors	The Servomotor is operating at the setting of Pn502 or faster.
			The Servomotor is operating at the setting of Pn581 or faster.		
	/TGON			Rotary Servomotors	The Servomotor is operating at a speed that is slower than the setting of Pn502.
				Linear Servomotors	The Servomotor is operating at a speed that is slower than the setting of Pn581.

Note: You must allocate the /TGON signal to use it. Use Pn50E = n.□X□□ (/TGON (Rotation Detection Output) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details. 7.1.2 Output Signal Allocations on page 7-6

Setting the Rotation Detection Level

Use the following parameter to set the speed detection level at which to output the /TGON signal.

· Rotary Servomotors

	Rotation Detection	_evel	Speed Position	Torque	
Pn502	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 10,000	1 min ⁻¹	20	Immediately	Setup

· Linear Servomotors

	Zero Speed Level		Speed Position Force		
Pn581	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 10,000	1 mm/s	20	Immediately	Setup

7.1.6 /S-RDY (Servo Ready) Signal

7.1.6 /S-RDY (Servo Ready) Signal

The /S-RDY (Servo Ready) signal turns ON when the SERVOPACK is ready to accept the SV_ON (Servo ON) command.

The /S-RDY signal is turned ON under the following conditions.

- Main circuit power supply is ON.
- There is no hard wire base block state.
- There are no alarms.
- There is no forced stop state (FSTP).
- If an absolute encoder is used, the SENS_ON (Turn ON Sensor) command has been input.
- If a Servomotor without a polarity sensor is used, polarity detection has been completed. *
- If an absolute encoder is used, the output of the position data from the absolute encoder to the host controller must have been completed if the SENS_ON (Turn ON Sensor) command is being input.
- * Do not include this condition if the SV_ON (Servo ON) command is input for the first time after the control power supply was turned ON. In that case, when the first SV_ON command is input, polarity detection is started immediately and the /S-RDY signal turns ON at the completion of polarity detection.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output	/S-RDY	Must be allocated.	ON (closed)	Ready to receive the SV_ON (Servo ON) com- mand.
Output /S-RD	73-NDT	Must be allocated.	OFF (open)	Not ready to receive the SV_ON (Servo ON) command.

Note: 1. You must allocate the /S-RDY signal to use it. Use Pn50E = n.XDDD (/S-RDY (Servo Ready) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

7.1.2 Output Signal Allocations on page 7-6

2. Refer to the following section for information on the hard wire base block and the /S-RDY signal. *12.2.8 /S-RDY (Servo Ready Output) Signal* on page 12-8

7.1.7 /V-CMP (Speed Coincidence Detection) Signal

7.1.7 /V-CMP (Speed Coincidence Detection) Signal

The /V-CMP (Speed Coincidence Detection Output) signal is output when the Servomotor speed is the same as the reference speed. This signal is used, for example, to interlock the SERVOPACK and the host controller. You can use this output signal only during speed control.

The /V-CMP signal is described in the following table.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output /V-CMP	Must be allocated.	ON (closed)	The speed coincides.	
		OFF (open)	The speed does not coincide.	

Note: You must allocate the /V-CMP signal to use it. Use Pn50E = n. $\Box \Box X \Box$ (/V-CMP (Speed Coincidence Detection Output) Signal Allocation) to allocate the signal to connector pins.

- Refer to the following section for details on allocations.
- 7.1.2 Output Signal Allocations on page 7-6


You can set the speed detection width for the /V-CMP signal in Pn503 (Speed Coincidence Detection Signal Output Width) for a Rotary Servomotor or in Pn582 (Speed Coincidence Detection Signal Output Width) for a Linear Servomotor.

Rotary Servomotors

	Speed Coincidence	Detection Signal Ou	Speed		
Pn503	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1 min ⁻¹	10	Immediately	Setup

The signal is output when the difference between the reference speed and motor speed is equal or less than the setting.

Example If Pn503 is set to 100 and the speed reference is 2,000 min⁻¹, the signal would be output when the motor speed is between 1,900 min⁻¹ and 2,100 min⁻¹.



• Linear Servomotors

	Speed Coincidence	Detection Signal Ou	tput Width	Speed	
Pn582	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1 mm/s	10	Immediately	Setup

The signal is output when the difference between the reference speed and motor speed is equal or less than the setting.

Example If Pn582 is set to 100 and the speed reference is 2,000 mm/s the signal would be output when the motor speed is between 1,900 mm/s and 2,100 mm/s. Motor speed
Motor speed
Pn582
Speed reference
The *N*-CMP signal is output when the motor speed is in the area between the dotted lines.

7.1.8 /COIN (Positioning Completion) Signal

7.1.8 /COIN (Positioning Completion) Signal

The /COIN (Positioning Completion) signal indicates that Servomotor positioning has been completed during position control.

The /COIN signal is output when the difference between the reference position output by the host controller and the current position of the Servomotor (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the positioning completed width (Pn522).

Use this signal to check the completion of positioning from the host controller.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output /COIN	Must be allocated.	ON (closed)	Positioning has been completed.	
		OFF (open)	Positioning has not been completed.	


7.1.2 Output Signal Allocations on page 7-6

Setting the Positioning Completed Width

The /COIN signal is output when the difference between the reference position and the current position (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the positioning completed width (Pn522).

	Positioning Complete	ted Width	Position		
Pn522	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,073,741,824	1 reference unit	7	Immediately	Setup

The setting of the positioning completed width has no effect on final positioning accuracy.



Note: If the parameter is set to a value that is too large, the /COIN signal may be output when the position deviation is low during a low-speed operation. If that occurs, reduce the setting until the signal is no longer output.

7.1.9 /NEAR (Near) Signal

Setting the Output Timing of the /COIN (Positioning Completion Output) Signal

You can add a reference input condition to the output conditions for the /COIN signal to change the signal output timing.

If the position deviation is always low and a narrow positioning completed width is used, change the setting of $Pn207 = n.X \square \square \square$ (/COIN (Positioning Completion Output) Signal Output Timing) to change output timing for the /COIN signal.

Parameter		Description	When Enabled	Classification
Pn207	n.0□□□ (default setting)	Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width).		
	n. 1000	Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width) and the reference after the position reference filter is 0.		Setup
	n. 2000	Output the /COIN signal when the absolute value of the position deviation is the same or less than the setting of Pn522 (Positioning Completed Width) and the reference input is 0.		

7.1.9 /NEAR (Near) Signal

The /NEAR (Near) signal indicates when positioning completion is being approached.

The host controller receives the NEAR signal before it receives the /COIN (Positioning Completion) signal, it can start preparations for the operating sequence to use after positioning has been completed. This allows you to reduce the time required for operation when positioning is completed.

The NEAR signal is generally used in combination with the /COIN signal.


Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output /NEAR		ON (closed)	The Servomotor has reached a point near to positioning completion.	
	Must be allocated.	OFF (open)	The Servomotor has not reached a point near to positioning completion.	

Note: You must allocate the /NEAR signal to use it. Use Pn510 = n. DDX (/NEAR (Near) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

7.1.2 Output Signal Allocations on page 7-6

/NEAR (Near) Signal Setting

You set the condition for outputting the /NEAR (Near) signal (i.e., the near signal width) in Pn524 (Near Signal Width). The /NEAR signal is output when the difference between the reference position and the current position (i.e., the position deviation as given by the value of the deviation counter) is equal to or less than the setting of the near signal width (Pn524).




Note: Normally, set Pn524 to a value that is larger than the setting of Pn522 (Positioning Completed Width).

7.1.10 Speed Limit during Torque Control

You can limit the speed of the Servomotor to protect the machine.

When you use a Servomotor for torque control, the Servomotor is controlled to output the specified torque, but the motor speed is not controlled. Therefore, if a reference torque is input that is larger than the machine torque, the speed of the Servomotor may increase greatly. If that may occur, use this function to limit the speed.

Note: The actual limit of Servomotor speed depends on the load conditions on the Servomotor.



/VLT (Speed Limit Detection) Signal

The signal that is output when the motor speed is being limited by the speed limit is described in the following table.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
		ON (closed)	The Servomotor speed is being limited.	
Output	/VLT	Must be allocated.	OFF (open)	The Servomotor speed is not being lim- ited.

Note: You must allocate the /VLT signal to use it. Use Pn50F = n.□□X□ (/VLT (Speed Limit Detection) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

7.1.2 Output Signal Allocations on page 7-6

7.1.10 Speed Limit during Torque Control

Selecting the Speed Limit

The smaller of the external speed limit and internal speed limit will be used.

Parameter		Meaning	When Enabled	Classification
n	n.🗆 🗆 🗆	Reserved parameter (Do not change.)		
Pn002	n.□□1□ (default setting)	Use the speed limit from the VLIM (Limit Speed for Torque Control) command as the speed limit. (Use external speed limiting.)	After restart	Setup

Internal Speed Limiting

Set the speed limit for the motor in Pn407 (Speed Limit during Torque Control) or Pn480 (Speed Limit during Force Control).

Also set $Pn408 = n.\square\squareX\square$ (Speed Limit Selection) to specify using the maximum motor speed or the overspeed alarm detection speed as the speed limit. Select the overspeed alarm detection speed to limit the speed to the equivalent of the maximum motor speed.

Parameter		meter	Meaning	When Enabled	Classification
Pn408	(def]□0□ fault setting)	Use the smaller of the maximum motor speed and the setting of Pn407 or Pn480 as the speed limit.	After restart	Setup
- 11		1010	Use the smaller of the overspeed alarm detec- tion speed and the setting of Pn407 or Pn480 as the speed limit.	Aller restart	Selup

Note: If you are using a Rotary Servomotor, set Pn407 (Speed Limit during Torque Control). If you are using a Linear Servomotor, set Pn480 (Speed Limit during Force Control).

Rotary Servomotors

	Speed Limit during	Torque			
Pn407	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 min ⁻¹	10000	Immediately	Setup

Linear Servomotors

	Speed Limit during	Force			
Pn480	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 mm/s	10000	Immediately	Setup

Note: If the parameter setting exceeds the maximum speed of the Servomotor, the Servomotor's maximum speed or the overspeed alarm detection speed will be used.

External Speed Limiting

The motor speed will be limited by VLIM (Limit Speed for Torque Control). Refer to the following manual for details.


Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

7.2 Operation for Momentary Power Interruptions

Even if the main power supply to the SERVOPACK is interrupted momentarily, power supply to the motor (servo ON status) will be maintained for the time set in Pn509 (Momentary Power Interruption Hold Time).

	Momentary Power In	terruption Hold Time	Speed Position	n Torque	
Pn509	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	20 to 50,000	1 ms	20	Immediately	Setup

If the momentary power interruption time is equal to or less than the setting of Pn509, power supply to the motor will be continued. If it is longer than the setting, power supply to the motor will be stopped. Power will be supplied to the motor again when the main circuit power supply recovers.



- Information 1. If the momentary power interruption time exceeds the setting of Pn509, the /S-RDY (Servo Ready) signal will turn OFF.
 - 2. If uninterruptible power supplies are used for the control power supply and main circuit power supply, the SERVOPACK can withstand a power interruption that lasts longer than 50,000 ms.
 - 3. The holding time of the SERVOPACK control power supply is approximately 100 ms. If control operations become impossible during a momentary power interruption of the control power supply, the setting of Pn509 will be ignored and the same operation will be performed as for when the power supply is turned OFF normally.



The holding time of the main circuit power supply depends on the output from the SERVOPACK. If the load on the Servomotor is large and an A.410 alarm (Undervoltage) occurs, the setting of Pn509 will be ignored.

7.3 SEMI F47 Function

The SEMI F47 function detects an A.971 warning (Undervoltage) and limits the output current if the DC main circuit power supply voltage to the SERVOPACK drops to a specified value or lower because the power was momentarily interrupted or the main circuit power supply voltage was temporarily reduced.

This function complies with the SEMI F47 standards for semiconductor manufacturing equipment.

You can combine this function with the momentary power interruption hold time (Pn509) to allow the Servomotor to continue operating without stopping for an alarm or without recovery work even if the power supply voltage drops.

Execution Sequence

This function can be executed either with the host controller or with the SERVOPACK. Use $Pn008 = n.\square\squareX\square$ (Function Selection for Undervoltage) to specify whether the function is executed by the host controller or by the SERVOPACK.


The default setting (Pn008 = $n.\Box\Box0\Box$) disables detection of an A.971 warning (Undervoltage).

P	arameter	Meaning	When Enabled	Classification
Pn008	n.□□0□ (default setting)	Do not detect undervoltage warning.		Setup
	n.0010	Detect undervoltage warning and limit torque at host controller.	After restart	
	n.0020	Detect undervoltage warning and limit torque with Pn424 and Pn425 (i.e., only in SERVOPACK).		

• Execution with the Host Controller (Pn008 = $n.\Box\Box1\Box$)


The host controller limits the torque in response to an A.971 warning (Undervoltage).

The host controller removes the torque limit after the Undervoltage warning is cleared.



• Execution with the SERVOPACK (Pn008 = $n.\Box\Box2\Box$)

The torque is limited in the SERVOPACK in response to an Undervoltage warning. The SERVOPACK controls the torque limit for the set time after the Undervoltage warning is cleared.



Related Parameters

The following parameters are related to the SEMI F47 function.

	Torque Limit at Mair	n Circuit Voltage Dro	Speed Position Torque		
Pn424	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1%*	50	Immediately	Setup
Pn425	Release Time for Torque Limit at Main Circuit Voltage Drop			Speed Position	Torque
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	1 ms	100	Immediately	Setup
	Momentary Power Interruption Hold Time			Speed Position	Torque
Pn509	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	20 to 50,000	1 ms	20	Immediately	Setup

* Set a percentage of the motor rated torque.

Note: If you will use the SEMI F47 function, set the time to 1,000 ms.

This function handles momentary power interruptions for the voltage and time ranges stipulated in SEMI F47. An uninterruptible power supply (UPS) is required as a backup for momentary power interruptions that exceed these voltage and time ranges.
Set the host controller or SERVOPACK torque limit so that a torque reference that exceeds the specified acceleration torque will not be output when the power supply for the main circuit is restored.
For a vertical axis, do not limit the torque to a value that is lower than the holding torque.
This function limits torque within the range of the SERVOPACK's capability for power interruptions. It is not intended for use under all load and operating conditions. Set the parameters while monitoring operation on the actual machine.
You can set the momentary power interruption hold time to increase the amount of time from when the power supply is turned OFF until power supply to the motor is stopped. To stop the

power supply to the motor immediately, use the SV_OFF (Servo OFF) command.

7.4 Setting the Motor Maximum Speed

You can set the maximum speed of the Servomotor with the following parameter. • Rotary Servomotors

	Maximum Motor Sp	eed	Speed Position Torque		
Pn316	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 min⁻¹	10,000	After restart	Setup

Linear Servomotors

	Maximum Motor Sp	beed	Speed Posit	ion Force	
Pn385	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 100	100 mm/s	50	After restart	Setup

You can achieve the following by lowering the maximum speed of the Servomotor.

• If the Servomotor speed exceeds the setting, an A.510 alarm (Overspeed) will occur.

With a Linear Servomotor, you can increase the upper limit for the setting of Pn281 (Encoder Output Resolution). Refer to the following section for details.
 7.5 Encoder Divided Pulse Output on page 7-19

Changing the setting of the parameter is effective in the following cases.

- To protect the machine by stopping machine operation with an alarm when the set speed is reached or exceeded
- To limit the speed so that the load is not driven beyond the allowable moment of inertia Refer to relevant manual from the following list for the relationship between the speed and the allowable moment of inertia.

Ω Σ-7-Series Rotary Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 86)

Ω Σ-7-Series Linear Servomotor with 400 V-Input Power Product Manual (Manual No.: SIEP S800001 81)

• To increase the encoder output resolution and increase the position resolution managed by the host controller (for a Linear Servomotor)

7.5 Encoder Divided Pulse Output


The encoder divided pulse output is a signal that is output from the encoder and processed inside the SERVOPACK. It is then output externally in the form of two phase pulse signals (phases A and B) with a 90° phase differential. At the host controller, it is used as the position feedback.

The following table describes the signals and output phase forms.


7.5.1 Encoder Divided Pulse Output Signals

Туре	Signal	Connector Pin No.	Name	Remarks	
Output	PAO	CN1-17	Encoder Divided Pulse Output,	 Rotary Servomotors These encoder divided pulse output pins output the number of pulses per Servomotor reso- lution that is set in Pn212 (Number of Encoder Output Pulses). The phase difference between phase A and phase B is an electric angle of 90°. Linear Servomotors 	
	/PAO	CN1-18	Phase A		
	РВО	CN1-19			
	/PBO	CN1-20	Encoder Divided Pulse Output, Phase B	These encoder divided pulse output pins output pulses at the resolution that is set in Pn281 (Encoder Output Resolution). The phase difference between phase A and phase B is an electric angle of 90°.	
	PCO	CN1-21	Encoder Divided Pulse Output,	These pins output one pulse	
	/PCO	CN1-22	Phase C*	every Servomotor rotation.	


· Rotary Servomotor



Linear Servomotors



Output Phase Forms



Note: The pulse width of the origin within one encoder rotation depends on the setting of number of encoder output pulses (Pn212) or the encoder output resolution (Pn281). It is the same as the width of phase A. Even for reverse operation (Pn000 = $n.\square\square\square$ 1), the output phase form is the same as shown above.



If you use the SERVOPACK's phase-C pulse output for an origin return, rotate the Servomotor two or more rotations before you start an origin return. If the Servomotor cannot be rotated two or more times, perform an origin return operation at a motor speed of 600 min⁻¹ or lower. If the motor speed is higher than 600 min⁻¹, the phase-C pulse may not be output correctly.

Linear Encoder Application Precautions

The following precautions apply to the encoder output pulses when an external linear encoder is used.


 Relation between Renishaw PLC Incremental Linear Encoders and Encoder Output Pulse Signal from the SERVOPACK When Using a RGS20 Scale and RGH22B Sensor Head

The output position of the origin signal (Ref) will depend on the direction of movement for some models of incremental linear encoders from Renishaw PLC.


In that case, the phase-C pulse of the SERVOPACK is output at two positions.

For detailed specifications on the origin signal, refer to the manual for the Renishaw PLC incremental linear encoder.

When Passing the First Origin Signal (Ref) in the Forward Direction and Returning after Turning ON the Power Supply



When Passing the First Origin Signal (Ref) in the Reverse Direction and Returning after Turning ON the Power Supply



Precautions When Using a Linear Incremental Encoder from Magnescale Co., Ltd.

■ Encoder Divided Phase-C Pulse Output Selection

You can also output the encoder's phase-C pulse for reverse movement. To do so, set Pn081 to n. DDD1.

F	Parameter	Meaning	When Enabled	Classification
Pn081	n.□□□0 (default setting)	Output phase-C pulses only in the forward direction.	After restart	Setup
1 11001	n.0001	Output phase-C pulses in both the forward and reverse directions.	Alter restart	Gerup
Important	 If you set Pn0 tions), the wid pulse. There is a difference encoder's phase when Pn081 = when it is set 	 Origin I/8 linear encoder pitch 	the forward and re r than the width of detection position and, or phase-C la nly in the forward of	verse direc- the phase-A n for the tch between direction) and

Observe the following precaution if you set Pn081 to n. $\Box\Box\Box$ (Output phase-C pulses only in the forward direction).

When a linear incremental encoder from Magnescale Co., Ltd. is used, the count direction of the encoder determines how the phase-C pulse (CN1-21 and CN1-22) is output.


Note: The count direction (up or down) of the linear encoder determines whether a phase-C pulse is output. The output of the pulse does not depend on the setting of the movement direction ($Pn000 = n.\square\square\square1$).

Encoder Model	Interpolator	Linear Encoder Pitch [µm]
SL710		800
SL720	PL101-RY MJ620-T13	800
SL730		800
SR75		80
SR85		80
SQ10	MQ10-FLA	400
	MQ10-GLA	400

When First Passing the Origin Signal in the Forward Direction and Returning after Turning ON the Power Supply

The encoder's phase-C pulse (CN1-21 and CN1-22) is output when the origin detection position is passed for the first time in the forward direction after the power supply is turned ON.


After that, the phase-C pulse is output whenever the origin detection position is passed in the forward or reverse direction.



When First Passing the Origin Signal in the Reverse Direction and Returning after Turning ON the Power Supply


The encoder's phase-C pulse (CN1-19 and CN1-20) is not output when the origin detection position is passed for the first time in the reverse direction after the power supply is turned ON.

However, after the origin detection position is passed in the forward direction and the encoder's phase-C pulse is output, it will then also be output when the origin detection point is passed in the reverse direction.



When Using a Linear Encoder with Multiple Origins and First Passing the Origin Position in the Forward Direction and Returning after Turning ON the Power Supply


The encoder's phase-C pulse is output when the origin detection position is passed for the first time in the forward direction after the power supply is turned ON. After that, the phase-C pulse is output whenever the origin detection position is passed in the forward or reverse direction.



When Using a Linear Encoder with Multiple Origins and First Passing the Origin Position in the Reverse Direction after Turning ON the Power Supply

The encoder's phase-C pulse is not output when the origin detection position is passed for the first time in the reverse direction after the power supply is turned ON.

However, after the origin detection position is passed in the forward direction and the encoder's phase-C pulse it output, it will then also be output when the origin detection point is passed in the reverse direction.



7.5.2 Setting for the Encoder Divided Pulse Output

Setting for the Encoder Divided Pulse Output 7.5.2

This section describes the setting for the encoder divided pulse output for a Rotary Servomotor or Linear Servomotor.

Encoder Divided Pulse Output When Using a Rotary Servomotor

If you will use a Rotary Servomotor, set the number of encoder output pulses (Pn212).

	Number of Encoder C	Speed Positio	n Torque		
Pn212	Setting Range Setting Unit Default Setting When Enabled Clas			Classification	
	16 to 1,073,741,824	1 P/Rev	2,048	After restart	Setup

The number of pulses from the encoder per rotation are processed inside the SERVOPACK, divided by the setting of Pn212, and then output.

Set the number of encoder divided output pulses according to the system specifications of the machine or host controller.

The setting of the number of encoder output pulses is limited by the resolution of the encoder.

Setting of the Number of	Setting	Encoder Resolution	Upper Limit of Servomotor Speed for
Encoder Output Pulses [P/Rev]	Increment	24 bits	Set Number of Encoder Output
		(16,777,216 pulses)	Pulses [min ⁻¹]
16 to 16,384	1	0	6,000
16,386 to 32,768	2	0	3,000
32,772 to 65,536	4	0	1,500
65,544 to 131,072	8	0	750
131,088 to 262,144	16	0	375
262,176 to 524,288	32	0	187
524,352 to 1,048,576	64	0	93
1,048,704 to 2,097,152	128	0*	46
2,097,408 to 4,194,304	256	0*	23

* Available only for incremental encoder


Note: 1. The setting range of the number of encoder output pulses (Pn212) depends on the resolution of the Servomotor encoder. An A.041 alarm (Encoder Output Pulse Setting Error) will occur if the above setting conditions are not met.

Correct setting example: Pn212 can be set to 25,000 [P/Rev]. Incorrect setting example: Pn212 cannot be set to 25,001 (P/Rev) because the setting increment in the above table is not used.

2. The upper limit of the pulse frequency is approximately 1.6 Mpps. The Servomotor speed will be limited if the setting of the number of encoder output pulses is too high. An A.511 alarm (Encoder Output Pulse Overspeed) will occur if the upper limit of the motor speed is

exceeded.

Output example: An output example is given below for the PAO (Encoder Pulse Output Phase A) signal and the PBO (Encoder Pulse Output Phase B) signal when Pn212 is set to 16 (16 pulses output per revolution).



7.5.2 Setting for the Encoder Divided Pulse Output

Encoder Divided Pulse Output When Using a Linear Servomotor

If you will use a Linear Servomotor, set the encoder output resolution (Pn281).

	Encoder Output Resolution			Speed Posit	ion Force
Pn281	Setting Range	Setting Unit	Default Setting	When Enabled Classifica	
	1 to 4,096	1 edge/pitch	20	After restart	Setup

Note: 1. The maximum setting for the encoder output resolution is 4,096. Pulse output at a linear encoder resolution of 4,096 or higher is not possible.

2. If the setting of Pn281 exceeds the resolution of the external encoder, the A.041 alarm (Encoder Output Pulse Setting Error) will be output.

Set the encoder output resolution for the encoder pulse output signals (PAO, /PAO, PBO, and /PBO) from the SERVOPACK to the host controller.

The number of feedback pulses per linear encoder pitch is divided by the setting of Pn281 (after multiplication by 4) inside the SERVOPACK and then the resulting number of pulses is output. Set the parameter according to the system specifications of the machine or host controller.

The setting range depends on the Servomotor's maximum speed (Pn385) and the Linear Encoder Scale Pitch (Pn282).* You can calculate the upper limit of the setting of Pn281 with the following formula.

Upper limit of Pn281 = $\frac{\text{Linear Encoder Pitch*/100}}{\text{Pn385}} \times 72$

* The value depends on whether a Serial Converter Unit is used.

Using a Seria	al Converter Unit	Setting of Pn282	
Not Using a Serial Converter Unit (when the lin- ear encoder and SERVOPACK are connected directly or when a linear encoder that does not require a Serial Converter Unit is used)		The linear encoder pitch is automatically detected by the SERVO- PACK, so the setting of Pn282 is disabled.	
Information	because of the maximum resp If the setting is out of range or (Encoder Output Pulse Setting limit for the set encoder output will be output.	is 4 μ m, the maximum motor speed is limited to 1 m/s onse frequency of the Serial Converter Unit. does not satisfy the setting conditions, an A.041 alarm Error) will be output. If the motor speed exceeds the upper resolution, an A.511 alarm (Encoder Output Pulse Overspeed) output resolution is restricted by the dividing specifications of	
Example	(Pn385 = 50): Pn281 = 28 (edg	oder pitch of 20 μm and a maximum motor speed of 5 m/s ges/pitch) (edges/pitch) (An A.041 alarm would be output.)	
Example	Pulse Output Example When Pn281 = 20 (20-edge of Phase A Phase B Phase B	utput (5-pulse output) per linear encoder pitch)	
	Linear end	coder pitch	

7.6.1 Setting to Enable/Disable Software Limits

7.6 Software Limits

You can set limits in the software for machine movement that do not use the overtravel signals (P-OT and N-OT). If a software limit is exceeded, an emergency stop will be executed in the same way as it is for overtravel.

You must make the following settings to use the software limits.

- You must enable the software limit function.
- You must set the software limits.

7.6.1 Setting to Enable/Disable Software Limits

You can use $Pn801 = n.\square\square\squareX$ (Software Limit Selection) to enable and disable the software limit function. One of following commands must be executed to define the origin of the machine coordinate system before the software limits will operate. Otherwise, the software limit function will not operate even if a software limit is exceeded.

- The ZRET command has been executed.
- The POS_SET command has been executed with REFE set to 1.
- If an absolute encoder is used, the SENS_ON (Turn ON Sensor) command must have been completed.

Parameter		Meaning	When Enabled	Classification
Pn801	n.□□□0	Enable both forward and reverse soft- ware limits.		
	n.0001	Disable forward software limit.		
	n.🗆 🗆 🗠 2	Disable reverse software limit.	Immediately	Setup
	n.ロロロ3 (default setting)	Disable both forward and reverse soft- ware limits.		

7.6.2 Setting the Software Limits

Software limits are set in both the forward and reverse directions.

The reverse software limit must be less than the forward software limit to set a limit in each direction.

	Forward Software Limit			Position		
Pn804	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
1 1100 1	-1,073,741,823 to 1,073,741,823	1 reference unit	1,073,741,823	Immediately	Setup	
Pn806	Reverse Software Limit			Position		
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	-1,073,741,823 to 1,073,741,823	1 reference unit	-1,073,741,823	Immediately	Setup	

7.6.3 Software Limit Check for References

You can enable or disable software limit checks for commands that have target position references, such as POSING or INTERPOLATE. If the target position exceeds a software limit, a deceleration stop will be performed from the position set as the software limit.

Parameter		Meaning	When Enabled	Classification
Dp801	n.□0□□ (default setting)	Do not perform software limit checks for references.	Immodiately	Sotup
Pn801	n.0100	Perform software limit checks for refer- ences.	- Immediately	Setup

7.7 Selecting Torque Limits

You can limit the torque that is output by the Servomotor. There are four different ways to limit the torque. These are described in the following table.

Limit Method	Outline	Control Method	Reference
Internal Torque Limits	The torque is always limited with the setting of a parameter.	Speed control, position control, or	7.7.1
External Torque Limits	The torque is limited with an input signal from the host computer.	torque control	7.7.2
Limiting Torque with TLIM Data in Commands [*]	The TLIM data in a command is used to set the required torque limits.	Speed control or position control	_
Torque Limiting with P_CL and N_CL in the Servo Command Output Signals (SVCMD_IO)*	The P_CL and N_CL signals in the servo command output signals (SVCMD_IO) are used to set the required limits.	Speed control or position control	_

* Refer to the following manual for details.

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

Note: If you set a value that exceeds the maximum torque of the Servomotor, the torque will be limited to the maximum torque of the Servomotor.

7.7.1 Internal Torque Limits


If you use internal torque limits, the maximum output torque will always be limited to the specified forward torque limit (Pn402) and reverse torque limit (Pn403).

	Forward Torque Limit			Speed Position Torque		
Pn402	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 800	1%*	800	Immediately	Setup	
	Reverse Torque Limit			Speed Positio	n Torque	
Pn403	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 800	1%*	800	Immediately	Setup	

Rotary Servomotors

* Set a percentage of the rated motor torque.

Note: If the setting of Pn402 or Pn403 is too low, the torque may be insufficient for acceleration or deceleration of the Servomotor.




7.7.2 External Torque Limits

• Linear Servomotors

	Forward Force Limit			Speed Position Force	
Pn483	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	30	Immediately	Setup
	Reverse Force Limit			Speed Positic	n Force
Pn484	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	30	Immediately	Setup

* Set a percentage of the rated motor force.

Note: If the setting of Pn483 or Pn484 is too low, the force may be insufficient for acceleration or deceleration of the Servomotor.



7.7.2 External Torque Limits

You can limit the torque only when required by the operating conditions of the machine by turning a signal ON and OFF.

You can use this for applications such as stopping on physical contact, or holding a workpiece with a robot.

External Torque Limit Reference Signals

The /P-CL (Forward External Torque Limit) and /N-CL (Reverse External Torque Limit) signals are used as the external torque limit reference signals. The /P-CL signal is used for the forward torque limit and the /N-CL signal is used for the reverse torque limit.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Input /P-CL	/P-CL	Must be allocated.	ON (closed)	Applies the forward external torque limit. The torque is limited to the smaller of the set- tings of Pn402 ^{*1} and Pn404.
			OFF (open)	Cancels the forward external torque limit. The torque is limited to the setting of Pn402 ^{*1} .
Input	Input /N-CL	_ Must be allocated.	ON (closed)	Applies the reverse external torque limit. The torque is limited to the smaller of the set- tings of Pn403 ^{*2} and Pn404.
			OFF (open)	Cancels the reverse external torque limit. The torque is limited to the setting of Pn403 ^{*2} .

*1. Pn483 is used for a Linear Servomotor.

*2. Pn484 is used for a Linear Servomotor.

Note: You must allocate the /P-CL and /N-CL signals to use them. You can use the following parameters to allocate the signal to a terminal.

• Pn50B = n. $\Box X \Box \Box$ (/P-CL (Forward External Torque Limit Input) Signal Allocation)

Pn50B = n.XDDD (/N-CL (Reverse External Torque Limit Input) Signal Allocation)

Refer to the following section for details.

7.1.1 Input Signal Allocations on page 7-4

Setting the Torque Limits

The parameters that are related to setting the torque limits are given below.

Rotary Servomotors

If the setting of Pn402 (Forward Torque Limit), Pn403 (Reverse Torque Limit), Pn404 (Forward External Torque Limit), or Pn405 (Reverse External Torque Limit) is too low, the torque may be insufficient for acceleration or deceleration of the Servomotor.

	Forward Torque Lim	Forward Torque Limit			n Torque
Pn402	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup
	Reverse Torque Lim	it		Speed Positio	on Torque
Pn403	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup
	Forward External Torque Limit			Speed Positio	on Torque
Pn404	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	100	Immediately	Setup
	Reverse External Torque Limit		Speed Positio	on Torque	
Pn405	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	100	Immediately	Setup

* Set a percentage of the rated motor torque.

Linear Servomotors

If the setting of Pn483 (Forward Force Limit), Pn484 (Reverse Force Limit), Pn404 (Forward External Force Limit), or Pn405 (Reverse External Force Limit) is too low, the force may be insufficient for acceleration or deceleration of the Servomotor.

	Forward Force Limit	t		Speed Positio	Force
Pn483	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	30	Immediately	Setup
	Reverse Force Limit			Speed Positio	on Force
Pn484	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	30	Immediately	Setup
	Forward External Force Limit			Speed Positio	on Force
Pn404	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	100	Immediately	Setup
	Reverse External Fo	orce Limit		Speed Positio	on Force
Pn405	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	100	Immediately	Setup

* Set a percentage of the rated motor force.

7


7.7.2 External Torque Limits

Changes in the Output Torque for External Torque Limits

The following table shows the changes in the output torque when the internal torque limit is set to 800%.


Rotary Servomotors

In this example, the Servomotor direction is set to $Pn000 = n.\Box\Box\Box\Box$ (Use CCW as the forward direction).



Linear Servomotors

In this example, the Servomotor direction is set to $Pn000 = n.\Box\Box\Box\Box$ (Use the direction in which the linear encoder counts up as the forward direction).



7.7.3 /CLT (Torque Limit Detection) Signal

7.7.3 /CLT (Torque Limit Detection) Signal

This section describes the /CLT signal, which indicates the status of limiting the motor output torque.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Output		Must be allocated.	ON (closed)	The motor output torque is being limited.
Output	/CLT		OFF (open)	The motor output torque is not being limited.

Note: You must allocate the /CLT signal to use it. Use Pn50F = n. DDX (/CLT (Torque Limit Detection Output) Signal Allocation) to allocate the signal to a connector pin. Refer to the following section for details.

7.1.2 Output Signal Allocations on page 7-6

7

7.8.1 Connecting an Absolute Encoder

7.8 Absolute Encoders

The absolute encoder records the current position of the stop position even when the power supply is OFF.

With a system that uses an absolute encoder, the host controller can monitor the current position. Therefore, it is not necessary to perform an origin return operation when the power supply to the system is turned ON.

There are three types of encoders for Rotary Servomotors. The usage of the encoder is specified in $Pn002 = n.\Box X \Box \Box$.

Refer to the following section for encoder models.

Encoder Resolution on page 6-43

· Parameter Settings When Using an Incremental Encoder

F	Parameter	Meaning	When Enabled	Classification
	n.□0□□ (default setting)	Use the encoder as an incremental encoder. A battery is not required.		
Pn002 n.□1□□	Use the encoder as an incremental encoder. A battery is not required.	After restart	Setup	
	n.0200	Use the encoder as a single-turn absolute encoder. A battery is not required.	1	

· Parameter Settings When Using a Multiturn Absolute Encoder

Parameter		Meaning	When Enabled	Classification
	n.□0□□ (default setting)	Use the encoder as a multiturn absolute encoder. A battery is required.		
Pn002 n.□1□□		Use the encoder as an incremental encoder. A battery is not required.	After restart	Setup
	n.0200	Use the encoder as a single-turn absolute encoder. A battery is not required.	*	

NOTICE

• Install a battery at either the host controller or on the Encoder Cable. If you install batteries both at the host controller and on the Encoder Cable at the same time, you will create a loop circuit between the batteries, resulting in a risk of damage or burning.

7.8.1 Connecting an Absolute Encoder

You can get the position data from the absolute encoder with MECHATROLINK communications. Therefore, it is not necessary to wire the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

If they need to be wired, refer to the following section.

- 4.4.3 Wiring the SERVOPACK to the Encoder on page 4-20
- 4.5.3 I/O Signal Wiring Examples on page 4-32

7.8.2 Structure of the Position Data of the Absolute Encoder

The position data of the absolute encoder is the position coordinate from the origin of the absolute encoder.

The position data from the absolute encoder contains the following two items.

- The number of rotations from the origin of the encoder coordinate system (called the multiturn data)
- · The position (number of pulses) within one rotation

The position data of the absolute encoder is as follows:


Position data of absolute encoder = Multiturn data \times Number of pulses within one encoder rotation (setting of Pn212)+ Position (number of pulses) within one rotation.

For a single-turn absolute encoder, the multiturn data is 0.

7.8.3 Output Ports for the Position Data from the Absolute Encoder

You can read the position data of the absolute encoder from the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

The output method and timing for the position data of the absolute encoder are different in each case. A conceptual diagram of the connections of the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals to the host controller is provided below.



Signal	Status	Signal Contents When Using an Absolute Encoder
PAO	First signal	Multiturn data position within one rotation (pulse train)
	During normal operation	Incremental pulses
PBO	First signal	Position within one rotation (pulse train)
FDU	During normal operation	Incremental pulses
PCO	Always	Origin pulse

The PAO (Encoder Divided Pulse Output) signal outputs the position data from the absolute encoder after the control power supply is turned ON. The SENS_ON (Turn ON Sensor) command is used to output the position data from the absolute encoder.

The position data of the absolute encoder is the current stop position. The absolute encoder outputs the multiturn data with the specified protocol. The absolute encoder outputs the position within one rotation as a pulse train. It then outputs pulses as an incremental encoder (incremental operation status).

The host controller must have a reception circuit (e.g., UART) for the position data from the absolute encoder. The pulse counter at the host controller will not count pulses when the multiturn data (communications message) is input because only phase A is input. Counting starts from the position of the absolute encoder within one rotation.

The output circuits for the PAO, PBO, and PCO signals use line drivers. Refer to the following section for details on line drivers.

4.5.4 I/O Circuits on page 4-34

7

7.8.4 Reading the Position Data from the Absolute Encoder


7.8.4 Reading the Position Data from the Absolute Encoder

The SENS_ON (Turn ON Sensor) command is used to read the position data from the absolute encoder.

The sequence for using the SENS_ON command to read the position data from the absolute encoder of a Rotary Servomotor is given below.

The multiturn data is sent according to the transmission specifications.

The position of the absolute encoder within one rotation is output as a pulse train.



*1. When you turn OFF the control power supply, input the SENS_OFF command.

*2. The pulse output time T for the position of the absolute encoder within one rotation depends on the setting of Pn212 (Number of Encoder Output Pulses). Refer to the following table.

Setting of Pn212	Calculation of the Pulse Output Speed for the Position of the Absolute Encoder within One Rotation	Calculation of the Pulse Output Time T for the Position of the Absolute Encoder within One Rotation
16 to 16,384	680 × Pn212/16,384 [kpps]	25 ms max.
16,386 to 32,768	680 × Pn212/32,768 [kpps]	50 ms max.
32,722 to 65,536	680 × Pn212/65,536 [kpps]	100 ms max.
65,544 to 131,072	680 × Pn212/131,072 [kpps]	200 ms max.
131,088 to 262,144	680 × Pn212/262,144 [kpps]	400 ms max.
262,176 to 524,288	680 × Pn212/524,288 [kpps]	800 ms max.
524,352 to 1,048,576	680 × Pn212/1,048,576 [kpps]	1,600 ms max.

7.8.5 Transmission Specifications

The position data transmission specifications for the PAO (Encoder Divided Pulse Output) signal are given in the following table.


The PAO signal sends only the multiturn data.

Refer to the following section for the timing of sending the position data from the absolute encoder. 7.8.4 Reading the Position Data from the Absolute Encoder on page 7-34

Item	PAO signal
Synchronization Method	Start-stop synchronization (ASYNC)
Transmission Speed	9,600 bps
Start Bits	1 bit
Stop Bits	1 bit
Parity	Even
Character Code	ASCII, 7 bits
Data Format	Refer to Data Format of PAO Signal.
Data Output Period	Each time the SENS_ON command is input after the control power supply is turned ON

Data Format of PAO Signal

As shown below, the message format consists of eight characters: "P," the sign, the 5-digit multiturn data, and "CR" (which indicates the end of the message).




7.8.6 Calculating the Current Position in Machine Coordinates

When you reset the absolute encoder, the reset position becomes the reference position.

The host controller reads the coordinate Ps from the origin of the encoder coordinate system. The host controller must record the value of coordinate Ps.

This section describes the reference position in the machine coordinate system.

The method to calculate the coordinate value of the present position from the origin of the machine coordinate system is given below.



The current position P_M in the machine coordinate system is calculated as follows:

$$\begin{split} P_M &= P_E - P_S \\ P_E &= M \times R + P_O \\ P_S &= M_S \times R + P_S' \end{split}$$

7.8.7 Alarm Output from Output Ports for the Position Data from the Absolute Encoder

Symbol	Meaning
Ρ _Ε	Position data for the current position of the absolute encoder
М	Current position of the multiturn data of the absolute encoder
Po	Position of the current position within one rotation
P _S	Position data of the absolute encoder when absolute encoder was reset
M _S	Multiturn data of the absolute encoder when absolute encoder was reset
P _S '	Position of the absolute encoder within one rotation when absolute encoder was reset
P _M	Current position in machine coordinate system
R	Pulses output per encoder rotation (value after dividing; setting of Pn212)

Note: The following formulas apply in Reverse Rotation Mode (Pn000 = $n.\square\square\square1$).

$$P_{M} = P_{E} - P_{S}$$

 $P_{F} = -M \times R + P_{O}$

$$P_{\rm S} = M_{\rm S} \times R + P_{\rm S}'$$

Information

If you are using a Rotary Servomotor, you must reset the absolute encoder. Refer to the following section for information on resetting the absolute encoder.

6.16 Resetting the Absolute Encoder on page 6-47

2. You can set the origin to a different position from the reset position. Refer to the following section for information on the origin position offset.


6.17 Setting the Origin of the Absolute Encoder on page 6-50

7.8.7 Alarm Output from Output Ports for the Position Data from the Absolute Encoder

Any alarm detected by the SERVOPACK is transmitted as alarm information to the host controller with the PAO (Encoder Divided Pulse Output) signal when the SENS_ON (Turn ON Sensor) command turns OFF.

ALM signal		
Motor power status	Servo ON (Power supplied.)	Servo OFF (Power not supplied.)
Main circuit power supply	ON	OFF
Control power supply	ON	
SENS_ON command	ON	OFF
PAO signal		Alarm information


The data format of the alarm information is shown below.



7.8.8 Multiturn Limit Setting

7.8.8 Multiturn Limit Setting

The multiturn limit is used in position control for a turntable or other rotating body. For example, consider a machine that moves the turntable shown in the following diagram in only one direction.




Because the turntable moves in only one direction, the upper limit to the number of rotations that can be counted by an absolute encoder will eventually be exceeded.

The multiturn limit is used in cases like this to prevent fractions from being produced by the integer ratio of the number of Servomotor rotations and the number of turntable rotations.

For a machine with a ratio of n:m between the number of Servomotor rotations and the number of turntable rotations, as shown above, the value of m minus 1 will be the setting for the multi-turn limit setting (Pn205).

Multiturn limit (Pn205) = m - 1

If m = 100 and n = 3 (i.e., the turntable rotates three times for each 100 Servomotor rotations), the relationship between the number of Servomotor rotations and the number of turntable rotations would be as shown below.



	Multiturn Limit			Speed Position Torque	
Pn205	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 Rev	65,535	After restart	Setup

Note: This parameter is enabled when you use an absolute encoder.

The data will change as shown below when this parameter is set to anything other than the default setting.


- If the Servomotor operates in the reverse direction when the multiturn data is 0, the multiturn data will change to the value set in Pn205.
- If the motor operates in the forward direction when the multiturn data is at the value set in Pn205, the multiturn data will change to 0.

Set Pn205 to one less than the desired multiturn data.

If you change the multiturn limit in Pn205, an A.CCO alarm (Multiturn Limit Disagreement) will be displayed because the setting disagrees with the value in the encoder. Refer to the following section for the procedure to change the multiturn limit settings in the encoder.

Application Functions

7.8.9 Multiturn Limit Disagreement Alarm (A.CC0)



- When you use a single-turn absolute encoder
- When the encoder is set to be used as a single-turn absolute encoder (Pn002 = $n.\Box 2\Box \Box$) Absolute encoder-related alarms (A.810 and A.820) will not occur.

7.8.9 Multiturn Limit Disagreement Alarm (A.CC0)

If you change the multiturn limit in Pn205 (Multiturn Limit), an A.CCO alarm (Multiturn Limit Disagreement) will be displayed because the setting disagrees with the value in the encoder.

Display	Name	Meaning
A.CC0	Multiturn Limit Disagreement	Different multiturn limits are set in the encoder and SERVO- PACK.

If this alarm is displayed, use the following procedure to change the multiturn limit in the encoder to the same value as the setting of Pn205.

Applicable Tools

The following table lists the tools that you can use to set the multiturn limit.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn013	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Encoder Setting – Multi-turn Limit Setting	G Operating Procedure on page 7-39

This setting can be made with the MEM_WR (Write Memory) command. Refer to the following manual for information on the MEM_WR (Write Memory) command.

Ω Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

7.8.9 Multiturn Limit Disagreement Alarm (A.CC0)

Operating Procedure

Use the following procedure to adjust the multiturn limit setting.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Multi-turn Limit Setting in the Menu Dialog Box. The Multiturn Limit Setting Dialog Box will be displayed.
- 3. Click the Continue Button.

Multiturn Limit Setting
The position data is cleared when this function is used. Since the Multiturn (multiple rotations) limit is changed, the position data of the machine system is changed and it is very dangerous.
Do you want to continue the process?
Continue

Click the **Cancel** Button to cancel setting the multiturn limit. The Main Window will return.

4. Change the setting.

🐻 Multiturn I	.imit Setting AXIS#00			
Multiturn Limit Setting Change				
Pn205:Multituri	n Limit			
65535	[Rev] 🕨 65535 [Rev]			
	(0-65535)			
Writing into the Servopack				

- 5. Click the Writing into the Servopack Button.
- 6. Click the OK Button.

Multiturn Limit Setting
⚠
Multiturn limit value was changed. The following procedure is needed to operate with changing the Multiturn limit.
1. Close this function program.
"A.CC0.Multiturn Limit Disagreement" is occurred when the power of the Servopack (control) is cycled.
3. Select "Multiturn Limit Setting function" again.
 Set the Multiturn limit setting value to the servomotor according to the instruction of the screen.
 Cycle power again Multiturn limit change is completed, through these procedures.
OK

7

7.8.9 Multiturn Limit Disagreement Alarm (A.CC0)

7. Turn the power supply to the SERVOPACK OFF and ON again.

An A.CCO alarm (Multiturn Limit Disagreement) will occur because setting the multiturn limit in the Servomotor is not yet completed even though the setting has been changed in the SERVOPACK.

- 8. Display the Multi-turn Limit Setting in the Menu Dialog Box.
- 9. Click the Continue Button.

🕐 Multiturn Limit Setting
The position data is cleared when this function is used. Since the Multiturn (multiple rotations) limit is changed, the position data of the machine system is changed and it is very dangerous.
Do you want to continue the process?

10. Click the Writing into the Motor Button.



Click the **Re-change** Button to change the setting.

11. Click the OK Button.

Multiturn Limit Setting
Multiturn Limit Setting has been completed. Cycle (control) power. The operation can be done with the set multiturn limit from the next time when the power is turned on.
It is very dangerous to operate the machine in this state. Be sure to perform the original point re-setup of a machine system after power is turned on again.
ОК

This concludes the procedure to set the multiturn limit.

7.9.1 Connecting an Absolute Linear Encoder

7.9 Absolute Linear Encoders

The absolute linear encoder records the current position of the stop position even when the power supply is OFF.

With a system that uses an absolute linear encoder, the host controller can monitor the current position. Therefore, it is not necessary to perform an origin return operation when the power supply to the system is turned ON.

There are three types of linear encoders for Linear Servomotors. The usage of the linear encoder is specified in Pn002 = $n.\Box X \Box \Box$.

Refer to the following section for linear encoder models.

Feedback Resolution of Linear Encoder on page 6-44

· Parameter Settings When Using an Incremental Linear Encoder

Parameter		Meaning	When Enabled	Classification
Pn002	n.□0□□ (default setting)	Use the encoder as an incremental linear encoder.	After restart	Setup
	n.🗆 1 🗆 🗆	Use the encoder as an incremental linear encoder.		

· Parameter Settings When Using an Absolute Linear Encoder

Parameter		Meaning	When Enabled	Classification
Pn00	n.□0□□ (default setting)	Use the encoder as an absolute linear encoder.	After restart	Setup
	n.🗆1🗆 🗆	Use the encoder as an incremental linear encoder.		

7.9.1 Connecting an Absolute Linear Encoder

You can get the position data from the absolute linear encoder with MECHATROLINK communications. Therefore, it is not necessary to wire the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

If they need to be wired, refer to the following section.


4.4.3 Wiring the SERVOPACK to the Encoder on page 4-20

(a) 4.5.3 I/O Signal Wiring Examples on page 4-32

7.9.2 Structure of the Position Data of the Absolute Linear Encoder

The position data of the absolute linear encoder is the distance (number of pulses) from the origin of the absolute linear encoder.

The position data is signed 36-bit data.



When the SERVOPACK sends the position data, it sends the upper 16-bit data (with sign) separately from the lower 20-bit data.


7.9.3 Output Ports for the Position Data from the Absolute Linear Encoder

7.9.3 Output Ports for the Position Data from the Absolute Linear Encoder

You can read the position data of the absolute linear encoder from the PAO, PBO, and PCO (Encoder Divided Pulse Output) signals.

The output method and timing for the position data of the absolute linear encoder are different in each case.

A conceptual diagram of the connections of the PAO, PBO, and PCO (Encoder Divided Pulse Output) ports to the host controller is provided below.



Signal	Status	Signal Contents	
Olghai	Oldius	When Using an Absolute Linear Encoder	
PAO	First signal	Upper 16-bit data (with sign) Lower 20-bit data (pulse train)	
	During normal operation	Incremental pulses	
PBO	First signal	Lower 20-bit data (pulse train)	
	During normal operation	Incremental pulses	
PCO	Always	Origin pulse	

The PAO (Encoder Divided Pulse Output) signal outputs the position data from the absolute linear encoder after the control power supply is turned ON. The SENS_ON (Turn ON Sensor) command is used to output the position data from the absolute linear encoder.

The position data of the absolute linear encoder is the current stop position. The absolute linear encoder outputs the upper 16-bit data (with sign) according to the specified protocol. The absolute encoder outputs the lower 20-bit data as a pulse train. It then outputs pulses as an incremental linear encoder (incremental operation status).

The host controller must have a reception circuit (e.g., UART) for the position data from the absolute linear encoder. The pulse counter at the host controller will not count pulses when the upper 16-bit data (with sign) (communications message) is input because only phase A is input.

The output circuits for the PAO, PBO, and PCO signals use line drivers. Refer to the following section for details on line drivers.

A.5.4 I/O Circuits on page 4-34

7.9.4 Reading the Position Data from the Absolute Linear Encoder


The SENS_ON (Turn ON Sensor) command is used to read the position data from the absolute linear encoder.

The sequence for using the SENS_ON command to read the position data from the absolute linear encoder of a Linear Servomotor is given below.

The upper 16-bit position data (with sign) are sent according to the transmission specifications.

The lower 20-bit data is output as a pulse train.

7.9.5 Transmission Specifications



* When you turn OFF the control power supply, input the SENS_OFF command.

7.9.5 Transmission Specifications

The position data transmission specifications for the PAO (Encoder Divided Pulse Output) signal are given in the following table.

The PAO signal sends only the 16-bit data (with sign).


Refer to the following section for the timing of sending the position data from the absolute encoder.

Æ	7.9.4 Reading the Position Data from the Absolute Linear Encoder	on page 7-42
---	--	--------------

Item	PAO signal
Synchronization Method	Start-stop synchronization (ASYNC)
Transmission Speed	9,600 bps
Start Bits	1 bit
Stop Bits	1 bit
Parity	Even
Character Code	ASCII, 7 bits
Data Format	Refer to Data Format of PAO Signal.
Data Output Period	Each time the SENS_ON command is input after the control power supply is turned ON

Data Format of PAO Signal

As shown below, the message format consists of eight characters: "P," the sign, the 5-digit upper 15bit position data, and "CR" (which indicates the end of the message).



Upper 15 bits of position data

7.9.6 Calculating the Current Position in Machine Coordinates

7.9.6 Calculating the Current Position in Machine Coordinates

With an absolute linear encoder, you must set the position of the origin (i.e., the origin of the machine coordinate system).


The host controller reads the coordinate from the origin of the encoder coordinate system. The host controller must record the value of this coordinate.

The method to calculate the coordinate value of the present position from the origin of the machine coordinate system is given below.

The position data from the absolute linear encoder is signed 36-bit data, but the upper 16 bits (with sign) and the lower 20 bits are output separately.

For the upper 16-bit data (with sign), the upper bits (16 bits, including the sign) of the current position after dividing by the setting of Pn281 are output with serial communications according to the transmission specifications.

For the lower 20-bit data, the lower bits (20 bits) of the current position after dividing by the setting of Pn281 are output as a pulse train.



The current position P_M in the machine coordinate system is calculated as follows:

 $P_{M} = P_{E} - P_{S}$ $P_{E} = M_{O} \times R + P_{O}$ $P_{S} = M_{S} \times R + P_{S}'$

Symbol	Meaning	
P _E	Position data for the current position of the absolute linear encoder	
M _O	Upper 16 bits (with sign) of the position data for the current position of the absolute linear encoder	
Po	Lower 20 bits of the position data for the current position of the absolute linear encoder	
P _S	Position data of the origin	
M _S	Upper 16 bits (with sign) of the position data of the origin	
P _S '	Lower 20 bits of the position data of the origin	
P _M	Current position in machine coordinate system	
R	1048576 (=2 ²⁰)	

Note: The above formulas also apply in reverse movement mode (Pn000 = $n.\Box\Box\Box$ 1).

Information If you are using a Linear Servomotor, you do not need to reset the absolute linear encoder to define the origin. (Some absolute linear encoders also allow you to set any position as the origin.)


7.9.7 Alarm Output from the Output Ports for the Position Data from the Absolute Linear Encoder

7.9.7 Alarm Output from the Output Ports for the Position Data from the Absolute Linear Encoder

Any alarm detected by the SERVOPACK is transmitted as alarm information to the host controller with the PAO (Encoder Divided Pulse Output) signal when the SENS_ON (Turn ON Sensor) command turns OFF.

ALM signal		
Motor power status	Servo ON (Power supplied.)	Servo OFF (Power not supplied.)
Main circuit power supply	ON	OFF
Control power supply	ON	
SENS_ON comm	and ON	OFF
PAO signal		Alarm information

The data format of the alarm information is shown below.



7

7.10.1 Preparations

7.10 Software Reset

You can reset the SERVOPACK internally with the software. A software reset is used when resetting alarms and changing the settings of parameters that normally require turning the power supply to the SERVOPACK OFF and ON again. This can be used to change those parameters without turning the power supply to the SERVOPACK OFF and ON again.

Information 1. Al

1. Always confirm that the servo is OFF and that the Servomotor is stopped before you start a software reset.

- 2. This function resets the SERVOPACK independently of the host controller. The SERVO-PACK carries out the same processing as when the power supply is turned ON and outputs the ALM (Servo Alarm) signal. The status of other output signals may be forcibly changed.
- 3. When you execute a software reset, the SERVOPACK will not respond for approximately five seconds.

Before you execute a software reset, check the status of the SERVOPACK and Servomotor and make sure that no problems will occur.

7.10.1 Preparations

Always check the following before you perform a software reset.

- The servo must be OFF.
- The motor must be stopped.

7.10.2 Applicable Tools

The following table lists the tools that you can use to perform a software reset.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn030	Ω-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Basic Functions – Software Reset	T.10.3 Operating Procedure on page 7-47

7.10.3 Operating Procedure

There are the following two methods that you can use to perform a software reset.

- Direct connection to the SERVOPACK
- · Connection though a controller

The procedure for each method is given below.

Direct Connection to the SERVOPACK

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Software Reset in the Menu Dialog Box. The Software Reset Dialog Box will be displayed.
- 3. Click the Execute Button.

Software Reset
The software reset function resets the Servopack by using software and re-calculates all settings including parameters. Be sure to carefully read the SigmaVVin+ Operation Manual before executing this function. Special care must be taken for the following.
The Servopack will stop responding for approximately 5 seconds after the execution begins. Before executing this function, always check the Servopack and motor status to ensure safety.
Execute

Click the Cancel Button to cancel the software reset. The Main Window will return.

4. Click the Execute Button.



5. Click the OK Button to end the software reset operation.

All settings including parameters will have been re-calculated. When you finish this operation, disconnect the SigmaWin+ from the SERVOPACK, and then connect it again.

Software Reset
The software reset function has been completed. All settings including parameters were re-calculated. Always reconnect the SigmaWin+ to the Servopack after execution of this function.
OK

This concludes the procedure to reset the software.

7.10.3 Operating Procedure

Connection through a Controller

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Software Reset in the Menu Dialog Box. The Software Reset Dialog Box will be displayed.
- 3. Click the Execute Button.

Software Reset
The software reset function resets the Servopack by using software and re-calculates all settings including parameters. Be sure to carefully read the SigmaWin+ Operation Manual before executing this function. Special care must be taken for the following.
The Servopack will stop responding for approximately 5 seconds after the execution begins. Before executing this function, always check the Servopack and motor status to ensure safety.
Execute

Click the Cancel Button to cancel the software reset. The Main Window will return.

4. Select the Reset MECHATROLINK communication Check Box.

O Software Reset Common for the Unit			
The software reset function will be executed. The Servopack will stop responding for approximately 5 seconds after the fuction begins.			
Execute			
0%			
Reset MECHATROLINK communication After executing the software reset function, communication with the axis #5 will be reset.	15		

5. Click the Execute Button.



If you perform a software reset without resetting MECHATROLINK communications, a communications error will occur between the controller and SERVOPACK, and communications will no longer be possible.

Always select the **Reset MECHATROLINK communication** Check Box and reset MECHATROLINK communications as well.

6. Click the OK Button.

All settings including parameters will have been re-calculated. When you finish this operation, disconnect the SigmaWin+ from the SERVOPACK, and then connect it again.

Software Reset
The software reset function has been completed. All settings including parameters were re-calculated. Always reconnect the SigmaWin+ to the Servopack after execution of this function.
ОК

This concludes the procedure to reset the software.

7.11 Initializing the Vibration Detection Level

You can detect machine vibration during operation to automatically adjust the settings of Pn312 or Pn384 (Vibration Detection Level) to detect A.520 alarms (Vibration Alarm) and A.911 warnings (Vibration) more precisely.

This function detects specific vibration components in the Servomotor speed.

F	Parameter	Meaning	When Enabled	Classification
	n.□□□0 (default setting)	Do not detect vibration.		
Pn310	n.0001	Output a warning (A.911) if vibration is detected.	Immediately	Setup
	n.🗆 🗆 🗠 2	Output an alarm (A.520) if vibration is detected.		

If the vibration exceeds the detection level calculated with the following formula, an alarm or warning occurs according to Pn310 (Vibration Detection Selection).

Rotary Servomotors

Detection level = <u>Vibration detection level (Pn312 [min-1]) × Vibration detection sensitivity (Pn311 [%])</u> 100

Linear Servomotors

Detection level = <u>Vibration detection level (Pn384 [mm/s]) × Vibration detection sensitivity (Pn311 [%])</u>

100

Use this function only if A.520 or A.911 alarms are not output at the correct times when vibration is detected with the default vibration detection level (Pn312 or Pn384).

There will be discrepancies in the detection sensitivity for vibration alarms and warnings depending on the condition of your machine. If there is a discrepancy, use the above formula to adjust Pn311 (Vibration Detection Sensitivity).

	Vibration Detection Sensitivity			Speed Positi	on Torque
Pn311	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 500	1%	100	Immediately	Tuning

- Information 1. Vibration may not be detected because of unsuitable servo gains. Also, not all kinds of vibrations can be detected.
 - 2. Set a suitable moment of inertia ratio (Pn103). An unsuitable setting may result in falsely detecting or not detecting vibration alarms or vibration warnings.
 - 3. To use this function, you must input the actual references that will be used to operate your system.
 - 4. Execute this function under the operating conditions for which you want to set the vibration detection level.
 - 5. Execute this function while the Servomotor is operating at 10% of its maximum speed or faster.

7.11.1 Preparations

Always check the following before you initialize the vibration detection level.

- The parameters must not be write prohibited.
- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).

7.11.2 Applicable Tools

7.11.2 Applicable Tools


The following table lists the tools that you can use to initialize the vibration detection level.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn01B	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Others – Initialize Vibration Detection Level	7.11.3 Operating Procedure on page 7-50

7.11.3 Operating Procedure

Use the following procedure to initialize the vibration detection level.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Initialize Vibration Detection Level in the Menu Dialog Box. The Initialize Vibration Detection Level Dialog Box will be displayed.
- Select Pn311: Vibration Detection Sensitivity and Pn310: Vibration Detection Selections and then click the Detection Start Button. A setting execution standby mode will be entered.



7.11.3 Operating Procedure

4. Click the Execute Button.

Initialize Vibration Detection Level AXIS#00
Setting Condition
Pn311 : Vibration Detection Sensitivity (50 - 500)
100 [%]
Pn310 : Vibration Detection Selections digit 0 Vibration Detection Selection
2 : Output an alarm (A.520) if vibration is detected.
Execute
Setting Result
Pn312 : Vibration Detection Level
50 [min-1]

The newly set vibration detection level will be displayed and the value will be saved in the SERVO-PACK.

Initialize Vibration Detection Level AXIS#00					
Setting Condition					
Pn311 : Vibration Detection Sensitivity (50 - 500)					
100 . [%]					
Pn310 : Vibration Detection Selections digit 0 Vibration Detection Selection					
2 : Output an alarm (A.520) if vibration is detected.					
Setting Result					
Pn312 : Vibration Detection Level					
50 [min-1] b 50 [min-1]					
When vibration exceeds a detection level 50 [min-1], Alarm(A.520) is detected.					

This concludes the procedure to initialize the vibration detection level.

7

7.11.4 Related Parameters

7.11.4 Related Parameters

The following three items are given in the following table.

- Parameters Related to this Function
 - These are the parameters that are used or referenced when this function is executed.
- Changes during Function Execution
 Not allowed: The parameter cannot be changed using the SigmaWin+ or other tool while this
 function is being executed.
 Allowed: The parameter can be changed using the SigmaWin+ or other tool while this func tion is being executed.
- Automatic Changes after Function Execution
 Yes: The parameter is automatically set or adjusted after execution of this function.
 No: The parameter is not automatically set or adjusted after execution of this function.

Parameter	Name	Setting Changes	Automatic Changes
Pn311	Vibration Detection Sensitivity	Allowed	No
Pn312	Vibration Detection Level	Not allowed	Yes
Pn384	Vibration Detection Level	Not allowed	Yes

7.12.1 Automatic Adjustment

7.12 Adjusting the Motor Current Detection Signal Offset

The motor current detection signal offset is used to reduce ripple in the torque. You can adjust the motor current detection signal offset either automatically or manually.

7.12.1 Automatic Adjustment

Perform this adjustment only if highly accurate adjustment is required to reduce torque ripple. It is normally not necessary to adjust this offset.



Execute the automatic offset adjustment if the torque ripple is too large when compared with other SERVOPACKs.

Information The offset does not use a parameter, so it will not change even if the parameter settings are initialized.

Preparations

Always check the following before you automatically adjust the motor current detection signal offset.

- The parameters must not be write prohibited.
- The servo must be in ready status.
- The servo must be OFF.

Applicable Tools

The following table lists the tools that you can use to automatically adjust the offset.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn00E	Ω Σ-7-Series Digital Operator Operating Manual (document No. SIEP S800001 33)
SigmaWin+	Others – Adjust the Motor Current Detection Offset	Operating Procedure on page 7-53

Operating Procedure


Use the following procedure to automatically adjust the motor current detection signal offset.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Adjust the Motor Current Detection Offset in the Menu Dialog Box. The Adjust the Motor Current Detection Signal Offsets Dialog Box will be displayed.

7

7.12.1 Automatic Adjustment

3. Click the Continue Button.



4. Click the Automatic Adjustment Tab in the Adjust the Motor Current Detection Signal Offsets Dialog Box.

Adjust the Motor Current Detection Signal O						
Automatic Adjustment Manual Adjustment						
U-phase Offset -73						
V-phase Offset						
Adjust						

5. Click the Adjust Button.

The values that result from automatic adjustment will be displayed in the New Boxes.

S Adjust the Motor Current Detection Signal O					
Automatic Adjustment Manual Adjustment					
New					
U-phase Offset -73					
V-phase Offset -63					
Adjust					

This concludes the procedure to automatically adjust the motor current detection signal offset.

7.12.2 Manual Adjustment

7.12.2 Manual Adjustment

You can use this function if you automatically adjust the motor current detection signal offset and the torque ripple is still too large.

If the offset is incorrectly adjusted with this function, the Servomotor characteristics may be adversely affected.

Observe the following precautions when you manually adjust the offset.
 Operate the Servomotor at a speed of approximately 100 min⁻¹.

- Adjust the offset while monitoring the torque reference with the analog monitor until the ripple is minimized.
- Adjust the offsets for the phase-U current and phase-V current of the Servomotor so that they
 are balanced. Alternately adjust both offsets several times.

Information The offset does not use a parameter, so it will not change even if the parameter settings are initialized.

Preparations

Always check the following before you manually adjust the motor current detection signal offset.

• The parameters must not be write prohibited.

Applicable Tools


The following table lists the tools that you can use to manually adjust the offset.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn00F	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Others – Adjust the Motor Current Detection Offset	Operating Procedure on page 7-55

Operating Procedure

Use the following procedure to manually adjust the motor current detection signal offset.

- 1. Operate the Servomotor at approximately 100 min⁻¹.
- 2. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Adjust the Motor Current Detection Offset in the Menu Dialog Box. The Adjust the Motor Current Detection Signal Offsets Dialog Box will be displayed.
- 4. Click the Continue Button.



7.12.2 Manual Adjustment

5. Click the Manual Adjustment Tab in the Adjust the Motor Current Detection Signal Offsets Dialog Box.

Automatic Adjustment Manual Adjustment					
Motor Current Detection Offset					
Channel U-phase 💌					
Offset +1 (2)↑ -74 -1 (2)↓					

- 6. Set the Channel Box in the Motor Current Detection Offset Area to U-phase.
- **7.** Use the +1 and -1 Buttons to adjust the offset for phase U. Change the offset by about 10 in the direction that reduces the torque ripple. Adjustment range: -512 to +511
- 8. Set the Channel Box in the Motor Current Detection Offset Area to V-phase.
- 9. Use the +1 and -1 Buttons to adjust the offset for phase V. Change the offset by about 10 in the direction that reduces the torque ripple.
- **10.** Repeat steps 6 to 9 until the torque ripple cannot be decreased any further regardless of whether you increase or decrease the offsets.
- **11.** Reduce the amount by which you change the offsets each time and repeat steps 6 to 9.

This concludes the procedure to manually adjust the motor current detection signal offset.

7.13.1 FSTP (Forced Stop Input) Signal

7.13 Forcing the Motor to Stop

You can force the Servomotor to stop for a signal from the host controller or an external device.

To force the motor to stop, you must allocate the FSTP (Forced Stop Input) signal in Pn516 = $n.\square\square\squareX$. You can specify one of the following stopping methods: dynamic brake (DB), coasting to a stop, or decelerating to a stop.

Note: Forcing the motor to stop is not designed to comply with any safety standard. In this respect, it is different from the hard wire base block (HWBB).

Information Panel Operator and Digital Operator Displays

When a forced stop is performed, the panel and the Digital Operator will display FSTP.



• To prevent accidents that may result from contact faults or disconnections, use a normally closed switch for the Forced Stop Input signal.

7.13.1 FSTP (Forced Stop Input) Signal

Classifica- tion	Signal	Connector Pin No.	Signal Status	Description
Input	FSTP	Must be allocated.	ON (closed)	Drive is enabled (normal operation).
input			OFF (open)	The motor is stopped.

Note: You must allocate the FSTP signal to use it. Use Pn516 = n.□□□X (FSTP (Forced Stop Input) Signal Allocation) to allocate the FSTP signal to a connector pin. Refer to the following section for details.

7.1.1 Input Signal Allocations on page 7-4

7.13.2 Stopping Method Selection for Forced Stops

Use $Pn00A = n.\square\squareX\square$ (Stopping Method for Forced Stops) to set the stopping method for forced stops.

Parameter		Description	When Enabled	Classifi- cation
	n. 00 0	Apply the dynamic brake or coast the motor to a stop (use the stopping method set in Pn001 = $n.\Box\Box\BoxX$).		Setup
	n.□□1□ (default set- ting)	Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque. Use the setting of Pn001 = $n.\Box\Box\BoxX$ for the status after stopping.	After restart	
Pn00A	n.0020	Decelerate the motor to a stop using the torque set in Pn406 as the maximum torque and then let the motor coast.		
	n.0030	Decelerate the motor to a stop using the deceleration time set in Pn30A. Use the setting of Pn001 = $n.\square\square\squareX$ for the status after stopping.		
	n.0040	Decelerate the motor to a stop using the deceleration time set in Pn30A and then let the motor coast.		

Note: You cannot decelerate a Servomotor to a stop during torque control. For torque control, the Servomotor will be stopped with the dynamic braking or coast to a stop according to the setting of Pn001 = n. DDX (Motor Stopping Method for Servo OFF and Group 1 Alarms).

7.13.2 Stopping Method Selection for Forced Stops

Stopping the Servomotor by Setting Emergency Stop Torque (Pn406)

To stop the Servomotor by setting emergency stop torque, set Pn406 (Emergency Stop Torque).

If $Pn00A = n.\Box\BoxX\Box$ is set to 1 or 2, the Servomotor will be decelerated to a stop using the torque set in Pn406 as the maximum torque.

The default setting is 800%. This setting is large enough to allow you to operate the Servomotor at the maximum torque. However, the maximum emergency stop torque that you can actually use is the maximum torque of the Servomotor.

	Emergency Stop Torque			Speed Position	
Pn406	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 800	1%*	800	Immediately	Setup

* Set a percentage of the motor rated torque.


Stopping the Servomotor by Setting the Deceleration Time for Servo OFF and Forced Stops (Pn30A)

To specify the Servomotor deceleration time and use it to stop the Servomotor, set Pn30A (Deceleration Time for Servo OFF and Forced Stops).

	Deceleration Time f	or Servo OFF and Fo	Speed Position	٦	
Pn30A	Setting Range	Setting Unit Default Setting		When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup

If you set Pn30A to 0, the Servomotor will be stopped with a zero speed.

The deceleration time that you set in Pn30A is the time to decelerate the Servomotor from the maximum motor speed.




7.13.3 Resetting Method for Forced Stops

7.13.3 Resetting Method for Forced Stops

This section describes the reset methods that can be used after stopping operation for an FSTP (Forced Stop Input) signal.

If the FSTP (Forced Stop Input) signal is OFF and the SV_ON (Servo ON) command is sent, the forced stop state will be maintained even after the FSTP signal is turned ON.

Send the SV_OFF (Servo OFF) command to place the SERVOPACK in the base block (BB) state and then send the SV_ON (Servo ON) command.



7.14.1 ZONE Table and ZONE Signals

7.14 ZONE Outputs (FT64 Specification)

You can use ZONE signals to output a ZONE number to indicate when the current value is within a registered zone.

The ZONE signals (/ZONE0 to /ZONE3) are assigned to output signals (/SO1 to /SO5) on CN1.

7.14.1 ZONE Table and ZONE Signals

You can register the desired zones in the ZONE table. The ZONE table consists of settings for the ZONE numbers (ZONE), ZONE N values (ZONE N), and ZONE P values (ZONE P). You can register up to 16 zones.

The ZONE numbers identify the registered zones.

ZONE N is the lower limit of the ZONE and ZONE P is the upper limit of the ZONE. The setting conditions for ZONE N and ZONE P are given in the following table.

Setting Range	Setting Unit	Default Setting	When Enabled	
-2,147,483,648 to 2,147,483,647	Reference units	0	Immediately	

The ZONE signals indicate the ZONE number. If the current value is within a zone registered in the ZONE table, the corresponding ZONE number is output on the ZONE signals.

	ZONE Signals					
ZONE Number (ID)	ZONE N [Reference units]	ZONE P [Reference units]	/ZONE3	/ZONE2	/ZONE1	/ZONE0
0	±nnnnnnnnn	±nnnnnnnnn	0	0	0	0
1	±nnnnnnnnn	±nnnnnnnnn	0	0	0	1
2	±nnnnnnnnn	±nnnnnnnnn	0	0	1	0
3	±nnnnnnnnn	±nnnnnnnnn	0	0	1	1
4	±nnnnnnnnn	±nnnnnnnnn	0	1	0	0
5	±nnnnnnnnn	±nnnnnnnnn	0	1	0	1
6	±nnnnnnnnn	±nnnnnnnnn	0	1	1	0
7	±nnnnnnnnn	±nnnnnnnnn	0	1	1	1
8	±nnnnnnnnn	±nnnnnnnnn	1	0	0	0
9	±nnnnnnnnn	±nnnnnnnnn	1	0	0	1
10	±nnnnnnnnn	±nnnnnnnnn	1	0	1	0
11	±nnnnnnnnn	±nnnnnnnnn	1	0	1	1
12	±nnnnnnnnn	±nnnnnnnnn	1	1	0	0
13	±nnnnnnnnn	±nnnnnnnnn	1	1	0	1
14	±nnnnnnnnn	±nnnnnnnnn	1	1	1	0
15	±nnnnnnnnn	±nnnnnnnnn	1	1	1	1

Note: 1: Signal is ON (active), 0: Signal is OFF (inactive).

7.14.1 ZONE Table and ZONE Signals

ZONE Table Settings and ZONE Numbers

The relationship between the ZONE table settings and the ZONE numbers is shown below.

• ZONE N \leq ZONE P

The ZONE signals for the corresponding ZONE number is output if the current value is between ZONE N and ZONE P, inclusive (the shaded part in the following figure).



• ZONE P < ZONE N

The ZONE signals for the corresponding ZONE number is output if the current value is less than or equal to ZONE P or greater than or equal to ZONE N (the shaded parts in the following figure).



- Duplicated Settings in the ZONE Table The smaller ZONE number is output.
- ZONE N and ZONE P = 0 The ZONE number is disabled.
- When the Current Value Is Not In Any ZONE All of the ZONE signals will be OFF (0).

7.14.2 ZONE Table Settings

7.14.2 ZONE Table Settings

ZONE outputs can be used by sending the MEM_WR (Write Memory) command. Set the addresses in the following table in the MEM_WR (Write Memory) command.

Name	Address	Unit	Default Setting	Setting Range	Data Size (Bytes)
ZONE ID 0	F0040000h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 1	F0040008h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 2	F0040010h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 3	F0040018h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 4	F0040020h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 5	F0040028h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 6	F0040030h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 7	F0040038h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 8	F0040040h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 9	F0040048h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 10	F0040050h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 11	F0040058h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 12	F0040060h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 13	F0040068h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 14	F0040070h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 15	F0040078h	Reference units	0	-2,147,483,648 to 2,147,483,647	4

• ZONE Table Forward Boundary Positions (ZONE P)

• ZONE Table Reverse Boundary Positions (ZONE N)

Name	Address	Unit	Default Setting	Setting Range	Data Size (Bytes)
ZONE ID 0	F0040004h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 1	F004000Ch	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 2	F0040014h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 3	F004001Ch	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 4	F0040024h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 5	F004002Ch	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 6	F0040034h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 7	F004003Ch	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 8	F0040044h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 9	F004004Ch	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 10	F0040054h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 11	F004005Ch	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 12	F0040064h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 13	F004006Ch	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 14	F0040074h	Reference units	0	-2,147,483,648 to 2,147,483,647	4
ZONE ID 15	F004007Ch	Reference units	0	-2,147,483,648 to 2,147,483,647	4

7.14.2 ZONE Table Settings

Data Formats of the MEM_WR (Write Memory) Command

The following table gives details and setting examples for the MEM_WR (Write Memory) command.

	ronnais						
Phases in Which the Com- mand Can Be Executed		2 and 3	Command Classification	Common command	Asynchronous command		
Pro	Processing Time		Subcommand Cannot be used.		be used.		
Byte	MEM	_WR		Contents			
Dyte	Command	Response		Contents			
0	1EH	1EH					
1	WDT	RWDT					
2	CMD_CTRL	CMD_STAT					
3							
4	Reserved.	Reserved.		ddress to write in th			
5	MODE/DATA TYPE	MODE/DATA TYPE	 area and the data size to write, and write the data to tual memory. This command performs an adjustment operation that equivalent to the ADJ command of the MECHATROLINK-II-compatible profile. Confirm the completion of command execution by checking that RCMD = MEM_WR (= 1Eh) and CMD = CMD = CMD = MEM_VR (= 1Eh) and CMD = CMD =				
6	SIZE	SIZE					
7	0.22	0.22					
8	-						
9	ADDRESS	ADDRESS	CMD_STAT.CMDRDY = 1, and with ADDRESS, SIZE, MODE/DATA TYPE, and DATA.				
10			_	,			
11			in the following cas is not executed.	es, an alarm occurs	and the command		
12	-		 ADDRESS was out of range: CMD_ALM = 9h (A.94A) MODE/DATA_TYPE was out of range: CMD_ALM = 9h (A.94B) 				
13	-						
14	-		• SIZE was out of range: CMD_ALM = 9h (A.94D)				
15	-		 DATA was out of range: CMD_ALM = 9h (A.94B) The conditions for Normal Mode (0000h) were not satis- 				
16	-		fied: CMD_ALM =		(1005b) wore pet		
17	-		 The conditions for Initialize Parameters (1005h) were satisfied: CMD_ALM = Ah (A.95A). The conditions for Absolute Encoder Reset (1008h) were not satisfied: CMD_ALM = Ah (A.95A). The conditions for Autotune Motor Current Detection Signal Offset (100Eh) were not satisfied: CMD_ALM = Ah (A.95A). 				
18	-						
19	-						
20	-						
21	DATA	DATA	 The conditions for 	r Multiturn Limit Set			
22	-		 not satisfied: CMD_ALM = Ah (A.95A). Editing using the SigmaWin or Digital Operator 				
23			progress: CMD_A				
24	-		Refer to the following manual for details.				
25 26	-		\sum 2-7-Series MEC	HATROLINK-III Com	munications Stan-		
20			dard Servo Prof (Manual No.: SI	ile Command Manua	I		
27							
20	-						
	-						
30	-						
31							

Data Formats

Command Parameters

This section describes the contents of MODE/DATA_TYPE.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
MODE				DAT	A_TYPE		

MODE = 1: Volatile memory, 2: Nonvolatile memory (Nonvolatile memory is used only for common parameters.)

DATA_TYPE = 1: Byte, 2: Short, 3: Long, 4: Unsupported

SIZE: Number of data (Type is specified with DATA_TYPE.) ADDRESS: First address DATA: Read data 7.14.3 ZONE Signals 1 to 4 Outputs (/ZONE0 to /ZONE3)

Example of ZONE Output Settings

An example of setting the ZONE table forward boundary position for ZONE ID 0 to 10,000 are given below.

Example ADDRESS = F0040000H MODE/DATA_TYPE = 0x13 SIZE = 0x01 DATA = 10000 Note: The current set value can also be read using the MEM_RD command.

Command Warnings

The following table describes the contents of CMD_ALM in the MEM_RD and MEM_WR commands.

CMD_ALM	Displayed Code	Error			
	A.94A	The first address accesses an address outside the defined area.			
		Addresses that are reserved for common parameters or vendor specifications were specified.			
9h		ADDRESS is not a multiple of the size specified with DATA_TYPE.			
911	A.94B	MODE or DATA_TYPE are out of range.			
	A.94D	The first address is within the defined area, but the size specification resulted in accessing an address outside the defined area.			
		SIZE exceeded the data size of the command format.			

7.14.3 ZONE Signals 1 to 4 Outputs (/ZONE0 to /ZONE3)

The /ZONE0 to /ZONE3 signals indicate when the current value is within a zone registered in the ZONE table.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
	/ZONE0	Must be allocated.	ON (closed)	The current value is within a zone in the ZONE table and / ZONE0 is active.
	ZUNLU	indsi be allocated.	OFF (open)	The current value is not within a zone in the ZONE table or / ZONE0 is inactive.
	/70NF1	Must be allocated.	ON (closed)	The current value is within a zone in the ZONE table and / ZONE1 is active.
Outputs		Nust be anocated.	OFF (open)	The current value is not within a zone in the ZONE table or / ZONE1 is inactive.
Outputs	/ZONE2	Must be allocated.	ON (closed)	The current value is within a zone in the ZONE table and / ZONE2 is active.
			OFF (open)	The current value is not within a zone in the ZONE table or / ZONE2 is inactive.
	/ZONE3	Must be allocated.	ON (closed)	The current value is within a zone in the ZONE table and / ZONE3 is active.
			OFF (open)	The current value is not within a zone in the ZONE table or / ZONE3 is inactive.

Note: You must allocate the /ZONE0 to /ZONE3 signals to use them. Use Pn53C (ZONE Output Signal Selections 1) to allocate them to connector pins. Refer to the following sections for details.

7.14.4 nZONE Signal Output

nZONE Signal Output 7.14.4

The /nZONE signal indicates when the current value is within a zone registered in the ZONE table.

Туре	Signal	Connector Pin No.	Signal Status	Meaning
Outout	(270NE	Must be allocated	ON (closed)	The current value is within a zone registered in the ZONE table.
Output	/nZONE	Must be allocated.	OFF (open)	The current value is not within a zone registered in the ZONE table.

Note: You must allocate the /nZONE signal to use it. Use Pn53D = n. DDX (/nZONE (ZONE n Signal Output) Signal Allocation) to allocate the signal to connector pins. Refer to the following sections for details.

	ZONE Table					
ZONE Number (ID)	ZONE N [Reference Units]	ZONE P [Reference Units]	/nZONE			
0	±nnnnnnnnn	±nnnnnnnnn	1			
1	±nnnnnnnnn	±nnnnnnnnn	1			
2	±nnnnnnnnn	±nnnnnnnnn	1			
3	±nnnnnnnnn	±nnnnnnnnn	1			
4	±nnnnnnnnn	±nnnnnnnnn	1			
5	±nnnnnnnnn	±nnnnnnnnn	1			
6	±nnnnnnnnn	±nnnnnnnnn	1			
7	±nnnnnnnnn	±nnnnnnnnn	1			
8	±nnnnnnnnn	±nnnnnnnnn	1			
9	±nnnnnnnnn	±nnnnnnnnn	1			
10	±nnnnnnnnn	±nnnnnnnnn	1			
11	±nnnnnnnnn	±nnnnnnnnn	1			
12	±nnnnnnnnn	±nnnnnnnnn	1			
13	±nnnnnnnnn	±nnnnnnnnn	1			
14	±nnnnnnnnn	±nnnnnnnnn	1			
15	±nnnnnnnnn	±nnnnnnnnn	1			

7.1.2 Output Signal Allocations on page 7-6

The relationship between the ZONE table and /nZONE signal is shown in the following table.

Note: The /nZONE signal will be 0 (OFF) if both ZONE N and ZONE P are zero.

7.14.5 ZONE Output Application Example

7.14.5 **ZONE** Output Application Example


Using the ZONE Outputs as Zone Signals

The ZONE signals are output when the current value is within a zone registered in the ZONE table. The relationship between the ZONE table and ZONE signals is shown in the following table.

The ZONE table is given below.

ZONE Number (ID)	ZONE N	ZONE P
0	0	0
1	-1000	+1000
2	+99000	+101000
3	0	0
4	+199000	+201000
5	0	0
6	0	0
7	0	0
8	+299000	+301000
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0

The relationship between the operation pattern and ZONE signals is shown in the following diagrams.



7.15.1 Connecting the Overheat Protection Input (TH) Signal

7.15 Overheat Protection

Overheat protection detects an A.93B warning (Overheat Warning) and an A.862 alarm (Overheat Alarm) by monitoring the overheat protection input signal (TH) from a Yaskawa SGLFW2 Linear Servomotor or from a sensor attached to the machine.

SERVOPACKs with software version 0023 or higher support overheat protection.

When you use overheat protection, you must wire the overheat protection input (TH) signal and select overheat protection (Pn61A = $n.\Box\Box\BoxX$).

7.15.1 Connecting the Overheat Protection Input (TH) Signal

To use overheat protection, you must connect an overheat protection input (TH) signal to the SERVOPACK. This section describes the connection methods for the overheat protection input (TH) signal.

Using Overheat Protection in the Linear Servomotor

- If you use a Serial Converter Unit, connect the connector for the polarity sensor and thermostat cable of the Linear Servomotor to the Serial Converter Unit.
- If you do not use a Serial Converter Unit, connect the thermostat cable of the Linear Servomotor to CN1-5.

Using Overheat Protection for the Machine

To use overheat protection for the machine, connect the overheat protection input (an analog voltage input) from the sensor mounted to the machine to the CN1-5.

7.15.2 Overheat Protection Selections

The overheat protection function is selected with $Pn61A = n.\Box\Box\BoxX$ (Overheat Protection Selections).

Parameter		Meaning	When Enabled	Classifi- cation
	n.□□□0 (default set- ting)	Disable overheat protection.	After restart	Setup
Pn61A	n.0001	Use overheat protection in the Yaskawa Linear Servomo- tor.*		
	n.0002	Monitor a negative voltage input from a sensor attached to the machine and use overheat protection.		
	n. DDD 3	Monitor a positive voltage input from a sensor attached to		

* The SGLFW2 is the only Yaskawa Linear Servomotor that supports this function.

7.15.2 Overheat Protection Selections

Using Overheat Protection in the Yaskawa Linear Servomotor

To use the overheat protection in a Yaskawa Linear Servomotor (SGLFW2), set Pn61A to n.DDD1.

An A.93B warning (Overheat Warning) will be detected if the overheat protection input (TH) signal from the Yaskawa SGLFW2 Linear Servomotor exceeds the warning temperature.

An A.862 alarm (Overheat Alarm) will be detected if the overheat protection input (TH) signal from the Yaskawa SGLFW2 Linear Servomotor exceeds the alarm temperature.

• If the overheat protection input signal line is disconnected or short-circuited, an A.862 alarm will occur.

• If you set Pn61A to n. DDD1 (Use overheat protection in the Yaskawa Linear Servomotor), the parameters in the Servomotor are enabled and the following parameters are disabled.

- Overheat Alarm Level (Pn61B)
- Overheat Warning Level (Pn61C)
- Overheat Alarm Filter Time (Pn61D)

Monitoring the Machine's Temperature and Using Overheat Protection

Set $Pn61A = n.\square\square\squareX$ to 2 or 3 to use overheat protection for the machine.

Set the following parameters as required.

	Overheat Alarm Lev	el	Speed Positi	on Torque	
Pn61B	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 500	0.01 V	250	Immediately	Setup
	Overheat Warning L	evel	Speed Positi	on Torque	
Pn61C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1%	100	Immediately	Setup
	Overheat Alarm Filte	er Time		Speed Positi	on Torque
Pn61D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 s	0	Immediately	Setup

When Pn61A is set to n. DDD, an A.862 alarm will occur if the overheat protection input signal line is disconnected or short-circuited.
When Pn61A is set to n. DDD3, an A.862 alarm will not occur if the overheat protection input signal line is disconnected or short-circuited. To ensure safety, we recommend that you connect the external circuits so that you can use a negative voltage input for the overheat protection input (an analog voltage input).

Trial Operation and Actual Operation

8

This chapter provides information on the flow and procedures for trial operation and convenient functions to use during trial operation.

8.1	Flow	of Trial Operation8-2
	8.1.1 8.1.2	Flow of Trial Operation for Rotary Servomotors 8-2 Flow of Trial Operation for Linear Servomotors 8-4
8.2	Inspect	tions and Confirmations before Trial Operation 8-6
8.3	Trial O	peration for the Servomotor without a Load 8-7
	8.3.1 8.3.2 8.3.3	Preparations
8.4	Trial Op	peration with MECHATROLINK-III Communications 8-10
8.5	Trial Ope	eration with the Servomotor Connected to the Machine8-12
	8.5.1 8.5.2 8.5.3	Precautions8-12Preparations8-12Operating Procedure8-13
8.6	Conve	nient Function to Use during Trial Operation8-14
	8.6.1 8.6.2 8.6.3	Program Jogging8-14Origin Search8-18Test without a Motor8-20
8.7	Operat	tion Using MECHATROLINK-III Commands 8-25

8.1.1 Flow of Trial Operation for Rotary Servomotors

8.1 Flow of Trial Operation

8.1.1 Flow of Trial Operation for Rotary Servomotors

The procedure for trial operation is given below.

• Preparations for Trial Operation

Step	Meaning	Reference
1	Installation Install the Servomotor and SERVOPACK according to the installation conditions. First, operation is checked with no load. Do not connect the Servomotor to the machine.	Chapter 3 SERVOPACK Installation
2	Wiring and Connections Wire and connect the SERVOPACK. First, Servomotor operation is checked without a load. Do not connect the CN1 connector on the SERVOPACK.	Chapter 4 Wiring and Connecting SERVOPACKs
3	Confirmations before Trial Operation	8.2 Inspections and Confirmations before Trial Operation on page 8-6
4	Power ON	-
5	Resetting the Absolute Encoder This step is necessary only for a Servomotor with an absolute encoder.	6.16 Resetting the Absolute Encoder on page 6-47

8.1.1 Flow of Trial Operation for Rotary Servomotors

• Trial Operation

Step	Meaning	Reference
1	Trial Operation for the Servomotor without a Load To power supply Secure the motor flange to the machine. Do not connect the motor shaft to the load shaft.	8.3 Trial Operation for the Servomotor without a Load on page 8-7
2	Trial Operation with MECHATROLINK-III Communications CN6A, to host controller To power Supply CN1, to host controller Secure the motor flange to the machine. Do not connect the motor shaft to the load shaft.	8.4 Trial Operation with MECHATROLINK-III Communica- tions on page 8-10
3	Trial Operation with the Servomotor Con- nected to the Machine CN6A, to host controller To power Supply CN1, to host controller Secure the motor flange to the machine, and connect the motor shaft to the load shaft with a coupling or other means.	8.5 Trial Operation with the Servomotor Connected to the Machine on page 8-12

8.1.2 Flow of Trial Operation for Linear Servomotors

8.1.2 Flow of Trial Operation for Linear Servomotors

The procedure for trial operation is given below.

• Preparations for Trial Operation

Step		Meaning			Reference	
1	Installation Install the Servomotor and SERVOPACK according to the installation conditions. First, operation is checked with no load. Do not connect the Servomotor to the machine.			Chapt	er 3 SERVOPACK Installation	
2	Wiring and Connections Wire and connect the SERVOPACK. First, Servomotor operation is checked without a load. Do not connect the CN1 connector on the SERVOPACK.			Chapt	er 4 Wiring and Connecting SER	VOPACKs
3	Confirm	ations before Trial Ope	ration		spections and Confirmations before on page 8-6	ore Trial Operation
4	Power (NC		_		
	Setting Parameters in the SERVOPACK Step No. of Parameter to Description			on	Remarks	Reference
	5-1	Pn282	Linear Encoder Scale Pitch		Set this parameter only if you are using a Serial Converter Unit.	page 6-16
	5-2	_	Writing Parameter to the Linear Serve motor		Set this parameter only if you are not using a Serial Converter Unit.	page 6-17
5	5-3	Pn080 = n. □□ X □	Motor Phase Sequence Selec- tion		_	page 6-21
	5-4	Pn080 = n. □□□ X	Polarity Senso Selection	or	_	page 6-23
	5-5	_	Polarity Detection		This step is necessary only for a Linear Servomotor without a Polarity Sensor.	page 6-24
	5-6	Pn50A = n.X□□□ and Pn50B = n.□□□X	Overtravel Sig Allocations	nal	_	page 6-27
	5-7	Pn483, Pn484	Force Control		-	page 7-27
6	Setting Encode	the Origin of the Absolu	ute Linear	6.17.2	Setting the Origin of the Absolut page 6-50	te Linear Encoder on
	Elicoder					

8.1.2 Flow of Trial Operation for Linear Servomotors

• Trial Operation

Step	Meaning	Reference
1	Trial Operation for the Servomotor without a Load	8.3 Trial Operation for the Servomotor without a Load on page 8-7
2	Trial Operation with MECHATROLINK-III Communications	8.4 Trial Operation with MECHATROLINK-III Communica- tions on page 8-10
3	Trial Operation with the Servomotor Con- nected to the Machine CN6A, to host controller To power supply CN1, to host controller	8.5 Trial Operation with the Servomotor Connected to the Machine on page 8-12


8.2 Inspections and Confirmations before Trial Operation

To ensure safe and correct trial operation, check the following items before you start trial operation.

- Make sure that the SERVOPACK and Servomotor are installed, wired, and connected correctly.
- Make sure that the correct power supply voltage is supplied to the SERVOPACK.
- Make sure that there are no loose parts in the Servomotor mounting.
- If you are using a Servomotor with an Oil Seal, make sure that the oil seal is not damaged. Also make sure that oil has been applied.
- If you are performing trial operation on a Servomotor that has been stored for a long period of time, make sure that all Servomotor inspection and maintenance procedures have been completed.

Refer to the manual for your Servomotor for Servomotor maintenance and inspection information.

• If you are using a Servomotor with a Holding Brake, make sure that the brake is released in advance. To release the brake, you must apply the specified voltage of 24 VDC to the brake. A circuit example for trial operation is provided below.



8.3.1 Preparations

8.3 Trial Operation for the Servomotor without a Load

You use jogging for trial operation of the Servomotor without a load.

Jogging is used to check the operation of the Servomotor without connecting the SERVOPACK to the host controller. The Servomotor is moved at the preset jogging speed.



• During jogging, the overtravel function is disabled. Consider the range of motion of your machine when you jog the Servomotor.

Ìmportar

The tuning-less function is enabled as the default setting. If the tuning-less function is enabled, gain may increase and vibrations may occur with no load. If vibrations occur, disable the tuning-less function (Pn170=n.□□□0).

8.3.1 Preparations

Always check the following before you execute jogging.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.
- The jogging speed must be set considering the operating range of the machine. The jogging speed is set with the following parameters.
 - Rotary Servomotors

	Jogging Speed			Speed Position Torque		
Pn304	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 min⁻¹	500	Immediately	Setup	
	Soft Start Acceleration Time Speed					
Pn305	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 ms	0	Immediately	Setup	
	Soft Start Decele	ration Time	Speed			
Pn306	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 ms	0	Immediately	Setup	

Linear Servomotors

	Jogging Speed			Speed Position Force	
Pn383	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 mm/s	50	Immediately	Setup
	Soft Start Acceleration Time			Speed	
Pn305	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup
	Soft Start Deceleration Time Speed				
Pn306	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	0	Immediately	Setup

8.3.2 Applicable Tools

8.3.2 Applicable Tools

The following table lists the tools that you can use to perform jogging.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn002	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Operation – Jog	S Operating Procedure on page 8-8


8.3.3 Operating Procedure

Use the following procedure to jog the motor.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select JOG Operation in the Menu Dialog Box. The Jog Operation Dialog Box will be displayed.
- 3. Read the warnings and then click the OK Button.



4. Check the jogging speed and then click the Servo ON Button.



The display in the Operation Area will change to Servo ON.

Information To change the speed, click the Edit Button and enter the new speed.

8.3.3 Operating Procedure

5. Click the Forward Button or the Reverse Button.

Jogging will be performed only while you hold down the mouse button.

JOG Operation AXIS#00 JOG Speed Setting	
Pn304 : Jogging Speed	[min-1] Edit
Operation	Servo OFF
Forward	Reverse

6. After you finish jogging, turn the power supply to the SERVOPACK OFF and ON again.

This concludes the jogging procedure.

8.4 Trial Operation with MECHATROLINK-III Communications

A trial operation example for MECHATROLINK-III communications is given below.

Refer to the following manual for command details.

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

1. Confirm that the wiring is correct, and then connect the I/O signal connector (CN1 connector).

Refer to the following chapter for details on wiring. Chapter 4 Wiring and Connecting SERVOPACKs

2. Turn ON the power supplies to the SERVOPACK and host controller.

If control power is being supplied correctly, the PWR indicator on the SERVOPACK will light. If main circuit power is being supplied correctly, the CHARGE indicator on the SERVOPACK will light. If communications are established, the L1 or L2 indicators, whichever one corresponds to the CN6A or CN6B connector where the MECHATROLINK-III cable is connected, will light. If the L1 or L2 indicator does not light, recheck the settings of MECHATROLINK-III setting switches (S1, S2, and S3) and then turn the power supply OFF and ON again.

3. Send the CONNECT command from the host controller.

If the SERVOPACK correctly receives the CONNECT command, the CN indicator will light. If the CN indicator does not light, the settings of the CONNECT command are not correct. Correct the settings of the CONNECT command, and then send it from the host controller again.

4. Confirm the product model with the ID_RD command.

The SERVOPACK will return the product model (example: SGD7S-1R9D30B).

5. Set the following items, which are necessary for trial operation.

Setting	Reference	
Electronic Gear	6.15 Electronic Gear Settings on page 6-42	
Motor Direction	6.5 Motor Direction Setting on page 6-15	
Overtravel	6.11 Overtravel and Related Settings on page 6-27	

6. Save the settings that you made in step 5.

If the settings are saved in the host controller, use the SVPRM_WR command with the mode set to RAM to save them.

If the settings are saved in the SERVOPACK, use the SVPRM_WR command with the mode set to non-volatile memory to save them.

7. Send the CONFIG command to enable the settings.

8. Send the SENS_ON command to obtain the position information (encoder ready).

9. Send the SV_ON command.

Servomotor operation will be enabled and the SERVOPACK will return 1 for SVON (power supplied to motor) in the status.

10. Operate the Servomotor at low speed.

Operating Example for a Positioning Command Command: POSING Command settings: Positioning position = 10,000 (If you are using an absolute encoder, add 10,000 to the present position), rapid traverse speed = 400.

11. While operation is in progress for step 10, confirm the following items.

Confirmation Item	Reference
Confirm that the rotational direction of the Servomotor agrees with the forward or reverse reference. If they do not agree, cor- rect the rotation direction of the Servomo- tor.	6.5 Motor Direction Setting on page 6-15
Confirm that no abnormal vibration, noise, or temperature rise occurs. If any abnor- malities are found, implement corrections.	13.5 Troubleshooting Based on the Operation and Condi- tions of the Servomotor on page 13-61

Note: If the load machine is not sufficiently broken in before trial operation, the Servomotor may become overloaded.

8.5.1 Precautions

8.5 Trial Operation with the Servomotor Connected to the Machine

This section provides the procedure for trial operation with both the machine and Servomotor.

8.5.1 Precautions

🗥 WARNING

• Operating mistakes that occur after the Servomotor is connected to the machine may not only damage the machine, but they may also cause accidents resulting in personal injury.



If you disabled the overtravel function for trial operation of the Servomotor without a load, enable the overtravel function (P-OT and N-OT signal) before you preform trial operation with the Servomotor connected to the machine in order to provide protection.

If you will use a holding brake, observe the following precautions during trial operation.

- Before you check the operation of the brake, implement measures to prevent vibration from being caused by the machine falling due to gravity or an external force.
- First check the Servomotor operation and brake operation with the Servomotor uncoupled from the machine. If no problems are found, connect the Servomotor to the machine and perform trial operation again.

Control the operation of the brake with the /BK (Brake) signal output from the SERVOPACK.

Refer to the following sections for information on wiring and the related parameter settings. 3 4.4.4 Wiring the SERVOPACK to the Holding Brake on page 4-27

■ 6.12 Holding Brake on page 6-32



Failures caused by incorrect wiring or incorrect voltage application in the brake circuit may cause the SERVOPACK to fail, damage the SERVOPACK, damage the equipment, or cause an accident resulting in death or injury.

Observe the precautions and instructions for wiring and trial operation precisely as described in this manual.

8.5.2 Preparations


Always confirm the following before you perform the trial operation procedure for both the machine and Servomotor.

- Make sure that the procedure described in 8.4 Trial Operation with MECHATROLINK-III Communications on page 8-10 has been completed.
- Make sure that the SERVOPACK is connected correctly to both the host controller and the peripheral devices.
 - Safety Function Wiring
 - If you are not using the safety function, leave the Safety Jumper Connector (provided as an accessory with the SERVOPACK) connected to CN8.
 - If you are using the safety function, remove the Safety Jumper Connector from CN8 and connect the safety function device.
 - Overtravel wiring
 - Brake wiring
 - Allocation of the /BK (Brake) signal to a pin on the I/O signal connector (CN1)
 - Emergency stop circuit wiring
 - Host controller wiring

8.5.3 Operating Procedure

8.5.3 Operating Procedure

- **1.** Enable the overtravel signals.
- 2. Make the settings for the protective functions, such as the safety function, overtravel, and the brake.
 - 4.6 Connecting Safety Function Signals on page 4-36
 - 6.11 Overtravel and Related Settings on page 6-27
 - 3 6.12 Holding Brake on page 6-32
- **3.** Turn OFF the power supplies to the SERVOPACK. The control power supply and main circuit power supply will turn OFF.
- 4. Couple the Servomotor to the machine.



- 5. Turn ON the power supplies to the machine and host controller and turn ON the control power supply and main circuit power supply to the SERVOPACK.
- 6. Check the protective functions, such overtravel and the brake, to confirm that they operate correctly.

Note: Enable activating an emergency stop so that the Servomotor can be stopped safely should an error occur during the remainder of the procedure.

- 7. Perform trial operation according to 8.4 Trial Operation with MECHATROLINK-III Communications on page 8-10 and confirm that the same results are obtained as when trial operation was performed on the Servomotor without a load.
- 8. If necessary, adjust the servo gain to improve the Servomotor response characteristics. The Servomotor and machine may not be broken in completely for the trial operation. Therefore, let the system run for a sufficient amount of time to ensure that it is properly broken in.
- 9. For future maintenance, save the parameter settings with one of the following methods.
 - Use the SigmaWin+ to save the parameters as a file.
 - Use the Parameter Copy Mode of the Digital Operator.
 - Record the settings manually.

This concludes the procedure for trial operation with both the machine and Servomotor.

8.6 Convenient Function to Use during Trial Operation

This section describes some convenient operations that you can use during trial operation. Use them as required.

8.6.1 **Program Jogging**

You can use program jogging to perform continuous operation with a preset operation pattern, travel distance, movement speed, acceleration/deceleration time, waiting time, and number of movements.

You can use this operation when you set up the system in the same way as for normal jogging to move the Servomotor without connecting it to the host controller in order to check Servomotor operation and execute simple positioning operations.

Preparations

Always check the following before you execute program jogging.


- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.
- The range of machine motion and the safe movement speed of your machine must be considered when you set the travel distance and movement speed.
- There must be no overtravel.

Additional Information

- You can use the functions that are applicable to position control. However, parameters related to motion control through MECHATROLINK communications (i.e., Pn800 and higher) are disabled.
- The overtravel function is enabled.


Program Jogging Operation Pattern

An example of a program jogging operation pattern is given below. In this example, the Servomotor direction is set to $Pn000 = n.\Box\Box\Box\Box$ (Use CCW as the forward direction).



Continued on next page.

Continued from previous page.



Information If Pn530 is set to n. DDD0, n. DDD1, n. DDD4, or n. DDD5, you can set Pn536 (Program Jogging Number of Movements) to 0 to perform infinite time operation. You cannot use infinite time operation if Pn530 is set to n. DDD2 or n. DDD3. If you perform infinite time operation from the Digital Operator, press the **JOG/SVON** Key to turn OFF the servo to end infinite time operation.

Related Parameters

Use the following parameters to set the program jogging operation pattern. Do not change the settings while the program jogging operation is being executed.

Rotary Servomotors

	Program Jogging-R	elated Selections		Speed Posit	ion Torque	
Pn530	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0000 to 0005	_	0000	Immediately	Setup	
	Program Jogging Travel Distance		Speed Posit	Speed Position Torque		
Pn531	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	1 to 1,073,741,824	1 reference unit	32,768	Immediately	Setup	
	Program Jogging M	ovement Speed		Speed Po	sition Torque	
Pn533	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	1 to 10,000	1 min ⁻¹	500	Immediately	Setup	
	Program Jogging Acceleration/Deceleration Time			Speed Posit	Speed Position Torque	
Pn534	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	2 to 10,000	1 ms	100	Immediately	Setup	
	Program Jogging W	Program Jogging Waiting Time		Speed Posit	ion Torque	
Pn535	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 ms	100	Immediately	Setup	
	Program Jogging N	rogram Jogging Number of Movements		Speed Position Torque		
Pn536	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 1,000	1	1	Immediately	Setup	

Linear Servomotors

	Program Jogging-R	elated Selections		Speed Pc	sition Force
Pn530	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0000 to 0005	_	0000	Immediately	Setup
	Program Jogging Travel Distance		Speed Pc	Speed Position Force	
Pn531	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 1,073,741,824	1 reference unit	32,768	Immediately	Setup
	Program Jogging M	ovement Speed		Speed Pc	sition Force
Pn585	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 10,000	1 mm/s	50	Immediately	Setup
	Program Jogging Acceleration/Deceleration Time			Speed Pc	sition Force
Pn534	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	2 to 10,000	1 ms	100	Immediately	Setup
	Program Jogging Waiting Time		Speed Pc	sition Force	
Pn535	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 ms	100	Immediately	Setup
	Program Jogging N	umber of Movemer	nts	Speed Pc	sition Force
Pn536	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	1	1	Immediately	Setup

Applicable Tools


The following table lists the tools that you can use to perform program jogging.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn004	$ \bigoplus_{\substack{\Sigma-7-\text{Series Digital Operator Operating Manual} \\ (Manual No.: SIEP S800001 33) } $
SigmaWin+	Operation – Program JOG Operation	Gerating Procedure on page 8-17


Operating Procedure

Use the following procedure for a program jog operation.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select JOG Program in the Menu Dialog Box. The Jog Program Dialog Box will be displayed.
- 3. Read the warnings and then click the OK Button.




4. Set the operating conditions, click the **Apply** Button, and then click the **Run** Button. A graph of the operation pattern will be displayed.



8.6.2 Origin Search

5. Click the Servo ON Button and then the Execute Button. The program jogging operation will be executed.



- Be aware of the following points if you cancel the program jogging operation while the Servomotor is operating.
 - If you cancel operation with the **Servo OFF** Button, the Servomotor will stop according to setting of the Servo OFF stopping method (Pn001 = n.□□□X).
 - If you cancel operation with the **Cancel** Button, the Servomotor will decelerate to a stop and then enter a zero-clamped state.

This concludes the program jogging procedure.

8.6.2 Origin Search


The origin search operation positions the motor to the origin within one rotation and the clamps it there.



 Make sure that the load is not coupled when you execute an origin search. The Forward Drive Prohibit (P-OT) signal and Reverse Drive Prohibit (N-OT) signal are disabled during an origin search.

Use an origin search when it is necessary to align the origin within one rotation with the machine origin. The following speeds are used for origin searches.

- Rotary Servomotors: 60 min⁻¹
- Linear Servomotors: 15 mm/s



8.6.2 Origin Search

Preparations

Always check the following before you execute an origin search.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.

Applicable Tools

The following table lists the tools that you can use to perform an origin search.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn003	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+*	Encoder Setting – Search Origin	G Operating Procedure on page 8-19

* Cannot be used when connecting a Linear Servomotor.


Operating Procedure

Use the following procedure to perform an origin search.

- 1. Click the 🔎 Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Search Origin in the Menu Dialog Box. The Origin Search Dialog Box will be displayed.
- 3. Read the warnings and then click the OK Button.



4. Click the Servo ON Button.



5. Click the Forward Button or the Reverse Button.


An origin search will be performed only while you hold down the mouse button. The motor will stop when the origin search has been completed.

🎳 Origin Search AXIS#00
Status
Origin Search Not Executed
Operation
Servo ON
Forward Reverse

This concludes the origin search procedure.

8.6.3 Test without a Motor

A test without a motor is used to check the operation of the host controller and peripheral devices by simulating the operation of the Servomotor in the SERVOPACK, i.e., without actually operating a Servomotor. This test allows you to check wiring, debug the system, and verify parameters to shorten the time required for setup work and to prevent damage to the machine that may result from possible malfunctions. The operation of the Servomotor can be checked with this test regardless of whether the Servomotor is actually connected or not.



Use $PnOOC = n.\Box\Box\BoxX$ to enable or disable the test without a motor.

Parameter		Meaning	When Enabled	Classification
Pn00C	n.□□□0 (default setting)	Disable tests without a motor.	After restart	Setup
	n.□□□1	Enable tests without a motor.		

Information An asterisk is displayed on the status display of the Digital Operator while a test without a motor is being executed.

Motor Information and Encoder Information

The motor and encoder information is used during tests without a motor. The source of the information depends on the device connection status.

Rotary Servomotor

Motor Connection Status	Information That Is Used	Source of Information
Connected	Motor information Rated motor speed Maximum motor speed 	Information in the Servomotor that is connected
Connected	Encoder information Encoder resolution Encoder type 	
Not connected	Motor information • Rated motor speed • Maximum motor speed	 Setting of Pn000 = n.X□□□ (Rotary/Linear Servomotor Startup Selection When Encoder Is Not Connected) Rated motor speed and maximum motor speed The values previously saved in the SERVOPACK will be used for the rated motor speed and maximum motor speed. Use the motor displays (Un020: Rated Motor Speed and Un021: Maximum Motor Speed) to check the values.
	Encoder information Encoder resolution Encoder type 	 Encoder resolution: Setting of Pn00C = n. \[\D]X\[D]X\[D] (Encoder Resolution for Tests without a Motor) Encoder type: Setting of Pn00C = n. \[D]X\[D]\[D]\[C](Encoder Type Selection for Tests without a Motor)

If you use fully-closed loop control, the external encoder information is also used.

External Encoder Connection Status	Information That Is Used	Source of Information
Connected	External encoder infor- mation	Information in the external encoder that is con- nected
Not connected	ResolutionEncoder type	Resolution: 256Encoder type: Incremental encoder

Linear Servomotors

Motor Connection Status	Information That Is Used	Source of Information			
	Motor information	Information in the motor that is connected			
Connected	Connected Linear encoder informa- tion • Resolution • Encoder pitch • Encoder type				
	Motor information	Setting of Pn000 = n.XDDD (Rotary/Linear Servomotor Startup Selection When Encoder Is Not Connected)			
Not connected	Linear encoder informa- tion • Resolution • Encoder pitch • Encoder type	 Resolution: 256 Encoder pitch: Setting of Pn282 (Linear Encoder Scale Pitch) Encoder type: Setting of Pn00C = n. IXIII (Encoder Type Selection for Tests without a Motor) 			

Related Parameters

Parameter		Meaning			When Enabled		Classification	
	n.0□□□ (default setting)	When an encoder is not connected, start as SERVOPACK for Rotary Servomotor.			After restart		Setup	
1 11000	n.1000	When an encoder is not connected, start as SERVOPACK for Linear Servomotor.						
	Linear Encoder S	Scale Pitch			Speed Posi		tion Force	
Pn282	Setting Range	Setting Unit	Default Setting	Whe	en Enabled	0	Classification	
	0 to 6,553,600	0.01 µm	0	Aft	fter restart		Setup	
P	arameter	Meaning			When Enabled		Classification	
	n.□□0□ (default setting)	Use 13 bits as encoder resolution for tests without a motor.			- After restart		Setup	
	n.0010	Use 20 bits as encoder resolution for tests without a motor.						
Pn00C	n.🗆 🗆 2 🗆	Use 22 bits as encoder resolution for tests without a motor.						
PHOUC	n.🗆 🗆 3 🗆	Use 24 bits as encoder resolution for tests without a motor.						
	n.□0□□ (default setting)	Use an incremental e a motor.	Use an incremental encoder for tests without a motor.					
	n.0100	Use an absolute encoder for tests without a motor.			1			

Motor Position and Speed Responses

For a test without a motor, the following responses are simulated for references from the host controller according to the gain settings for position or speed control.

- Servomotor position
- Motor speed
- External encoder position

The load model will be for a rigid system with the moment of inertia ratio that is set in Pn103.

Restrictions

The following functions cannot be used during the test without a motor.

- Regeneration and dynamic brake operation
- Brake output signal
- Items marked with " $\!\times\!\!$ " in the following utility function table

SigmaWin+		Digital Operator		Execu	Executable?		
Button in Menu Dialog Box	SigmaWin+ Function Name	Fn No.	Utility Function Name	Motor Not Connected	Motor Connected	Reference	
	Initialize *1	Fn005	Initializing Parameters	0	0	page 6-10	
	Software Reset	Fn030	Software Reset	0	0	page 7-46	
		Fn011	Display Servomotor Model	0	0		
Basic Functions		Fn012	Display Software Ver- sion	0	0		
	Product Information	Fn01E	Display SERVOPACK and Servomotor IDs	0	0	page 10-2	
		Fn01F	Display Servomotor ID from Feedback Option Module	0	0		
	Reset Absolute Encoder	Fn008	Reset Absolute Encoder	×	0	page 6-47	
Encoder	Multi-turn Limit Setup	Fn013	Multiturn Limit Setting after Multiturn Limit Disagreement Alarm	×	0	page 7-38	
Setting	Search Origin ^{*2}	Fn003	Origin Search	0	0	page 8-18	
	Zero Point Position Setting	Fn020	Set Absolute Linear Encoder Origin	×	0	page 6-50	
	Polarity Detection	Fn080	Polarity Detection	×	×	page 6-26	
		Fn000	Display Alarm History	0	0	page 13-45	
	Display Alarm	Fn006	Clear Alarm History	0	0	page 13-46	
Trouble- shooting		Fn014	Reset Option Module Configuration Error	0	0	page 13-47	
	Reset Motor Type Alarm	Fn021	Reset Motor Type Alarm	0	0	page 13-49	
	Jog	Fn002	Jog	0	0	page 8-7	
Operation	Program JOG Opera- tion	Fn004	Jog Program	0	0	page 8-14	
	Tuning - Autotuning without Host Reference	Fn201	Advanced Autotuning without Reference	×	×	page 9-24	
	Tuning - Autotuning with Host Reference	Fn202	Advanced Autotuning with Reference	×	×	page 9-35	
Tuning	Tuning - Custom Tuning	Fn203	One-Parameter Tuning	×	×	page 9-42	
Tuning	Tuning - Custom Tun- ing - Adjust Anti-res- onance Control	Fn204	Adjust Anti-resonance Control	×	×	page 9-51	
	Tuning - Custom Tun- ing - Vibration Sup- pression	Fn205	Vibration Suppression	×	×	page 9-56	
	Response Level Set- ting	Fn200	Tuning-less Level Set- ting	×	×	page 9-12	
Diagnostic	Easy FFT	Fn206	Easy FFT	×	× Continued or	page 9-99	

8

Continued on next page.

	Continued from previous page.						
SigmaWin+		Digital Operator		Executable?			
Button in Menu Dialog Box	SigmaWin+ Function Name	Fn No.	Utility Function Name	Motor Not Connected	Motor Connected	Reference	
	Adjust the Analog	Fn00C	Adjust Analog Monitor Output Offset	0	0		
	Monitor Output	Fn00D	Adjust Analog Monitor Output Gain	0	0	page 10-9	
Othere	Adjust the Motor Cur- rent Detection Offsets	Fn00E	Autotune Motor Cur- rent Detection Signal Offset	×	0	2222 7 52	
Others		Fn00F	Manually Adjust Motor Current Detection Sig- nal Offset	×	0	page 7-53	
	Initialize Vibration Detection Level	Fn01B	Initialize Vibration Detection Level	×	×	page 7-49	
	Write Prohibited Set- ting	Fn010	Write Prohibition Set- ting	0	0	page 6-7	

*1. An Initialize Button will be displayed in the Parameter Editing Dialog Box.*2. Cannot be used when connecting a Linear Servomotor.

8.7 Operation Using MECHATROLINK-III Commands

Refer to the following manual for information on MECHATROLINK-III commands. Ω Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

Tuning

This chapter provides information on the flow of tuning, details on tuning functions, and related operating procedures.

9.1	Over	iew and Flow of Tuning
9.1	Overv	Tew and Flow of Turning
	9.1.1 9.1.2	Tuning Functions9-5Diagnostic Tool9-6
9.2	Monit	oring Methods9-7
9.3	Preca	utions to Ensure Safe Tuning9-8
	9.3.1 9.3.2 9.3.3 9.3.4	Overtravel Settings 9-8 Torque Limit Settings 9-8 Setting the Position Deviation Overflow Alarm Level 9-8 Vibration Detection Level Setting 9-10 Setting the Position Deviation Overflow
	9.3.5	Setting the Position Deviation Overflow Alarm Level at Servo ON
9.4	Tuning	g-less Function
	9.4.1 9.4.2 9.4.3 9.4.4 9.4.5 9.4.6	Application Restrictions9-12Operating Procedure9-13Troubleshooting Alarms9-14Parameters Disabled by Tuning-less Function9-15Automatically Adjusted Function Setting9-15Related Parameters9-15
9.5	Estim	ating the Moment of Inertia9-16
	9.5.1 9.5.2 9.5.3 9.5.4	Outline9-16Restrictions9-16Applicable Tools9-17Operating Procedure9-17

9.6	Autot	uning without Host Reference9-24
	9.6.1 9.6.2 9.6.3 9.6.4 9.6.5	Outline
	9.6.6 9.6.7	Automatically Adjusted Function Settings
9.7	Autot	uning with a Host Reference 9-35
	9.7.1 9.7.2 9.7.3 9.7.4 9.7.5 9.7.6 9.7.7	Outline.9-35Restrictions.9-36Applicable Tools.9-36Operating Procedure.9-36Troubleshooting Problems in Autotuningwith a Host Reference.9-40Automatically Adjusted Function Settings.9-41Related Parameters.9-41
9.8	Custo	om Tuning9-42
	9.8.1 9.8.2 9.8.3 9.8.4 9.8.5 9.8.6 9.8.7	Outline.9-42Preparations.9-42Applicable Tools.9-43Operating Procedure.9-43Automatically Adjusted Function Settings.9-49Tuning Example for Tuning Mode 2 or 3.9-49Related Parameters.9-50
9.9	Anti-F	Resonance Control Adjustment 9-51
	9.9.1 9.9.2 9.9.3 9.9.4 9.9.5 9.9.6	Outline.9-51Preparations.9-51Applicable Tools.9-52Operating Procedure.9-52Related Parameters.9-54Suppressing Different Vibration Frequencieswith Anti-resonance Control.9-54
9.10	Vibrat	tion Suppression9-56
	9.10.1 9.10.2 9.10.3 9.10.4 9.10.5 9.10.6	Outline
9.11	Speed	d Ripple Compensation
	9.11.1 9.11.2 9.11.3	Outline

9.12	Addit	ional Adjustment Functions9-66
	9.12.1 9.12.2 9.12.3 9.12.4 9.12.5 9.12.6 9.12.7 9.12.8	Gain Switching9-66Friction Compensation9-70Gravity Compensation9-72Current Control Mode Selection9-74Current Gain Level Setting9-74Speed Detection Method Selection9-75Speed Feedback Filter9-75Backlash Compensation9-75
9.13	Manu	al Tuning9-82
	9.13.1 9.13.2	Tuning the Servo Gains9-82Compatible Adjustment Functions9-93
9.14	Diagn	ostic Tools9-97
	9.14.1 9.14.2	Mechanical Analysis


9.1 Overview and Flow of Tuning

Tuning is performed to optimize response by adjusting the servo gains in the SERVOPACK.

The servo gains are set using a combination of parameters, such as parameters for the speed loop gain, position loop gain, filters, friction compensation, and moment of inertia ratio. These parameters influence each other, so you must consider the balance between them.

The servo gains are set to stable settings by default. Use the various tuning functions to increase the response even further for the conditions of your machine.

The basic tuning procedure is shown in the following flowchart. Make suitable adjustments considering the conditions and operating requirements of your machine.



* If possible, perform autotuning with a host reference.

If a host controller is not available, set an operation pattern that is as close as possible to the host reference and perform autotuning without a host reference.

If an operation pattern that is close to the host reference is not possible, perform autotuning with a host reference while performing program jogging.

9.1.1 Tuning Functions

9.1.1 Tuning Functions

Tuning Function	Outline	Applicable Con- trol Methods	Reference	
Tuning-less Function	This automatic adjustment function is designed to enable stable operation without servo tuning. This function can be used to obtain a stable response regardless of the type of machine or changes in the load. You can use it with the default settings.	Speed control or position control	page 9-12	
Moment of Inertia Estimation	The moment of inertia ratio is calculated by operat- ing the Servomotor a few times. The moment of inertia ratio that is calculated here is used in other tuning functions.	Speed control, position control, or torque control	page 9-16	
Autotuning without Host ReferenceThe following parameters are automatically adjusted in the internal references in the SERVO- PACK during automatic operation.• Gains (e.g., position loop gain and speed loop gain)• Filters (torque reference filter and notch filters) • Friction compensation • Anti-resonance control • Vibration suppression		Speed control or position control	page 9-24	
Autotuning with Host Reference	 The following parameters are automatically adjusted with the position reference input from the host controller while the machine is in operation. You can use this function for fine-tuning after you perform autotuning without a host reference. Gains (e.g., position loop gain and speed loop gain) Filters (torque reference filter and notch filters) Friction compensation Anti-resonance control Vibration suppression 	Position control	page 9-35	
Custom Tuning	 The following parameters are adjusted with the position reference or speed reference input from the host controller while the machine is in operation. Gains (e.g., position loop gain and speed loop gain) Filters (torque reference filter and notch filters) Friction compensation Anti-resonance control 	Speed control or position control	page 9-42	
Anti-resonance Control Adjustment	This function effectively suppresses continuous vibration.	Speed control or position control	page 9-51	
Vibration Suppression			page 9-56	
Speed Ripple Com- pensation	This function reduces the ripple in the motor speed.	Speed control, position control, or torque control	page 9-60	
Additional Adjustment Function	tuning. You can use it to improve adjustment		page 9-66	
Manual Tuning	You can manually adjust the servo gains to adjust the response.	Speed control, position control, or torque control	page 9-82	

The following table provides an overview of the tuning functions.

9.1.2 Diagnostic Tool

9.1.2 Diagnostic Tool

You can use the following tools to measure the frequency characteristics of the machine and set notch filters.

Diagnostic Tool	Outline	Applicable Control Methods	Reference
Mechanical Analysis	The machine is subjected to vibration to detect resonance frequencies. The measurement results are displayed as waveforms or numeric data.	Speed control, position control, or torque control	page 9-97
Easy FFT	The machine is subjected to vibration to detect resonance frequencies. The measurement results are displayed only as numeric data.	Speed control, position control, or torque control	page 9-99

9.2 Monitoring Methods

You can use the data tracing function of the SigmaWin+ or the analog monitor signals of the SERVOPACK for monitoring. If you perform custom tuning or manual tuning, always use the above functions to monitor the machine operating status and SERVOPACK signal waveform while you adjust the servo gains.

Check the adjustment results with the following response waveforms.

• Position Control

Item	Unit		
nem	Rotary Servomotor	Linear Servomotor	
Torque reference	%		
Feedback speed	min ⁻¹ mm/s		
Position reference speed	d min ⁻¹ mm/s		
Position deviation	Reference units		

• Speed Control

Item	Unit		
Item	Rotary Servomotor	Linear Servomotor	
Torque reference	%		
Feedback speed	min ⁻¹	mm/s	
Reference speed	min ⁻¹	mm/s	

Torque Control

ltem	Unit		
	Rotary Servomotor	Linear Servomotor	
Torque reference	%		
Feedback speed	min ⁻¹ mm/s		

9.3.1 Overtravel Settings

Precautions to Ensure Safe Tuning

CAUTION

- Observe the following precautions when you perform tuning.
 - Do not touch the rotating parts of the motor when the servo is ON.
 - · Before starting the Servomotor, make sure that an emergency stop can be performed at any time.
 - Make sure that trial operation has been successfully performed without any problems.
 - · Provide an appropriate stopping device on the machine to ensure safety.

Perform the following settings in a way that is suitable for tuning.

9.3.1 **Overtravel Settings**

Overtravel settings are made to force the Servomotor to stop for a signal input from a limit switch when a moving part of the machine exceeds the safe movement range.

Refer to the following section for details.

3 6.11 Overtravel and Related Settings on page 6-27

9.3.2 **Torque Limit Settings**

You can limit the torque that is output by the Servomotor based on calculations of the torque required for machine operation. You can use torque limits to reduce the amount of shock applied to the machine when problems occur, such as collisions or interference. If the torque limit is lower than the torgue that is required for operation, overshooting or vibration may occur. Refer to the following section for details.

7.7 Selecting Torque Limits on page 7-27

Setting the Position Deviation Overflow Alarm Level 9.3.3

The position deviation overflow alarm is a protective function that is enabled when the SERVO-PACK is used in position control.

If the alarm level is set to a suitable value, the SERVOPACK will detect excessive position deviation and will stop the Servomotor if the Servomotor operation does not agree with the reference.

The position deviation is the difference between the position reference value and the actual position.

You can calculate the position deviation from the position loop gain (Pn102) and the motor speed with the following formula.

Rotary Servomotors

Motor speed [min⁻¹] Encoder resolution^{*1} Pn210 Position deviation [reference units] 60 Pn102 [0.1/s]/10*2,*3 × Pn20E

Linear Servomotors

	Motor speed [mm/s]	Resolution	Pn210
Position deviation [reference units] =	= Pn102 [0.1/s]/10 ^{*2, *3}	× Linear encoder pitch [μ m]/1,000	× Pn20E

9.3.3 Setting the Position Deviation Overflow Alarm Level

Position Deviation Overflow Alarm Level (Pn520) [setting unit: reference units]

Rotary Servomotors

 $Pn520 > \frac{Maximum motor speed [min⁻¹]}{60} \times \frac{Encoder resolution^{*1}}{Pn102 [0.1/s]/10^{*2, *3}} \times \frac{Pn210}{Pn20E} \times \frac{(1.2 \text{ to } 2)^{*4}}{Encoder model}$

· Linear Servomotors

D- 500	Maximum motor speed [mm/s]	Resolution	$\times \frac{\text{Pn210}}{\text{m210}} \times (1.2 \text{ to } 2)^{*4}$
Pn520 >	Pn102 [0.1/s]/10 ^{*2, *3}	Linear encoder pitch [µm]/1,000	Pn20E (1.2 to 2)

*1. Refer to the following section for details.

6.15 Electronic Gear Settings on page 6-42

- *2. When model following control (Pn140 = n.
 DDD1) is enabled, use the setting of Pn141 (Model Following Control Gain) instead of the setting of Pn102 (Position Loop Gain).
- *3. To check the setting of Pn102 on the Digital Operator, change the parameter display setting to display all parameters (Pn00B = n.□□□1).
- *4. The underlined coefficient "× (1.2 to 2)" adds a margin to prevent an A.d00 alarm (Position Deviation Overflow) from occurring too frequently.

If you set a value that satisfies the formula, an A.d00 alarm (Position Deviation Overflow) should not occur during normal operation.

If the Servomotor operation does not agree with the reference, position deviation will occur, an error will be detected, and the Servomotor will stop.

The following calculation example uses a Rotary Servomotor with a maximum motor speed of

6,000 and an encoder resolution of 16,777,216 (24 bits). Pn102 is set to 400. $\frac{Pn210}{Pn20E} = \frac{1}{16}$

$$Pn520 = \frac{6,000}{60} \times \frac{16,777,216}{400/10} \times \frac{1}{16} \times 2$$
$$= 2,621,440 \times 2$$

= 5,242,880 (default setting of Pn520)

If the acceleration/deceleration rate required for the position reference exceeds the tracking capacity of the Servomotor, the tracking delay will increase and the position deviation will no longer satisfy the above formulas. If this occurs, lower the acceleration/deceleration rate so that the Servomotor can follow the position reference or increase the position deviation overflow alarm level.

Related Parameters

	Position Deviation Overflow Alarm Level			Position		
Pn520	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup	
	Position Deviation Overflow Warning Level Position				on	
Pn51E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 100	1%	100	Immediately	Setup	

Related Alarms

Alarm Number	Alarm Name	Alarm Meaning
A.d00	Position Deviation Overflow	This alarm is displayed when the position deviation exceeds the set- ting of Pn520 (Position Deviation Overflow Alarm Level).

9.3.4 Vibration Detection Level Setting

Related Warnings

Warning Number	Warning Name	Meaning
A.900	Position Deviation Overflow	This warning occurs if the position deviation exceeds the specified percentage (Pn520 \times Pn51E/100).

9.3.4 Vibration Detection Level Setting

You can set the vibration detection level (Pn312) to more accurately detect A.520 alarms (Vibration Alarm) and A.911 warnings (Vibration) when vibration is detected during machine operation.

Set the initial vibration detection level to an appropriate value. Refer to the following section for details.

7.11 Initializing the Vibration Detection Level on page 7-49

9.3.5 Setting the Position Deviation Overflow Alarm Level at Servo ON

If the servo is turned ON when there is a large position deviation, the Servomotor will attempt to return to the original position to bring the position deviation to 0, which may create a hazardous situation. To prevent this, you can set a position deviation overflow alarm level at servo ON to restrict operation.

The related parameters and alarms are given in the following tables.

Related Parameters

	Position Deviation Overflow Alarm Level at Servo ON				ion
Pn526	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup
	Position Deviation Overflow Warning Level at Servo ON Position				ion
Pn528	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 100	1%	100	Immediately	Setup

Rotary Servomotors

	Speed Limit Level at Servo ON			Positie	on
Pn529	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 min ⁻¹	10,000	Immediately	Setup

Linear Servomotors

	Speed Limit Level at Servo ON			Positi	on
Pn584	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 mm/s	10,000	Immediately	Setup

9.3.5 Setting the Position Deviation Overflow Alarm Level at Servo ON

Related Alarms

Alarm Number	Alarm Name	Alarm Meaning
A.d01	Position Deviation Overflow Alarm at Servo ON	This alarm occurs if the servo is turned ON after the position devia- tion exceeded the setting of Pn526 (Position Deviation Overflow Alarm Level at Servo ON) while the servo was OFF.
A.d02	Position Deviation Overflow Alarm for Speed Limit at Servo ON	If position deviation remains in the deviation counter, the setting of Pn529 or Pn584 (Speed Limit Level at Servo ON) will limit the speed when the servo is turned ON. This alarm occurs if a position refer- ence is input and the setting of Pn520 (Position Deviation Overflow Alarm Level) is exceeded.

Refer to the following section for information on troubleshooting alarms. *13.2.3 Resetting Alarms* on page 13-43

Related Warnings

Warning Number	Warning Name	Meaning	
A.901	Position Deviation Overflow Warning at Servo ON	This warning occurs if the servo is turned ON while the position deviation exceeds the specified percentage (Pn526 × Pn528/100).	

9.4.1 Application Restrictions

0.4 Tuning-less Function

The tuning-less function performs autotuning to obtain a stable response regardless of the type of machine or changes in the load. Autotuning is started when the servo is turned ON.



- The tuning-less function is disabled during torque control.
- The Servomotor may momentarily emit a sound or vibrate the first time the servo is turned ON after the Servomotor is connected to the machine. This sound is caused by setting the automatic notch filter. It does not indicate a problem. However, if this sound or vibration continues, manually set a function to suppress vibration (e.g., a notch filter).
- The Servomotor may vibrate if it exceeds the allowable load moment of inertia. If that occurs, set the tuning-less load level to 2 (Pn170 = n.2□□□) or reduce the Tuning-less Rigidity Level (Pn170 = n.□X□□).
- To ensure safety, make sure that you can perform an emergency stop at any time when you execute the tuning-less function.

9.4.1 Application Restrictions

The following application restrictions apply to the tuning-less function.

Function	Executable*	Remarks
Vibration Detection Level Initialization	0	-
Moment of Inertia Estimation	×	Disable the tuning-less function (Pn170 = $n.\Box\Box\Box$ 0) before you execute moment of inertia estimation.
Autotuning without Host Reference	×	Disable the tuning-less function (Pn170 = $n.\Box\Box\Box$ 0) before you execute autotuning without a host reference.
Autotuning with Host Reference	×	-
Custom Tuning	×	-
Anti-Resonance Control Adjustment	×	_
Vibration Suppression	×	-
Easy FFT	0	The tuning-less function is disabled while you execute Easy FFT and then it is enabled when Easy FFT has been completed.
Friction Compensation	×	-
Gain Selection	×	-
Mechanical Analysis	0	The tuning-less function is disabled while you execute mechanical analysis and then it is enabled when mechan- ical analysis has been completed.

* O: Yes ×: No

The tuning-less function is enabled in the default settings. No specific procedure is required. You can use the following parameter to enable or disable the tuning-less function.

Parameter		Meaning	When Enabled	Classification
	n.🗆 🗆 🗆 0	Disable tuning-less function.		
	n.□□□1 (default setting)	Enable tuning-less function.		
Pn170	n.□□0□ (default setting)	Use for speed control.	After restart	Setup
n.0010		Use for speed control and use host controller for position control.		

When you enable the tuning-less function, you can select the tuning-less type. Normally, set Pn14F to $n.\square\square2\square$ (Use tuning-less type 3) (default setting). If compatibility with previous models is required, set Pn14F to $n.\square\square0\square$ (Use tuning-less type 1) or $n.\square\square1\square$ (Use tuning-less type 2).

Parameter		Meaning	When Enabled	Classification
	n.🗆 🗆 🗆	Use tuning-less type 1.		
Pn14F	n.0010	Use tuning-less type 2. (The noise level is improved more than with tuning-less type 1.)	After restart	Tuning
	n.□□2□ (default setting)	Use tuning-less type 3.		

Tuning-less Level Settings

If vibration or other problems occur, change the tuning-less levels. To change the tuning-less levels, use the SigmaWin+.

Preparations

Always check the following before you set the tuning-less levels.

- The tuning-less function must be enabled (Pn170 = $n.\Box\Box\Box$ 1).
- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).
- The Servomotor must be connected to the machine.

♦ Procedure

Use the following procedure to set the tuning-less levels.

In addition to the following procedure, you can also set the parameters directly. Refer to *Related Parameters*, below, for the parameters to set.

- 1. Click the <u>J</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Response Level Setting in the Menu Dialog Box. The Tuning-less Level Setting-Adj Dialog Box will be displayed.

9.4.3 Troubleshooting Alarms

3. Click the ▲ or ▼ Button to adjust the response level setting. Increase the response level setting to increase the response. Decrease the response level setting to suppress vibration.

The default response level setting is 4.

Response Level Setting	Description	Remarks
7	Response level: High	
6		You cannot select these levels if tuning-less type 1 or 2 (Pn14F = $n.\Box\Box\Box\Box$ or $n.\Box\Box\Box\Box$) is used.
5		
4 (default setting)		
3		
2		-
1	25	
0	Response level: Low	

4. Click the Completed Button.

The adjustment results will be saved in the SERVOPACK.



Reset the tuning-less level to the default setting when removing the Servomotor from the machine. The Servomotor may vibrate if the tuning-less level is not reset and the servo is turned ON when the Servomotor has been removed from the machine.

Related Parameters

■ Tuning-less Rigidity Level

If you use tuning-less type 1 or 2 (Pn14F = $n.\square\square\square\square$ or $n.\square\square\square\square$), set the tuning-less level to between 0 and 4 (Pn170 = $n.\square\square\square\square$ to $n.\square4\square\square$). Do not set the tuning-less level to between 5 and 7 (Pn170 = $n.\square5\square\square$ to $n.\square7\square\square$).

Parameter		Description	When Enabled	Classification
n.0000		Tuning-less rigidity level 0 (low rigidity)		
	n.0100	Tuning-less rigidity level 1		
	n.0200	Tuning-less rigidity level 2		
Pn170	n.¤3¤¤	Tuning-less rigidity level 3		Setup
	n.□4□□ (default setting)	Tuning-less rigidity level 4	Immediately	
	n.¤5¤¤	Tuning-less rigidity level 5		
	n.¤6¤¤	Tuning-less rigidity level 6		l
	n.0700	Tuning-less rigidity level 7 (high rigidity)		

Tuning-less Load Level

Parameter		Description	When Enabled	Classification
	n.0000	Tuning-less load level 0		
Pn170	n.1□□□ (default setting)	Tuning-less load level 1	Immediately	Setup
	n.2000	Tuning-less load level 2		

9.4.3 Troubleshooting Alarms

An A.521 alarm (Autotuning Alarm) will occur if a resonant sound occurs or if excessive vibration occurs during position control. If an alarm occurs, implement the following measures.

Resonant Sound

Decrease the setting of Pn170 = $n.X\square\square\square$ or the setting of Pn170 = $n.\squareX\square\square$.

• Excessive Vibration during Position Control Increase the setting of Pn170 = n.□X□□ or decrease the setting of Pn170 = n.□X□□.

9.4.4 Parameters Disabled by Tuning-less Function

9.4.4 Parameters Disabled by Tuning-less Function

When the tuning-less function is enabled (Pn170 = $n.\Box\Box\Box$ 1) (default setting), the parameters in the following table are disabled.

Item	Parameter Name	Parameter Number
	Speed Loop Gain Second Speed Loop Gain	Pn100 Pn104
Gain-Related Parameters	Speed Loop Integral Time Constant Second Speed Loop Integral Time Constant	Pn101 Pn105
	Position Loop Gain Second Position Loop Gain	Pn102 Pn106
	Moment of Inertia Ratio	Pn103
Advanced Control-Related	Friction Compensation Function Selection	Pn408 = n.X□□□
Parameters	Anti-Resonance Control Selection	Pn160= n.□□□X
Gain Selection-Related Parameters	Gain Switching Selection	Pn139= n.□□□X

The tuning-less function is disabled during torque control, Easy FFT, and mechanical analysis for a vertical axis. The gain-related parameters in the above table are enabled for torque control, Easy FFT, and mechanical analysis. Of these, Pn100, Pn103, and Pn104 are enabled for torque control.

9.4.5 Automatically Adjusted Function Setting

You can also automatically adjust notch filters.

Normally, set Pn460 to n. $\Box 1 \Box \Box$ (Adjust automatically) (default setting). Vibration is automatically detected and a notch filter is set.

Set Pn460 to n. $\Box 0 \Box \Box$ (Do not adjust automatically) only if you do not change the setting of the notch filter before you execute the tuning-less function.

Parameter		Meaning	When Enabled	Classification
Pn460	n.□0□□	Do not adjust the second stage notch filter automatically when the tuning-less function is enabled or during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.	Immediately	Tuning
1 11400	n.□1□□ (default setting)	Adjust the second stage notch filter automati- cally when the tuning-less function is enabled or during execution of autotuning without a host reference, autotuning with a host refer- ence, and custom tuning.	initiculately	Tuning

9.4.6 Related Parameters

The following parameters are automatically adjusted when you execute the tuning-less function.

Do not manually change the settings of these parameters after you have enabled the tuningless function.

Parameter	Name	
Pn401	First Stage First Torque Reference Filter Time Constant	
Pn40A	First Stage Notch Filter Q Value	
Pn40C	Second Stage Notch Filter Frequency	
Pn40D	Second Stage Notch Filter Q Value	

9.5.1 Outline

9.5 Estimating the Moment of Inertia

This section describes how the moment of inertia is calculated.

The moment of inertia ratio that is calculated here is used in other tuning functions. You can also estimate the moment of inertia during autotuning without a host reference. Refer to the following section for the procedure.

9.6.4 Operating Procedure on page 9-26

9.5.1 Outline


The moment of inertia during operation is automatically calculated by the SERVOPACK for round-trip (forward and reverse) operation. A reference from the host controller is not used.

The moment of inertia ratio (i.e., the ratio of the load moment of inertia to the motor moment of inertia) is a basic parameter for adjusting gains. It must be set as accurately as possible.

Although the load moment of inertia can be calculated from the weight and structure of the mechanisms, doing so is very troublesome and calculating it accurately can be very difficult with the complex mechanical structures that are used these days. With an estimate of the moment of inertia, you can obtain an accurate load moment of inertia simply by running the Servomotor in the actual system in a forward and reverse direction a few times.

The Servomotor is operated with the following specifications.

- Maximum speed: ±1,000 min⁻¹ (can be changed)
- Acceleration rate: ±20,000 min⁻¹/s (can be changed)
- Travel distance: ±2.5 rotations max. (can be changed)



Note: Execute moment of inertia estimation after jogging to a position that ensures a suitable range of motion.

9.5.2 Restrictions

The following restrictions apply to estimating the moment of inertia.

Systems for which Execution Cannot Be Performed

- When the machine system can move only in one direction
- When the range of motion is 0.5 rotations or less

Systems for Which Adjustments Cannot Be Made Accurately

- When a suitable range of motion is not possible
- When the moment of inertia changes within the set operating range
- When the machine has high dynamic friction
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used

9.5.3 Applicable Tools

• When proportional control is used

Note: If you specify calculating the moment of inertia, an error will occur if V_PPI in the servo command output signals (SVCMD_IO) changes to specify the proportional action during moment of inertia estimation.

- When mode switching is used
 - Note: If you specify moment of inertia estimation, mode switching will be disabled and PI control will be used while the moment of inertia is being calculated. Mode switching will be enabled after moment of inertia estimation has been completed.
- When speed feedforward or torque feedforward is input

Preparations

Always check the following before you execute moment of inertia estimation.

- The main circuit power supply must be ON.
- There must be no overtravel.
- The servo must be OFF.
- The control method must not be set to torque control.
- The gain selection switch must be set to manual gain selection (Pn139 = $n.\Box\Box\Box$).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).
- There must be no alarms or warnings.
- There must be no hard wire base block (HWBB).
- The parameters must not be write prohibited.
- The tuning-less function must be disabled (Pn170 = $n.\Box\Box\Box$ 0).

9.5.3 Applicable Tools

The following table lists the tools that you can use to estimate the moment of inertia.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	You cannot estimate the moment of inertia from the Digital Operator.	
SigmaWin+	Tuning - Tuning 9.5.4 Operating Procedure on pa	

9.5.4 Operating Procedure

Use the following procedure to estimate the moment of inertia ratio.


• Estimating the moment of inertia requires operating the Servomotor and therefore presents hazards. Observe the following precaution.

· Confirm safety around moving parts.

This function involves automatic operation with vibration. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time. There will be movement in both directions within the set range of movement. Check the range of movement and the directions and implement protective controls for safety, such as the overtravel functions.

- Be aware of the following points if you cancel the moment of inertia estimation while the Servomotor is operating.
 - If you cancel operation with the **Servo OFF** Button, the Servomotor will stop according to setting of the Servo OFF stopping method (Pn001 = n.□□□X).
 - If you cancel operation with the **Cancel** Button, the Servomotor will decelerate to a stop and then enter a zero-clamped state.


- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.
- 3. Click the Execute Button.



4. Click the Execute Button.

Tuning AXIS#00	— ×—			
Set the moment of inertia (mass) ratio before executing autotuning.	Precautions			
Moment of inertia (mass) ratio identification				
Philos Money (Money) (and Commission Ratio				
100 % Edit				
Autotuning Reference input from host controller © Postion Reference Input No Reference Input]			
Advanced adjustment	Finish			

5. Set the conditions as required.



① Speed Loop Setting Area

Make the speed loop settings in this area.

If the speed loop response is too bad, it will not be possible to measure the moment of inertia ratio accurately.

The values for the speed loop response that are required for moment of inertia estimation are set for the default settings. It is normally not necessary to change these settings. If the default speed loop gain is too high for the machine (i.e., if vibration occurs), lower the setting. It is not necessary to increase the setting any farther.

2 Identification Start Level Group

This is the setting of the moment of inertia calculation starting level.

If the load is large or the machine has low rigidity, the torgue limit may be applied, causing moment of inertia estimation to fail.

If that occurs, estimation may be possible if you double the setting of the start level. ③ Edit Buttons

Click the button to display a dialog box to change the settings related to the speed loop or estimation start level.

④ Help Button


Click this button to display guidelines for setting the reference conditions. Make the following settings as required.

- Operate the Servomotor to measure the load moment of inertia of the machine in comparison with the rotor moment of inertia.
- Set the operation mode, reference pattern (maximum acceleration rate, maximum speed, and maximum travel distance), and speed loop-related parameters.
- · Correct measurement of the moment of inertia ratio may not be possible depending on the settings. Set suitable settings using the measurement results as reference.
- S Reference Selection Area
 - Either select the reference pattern for estimation processing from the box, or set the values in the **Detailed Setting** Group. Generally speaking, the larger the maximum acceleration rate is, the more accurate the moment of inertia estimation will be. Set the maximum acceleration range within the possible range of movement considering

the gear ratio, e.g., the pulley diameters or ball screw pitch.

6 Confirm Button

Click this button to display the Reference Confirmation Dialog Box.



⑦ Detailed Setting Area


You can change the settings by moving the bars or directly inputting the settings to create the required reference pattern.

® Next Button

Click this button to display the Reference Transmission Dialog Box.

③ Cancel Button

Click this button to return to the Tuning Dialog Box.




Information When Measurement Is Not Correct

Estimating the moment of inertia ratio cannot be performed correctly if the torque limit is activated. Adjust the limits or reduce the acceleration rate in the reference selection so that the torque limit is not activated.

6. Click the Next Button.

The Reference Transmission Dialog Box will be displayed.

7. Click the Start Button.



① Start Button

The reference conditions will be transferred to the SERVOPACK. A progress bar will show the progress of the transfer.

2 Cancel Button

The **Cancel** Button is enabled only while data is being transferred to the SERVOPACK. You cannot use it after the transfer has been completed.

③ Back Button

This button returns you to the Condition Setting Dialog Box. It is disabled while data is being transferred.

④ Next Button

This button is enabled only when the data has been transferred correctly. You cannot use it if an error occurs or if you cancel the transfer before it is completed.

Click the **Next** Button to display the Operation/Measurement Dialog Box. (S Cancel Button

This button cancels process

This button cancels processing and returns you to the Tuning Dialog Box.

8. Click the Next Button.

The Operation/Measurement Dialog Box will be displayed.


9. Click the Servo On Button.



10. Click the Forward Button.

The shaft will rotate in the forward direction and the measurement will start. After the measurement and data transfer have been completed, the **Reverse** Button will be displayed in color.

11. Click the Reverse Button.



The shaft will rotate in the reverse direction and the measurement will start. After the measurement and data transfer have been completed, the **Forward** Button will be displayed in color.

Uperation/M	easurement AXIS#00				
Condition Setting	 Reference Transmission 	Operation / Measurement		White Results	Precautions
2Count	Identification	v/Fwd Measurement	Prep. C	Complete	
-Servo ON/	OFF operation	Forward		•	Reverse
			<u>-</u> 5		Moment of Inertia Ratio prior to Identifying 300 (N)
					Identified Moment of Inertia Ratio
		100%			

12. Repeat steps 9 to 11 until the Next Button is enabled.

Measurements are performed from 2 to 7 times and then verified. The number of measurements is displayed in upper left corner of the dialog box. A progress bar at the bottom of the dialog box will show the progress of the transfer each time.

13. When the measurements have been completed, click the Servo On Button to turn OFF the servo.


14. Click the Next Button.

The Write Results Dialog Box will be displayed.

Information If you click the **Next** Button before you turn OFF the servo, the following Dialog Box will be displayed. Click the **OK** Button to turn OFF the servo.



15. Click the Writing Results Button.



① Identified Moment of Inertia Ratio Box

The moment of inertia ratio that was found with operation and measurements is displayed here.

2 Writing Results Button

If you click this button, Pn103 (Moment of Inertia Ratio) in the SERVOPACK is set to the value that is displayed for the identified moment of inertia ratio.

3 Pn103: Moment of Inertia Ratio Box

The value that is set for the parameter is displayed here.

After you click the **Writing Results** Button, the value that was found with operation and measurements will be displayed as the new setting.


④ Back Button

This button is disabled.


S Cancel Button

This button will return you to the Tuning Dialog Box.

- 16. Confirm that the Identified Moment of Inertia Ratio Box and the Pn103: Moment of Inertia Ratio Box show the same value and then click the Finish Button.
- 17. Click the OK Button.



18. Click the Execute Button.



If the setting of the moment of inertia ratio (Pn103) was changed, the new value will be saved and the Tuning Dialog Box will be displayed again.

This concludes the procedure to estimate the moment of inertia ratio.

9.6.1 Outline

9.6 Autotuning without Host Reference

This section describes autotuning without a host reference.

Important	 Autotuning without a host reference performs adjustments based on the setting of the speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when adjustments are started. Make adjustments after lowering the speed loop gain (Pn100) until vibration is eliminated. You cannot execute autotuning without a host reference if the tuning-less function is enabled (Pn170 = n.□□□1 (default setting)). Disable the tuning-less function (Pn170 = n.□□□0) before you execute autotuning without a host reference. If you change the machine load conditions or drive system after you execute autotuning without a host reference and then you execute autotuning without a host reference with moment of inertia estimation specified, use the following parameter settings. If you execute autotuning without a host reference for any other conditions, the machine may vibrate and may be damaged. Pn140 = n.□□□0 (Do not use model following control.) Pn160 = n.□□□0 (Do not use anti-resonance control.) Pn408 = n.00□0 (Disable friction compensation, first stage notch filter, and second stage notch filter.)
	Note: If you are using the Digital Operator and the above parameters are not displayed, change the parameter display setting to display all parameters (Pn00B = n.□□□1) and then turn the power supply OFF and ON again.

9.6.1 Outline

For autotuning without a host reference, operation is automatically performed by the SERVO-PACK for round-trip (forward and reverse) operation to adjust for machine characteristics during operation. A reference from the host controller is not used.

The following items are adjusted automatically.


- Moment of inertia ratio
- · Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control
- Vibration suppression (only for mode 2 or 3)

Refer to the following section for details on the parameters that are adjusted. **9.6.7** *Related Parameters* on page 9-34

The Servomotor is operated with the following specifications.

Maximum Speed	Rated motor speed × $\frac{2}{3}$		
Acceleration Torque	Rated motor torque: Approx. 100% Note: The acceleration torque depends on the setting of the influence of the moment of inertia ratio (Pn103), machine friction, and external disturbance.		
Travel Distance	Rotary Servomotors	You can set the desired travel distance. The default setting is for a value equivalent to 3 Servomotor shaft rotations.	
	Linear Servomotors	You can set the desired travel distance in increments of 1,000 reference units. (The default setting is for 90 mm.)	

9.6.2 Restrictions



Example of Automatic Operation Pattern

- Autotuning without a host reference requires operating the Servomotor and therefore presents hazards. Observe the following precaution.
 - Confirm safety around moving parts. This function involves automatic operation with vibration. Make sure that you can perform an

emergency stop (to turn OFF the power supply) at any time. There will be movement in both directions within the set range of movement. Check the range of movement and the directions and implement protective controls for safety, such as the overtravel functions.

9.6.2 Restrictions

The following restrictions apply to autotuning without a host reference.

If you cannot use autotuning without a host reference because of these restrictions, use autotuning with a host reference or custom tuning. Refer to the following sections for details. $\boxed{37}$ 9.7 Autotuning with a Host Reference on page 9-35

3.8 Custom Tuning on page 9-42

Systems for Which Execution Cannot Be Performed

- · When the machine system can move only in one direction
- When the range of motion is 0.5 rotations or less

Systems for Which Adjustments Cannot Be Made Accurately

- When a suitable range of motion is not possible
- · When the moment of inertia changes within the set operating range
- When the machine has high friction
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used
- When proportional control is used

Note: If you specify calculating the moment of inertia, an error will occur if V_PPI in the servo command output signals (SVCMD_IO) changes to specify the proportional action during moment of inertia estimation.

· When mode switching is used

Note: If you specify moment of inertia estimation, mode switching will be disabled and PI control will be used while the moment of inertia is being calculated. Mode switching will be enabled after moment of inertia estimation has been completed.

- When speed feedforward or torque feedforward is input
- When the positioning completed width (Pn522) is too narrow

9.6.3 Applicable Tools

Preparations

Always check the following before you execute autotuning without a host reference.

- The main circuit power supply must be ON.
- There must be no overtravel.
- The servo must be OFF.
- The control method must not be set to torque control.
- The gain selection switch must be set to manual gain selection (Pn139 = $n.\Box\Box\Box$).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).
- There must be no alarms or warnings.
- There must be no hard wire base block (HWBB).
- The parameters must not be write prohibited.
- The tuning-less function must be disabled (Pn170 = n.□□□0), or the tuning-less function must be enabled (Pn170 = n.□□□1) and moment of inertia estimation must be specified.
- If you execute autotuning without a host reference during speed control, set the mode to 1.

Information • If you start autotuning without a host reference while the SERVOPACK is in speed control for mode 2 or 3, the SERVOPACK will change to position control automatically to perform autotuning without a host reference. The SERVOPACK will return to speed control after autotuning has been completed.


9.6.3 Applicable Tools

The following table lists the tools that you can use to perform autotuning without a host reference.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn201	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	■ 9.6.4 Operating Procedure on page 9-26

9.6.4 Operating Procedure

Use the following procedure to perform autotuning without a host reference.



If 2 or 3 is selected for the mode, correct phase control may not be possible.

- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Click the <u>J</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.
- 4. Click the Execute Button.

WARNING This function executes tuning for the Servopack. Using this function while the motor is running is dangerous. Be sure to carefully read the SigmaWith- Operation Manual before executing this function. Special care must be taken for the following.
-Safety Precautions> 1. Before executing this function, make sure that the emergency stop (power off) can be activated when needed. The response speed may change considerably during tuning. Before executing this function, make sure that the emergency stop (power off) can be activated when needed.
 Confirm the safety of the area adjoining the drive unit. Before executing this function, always confirm that the area within the motor motion range and direction is clear for safe operation. Provide protective devices to ensure safety in the event of overtraveling or other unexpected movement.
 Always confirm that there is no position error before running the motor. Be sure to return to the origin and reset the position prior to normal operation. Running the motor without resetting the origin can lead to an overrun and is extremely dangerous.
4. When the moment of inertia (mass) identification function is used for a vertical axis, check the safety of the system. When the moment of inertia (mass) identification function is used for a vertical axis, confirm that the axis level does not drop when the serve is turned of if.
<turing precautions=""> 5. Set the moment of inertia (mass) ratio first. The moment of intertia (mass) ratio must be set to achieve correct tuning. Be sure to set the ratio. The setting can be performed from the Tuning window.</turing>
 If vibration is generated, execute custom tuning. Lower the gain until there is no vibration by executing custom tuning.
Note: While tuning, you can read the precautions related to the process. Click the Precautions button provided in each tuning window.
Execute Cancel

5. Select the No Reference Input Option in the Autotuning Area and then click the Autotuning Button.

Tuning AXIS#00	×
Set the moment of inertia (mass) ratio before executing autotuning.	Precautions
Moment of inertia (mass) ratio identification	
Pn103 : Moment of Inertia Ratio	
Execute.	_
0 % Edit	
Autotuning	
Reference input from host controller	
C Position Reference Input	X
Advanced adjustment	Finish

Information

When the following dialog box is displayed, click the **OK** Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).

Tuning
The moment of inertia (mass) ratio has never been changed from the default setting. Set a correct moment of inertia (mass) ratio in the Moment of Inertia (Mass) Setting window before starting huning. If an incorrect moment of inertia (mass) ratio is set, vibration may be generated during funing. Do you want to continue tuning?
Cancel

6. Set the conditions in the Switching the load moment of inertia (load mass) identification Box, the Mode selection Box, the Mechanism selection Box, and the Distance Box, and then click the Next Button.

361 0	onditions.
Swite	hing the load moment of intertia (load mass) identification
1:A	moment of inertia is not presumed.
Mode	selection
2:F	or positioning
follo	in adjustment specialized for positioning will be executed. In addition, the wing automatic adjustments can be executed: Model following control, notch , anti-resonance control, and vibration suppression.
Mech	anism selection
2:B	all screw mechanism or linear motor
	cutes adjustment suitable for relatively high-rigidity mechanism, such as a ball w or linear motor. Select this type if there is no applicable mechanism.
Distar	
78	moving range from the current value is specified.
	foreitario annaj
	9990 - 99990) tting invalid range : -131 - 131) 3.0 [Rotation]
Tunin	parameters
□ 5	tart tuning using the default settings.
5	tart tuning using the default settings.
	Next > Cancel
stai	■ Cancel Cancel Cancel Cancel Cancel Cancel
stai	■ Cancel Cancel Cancel Cancel Cancel Cancel
stal et th	nce Box e travel distance. ment range: -99,990,000 to
stal et th over	nce Box e travel distance. ment range: -99,990,000 to 90,000 [reference units]
stal et th over 99,9	Lence Box e travel distance. ment range: -99,990,000 to 90,000 [reference units] um setting increment for travel dis-
star et th over 99,9 inim	Leet → Cancel Cance
stal et th over 99,9 inim nce: egat	Lence Box e travel distance. ment range: -99,990,000 to 90,000 [reference units] um setting increment for travel dis-

Rotary Servomotors: Approx. 3 rotations Linear Servomotors: Approx 90 mm Set the distance to the following values or higher. To ensure tuning precision, we recommend that you use approximately the default distance setting. Rotary Servomotors: 0.5 rotations

Linear Servomotors: 5 mm

· Switching the load moment of inertia (load mass) identification Box

Specify whether to estimate the moment of inertia. 0: A moment of inertia is presumed. (default setting) 1: A moment of inertia is not presumed.

Mode selection Box

Set the mode.		
Mode Selection	Description	
1: Standard	Standard gain adjustment is per- formed. In addition to gain adjust- ment, notch filters and anti-resonance control are automatically adjusted.	
2: For positioning	Tuning is performed for positioning applications. In addition to gain adjustment, model following control, notch filters, anti-resonance control, and vibration suppression are auto- matically adjusted.	
3: For positioning especially to pre- vent overshooting	Tuning is performed for positioning applications with emphasis on elimi- nating overshooting. In addition to gain adjustment, notch filters, anti- resonance control, and vibration sup- pression are automatically adjusted.	

Mechanism selection Box

Select the type according to the machine element to drive.

If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

Mechanism Selection	Description
1: Belt mechanism	Tuning is performed for a mecha- nism with relatively low rigidity, e.g., a belt.
2: Ball screw mech- anism or linear motor	Tuning is performed for a mecha- nism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting.
3: Rigid model	Tuning is performed for a mecha- nism with high rigidity, e.g., a rigid body system.

Tuning parameters Box

Specify the parameters to use for tuning. If you select the Start tuning using the default settings Check Box, the tuning parameters will be returned to the default settings before tuning is started.

7. Click the Servo ON Button.

SAutotuning - Automatic s	setting AXIS#00	×
Waiting for execution	Servo ON/OFF ope	vo OFF
Gain search behaviour evaluation	Mode selection 2:For positionin	Start tuning
	Mechanism sele	
	2:Ball screw m Distance	echanism or linear motor
Notch filter	786000	[reference units]
OAnti-res Adj Vib Suppress	3.0	[Rotation]
Precautions	< Back	Finish

8. Click the Start tuning Button.

Autotuning - Automatic s	setting AXIS#00
Waiting for execution	Servo ON/OFF operation Servo OFF Servo OFF
Gain search behaviour evaluation	Tuning Start tuning Mode selection
	2:For positioning Mechanism selection 2:Ball screw mechanism or linear motor Distance
Notch filter Anti-res Adj Vib Suppress	786000 [reference units] 3.0 [Rotation]
Precautions	< Back Finish Cancel

9.6.5 Troubleshooting Problems in Autotuning without a Host Reference

9. Confirm safety around moving parts and click the Yes Button.



The Servomotor will start operating and tuning will be executed.

Vibration that occurs during tuning will be detected automatically and suitable settings will be made for that vibration. When the settings have been completed, the indicators for the functions that were used will light at the lower left of the dialog box.

SAutotuning - Automatic s	setting AXIS#00	×
Waiting for execution	Servo ON/OFF operation	Servo OFF
Oscillation level measurement		-O
		Cancel
Gain search behaviour evaluation		-
Tuning completed	Mode selection	<u></u>
	2:For positioning	
	Mechanism selection	
	2:Ball screw mechanism of Distance	or linear motor
Notch filter		erence units]
Anti-res Adj Vib Suppress		ation]
Precautions	< Back Finish	Cancel

10. When tuning has been completed, click the **Finish** Button.

The results of tuning will be set in the parameters and you will return to the Tuning Dialog Box.

This concludes the procedure to perform autotuning without a host reference.

9.6.5 Troubleshooting Problems in Autotuning without a Host Reference

The following tables give the causes of and corrections for problems that may occur in autotuning without a host reference.

Autotuning without a Host Reference Was Not Performed

Possible Cause	Corrective Action
Main circuit power supply is OFF.	Turn ON the main circuit power supply.
An alarm or warning occurred.	Remove the cause of the alarm or warning.
Overtraveling occurred.	Remove the cause of overtraveling.
The second gains were selected with the gain selection.	Disable automatic gain switching.
The HWBB was activated.	Release the HWBB.
The setting of the travel distance is too small.	Set the travel distance again in step 6 of the proce- dure.
The settings for the tuning-less function are not correct.	 Disable the tuning-less function (Pn170 = n.□□□0). Enable the tuning-less function (Pn170 = n.□□□1) and specify moment of inertia estimation.

9.6.5 Troubleshooting Problems in Autotuning without a Host Reference

When an Error Occurs during Execution of Autotuning without a Host Reference

Error	Possible Cause	Corrective Action
The gain adjustments were not successfully completed.	Machine vibration occurs or the posi- tioning completion signal is not stable when the Servomotor stops.	 Increase the setting of the positioning completed width (Pn522). Change the mode from 2 to 3. If machine vibration occurs, suppress the vibration with the anti-resonance control function and the vibration suppression function.
An error occurred during calculation of the moment of inertia.	Refer to the following section for trouble	eshooting information. Iation of Moment of Inertia on page 9-31
Positioning was not completed within approximately 10 sec- onds after position adjustment was com- pleted.	The positioning completed width is too narrow or proportional control is being used.	 Increase the setting of the positioning completed width (Pn522). Set V_PPI to 0 in the servo command output signals (SVCMD_IO).

When an Error Occurs during Calculation of Moment of Inertia

Possible Cause	Corrective Action
The SERVOPACK started calculating the moment of inertia but the calculation was not completed.	Increase the setting of the speed loop gain (Pn100).Increase the stroke (travel distance).
The moment of inertia fluctuated greatly and did not converge within 10 tries.	Set Pn103 (Moment of Inertia Ratio) from the machine specifications and specify not estimating the moment of inertia.
Low-frequency vibration was detected.	Double the setting of moment of inertia calculation starting level (Pn324).
The torque limit was reached.	 If you are using the torque limit, increase the torque limit. Double the setting of moment of inertia calculation starting level (Pn324).
The speed control section changed to proportional control during calculation of the moment of inertia, e.g., V_PPI in the servo command output signals (SVCMD_IO) was set to 1.	Use PI control when calculating the moment of inertia.

◆ Adjustment Results Are Not Satisfactory for Position Control

You may be able to improve the adjustment results by changing the settings of the positioning completed width (Pn522) and the electronic gear ratio (Pn20E/Pn210).

If satisfactory results are still not possible, adjust the overshoot detection level (Pn561). That may improve the adjustment results.

- Pn561 = 100% (default setting)
- This will allow tuning with overshooting that is equivalent to the positioning completed width. • Pn561 = 0%
 - This will allow tuning to be performed without overshooting within the positioning completed width, but the positioning completed width may be extended.

	Overshoot Detection Level		Speed Posit	ion Torque	
Pn561	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1%	100	Immediately	Setup

9.6.6 Automatically Adjusted Function Settings

9.6.6 Automatically Adjusted Function Settings

You can specify whether to automatically adjust the following functions during autotuning.

Automatic Notch Filters

Normally, set Pn460 to n. D1DD (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and a notch filter will be adjusted.

Set Pn460 to n. $\Box 0 \Box \Box$ (Do not adjust automatically) only if you do not change the setting of the notch filter before you execute this function.

F	Parameter	Function	When Enabled	Classification
Pn460	n.□□□0	Do not adjust the first stage notch filter auto- matically during execution of autotuning with- out a host reference, autotuning with a host reference, and custom tuning.	Immediately	Tuning
	n.□□□1 (default setting)	Adjust the first stage notch filter automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.		
	n.0000	Do not adjust the second stage notch filter automatically when the tuning-less function is enabled or during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.		
	n.□1□□ (default setting)	Adjust the second stage notch filter automati- cally when the tuning-less function is enabled or during execution of autotuning without a host reference, autotuning with a host refer- ence, and custom tuning.		

Anti-Resonance Control Adjustment

This function reduces low vibration frequencies, for which the notch filters cannot be used.

Normally, set Pn160 to n. DD1D (Adjust automatically) (default setting).

Vibration will be detected during autotuning without a host reference and anti-resonance control will be automatically adjusted.

F	Parameter	Function	When Enabled	Classification
Pn160	n.□□0□	Do not adjust anti-resonance control automat- ically during execution of autotuning without a host reference, autotuning with a host refer- ence, and custom tuning.	Immediately	Turing
FIII00	n.□□1□ (default setting)	Adjust anti-resonance control automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.	inineulately	Tuning

Vibration Suppression

You can use vibration suppression to suppress transitional vibration at a low frequency from 1 Hz to 100 Hz, which is generated mainly when the machine vibrates during positioning.

Normally, set Pn140 to n. D1DD (Adjust automatically) (default setting). Vibration will be detected during autotuning without a host reference and vibration suppression control will be automatically set.

Set $Pn140 = n.\Box 0 \Box \Box$ (Do not adjust automatically) only if you do not change the settings for vibration suppression before you execute autotuning without a host reference.

Note: Autotuning without a host reference uses model following control. Therefore, it can be executed only if the mode is set to 2 or 3.

9.6.6 Automatically Adjusted Function Settings

P	arameter	Function	When Enabled	Classification
Pn140	n.0000	Do not adjust vibration suppression automati- cally during execution of autotuning without a host reference, autotuning with a host refer- ence, and custom tuning.	Immediately	Tuning
11140	n.⊡1□□ (default setting)	Adjust vibration suppression automatically during execution of autotuning without a host reference, autotuning with a host reference, and custom tuning.	inineulately	Turning

◆ Friction Compensation

Friction compensation compensates for changes in the following conditions.

- Changes in the viscous resistance of the lubricant, such as grease, on the sliding parts of the machine
- · Changes in the friction resistance resulting from variations in the machine assembly
- · Changes in the friction resistance due to aging

The conditions for applying friction compensation depend on the mode selection.

Mode Selection Settings	Friction Compensation	
1: Standard	Based on the setting of Pn408 = n.X□□□ (Friction Compensation Function Selection)*	
2: For position control	- Adjusted with friction compensation.	
3: For position control (emphasis on overshooting)		

Parameter		Function	When Enabled	Classification
Pn408	n. 0□□□ (default setting)	Disable friction compensation.	Immediately	Setup
	n. 1000	Enable friction compensation.		

* Refer to the following section for details.

Required Parameter Settings on page 9-70

Feedforward

If Pn140 is set to n.0 [10] (Do not use model following control and speed/torque feedforward together (default setting)) and tuning is performed with the mode selection set to 2 or 3, feed-forward (Pn109), the speed feedforward input (VFF), and the torque feedforward input (TFF) will be disabled.

To use the speed feedforward input (VFF), the torque feedforward input (TFF), and model following control from the host controller in the system, set Pn140 to n.1DDD (Use model following control and speed/torque feedforward together).

F	Parameter	Function	When Enabled	Classification
Pn140	n.0□□□ (default setting)	Do not use model following control and speed/torque feedforward together.	Immediately	Tuning
111140	n.1000	Use model following control and speed/torque feedforward together.	Intinediately	runnig

Refer to the following manual for information on the torque feedforward input (TFF) and the speed feedforward input (VFF).

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)



When model following control is used with the feedforward function, it is used to make optimum feedforward settings in the SERVOPACK. Therefore, model following control is not normally used together with either the speed feedforward input (VFF) or torque feedforward input (TFF) from the host controller. However, model following control can be used with the speed feedforward input (VFF) or torque feedforward input (TFF) if required. An unsuitable feedforward input may result in overshooting.

9.6.7 Related Parameters

9.6.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute autotuning without a host reference.

Do not change the settings while autotuning without a host reference is being executed.

Parameter	Name	Automatic Changes
Pn100	Speed Loop Gain	Yes
Pn101	Speed Loop Integral Time Constant	Yes
Pn102	Position Loop Gain	Yes
Pn103	Moment of Inertia Ratio	Yes
Pn121	Friction Compensation Gain	Yes
Pn123	Friction Compensation Coefficient	Yes
Pn124	Friction Compensation Frequency Correction	No
Pn125	Friction Compensation Gain Correction	Yes
Pn401	First Stage First Torque Reference Filter Time Constant	Yes
Pn408	Torque-Related Function Selections	Yes
Pn409	First Stage Notch Filter Frequency	Yes
Pn40A	First Stage Notch Filter Q Value	Yes
Pn40C	Second Stage Notch Filter Frequency	Yes
Pn40D	Second Stage Notch Filter Q Value	Yes
Pn140	Model Following Control-Related Selections	Yes
Pn141	Model Following Control Gain	Yes
Pn142	Model Following Control Gain Correction	Yes
Pn143	Model Following Control Bias in the Forward Direction	Yes
Pn144	Model Following Control Bias in the Reverse Direction	Yes
Pn145	Vibration Suppression 1 Frequency A	Yes
Pn146	Vibration Suppression 1 Frequency B	Yes
Pn147	Model Following Control Speed Feedforward Compensation	Yes
Pn160	Anti-Resonance Control-Related Selections	Yes
Pn161	Anti-Resonance Frequency	Yes
Pn163	Anti-Resonance Damping Gain	Yes
Pn531	Program Jogging Travel Distance	No
Pn533	Program Jogging Movement Speed for Rotary Servomotor	No
Pn585	Program Jogging Movement Speed for Linear Servomotor	No
Pn534	Program Jogging Acceleration/Deceleration Time	No
Pn535	Program Jogging Waiting Time	No
Pn536	Program Jogging Number of Movements	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

9.7.1 Outline

9.7 Autotuning with a Host Reference

This section describes autotuning with a host reference.



Autotuning with a host reference makes adjustments based on the set speed loop gain (Pn100). Therefore, precise adjustments cannot be made if there is vibration when adjustments are started. Make adjustments after lowering the speed loop gain (Pn100) until vibration is eliminated.


9.7.1 Outline

Autotuning with a host reference automatically makes optimum adjustments for operation references from the host controller.

The following items are adjusted automatically.

- Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control
- Vibration suppression

Refer to the following section for details on the parameters that are adjusted. 9.7.7 Related Parameters on page 9-41



• Because autotuning with a host reference adjusts the SERVOPACK during automatic operation, vibration or overshooting may occur. To ensure safety, make sure that you can perform an emergency stop at any time.

9.7.2 Restrictions

9.7.2 Restrictions

Systems for Which Adjustments Cannot Be Made Accurately

Adjustments will not be made correctly for autotuning with a host reference in the following cases. Use custom tuning.

- When the travel distance for the reference from the host controller is equal to or lower than the setting of the positioning completed width (Pn522)
- Rotary Servomotors: When the movement speed for the reference from the host controller is equal to or lower than the setting of the rotation detection level (Pn502)
- Linear Servomotors: When the movement speed for the reference from the host controller is equal to or lower than the setting of the zero speed level (Pn581)
- When the time required to stop is 10 ms or less
- When the rigidity of the machine is low and vibration occurs when positioning is performed
- When the position integration function is used
- · When proportional control is used
- When mode switching is used
- When the positioning completed width (Pn522) is too narrow

Refer to the following sections for details on custom tuning.

3.8 Custom Tuning on page 9-42

Preparations

Always check the following before you execute autotuning with a host reference.

- The servo must be in ready status.
- There must be no overtravel.
- The servo must be OFF.
- Position control must be selected if power is supplied to the motor (i.e., when the servo is ON).
- The gain selection switch must be set to manual gain selection (Pn139 = $n.\Box\Box\Box$).
- The first gains must be selected.
- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).
- There must be no warnings.
- The tuning-less function must be disabled (Pn170 = $n.\Box\Box\Box$).
- The parameters must not be write prohibited.

9.7.3 Applicable Tools

The following table lists the tools that you can use to perform autotuning with a host reference.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn202	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	9.7.4 Operating Procedure on page 9-36

9.7.4 Operating Procedure

Use the following procedure to perform autotuning with a host reference.



• If you are using an MP3000-Series Controller for phase control, set the mode selection to 1. If 2 or 3 is selected for the mode, correct phase control may not be possible.

- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Click the *P* Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.
- 4. Click the Execute Button.

Tuning	×
This function executes tuning for the Servopack. Using this function while the motor is running is dangerous. Be sure to carefully read the SigmaWin+ Operation Manual before executing this function. Special care must be taken for the following	g.
-Safety Precautions> 1. Before executing this function, make sure that the emergency stop (power off) can be activated when needed. The response speed may change considerably during tuning. Before executing this function, make sure that the emergency stop (power off) can be activated when needed.	
 Confirm the safety of the area adjoining the drive unt. Before executing this function, always confirm that the area within the motor motion range and direction is clear for safe operation. Provide protective devices to ensure safety in the event of overtraveling or other unexpected movement. 	
 Averys confirm that there is no position error before running the motor. Be sure to return to the origin and reset the position prior to normal operation. Running the motor without resetting the origin can lead to an overrun and is extremely dangerous. 	
4. When the moment of inertia (mass) identification function is used for a vertical axis, check the safety of the system. When the moment of inertia (mass) identification function is used for a vertical axis, confirm that the axis level does not drop when the servo is turned off.	
<turning precautions»<br="">5. Set he moment of inertia (mass) ratio first. The moment of inertia (mass) ratio must be set to achieve correct tuning. Be sure to set the ratio. The setting can be performed from the Tuning window.</turning>	
 If vitration is generated, execute custom tuning. Lower the gain until there is no vibration by executing custom tuning. Note: White tuning, you can read the orecautions related to the process. 	
Click the Precautions button provided in each tuning window.	
Execute Cancel	

5. Select the **Position reference input** Option in the **Autotuning** Area and then click the **Autotuning** Button.

Tuning AXIS#00	×		
Set the moment of inertia (mass) ratio before executing autotuning.	Precautions		
Moment of inertia (mass) ratio identification			
Pn103 : Moment of Inertia Ratio			
Execute.			
202 % Edit			
Reference input from host controller			
Position Reference Input			
C No Reference Input			
Advanced adjustment	Finish		

Information

When the following dialog box is displayed, click the **OK** Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).

Tuning
The moment of inertia (mass) ratio has never been changed from the default setting. Set a correct moment of inertia (mass) ratio in the Moment of Inertia (Mass) Setting window before starting buning. If an incorrect moment of inertia (mass) ratio is set, vibration may be generated during tuning. Do you want to continue tuning?
Cancel

6. Set the conditions in the Mode selection Box and the Mechanism selection Box, and then click the Next Button.

If you select the **Start tuning using the default settings** Check Box in the **Tuning parameters** Area, the tuning parameters will be returned to the default settings before tuning is started.

Mode selection Box

	ection
2:For p	psitioning
addition	djustment specialized for positioning will be executed. In the following automatic adjustments can be executed: Model g control, notch filter, anti-resonance control, and vibration sion.
Mechanis	m selection
2:Ball s	crew mechanism or linear motor
such as	s adjustment suitable for relatively high-rigidity mechanism, a ball screw or linear motor. Select this type if there is no le mechanism.
- Tuning pa	arameters
☐ Start	tuning using the default settings.

• Tuning parameters Box Specify the parameters to use for tuning. If you select the **Start tuning using the default settings** Check Box, the tuning parameters will be returned to the default settings before tuning is started.

Set the mode.		
Mode Selection	Description	
1: Standard	Standard gain adjustment is per- formed. In addition to gain adjust- ment, notch filters and anti- resonance control are automatically adjusted.	
2: For positioning	Tuning is performed for positioning applications. In addition to gain adjustment, model following control, notch filters, anti-resonance control, and vibration suppression are auto- matically adjusted.	
3: For positioning especially to pre- vent overshooting	Tuning is performed for positioning applications with emphasis on elimi- nating overshooting. In addition to gain adjustment, notch filters, anti- resonance control, and vibration sup- pression are automatically adjusted.	

Mechanism selection Box

Select the type according to the machine element to drive.

If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

Mechanism Selection	Description
1: Belt mechanism	Tuning is performed for a mecha- nism with relatively low rigidity, e.g., a belt.
2: Ball screw mechanism or linear motor	Tuning is performed for a mecha- nism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting.
3: Rigid model	Tuning is performed for a mecha- nism with high rigidity, e.g., a rigid body system.

7. Click the Yes Button.



8. Input the correct moment of inertia ratio and click the Next Button.

📲 Autotuning - Moment of Inertia Ratio Setting AXI 🗪		
If Moment of Inertia Ratio is not correctly set, vibration may be		
generated. Is Moment of Inertia Ratio correctly set?		
Pn103 : Moment of Inertia Ratio (0 - 20000)		
202 [%]		
< Back Next > Cancel		

9. First confirm safety around moving parts. Then turn ON the servo, enter a reference from the host controller, and click the **Start tuning** Button.

Autotuning - Automatic s	etting AXIS#00	×
Waiting for execution Oacillation level measurement Gain search behaviour evaluation	Tuning Turn the servo on, input the reference from the host controller, and then click the Start button.	
	Mode selection 2:For positioning	_
Notch filter Anti-res Adj Vib Suppress	Mechanism selection 2:Ball screw mechanism or linear motor	
Precautions	< Back Finish Cance	

10. Click the Yes Button.



Tuning will be executed.

Vibration that occurs during tuning will be detected automatically and suitable settings will be made for that vibration. When the settings have been completed, the indicators for the functions that were used will light at the lower left of the dialog box.

Fig		
Salaria - Automatic s	etting AXIS#00	8
Waiting for execution	TuningExecuting tuning (Input the reference.)	
Oscillation level measurement	Cancel	
Gain search behaviour evaluation		
Tuning completed		
	Mode selection 2:For positioning	
Notch filter	Mechanism selection	
OAnti-res Adj Vib Suppress	2:Ball screw mechanism or linear motor	
Precautions	< Back Finish Cancel	

9.7.5 Troubleshooting Problems in Autotuning with a Host Reference

11. When tuning has been completed, click the **Finish** Button.

The results of tuning will be set in the parameters and you will return to the Tuning Dialog Box.

This concludes the procedure to perform autotuning with a host reference.

9.7.5 Troubleshooting Problems in Autotuning with a Host Reference

The following tables give the causes of and corrections for problems that may occur in autotuning with a host reference.

Autotuning with a Host Reference Was Not Performed

Possible Cause	Corrective Action
Main circuit power supply is OFF.	Turn ON the main circuit power supply.
An alarm or warning occurred.	Remove the cause of the alarm or warning.
Overtraveling occurred.	Remove the cause of overtraveling.
The second gains were selected with the gain selection.	Disable automatic gain switching.
The HWBB was activated.	Release the HWBB.

Troubleshooting Errors

Error	Possible Cause	Corrective Action
The gain adjustments were not successfully completed.	Machine vibration occurs or positioning completion is not stable when the Servomotor stops.	 Increase the setting of the positioning completed width (Pn522). Change the mode from 2 to 3. If machine vibration occurs, suppress the vibration with the anti-resonance control function and the vibration suppression function.
Positioning was not completed within approximately 10 seconds after posi- tion adjustment was completed.	The positioning com- pleted width is too nar- row or proportional control is being used.	 Increase the setting of the positioning completed width (Pn522). Set V_PPI to 0 in the servo command output signals (SVCMD_IO).

Adjustment Results Are Not Satisfactory for Position Control

You may be able to improve the adjustment results by changing the settings of the positioning completed width (Pn522) and the electronic gear ratio (Pn20E/Pn210).

If satisfactory results are still not possible, adjust the overshoot detection level (Pn561). That may improve the adjustment results.

- Pn561 = 100% (default setting)
- This will allow tuning with overshooting that is equivalent to the positioning completed width. • Pn561 = 0%

This will allow tuning to be performed without overshooting within the positioning completed width, but the positioning completed width may be extended.

	Overshoot Detection Level			Speed Position Torque	
Pn561	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1%	100	Immediately	Setup

9.7.6 Automatically Adjusted Function Settings

These function settings are the same as for autotuning without a host reference. Refer to the following section.

3.6.6 Automatically Adjusted Function Settings on page 9-32

9.7.7 Related Parameters

9.7.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute autotuning with a host reference.

Do not change the settings while autotuning with a host reference is being executed.

Parameter	Name	Automatic Changes
Pn100	Speed Loop Gain	Yes
Pn101	Speed Loop Integral Time Constant	Yes
Pn102	Position Loop Gain	Yes
Pn103	Moment of Inertia Ratio	No
Pn121	Friction Compensation Gain	Yes
Pn123	Friction Compensation Coefficient	Yes
Pn124	Friction Compensation Frequency Correction	No
Pn125	Friction Compensation Gain Correction	Yes
Pn401	First Stage First Torque Reference Filter Time Constant	Yes
Pn408	Torque-Related Function Selections	Yes
Pn409	First Stage Notch Filter Frequency	Yes
Pn40A	First Stage Notch Filter Q Value	Yes
Pn40C	Second Stage Notch Filter Frequency	Yes
Pn40D	Second Stage Notch Filter Q Value	Yes
Pn140	Model Following Control-Related Selections	Yes
Pn141	Model Following Control Gain	Yes
Pn142	Model Following Control Gain Correction	Yes
Pn143	Model Following Control Bias in the Forward Direction	Yes
Pn144	Model Following Control Bias in the Reverse Direction	Yes
Pn145	Vibration Suppression 1 Frequency A	Yes
Pn146	Vibration Suppression 1 Frequency B	Yes
Pn147	Model Following Control Speed Feedforward Compensation	Yes
Pn160	Anti-Resonance Control-Related Selections	Yes
Pn161	Anti-Resonance Frequency	Yes
Pn163	Anti-Resonance Damping Gain	Yes

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

9.8.1 Outline

9.8 Custom Tuning

This section describes custom tuning.

9.8.1 Outline

You can use custom tuning to manually adjust the servo during operation using a speed or position reference input from the host controller. You can use it to fine-tune adjustments that were made with autotuning.

The following items are adjusted automatically.

- · Gains (e.g., speed loop gain and position loop gain)
- Filters (torque reference filter and notch filters)
- Friction compensation
- Anti-resonance control

Refer to the following section for details on the parameters that are adjusted. **9.8.7** *Related Parameters* on page 9-50

There are two adjustment methods that you can use for custom tuning.

 Tuning Mode 0 (Setting Servo Gains Giving Priority to Stability) or 1 (Setting Servo Gains Giving Priority to Good Response)

These modes allow you to set stable control conditions for multiple servo gains by manipulating only one tuning level. Automatic setting of notch filters and anti-resonance control is provided if vibration is detected. Manual anti-resonance control adjustment is also possible during custom tuning.

 Tuning Mode 2 (Setting Servo Gains Giving Priority to Position Control Applications) or 3 (Setting Servo Gains Giving Priority to Preventing Overshooting in Position Control Applications)

Two tuning levels are manipulated to reduce positioning time even further and set multiple servo gains.

Model following control is used to reduce the positioning time. If vibration is detected, notch filters and anti-resonance control are automatically adjusted, and friction compensation is automatically set. Manual anti-resonance control adjustment and vibration suppression are also possible during custom tuning.

A CAUTION

• Vibration or overshooting may occur during custom tuning. To ensure safety, make sure that you can perform an emergency stop at any time.

9.8.2 Preparations

Always check the following before you execute custom tuning.

- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).
- The tuning-less function must be disabled (Pn170 = $n.\Box\Box\Box$ 0).
- If speed control is used, tuning mode 0 or 1 must be set.
- The parameters must not be write prohibited.

9.8.3 Applicable Tools

9.8.3 Applicable Tools

The following table lists the tools that you can use to perform custom tuning.


Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn203	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning – Tuning	3.8.4 Operating Procedure on page 9-43

9.8.4 Operating Procedure

Use the following procedure to perform custom tuning.

 Before you execute custom tuning, check the information provided in the SigmaWin+ operating manual. Observe the following precautions. Make sure that you can perform an emergency stop at any time. When custom tuning is started, several parameters will be overwritten with the recommended settings, which may greatly affect the response before and after execution. Make sure that you can perform an emergency stop at any time. Set the moment of inertia correctly before you execute custom tuning. If the setting greatly differs from the actual moment of inertia, vibration may occur. If you change the feedforward level, the new setting will not be used immediately. It will be used after positioning is completed. 		
 If you are using an MP3000-series Controller for phase control, set the tuning mode to 0 or 1. If 2 or 3 is selected for the tuning mode, correct phase control may not be possible. 		

- 1. Confirm that the moment of inertia ratio (Pn103) is set correctly.
- 2. Click the *P* Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **3.** Select Tuning in the Menu Dialog Box. The Tuning Dialog Box will be displayed. Click the **Cancel** Button to cancel tuning.
- 4. Click the Execute Button.



5. Click the Advanced adjustment Button.


Tuning AXIS#00				
Set the moment of inertia (mass) ratio before Precautions executing autotuning.				
Moment of inertia (mass) ratio identification				
Pn103 : Moment of Inertia Ratio				
Execute.				
100 % <u>Edit</u>				
Autotuning				
Reference input from host controller				
Position Reference Input				
Advanced adjustment Finish				

Information

When the following dialog box is displayed, click the **OK** Button and then confirm that the correct moment of inertia ratio is set in Pn103 (Moment of Inertia Ratio).

Tuning
The moment of inertia (mass) ratio has never been changed from the default seting. Set a correct moment of inertia (mass) ratio in the Moment of Inertia (Mass) Setting window before starting tuning. If an incorrect moment of inertia (mass) ratio is set, vibration may be generated during tuning. Do you want to continue tuning?
OK Cancel

6. Click the Custom tuning Button.



7. Set the Tuning mode Box and Mechanism selection Box, and then click the Next Button.

Tuning - Mode selection AXIS#00	Tuning mode Box	
- Tuning mode	Mode Selection	Description
Set servo gains for positioning application. Overshoot will rarely occur since priority is given to stability. Overshoot will rarely occur since priority is given to stability. In addition to gain adjustments, the notch filter and anti-resonance control (except for torque (force) control) can be adjusted. Set servo gains with priority given to response. Overshoot may occur since priority is given to responsiveness. In	0: Set servo gains with priority given to stability.	This setting gives priority to stability and preventing overshooting. In addi- tion to gain adjustment, notch filters and anti-resonance control (except during torque control) are automatically adjusted.
Oversitiou may occur since priority is given to responsedness. In addition to gain adjustments, the notice filter and anti-resonance control (except for torque (force) control) can be adjusted. Mechanism selection 2:Ball screw mechanism or linear motor	1: Set servo gains with priority given to response.	Overshooting may occur because pri- ority is given to response. In addition to gain adjustment, notch filters and anti- resonance control (except during torque control) are automatically adjusted.
Executes adjustment suitable for relatively high-rigidity mechanism, such as a ball screw or linear motor. Select this type if there is no applicable Option Friction compensation © Enable © Disable	2: Set servo gains for positioning application.	Tuning is performed for positioning applications. In addition to gain adjust- ment, notch filters, anti-resonance control, and vibration suppression are adjusted.
Next > Cancel	3: Set servo gains especially to pre- vent overshooting during positioning application.	Tuning is performed for positioning applications with emphasis on elimi- nating overshooting. In addition to gain adjustment, notch filters, anti-reso- nance control, and vibration suppres- sion are adjusted.

Mechanism Selection Box

Select the type according to the machine element to drive.

If there is noise or if the gain does not increase, better results may be obtained by changing the rigidity type. Select the type according to the following guidelines.

Mechanism Selection	Description
1: Belt mechanism	Tuning is performed for a mechanism with relatively low rigidity, e.g., a belt.
2: Ball screw mechanism or Linear motor	Tuning is performed for a mechanism with relatively high rigidity, e.g., a ball screw or Linear Servomotor. Use this setting if there is no other appropriate setting.
3: Rigid body system	Tuning is performed for a mechanism with high rigidity, e.g., a rigid body system.

Information The tuning modes that you can select depend on the SERVOPACK setting.

8. If the moment of inertia ratio is not set correctly, correct the setting and then click the Next Button.

📑 Custom Tuning - Moment of Inertia Ratio Setti 💽		
When Moment of Inertia Ratio is not correctly set, vibration may be generated.		
Is Moment of Inertia Ratio correctly set?		
Pn103: Moment of Inertia Ratio (0 - 20000)		
< Back Cancel		

9. Turn ON the servo, enter a reference from the host controller, and then click the **Start tuning** Button.

Tuning Mode 0 or 1

	0 : Set servo gains with priority given to stability.	Tuning
Mechanism selection	2 : Ball screw mechanism or linear motor	Mecha
Friction compensation	Enable	Friction
Gain status	1 gain	Gain st
Tuning level adjustmer Setting the tuning level too high can cause vibration or abnormal noise.		FF I Index oversh FB
	Auto-setting	oversh
	Notch filter Vib Detect	
	Notch filter Vib Detect	No


uning - Adust AXIS#00 - # X 2 : Set servo gains for po 2 : Ball screw mechanism or linear motor Enable 1 gain Funing level Set the tuning level and start the tu Feed forward level (FF) 8889 **`_**] Notch filter 1 step 2 step Anti-res Ctrl Adj Anti-res Ctrl Adi Anti-res Adj Vib Suppress Vib Suppress Frequency 1 ive Cancel < Back To Autotuning Com Cancel

10. Use the \blacktriangle and \blacktriangledown Buttons to change the tuning level.

Click the **Back** Button during tuning to restore the setting to its original value. The tuning level will return to the value from before when custom tuning was started.

Tuning Mode 0 or 1

Increase the tuning level until overshooting occurs.



Tuning Mode 2 or 3

Tuning Mode 2 or 3

Increase the feedforward level until overshooting occurs and then increase the feedback level until overshooting is eliminated. Repeat these changes to make the adjustment.

Custom Tuning - Ac	lust AXIS#00	×
Tuning mode	2 : Set servo gains for positioning application.	
Mechanism selection	2 : Ball screw mechanism or linear motor	
Friction compensation	Enable	
Gain status	1 gain	
	Tuning level	
FF level adjustment	Set the tuning level. Feed forward level (FF)	Back
Increase until		
overshooting occurs.	T	
	Feedback level (FB)	
FB level adjustment		
Increase until	(1 - 2000)	
overshooting disappears.	Auto-setting	
1 1	Notch filter Vibration not detected	Vib Detect
	1 step inactive	
Response level OK?	2 step inactive Cancel	
No		
Yes	Anti-res Ctrl Adj Vibration not detected	
V	Anti-res Adj inactive Cancel	Anti-res Ctrl Adj
Finish	Vib Suppression	
	Frequency 1 inactive Cancel	Vib Suppress
Precautions	< Back To Autotuning Completed.	Cancel

Information

The new feedforward level will not be used until the positioning completed signal is output.

- **11.** You can set the functions to suppress vibration (notch filters, automatic anti-resonance setting, anti-resonance control adjustment, and autotuning with a host reference) as required.
 - Refer to the following section for details.
 - Vibration Suppression Functions on page 9-48

12. When tuning has been completed, click the Completed Button. The values that were changed will be saved in the SERVOPACK and you will return to the Tuning Dialog Box.

	lust AXIS#00	
Tuning mode	0 : Set servo gains with priority given to stability.	
Mechanism selection	2 : Ball screw mechanism or linear motor	
Friction compensation	Enable	
Gain status	1 gain	
Tuning level adjustmen Setting the tuning level too high can cause vibration or abnormal noise.	Tuning level. Set the tuning level. Tuning level Tuning level Tuning level Tuning level Tuning level Tuning level. Tuning levele	Back
	Auto-setting Notch filter Vibration not detected	
	1 step inactive	Vib Detect
	2 step inactive Cancel	-lQ
	2 step	
	Anti-res Ctrl Adj Vibration not detected	
	Anti-res Adj inactive Cancel	Anti-res Ctrl Adj

This concludes the procedure to set up custom tuning.

Vibration Suppression Functions


Notch Filters and Automatic Anti-resonance Setting

If the vibration frequency that occurs when you increase the servo gains is at 1,000 Hz or higher, notch filters are effective to suppress vibration. If the vibration is between 100 Hz and 1,000 Hz, anti-resonance control is effective.

Automatic Setting

To set vibration suppression automatically, use the parameters to enable notch filters and automatic anti-resonance control setting.

The notch filter frequency (stage 1 or 2) or anti-resonance control frequency that is effective for the vibration that was detected during tuning will be automatically set.



Auto-setting Cancel Buttons

The automatically set notch filter frequencies or the anti-resonance control frequencies may not always suppress vibration. Click the **Cancel** Button to reset the notch filter frequencies or the anti-resonance control frequencies to the values from just before these frequencies were set automatically.

When they are reset, vibration detection will start again.

• Vib Detect Button

While the notch filter or anti-resonance control adjustment automatic setting function is enabled, you can click the **Vib Detect** Button to manually detect vibration. When you click the **Vib Detect** Button, the SERVOPACK will detect vibration at that time, and set the notch filter frequency (stage 1 or 2) or anti-resonance control frequency that is effective for the detected vibration. You can also perform manual vibration detection even when the SERVOPACK does not detect vibration.

• Anti-res Ctrl Adj Button

You can use the **Anti-res Ctrl Adj** Button to execute the anti-resonance control function if fine-tuning is required. Refer to the following section.

3.9 Anti-Resonance Control Adjustment on page 9-51

Vib Suppress Button

Click the **Vib Suppress** Button to suppress low and transient vibration (oscillation) of approximately 1 Hz to 100 Hz that occurs during positioning. Refer to the following section.

3.10 Vibration Suppression on page 9-56

Autotuning with a Host Reference

You can perform autotuning with a host reference. Refer to the following section for details. **9.7** Autotuning with a Host Reference on page 9-35

9.8.5 Automatically Adjusted Function Settings

9.8.5 Automatically Adjusted Function Settings

You cannot use vibration suppression functions at the same time. Other automatic function settings are the same as for autotuning without a host reference. Refer to the following section. $\square = 9.6.6$ Automatically Adjusted Function Settings on page 9-32

9.8.6 <u>Tuning Example for Tuning Mode 2 or 3</u>

Step	Measurement Display Examples	Operation
1	Position deviation Reference speed Positioning completion signal	The positioning time is measured after the moment of inertia ratio (Pn103) is set correctly. Tuning is completed if the specifications are met. The tuning results are saved in the SERVOPACK.
2		The positioning time will be reduced if the feedforward level is increased. Tuning is completed if the specifications are met. The tuning results are saved in the SERVOPACK. If overshooting occurs before the specifications are met, pro- ceed to step 3.
3		Overshooting will be reduced if the feedback level is increased. If the overshooting is eliminated, proceed to step 4.
4		The graph shows overshooting that occurred when the feed- forward level was increased even more after step 3. In this state, overshooting occurs, but the positioning settling time is shorter. Tuning is completed if the specifications are met. The tuning results are saved in the SERVOPACK. If over- shooting occurs before the specifications are met, repeat steps 3 and 4. If vibration occurs before the overshooting is eliminated, the vibration is suppressed with the notch filters and anti-reso- nance control.
5	_	The tuning results are saved in the SERVOPACK.

9.8.7 Related Parameters

9.8.7 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute custom tuning.

Parameter	Name	Automatic Changes
Pn100	Speed Loop Gain	Yes
Pn101	Speed Loop Integral Time Constant	Yes
Pn102	Position Loop Gain	Yes
Pn103	Moment of Inertia Ratio	No
Pn121	Friction Compensation Gain	Yes
Pn123	Friction Compensation Coefficient	Yes
Pn124	Friction Compensation Frequency Correction	No
Pn125	Friction Compensation Gain Correction	Yes
Pn401	First Stage First Torque Reference Filter Time Constant	Yes
Pn408	Torque-Related Function Selections	Yes
Pn409	First Stage Notch Filter Frequency	Yes
Pn40A	First Stage Notch Filter Q Value	Yes
Pn40C	Second Stage Notch Filter Frequency	Yes
Pn40D	Second Stage Notch Filter Q Value	Yes
Pn140	Model Following Control-Related Selections	Yes
Pn141	Model Following Control Gain	Yes
Pn142	Model Following Control Gain Correction	Yes
Pn143	Model Following Control Bias in the Forward Direction	Yes
Pn144	Model Following Control Bias in the Reverse Direction	Yes
Pn145	Vibration Suppression 1 Frequency A	No
Pn146	Vibration Suppression 1 Frequency B	No
Pn147	Model Following Control Speed Feedforward Compensation	Yes
Pn160	Anti-Resonance Control-Related Selections	Yes
Pn161	Anti-Resonance Frequency	Yes
Pn163	Anti-Resonance Damping Gain	Yes

Do not change the settings while custom tuning is being executed.

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

9.9.1 Outline

9.9 Anti-Resonance Control Adjustment

This section describes anti-resonance control.

9.9.1 Outline


Anti-resonance control increases the effectiveness of vibration suppression after custom tuning.

Anti-resonance control is effective for suppression of continuous vibration frequencies from 100 to 1,000 Hz that occur when the control gain is increased. Vibration can be eliminated by setting vibration frequencies through automatic detection or by manually setting them to adjust the damping gain. Input an operation reference and execute this anti-resonance control adjustment when there is vibration.

Anti-resonance control is automatically set by autotuning without a host reference or autotuning with a host reference. Use anti-resonance control adjustment only if fine-tuning is required or readjustment is required as a result of a failure to detect vibration.

Perform custom tuning if required to increase the response after performing anti-resonance control adjustment. If the control gain is increased, e.g., when custom tuning is performed, vibration may occur again. If that occurs, perform anti-resonance control adjustment again to fine-tune the parameters.

- Related parameters will be set automatically when anti-resonance control adjustment is executed. This may greatly affect the response before and after execution. Make sure that you can perform an emergency stop at any time.
- Before you execute anti-resonance control adjustment, set the correct moment of inertia ratio (Pn103). If the setting greatly differs from the actual moment of inertia ratio, normal control of the machine may not be possible, and vibration may occur.



Vibration reduction can be made more effective by increasing the anti-resonance damping gain (Pn163), but the vibration may become larger if the damping gain is too high. Increase the damping gain by approximately 0% to 200% in 10% increments while checking the effect on vibration. If vibration reduction is still insufficient at a gain of 200%, cancel the setting, and lower the control gain by using a different method, such as custom tuning.

9.9.2 Preparations

0

Always check the following before you execute anti-resonance control adjustment.

- The tuning-less function must be disabled (Pn170 = $n.\Box\Box\Box$ 0).
- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).
- The control method must not be set to torque control.
- The parameters must not be write prohibited.

Tuning

9.9.3 Applicable Tools

9.9.3 Applicable Tools

The following table lists the tools that you can use to perform anti-resonance control adjustment.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn204	Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	🕼 9.9.4 Operating Procedure on page 9-52

9.9.4 Operating Procedure

To execute anti-resonance control adjustment, an operation reference is input, and the adjustment is executed while vibration is occurring.

The following methods can be used to execute anti-resonance control adjustment.

- To automatically detect the vibration frequency
- To manually set the vibration frequency

Use the following procedure to perform anti-resonance control.

 Before you execute anti-resonance control adjustment, check the information provided in the SigmaWin+ operating manual. Observe the following precautions. Make sure that you can perform an emergency stop at any time. Parameters will be set automatically when anti-resonance control adjustment is executed. This may greatly affect the response before and after execution. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time. Set the moment of inertia correctly before you execute anti-resonance control adjustment. If the setting greatly differs from the actual moment of inertia, effective vibration reduction may not be possible. If you have already performed anti-resonance control adjustment and then you change the frequency, the current anti-resonance control effect may be lost. Caution is particularly required when automatically detecting the vibration frequency. If effective vibration reduction is not achieved even after you execute anti-resonance control adjustment, cancel the function and lower the control gain by using a different method, such as custom tuning. Perform custom tuning separately if required to increase the response after performing anti-resonance control adjustment. If the servo gain is increased, e.g., when custom tuning is performed, vibration may occur again. If that occurs, perform and lower control adjustment again to fine-tune the parameters.

1. Perform steps 1 to 8 of the procedure for custom tuning. Refer to the following section for details.

9.8.4 Operating Procedure on page 9-43

2. Click the Anti-res Ctrl Adj Button.

The rest of the procedure depends on whether you know the vibration frequency.

Tuning mode	0 : Set servo gains with priority given to stability.	
Mechanism selection	2 : Ball screw mechanism or linear motor	
Friction compensation	Enable	
Gain status	1 gain	
Tuning level adjustmer Setting the tuning level too high can cause vibration or abnormal noise.		Start tuning
Finish		
Finish	Auto-setting	
Finish	Notch filter	Vib Detect
Finish	Notch filter	Vib Detect
Finish	Notch filter	Vib Detect
Finish	Notch filter 1 step 2 step 860Hz active Cancel	Vib Detect
Finish	Notch filter 1 step Cancel Cancel	Vib Detect

3. If you do not know the vibration frequency, click the **Auto Detect** Button. If you know the vibration frequency, click the **Manual Set** Button.

To Automatically Detect the Vibration Frequency

The frequency will be set.

88886

To Manually Set the Vibration Frequency


W Adjust Anti-resonance Control AXIS	- Adjustment		Anti-res Adj: Inactiv	
Click the Auto Detect button to automatically set the Requency:	Frequency Setting Management	Manual Set	Ano res Adj nacov	
Set frequency Click the Start adjustment button.	<< Frequency >>		Start adjustment	
Adjust damping gan Increase (Damping Gain).	«Damping Gain»»	(1-200) <u> </u>	<caution> if a frequency significantly different from the value before adjustment is set, the current anti-resonance control effect may be lost. Once the vibralis problem is solved, do not increase damping gain.</caution>	
	Precautions		Finish Cano	e

4. Click the Start adjustment Button.

4

5. Use the ▲ and ▼ Buttons in the Adjustment Area to change the settings. Click the **Reset** Button during tuning to restore the setting to its original value. The tuning level will return to the value from before when custom tuning was started.

To Automatically Detect the Vibration Frequency To Manually Set the Vibration Frequency Change the settings of the frequency and damping gain.



9.9.5 Related Parameters

6. When the adjustment has been completed, click the Finish Button.

The values that were changed will be saved in the SERVOPACK and you will return to the Tuning Dialog Box.

Determine frequency	Adjustment		Anti-res Adj Active
Click the Auto Detect button to automatically set the frequency.	Auto Detect		
Set frequency		Before adjustment 760 [Hz]	
Click the Start adjustment button.	<< Frequency >>		Reset
Adjust damping gain Increase (Damping Gain).)	(1-2000)	«Caution» If a frequency significantly different from the value before
Foan	< <damping gain="">></damping>		adjustment is set, the current anti-resonance control effect may be lost. Once the vibration problem is solved, do not increase damping gain.

This concludes the procedure to set up anti-resonance control.

9.9.5 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute anti-resonance control adjustment.

Do not change the settings while anti-resonance control adjustment is being executed.

Parameter	Name	Automatic Changes
Pn160	Anti-Resonance Control-Related Selections	Yes
Pn161	Anti-Resonance Frequency	Yes
Pn162	Anti-Resonance Gain Correction	No
Pn163	Anti-Resonance Damping Gain	Yes
Pn164	Anti-Resonance Filter Time Constant 1 Correction	No
Pn165	Anti-Resonance Filter Time Constant 2 Correction	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

9.9.6 Suppressing Different Vibration Frequencies with Anti-resonance Control

When you use anti-resonance control and increase the control gain, for some mechanism, vibration can occur at a higher frequency than the frequency for which vibration was suppressed. If this occurs, you can suppress vibration for more than one frequency by adjusting Pn166 (Anti-Resonance Damping Gain 2).

Information

tion Guidelines for Vibration That Can Be Suppressed

- Anti-resonance frequency (Pn161): fa [Hz], Another vibration frequency that occurs when the control gain is increased: fb [Hz]
- Vibration frequencies: 100 Hz to 1,000 Hz
- Range of different vibration frequencies: $1 < (fb/fa) \le 3$ to 4

Required Parameter Settings

The following parameter settings are required to use anti-resonance control for more than one vibration frequency.

	Parameter	I	Description		Wher Enable	
Pn160	n.□□□0 (default setting)	Do not use anti-resona			After restar	Setun
	n.🗆 🗆 🗆 1	Use anti-resonance co	ontrol.		Testal	L
	Anti-Resonance Frequency Speed				Positic	n Torque
Pn161	Setting Range	Setting Unit	Default Setting	When Ena	abled	Classification
	10 to 20,000	0.1 Hz	1000	Immedia	ately	Tuning
	Anti-Resonance Ga	ain Correction		Speed	Positic	n Torque
Pn162	Setting Range	Setting Unit	Default Setting	When Ena	abled	Classification
	1 to 1,000	1%	100	Immedia	ately	Tuning
	Anti-Resonance Da	amping Gain		Speed	Positic	n Torque
Pn163	Setting Range	Setting Unit	Default Setting	When Ena	abled	Classification
	0 to 300	1%	0	Immedia	ately	Tuning
	Anti-Resonance Fi	ter Time Constant 1 C	orrection	Speed	Positic	n Torque
Pn164	Setting Range	Setting Unit	Default Setting	When Ena	abled	Classification
	-1,000 to 1,000	0.01 ms	0	Immedia	ately	Tuning
	Anti-Resonance Fi	ter Time Constant 2 C	orrection	Speed	Positic	n Torque
Pn165	Setting Range	Setting Unit	Default Setting	When Ena	abled	Classification
	-1,000 to 1,000	0.01 ms	0	Immedia	ately	Tuning
	Anti-Resonance Da	amping Gain 2		Speed	Positic	n Torque
Pn166	Setting Range	Setting Unit	Default Setting	When Ena	abled	Classification
	0 to 1,000	1%	0	Immedia	ately	Tuning

Adjustment Procedure for Suppressing Different Vibration Frequencies with Anti-resonance Control

Use the following procedure to make adjustments to suppress different vibration frequencies with anti-resonance control.

Step	Operation
1	Use the gain adjustment and anti-resonance control. Refer to the following section for details. 3.9.9.4 Operating Procedure on page 9-52
2	If there is vibration at a higher frequency than the vibration suppressed with anti-resonance control in step 1, adjust Pn166 (Anti-Resonance Damping Gain 2).
3	Adjust Pn166 (Anti-Resonance Damping Gain 2) while checking to see if vibration reduction is effective. To adjust Pn166 (Anti-Resonance Damping Gain 2), increase the setting by 10% at a time starting from the value that resulted in Pn163 (Anti-Resonance Damping Gain) from the adjustment in step 1.
4	If the vibration disappears, the adjustment is completed. However, if the vibration does not disappear even when you adjust Pn166 (Anti-Resonance Damping Gain 2), reduce the tuning level or feedback level until vibration does not occur.

9.10.1 Outline

9.10 Vibration Suppression

This section describes vibration suppression.


9.10.1 Outline


Important

You can use vibration suppression to suppress transient vibration at a low frequency from 1 Hz to 100 Hz, which is generated mainly when the machine vibrates during positioning. This is effective for vibration frequencies for which notch filters and anti-resonance control adjustment are not effective.

Vibration suppression is automatically set by autotuning without a host reference or autotuning with a host reference. Use vibration suppression only if fine-tuning is required or readjustment is required as a result of a failure to detect vibration. To execute vibration suppression, input an operation reference and execute the function when there is vibration.

Perform custom tuning if required to increase the response after performing vibration suppression.





a device such as a displacement meter or vibration sensor to measure the vibration frequency.If an automatically detected vibration frequency is not suppressed, the actual frequency and the detected frequency may be different. Fine-tune the detected frequency if necessary.

Items That Influence Performance

If continuous vibration occurs while the Servomotor is stopping, vibration suppression cannot be used to suppress the vibration effectively. In this case, use anti-resonance control adjustment or custom tuning.

Detection of Vibration Frequencies

Frequency detection may not be possible if vibration does not appear in the position deviation or the vibration that results from the position deviation is too small. You can adjust the detection sensitivity by changing the setting of the residual vibration detection width (Pn560), which is set as a percentage of the positioning completed width (Pn522). Perform the detection of vibration frequencies again after adjusting the setting of Pn560.

	Residual Vibration D	Detection Width		Posit	on
Pn560	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 3,000	0.1%	400	Immediately	Setup

Note: As a guideline, change the setting 10% at a time. If the setting of this parameter is lowered, the detection sensitivity will be increased. Vibration may not be detected accurately if the setting is too small.

Information The vibration frequencies that are automatically detected may vary somewhat with each positioning operation. Perform positioning several times and make adjustments while checking the effect of vibration suppression.

9.10.2 Preparations

Always check the following before you execute vibration suppression.

- Position control must be used.
- The tuning-less function must be disabled (Pn170 = $n.\Box\Box\Box$ 0).
- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).
- The parameters must not be write prohibited.

9.10.3 Applicable Tools

The following table lists the tools that you can use to perform vibration suppression.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn205	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Tuning - Tuning	9.10.4 Operating Procedure on page 9-57


9.10.4 Operating Procedure

Use the following procedure to perform vibration suppression.

1. Perform steps 1 to 8 of the procedure for custom tuning. Refer to the following section for details.

9.8.4 Operating Procedure on page 9-43

2. Click the Vib Suppress Button.



3. Click the Import Button or click ▲ and ▼ Button to manually adjust the set frequency. When you click the Import Button, the residual vibration frequency in the motor is read as the set frequency. (The frequency can be read only when the residual vibration frequency is between 1.0 and 100.0.)



Frequency detection will not be performed if there is no vibration or if the vibration frequency is outside the range of detectable frequencies. If a vibration frequency is not detected, provide a means of measuring the vibration frequency.

Vibration Suppression AXIS	#00	×
Determine the frequency for setting. Crick the imposition Manual setting in also possible. Set the frequency. Crick was be budien. If the vibration problem could not be solved. In the signal set budien setting and the disk the seturency and	Adjustment Vib Suppr Residual Vibration Frequency 9.0 [Hz] Import Set frequency 9.0 [Hz] (10 - 100.0)	Reset
Finish	Precautions	Cancel


4. Click the Set Button.



No settings related to vibration suppression are changed during operation. If the Servomotor does not stop within approximately 10 seconds after changing the setting, an update timeout will occur. The setting will be automatically returned to the previous value.

Vibration Suppression AXIS	#00	×
Determine the frequency for setting. Click the Import button. Manual setting is also possible. Set the frequency.	Adjustment Vib Suppression Active Residual Vibration Frequency 9.0 [Hz] Import	
Click the Set button. If the vibration problem could not be solved. finely adjust the frequency and then click the Set button again.	Set frequency	
	Precautions Finish Cancel	1

If the vibration is not eliminated, use the \blacktriangle and \blacktriangledown Buttons for the set frequency to fine-tune the value and click the **Set** Button again.



Click the **Reset** Button during adjustment to restore the setting to its original value. The status from before when adjustment was started will be restored.

5. When the vibration has been eliminated, click the Finish Button. The updated value will be saved in the SERVOPACK.



Vibration suppression will be enabled in step 5. The Servomotor response, however, will change when the Servomotor comes to a stop with no reference input.

This concludes the procedure to set up vibration suppression.

9.10.5 Setting Combined Functions

9.10.5 Setting Combined Functions

You can also use the feedforward function when you execute vibration suppression.

In the default settings, feedforward (Pn109), the speed feedforward input (VFF), and the torque feedforward input (TFF) are disabled.

To use the speed feedforward input (VFF), the torque feedforward input (TFF), and model following control from the host controller in the system, set Pn140 to n.1DDD (Use model following control and speed/torque feedforward together).

Parameter		Parameter Function		Classification
Pn140	n.0□□□ (defaultsetting)	Do not use model following control and speed/torque feedforward together.	- Immediately	Tuning
	n.1000	Use model following control and speed/ torque feedforward together.		runnig

Refer to the following manual for information on the torque feedforward input (TFF) and the speed feedforward input (VFF).

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

When model following control is used with the feedforward function, it is used to make optimum feedforward settings in the SERVOPACK. Therefore, model following control is not normally used together with either the speed feedforward input (VFF) or torque feedforward input (TFF) from the host controller. However, model following control can be used with the speed feedforward input (VFF) or torque feedforward input (TFF) if required. An unsuitable feedforward input may result in overshooting.

9.10.6 Related Parameters

The following parameters are automatically adjusted or used as reference when you execute vibration suppression.

Do not change the settings while vibration suppression is being executed.

Parameter	Name	Automatic Changes
Pn140	Model Following Control-Related Selections	Yes
Pn141	Model Following Control Gain	Yes
Pn142	Model Following Control Correction	No
Pn143	Model Following Control Bias in the Forward Direction	No
Pn144	Model Following Control Bias in the Reverse Direction	No
Pn145	Vibration Suppression 1 Frequency A	Yes
Pn146	Vibration Suppression 1 Frequency B	Yes
Pn147	Model Following Control Speed Feedforward Compensation	No
Pn14A	Pn14A Vibration Suppression 2 Frequency	
Pn14B	Vibration Suppression 2 Correction	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

9.11.1 Outline

9.11 Speed Ripple Compensation

This section describes speed ripple compensation.

9.11.1 Outline

Speed ripple compensation reduces the amount of ripple in the motor speed due to torque ripple or cogging torque. You can enable speed ripple compensation to achieve smoother operation. To enable it, you must set up ripple compensation on the SigmaWin+.

• Speed ripple compensation requires operating the Servomotor and therefore presents hazards. Observe the following precaution.

Confirm safety around moving parts.

This function involves automatic operation. Make sure that you can perform an emergency stop (to turn OFF the power supply) at any time.



- Execute speed ripple compensation only after adjusting the gains.
- Reset speed ripple compensation after you replace the Servomotor or SERVOPACK.

• Execute speed ripple compensation after jogging to a position that ensures a suitable range of motion.

9.11.2 Setting Up Speed Ripple Compensation

Restrictions

The following restrictions apply to the setup for speed ripple compensation.

Systems for Which Execution Cannot Be Performed

There are no restrictions.

Systems for Which Adjustments Cannot Be Made Accurately

Systems for which there is not a suitable range of motion

Preparations

Always check the following before you set up speed ripple compensation.

- The main circuit power supply must be ON.
- The servo must be OFF.
- There must be no alarms or warnings.
- There must be no hard wire base block (HWBB).
- The parameters must not be write prohibited.

9.11.2 Setting Up Speed Ripple Compensation

Applicable Tools


The following table lists the tools that you can use to set up speed ripple compensation.

Tool	Fn No./Function Name	Reference	
Digital Operator	You cannot set up speed ripple compensation from the Digital Operator.		
SigmaWin+	Diagnostic – Ripple Compensation	G Operating Procedure on page 9-61	

Operating Procedure

Use the following procedure to set up speed ripple compensation.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Ripple Compensation in the Menu Dialog Box. The Ripple Compensation Dialog Box will be displayed.
- 3. Click the OK Button.



Information 1. Click the **Cancel** Button to cancel ripple compensation. The Main Window will return.



Click the **OK** Button to cancel write prohibition.

9.11.2 Setting Up Speed Ripple Compensation

4. Click the Edit Button.

leasure Writing Results Ve	rification 🕶 Confirm	Noasurement	
ian)	v [plv]	Ph304 : Jogging Spr 500 Please execu	te by 100(min-1) Edit
4		0 5	ervo OFF
2		Forward	Reverse
0			_
-2			Write
		. <u>. </u>	
v 0.0 60.0 120.0 180.0 240.0 30 Time		Confirm-	•

5. Enter the jogging speed in the Input Value Box and click the OK Button.

Edit AXIS#00	—X —
Pn304 Jogging Speed	
Input value 500 min 1 (0 - 10000)	
ОК	Cancel

6. Click the Servo ON Button.

₩ Ripple Compensation AXIS#00						
Measure Writing Results Verification Confin						
0	M R Measurement Ph304 : Jogging Speed					
[dw]	[div] 600 [min-1] Edt					
4	Serve OFF					
2						
1 0						
.1						
-5 00 60.0 120.0 180.0 240.0 360.0 420.0 480.0 5	100 6000					
Before adjustment After adjustment	Patrix Reset Completed					


9.11.2 Setting Up Speed Ripple Compensation


7. Click the Forward Button or the Reverse Button.

Measurement operation is started.

The Servomotor shaft will rotate at the preset jogging speed while you hold down the **Forward** or **Reverse** Button and the speed ripple will be measured.

The feedback speed and torque reference graph will be displayed in the Ripple Compensation Dialog Box during jogging.





- 8. After speed ripple measurement has been completed, click the Write Button. The ripple compensation value will be written to the SERVOPACK.
- 9. After writing has been completed, click the OK Button.

Ripple Co	mpensation	×
Í	The Ripple Compensation value was written in. Please measure again and verify. If a verification result is good, please click the "Completed" button.	
	ОК	


9.11.3 Setting Parameters

10. Click the Forward Button or the Reverse Button.

Verification operation is started.

The Servomotor shaft will rotate at the preset jogging speed while you hold down the **Forward** or **Reverse** Button.

The waveform with speed ripple compensation applied to it will be displayed.



11. If the verification results are OK, click the Finish Button.

Information To discard the setup results, click the Reset Button.

This concludes the setup for speed ripple compensation.

9.11.3 Setting Parameters

The function is enabled when you perform the operating procedure on *Operating Procedure* on page 9-61. To cancel speed ripple compensation, use $Pn423 = n.\square\square\square$ (Disable speed ripple compensation) to disable it.

Parameter		Description	When Enabled	Classifi- cation
Pn423	n.□□□0 (default setting)	Disable speed ripple compensation.	Immedi-	Setup
	n.0001	Enable speed ripple compensation.	ately	

If you enable speed ripple compensation, a compensation reference will be applied to reduce ripple even when stopped at a 0 speed reference. In speed control mode, this may result in the Servomotor moving slightly. To prevent this, set $Pn423 = n.\Box X \Box \Box$ (Speed Ripple Compensation Enable Condition Selection) and Pn427 or Pn49F (Speed Ripple Compensation Enable Speed).

Parameter		Description	When Enabled	Classifi- cation
Pn423	n.0000 (default setting)	Speed reference	After restart	Setup
	n.🗆 1 🗖 🗖	Motor Speed	restart	


For Rotary Servomotors

	Speed Ripple Compensation Enable Speed			Speed Positio	Torque
Pn427	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 min ⁻¹	0	Immediately	Tuning

• For Linear Servomotors

	Speed Ripple Comp	ensation Enable Spe	Speed Position Torque		
Pn49F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	1 mm/s	0	Immediately	Tuning

9.11.3 Setting Parameters



Speed Ripple Compensation Warnings

The speed ripple compensation value is specific to each Servomotor. If you replace the Servomotor while speed ripple compensation is enabled, an A.942 warning (Speed Ripple Compensation Information Disagreement) will occur to warn you.

- You can use any of the following methods to clear A.942.
- Reset the speed ripple compensation value on the SigmaWin+.
- Disable speed ripple compensation (Pn423 = $n.\Box\Box\Box$).
- Disable detection of A.942 (Pn423 = $n.\Box\Box1\Box$).

Pa	rameter	Description	When Enabled	Classifi- cation
Pn423	n.□□0□ (default setting)	Detect A.942 alarms.	After restart	Setup
	n.0010	Do not detect A.942 alarms.	restart	

9.12 Additional Adjustment Functions

This section describes the functions that you can use to make adjustments after you perform autotuning without a host reference, autotuning with a host reference, and custom tuning.

Function	Applicable Control Methods	Reference
Gain Switching	Position control, speed control, or torque control*	page 9-66
Friction Compensation	Position control or speed control	page 9-70
Current Control Mode Selection	Position control, speed control, or torque control	page 9-74
Current Gain Level Setting	Position control or speed control	page 9-74
Speed Detection Method Selection	Position control, speed control, or torque control	page 9-75
Backlash Compensation	Position Control	page 9-75

* Automatic gain switching is enabled only for position control.

9.12.1 Gain Switching

Two gain switching functions are available, manual selection and automatic switching. The manual switching function uses an external input signal to select the gains, and the automatic switching function changes the gains automatically.

You can use gain switching to shorten the positioning time by increasing the gains during positioning and suppressing vibration by decreasing the gains while stopping.

P	Parameter Function		When Enabled	Classification
	n.□□□0 (default setting)	Use manual gain switching.	Immediately	Tuning
n.□□□2		Use automatic gain switching pattern 1.	† 	

Note: $Pn139 = n.\square\square\square1$ is a reserved parameter. Do not change.

Refer to the following section for gain switching combinations.

Gain Switching Combinations on page 9-66

Refer to the following sections for information on manual and automatic gain switching. *Manual Gain Switching* on page 9-67 and *Automatic Gain Switching* on page 9-67

Gain Switching Combinations

Selected Gains	Speed Loop Gain	Speed Loop Integral Time Constant	Position Loop Gain	Torque Refer- ence Filter	Model Fol- lowing Con- trol Gain	Model Follow- ing Control Correction	Friction Compensa- tion Gain
Gain Set- tings 1	Speed Loop Gain (Pn100)	Speed Loop Integral Time Constant (Pn101)	Position Loop Gain (Pn102)	First Stage First Torque Reference Fil- ter Time Con- stant (Pn401)	Model Fol- lowing Con- trol Gain* (Pn141)	Model Follow- ing Control Correction* (Pn142)	Friction Compensa- tion Gain (Pn121)
Gain Set- tings 2	Second Speed Loop Gain (Pn104)	Second Speed Loop Integral Time Constant (Pn105)	Second Position Loop Gain (Pn106)	First Stage Second Torque Refer- ence Filter Time Con- stant (Pn412)	Second Model Fol- lowing Con- trol Gain* (Pn148)	Second Model Following Control Gain Correction* (Pn149)	Second Friction Compensa- tion Gain (Pn122)

* Gain switching for the model following control gain and the model following control gain correction is applicable only to manual gain switching.

To enable gain switching with these parameters, a gain switching input signal must be used and the following conditions must be met. If the conditions are not met, these parameters will not be changed even if the other parameters in the above table are changed.

There must be no reference.

• The motor must be stopped.

Manual Gain Switching

With manual gain switching, you use G-SEL in the servo command output signals (SVCMD_IO) to change between gain settings 1 and gain settings 2.

Туре	Command Name	Value	Meaning
Input	G-SEL in the servo command output sig-	0	Changes the gain settings to gain settings 1.
	nals (SVCMD_IO)	1	Changes the gain settings to gain settings 2.

Automatic Gain Switching


Automatic gain switching is enabled only for position control. The switching conditions are specified by using the following settings.

Para	ameter	Switching Condition	Selected Gains	Switching Waiting Time	Switching Time
Dp120	~ 0002	Condition A satisfied	Gain settings 1 to gain set- tings 2	Gain Switching Waiting Time 1 Pn135	Gain Switching Time 1 Pn131
Pn139 n.□□□2	Condition A not satisfied	Gain settings 2 to gain set- tings 1	Gain Switching Waiting Time 2 Pn136	Gain Switching Time 2 Pn132	

Select one of the following settings for switching condition A.


P	Parameter	Position Control Gain Switching Condition A	For Control Methods Other Than Position Control (No Switching)	When Enabled	Classification
	n.□□0□ (default setting)	/COIN (Positioning Com- pletion) signal ON	Gain settings 1 used.		
	n.0010	/COIN (Positioning Com- pletion) signal OFF	Gain settings 2 used.		
	n.🗆 🗆 2 🗆	/NEAR (Near) signal ON	Gain settings 1 used.		
Pn139	n.🗆 🗆 3 🗆	/NEAR (Near) signal OFF	Gain settings 2 used.	Immediately	Tuning
	n.0040	Position reference filter output is 0 and position reference input is OFF.	Gain settings 1 used.		
	n.0050	Position reference input is ON.	Gain settings 2 used.		

Automatic Switching Pattern 1 (Pn139 = n.



Relationship between the Waiting Times and Switching Times for Gain Switching

In this example, an ON /COIN (Positioning Completion) signal is set as condition A for automatic gain switching. The position loop gain is changed from the value in Pn102 (Position Loop Gain) to the value in Pn106 (Second Position Loop Gain). When the /COIN signal turns ON, the switching operation begins after the waiting time (Pn135). The switching operation changes the position loop gain linearly from the gain set in Pn102 to the gain set in Pn106 over the switching time (Pn131).





ation You can use gain switching for either PI control or I-P control (Pn10B = $n.\Box\Box\Box\Box$ or $\Box\Box$ 1 \Box).

Related Parameters

10 to Pn101 Speed L Pn101 Settin 15 to Position Pn102 Settin 10 to First Sta Pn401 Settin 0 to O to Model F Model F	g Range 51,200 Loop Gain g Range 20,000 ge First Torq g Range	Setting Unit 0.1 Hz Time Constant Setting Unit 0.01 ms Setting Unit 0.1/s ue Reference Filter Setting Unit		When Enabled Immediately Speed Posit When Enabled Immediately Posit When Enabled Immediately Speed Posit Posit Posit Posit Posit Posit Posit Posit	Classification Tuning ion Classification Tuning
Pn101 Speed L Settin 15 to Pn102 Settin 10 to Pn401 Settin 0 to Model F	oop Integral g Range 51,200 Loop Gain g Range 20,000 ge First Torq g Range	Time Constant Setting Unit 0.01 ms Setting Unit 0.1/s ue Reference Filter	Default Setting 2,000 Default Setting 400 Time Constant	Speed Posit When Enabled Immediately Posit When Enabled Immediately	Classification Tuning ion Classification Tuning
Pn101 Settin 15 to Position Pn102 Settin 10 to First Sta Pn401 Settin 0 to Model F	g Range 51,200 Loop Gain g Range 20,000 ge First Torq g Range	Setting Unit 0.01 ms Setting Unit 0.1/s ue Reference Filter	2,000 Default Setting 400 Time Constant	When Enabled Immediately Posit When Enabled Immediately	Classification Tuning ion Classification Tuning
15 toPn102PositionPn104Settin10 toFirst StaPn401Settin0 toModel F	51,200 Loop Gain g Range 20,000 ge First Torq g Range	0.01 ms Setting Unit 0.1/s ue Reference Filter	2,000 Default Setting 400 Time Constant	Immediately Posit When Enabled Immediately	Tuning ion Classification Tuning
Pn102 Position Pn102 Settin 10 to First Sta Pn401 Settin 0 to Model F	Loop Gain g Range 20,000 ge First Torq g Range	Setting Unit 0.1/s ue Reference Filter	Default Setting 400 Time Constant	Posit When Enabled Immediately	Classification Tuning
Pn102 Settin 10 to First Sta Pn401 Settin 0 to Model F	g Range 20,000 ge First Torq g Range	0.1/s ue Reference Filter	400 Time Constant	When Enabled Immediately	Classification Tuning
10 toPn401First StaSettin 0 toModel F	20,000 ge First Torq g Range	0.1/s ue Reference Filter	400 Time Constant	Immediately	Tuning
Pn401 First Sta 0 to Model F	ge First Torq g Range	ue Reference Filter	Time Constant		<u> </u>
Pn401 Settin 0 to Model F	g Range			Speed Posit	
0 to Model F		Setting Unit			ion Torque
Model F	65 535	U	Default Setting	When Enabled	Classification
	00,000	0.01 ms	100	Immediately	Tuning
Pn141 Settin	ollowing Con	trol Gain		Posit	ion
	g Range	Setting Unit	Default Setting	When Enabled	Classification
10 to	20,000	0.1/s	500	Immediately	Tuning
Model F	ollowing Con	trol Correction		Posit	ion
Pn142 Settin	g Range	Setting Unit	Default Setting	When Enabled	Classification
500 t	o 2,000	0.1%	1,000	Immediately	Tuning
Friction	Compensatio	on Gain		Speed Posit	ion
Pn121 Settin	g Range	Setting Unit	Default Setting	When Enabled	Classification
10 to	o 1,000	1%	100	Immediately	Tuning
Second	Speed Loop	Gain		Speed Posit	ion
Pn104 Settin	g Range	Setting Unit	Default Setting	When Enabled	Classification
10 to	20,000	0.1 Hz	400	Immediately	Tuning
Second	Speed Loop	Integral Time Cons	tant	Speed Posit	ion
Pn105 Settin	g Range	Setting Unit	Default Setting	When Enabled	Classification
15 to	51,200	0.01 ms	2,000	Immediately	Tuning

Continued on next page.

Continued from previous page.

	1					
	Second Position Lo	op Gain		Posit	ion	
Pn106	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 20,000	0.1/s	400	Immediately	Tuning	
	First Stage Second	Torque Reference Fi	Iter Time Constant	Speed Posit	ion Torque	
Pn412	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 65,535	0.01 ms	100	Immediately	Tuning	
	Second Model Following Control Gain			Position		
Pn148	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 20,000	0.1/s	500	Immediately	Tuning	
	Second Model Following Control Gain Correction			Position		
Pn149	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	500 to 2,000	0.1%	1,000	Immediately	Tuning	
	Second Friction Co	mpensation Gain		Speed Posit	ion	
Pn122	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 1,000	1%	100	Immediately	Tuning	

Parameters Related to Automatic Gain Switching

	Gain Switching Time	e 1		Posit	ion
Pn131	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 ms	0	Immediately	Tuning
	Gain Switching Time	e 2	Posit	ion	
Pn132	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 ms	0	Immediately	Tuning
	Gain Switching Wait	ting Time 1		Posit	ion
Pn135	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 ms	0	Immediately	Tuning
	Gain Switching Wait	ting Time 2		Posit	ion
Pn136	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	1 ms	0	Immediately	Tuning

Related Monitoring

• SigmaWin+

You can monitor gain switching with the status monitor or with tracing.

Analog Monitors

Parameter	Analog Monitor	Monitor Name	Output Value	Description
Pn006		Active Gain Monitor	1 V	Gain settings 1 are enabled.
Pn007	n. □□ 0B		2 V	Gain settings 2 are enabled.

Tuning

9.12.2 Friction Compensation

9.12.2 Friction Compensation

Friction compensation is used to compensate for viscous friction fluctuations and regular load fluctuations.

You can automatically adjust friction compensation with autotuning without a host reference, autotuning with a host reference, or custom tuning, or you can manually adjust it with the following procedure.

Required Parameter Settings

The following parameter settings are required to use friction compensation.

F	Parameter	Func	tion	When Enabled	Classification	
Pn408	n.0□□□ (default setting)	Disable friction comper	nsation.	Immediately	Setup	
	n.1000	Enable friction compen	sation.			
	Friction Compension	sation Gain	Speed Posit	tion		
Pn121	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 1,000	1%	100	Immediately	Tuning	
	Second Friction	Compensation Gain		Speed Posit	tion	
Pn122	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 1,000	1%	100	Immediately	Tuning	
	Friction Compension	sation Coefficient	Speed Posit	Speed Position		
Pn123	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 100	1%	0	Immediately	Tuning	
	Friction Compensation Frequency Correction			Speed Posit	tion	
Pn124	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	-10,000 to 10,00	0 0.1 Hz	0	Immediately	Tuning	
	Friction Compension	sation Gain Correction		Speed Posit	tion	
Pn125	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	1 to 1,000	1%	100	Immediately	Tuning	

9.12.2 Friction Compensation

Operating Procedure for Friction Compensation

Use the following procedure to perform friction compensation.



• Before you execute friction compensation, set the moment of inertia ratio (Pn103) as accurately as possible. If the setting greatly differs from the actual moment of inertia, vibration may occur.


Step	Operation					
1	Set the following parameters related to friction compensation to their default settings. Friction compensation gain (Pn121): 100 Second friction compensation gain (Pn122): 100 Friction compensation coefficient (Pn123): 0 Friction compensation frequency correction (Pn124): 0 Friction compensation gain correction (Pn125): 100 Note: Always use the default settings for the friction compensation frequency correction (Pn124) and friction com- pensation gain correction (Pn125).					
2	 Gradually increase the friction compensation coefficient (Pn123) to check the effect of friction compensation. Note: Usually, set the friction compensation coefficient (Pn123) to 95% or less. If the effect is insufficient, increase the friction compensation gain (Pn121) by 10% increments until vibration stops. Effect of Adjusted Parameters Pn121: Friction Compensation Gain and Pn122: Second Friction Compensation Gain These parameters set the response to external disturbances. The higher the setting is, the better the response will be. If the machine has a resonance frequency, however, vibration may occur if the setting is too high. Pn123: Friction Compensation Coefficient This parameter sets the effect of friction compensation. The higher the setting is, the more effective friction compensation will be. If the setting is too high, however, vibration will occur more easily. Usually, set the value to 95% or less. 					
3	Effect of Adjustments The following graphs show the response with and without adjustment. Poor response because of friction Position deviation High friction Before Friction Compensation High Friction Compensation After Friction Compensation					

9.12.3 Gravity Compensation

9.12.3 Gravity Compensation


When the Servomotor is used with a vertical axis, gravity compensation prevents the moving part from falling due to the machine's own weight when the brake is released.

SERVOPACKs with software version 0023 or higher support gravity compensation.



A timing chart for when the moving part is raised then lowered is provided below. Refer to the following section for details on brake operation timing.

6.12.1 Brake Operating Sequence on page 6-32



9.12.3 Gravity Compensation

Required Parameter Settings

The following parameter settings are required to use gravity compensation.

Parameter		Description		When Enabled	Classification
Pn475	n.□□□0 (default setting)	Disable gravity compensation.		After restart	Setup
	n.0001	Enable gravity comper	nsation.		
	Gravity Compensa	Speed Posi	tion Torque		
Pn476	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	-1,000 to 1,000	0.1% 0		Immediately	Tuning

Operating Procedure for Gravity Compensation

Use the following procedure to perform gravity compensation.

- 1. Set Pn475 to n. DDD1 (Enable gravity compensation).
- 2. To enable changes to the settings, turn the power supply to the SERVOPACK OFF and ON again.
- **3.** Use SigmaWin+ or an analog monitor to find the torque reference value when the motor is stopped with the servo ON.
- 4. Set the torque reference value found in step 3 in Pn476 (Gravity Compensation Torque).
- 5. Turn the servo ON and OFF a few times and fine-tune Pn476 so that the moving part of the machine does not fall.

9.12.4 Current Control Mode Selection

9.12.4 Current Control Mode Selection

Current control mode selection reduces high-frequency noise while the Servomotor is being stopped.

Parameter		Meaning	When Enabled	Classification	
Pn009	n. 🗆 🗆 🗆	Use current control mode 1.			
	n. DD1D (default setting)	Use current control mode 2 (low noise).	After restart	Tuning	
	n. 🗆 🗆 2 🗆	Reserved parameter (Do not change.)			



If current control mode 2 is selected, the load ratio may increase while the Servomotor is being stopped.

9.12.5 Current Gain Level Setting

You can set the current gain level to reduce noise by adjusting the parameter for current control inside the SERVOPACK according to the speed loop gain (Pn100). The noise level can be reduced by decreasing the current gain level (Pn13D) from its default setting of 2,000% (disabled). However, if the setting is decreased, the level of noise will be lowered, but the response characteristic of the SERVOPACK will also be reduced. Adjust the current gain level within the range that maintains the SERVOPACK response characteristic.

	Current Gain Level	I Speed Position			ion
Pn13D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	100 to 2,000	1%	2,000	Immediately	Tuning



If the current gain level is changed, the response characteristic of the speed loop will also change. Servo tuning must therefore be performed again.

9.12.6 Speed Detection Method Selection

9.12.6 Speed Detection Method Selection

You can use the speed detection method selection to ensure smooth Servomotor speed changes during operation. To ensure smooth motor speed changes during operation, set Pn009 to $n.\Box 1 \Box \Box$ (Use speed detection 2).

With a Linear Servomotor, you can reduce the noise level of the running motor when the linear encoder scale pitch is large.

Parameter		Meaning	When Enabled	Classification
Pn009	n. □0□□ (default setting)	Use speed detection 1.	After restart	Tuning
	n. 🗆 1 🗆 🗆	Use speed detection 2.		



If the speed detection method is changed, the response characteristic of the speed loop will also change. Servo tuning must therefore be performed again.

9.12.7 Speed Feedback Filter

You can set a first order lag filter for the speed feedback in the speed loop. This ensures smooth changes in the feedback speed to reduce vibration. If a large value is set, it will increase the delay and make response slower.

Pn308	Speed Feedback Filter	Time Constant		Speed Positi	ion
	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535 (0.00 ms to 655.35 ms)	0.01 ms	0 (0.00 ms)	Immediately	Setup


9.12.8 Backlash Compensation

Outline

If you drive a machine that has backlash, there will be deviation between the travel distance in the position reference that is managed by the host controller and the travel distance of the actual machine. Use backlash compensation to add the backlash compensation value to the position reference and use the result to drive the Servomotor. This will ensure that the travel distance of the actual machine will be the same as the travel distance in the host controller.

Note: 1. Backlash compensation can be used only with a Rotary Servomotor.

2. Backlash compensation can be used only for position control.



9.12.8 Backlash Compensation

Related Parameters

Set the following parameters to use backlash compensation.

Backlash Compensation Direction

Set the direction in which to apply backlash compensation.

Parameter		Meaning	When Enabled	Classification
Pn230	n. □□□0 (default setting)	Compensate forward references.	After restart	Setup
	n. 🗆 🗆 🗆 1	Compensate reverse references.		

Backlash Compensation Value

Set the amount of backlash compensation to add to the position reference. The amount is set in increments of 0.1 reference unit. However, when the amount is converted to encoder pulses, it is rounded off at the decimal point.

Example

When Pn231 = 6,553.6 [reference units] and electronic gear ratio (Pn20E/Pn210) = 4/1: 6,553.6 × 4 = 26,214.4 [pulses]

 \Rightarrow The backlash compensation will be 26,214 encoder pulses.

	Backlash Compensation	า		Po	sition	
Pn231	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	-500,000 to 500,000	0.1 reference units	0	Immediately	Setup	
Important	• The backlash compensation value is restricted by the following formula. Backlash compensation is not performed if this condition is not met. $Pn231 \le \frac{Pn210}{Pn20E} \times \frac{Maximum motor speed [min-1]}{60} \times Encoder resolution* \times 0.00025$					
	 *Refer to the following section for the encoder resolution. 6.15 Electronic Gear Settings on page 6-42 With fully-closed loop control, substitute the number of external encoder pulses per motor rotation for the encoder resolution in the above formula. 					
	Example 1: Pn20E = 4, Pn210 = 1, Maximum motor speed = 6,000 [min ⁻¹], and Encoder resolution = 16,777,216 (24 bits) $1/4 \times 6,000/60 \times 16,777,216 \times 0.00025 = 104,857.6$ [reference units] \Rightarrow The backlash compensation will be limited to 104,857.6 reference units.					
	Example 2: Pn20E = 4, Pn210 = 1, Maximum motor speed = 6,000 [min ⁻¹], Number of External Encoder Scale Pitches (Pn20A) = 500, and Use of the JZDP-H00 \square -000 (signal resolution: 1/256): 1/4 × 6,000/60 × (500 × 256) × 0.00025 = 800.0 [reference units] \Rightarrow The backlash compensation will be limited to 800.0 reference units.					
	Do not exceed the upp limit on the operation r			on value. You can c	heck the upper	

9.12.8 Backlash Compensation

Backlash Compensation Time Constant

You can set a time constant for a first order lag filter for the backlash compensation value (Pn231) that is added to the position reference.

If you set Pn233 (Backlash Compensation Time Constant) to 0, the first order lag filter is disabled.

	Backlash Compensation	n Time Constant	Position		
Pn233	Setting Range Setting Unit Default Setting			When Enabled	Classification
	0 to 65,535	0.01 ms	0	Immediately	Setup

Note: Changes to the settings are applied when there is no reference pulse input and the Servomotor is stopped. The current operation is not affected if the setting is changed during Servomotor operation.

Related Monitoring

You can monitor the following values on the operation monitor of the SigmaWin+.

Displayed Value	Setting Unit
Current Backlash Compensation Value	0.1 reference units
Backlash Compensation Value Setting Limit	0.1 reference units

Compensation Operation

This section describes the operation that is performed for backlash compensation.

Note: The following figures are for when backlash compensation is applied to references in the forward direction (Pn230 = n. $\Box \Box \Box \Box$). The following monitor information is provided in the figures: TPOS (target position in the reference coordinate system), POS (reference position in the reference coordinate system), and APOS (feed-back position in the machine coordinate system). The monitor information includes the feedback position in machine coordinate system (APOS) and other feedback information.

The backlash compensation value is subtracted from the feedback positions in the monitor information, so it is not necessary for the host controller to consider the backlash compensation value.



• The encoder divided pulse output will output the number of encoder pulses for which driving was actually performed, including the backlash compensation value. If you use the encoder output pulses for position feedback at the host controller, you must consider the backlash compensation value. 9.12.8 Backlash Compensation

Operation When the Servo Is ON

The backlash compensation value (Pn231) is added in the backlash compensation direction when the servo is ON (i.e., while power is supplied to the motor) and a reference is input in the same direction as the backlash compensation direction (Pn230.0 = $n.\square\square\squareX$).


When there is a reference input in the direction opposite to the backlash compensation direction, the backlash compensation value is not added (i.e., backlash compensation is not performed).

The relationship between APOS and the motor shaft position is as follows:

- If a reference is input in the compensation direction: APOS = Motor shaft position Pn231
- If a reference is input in the direction opposite to the compensation direction: APOS = Motor shaft position

The following figure shows driving the Servomotor in the forward direction from target position TPOS0 to TPOS1 and then to TPOS2, and then returning from TPOS2 to TPOS1 and then to TPOS0.

Backlash compensation is applied when moving from TPOS0 to TPOS1, but not when moving from TPOS2 to TPOS1.



9.12.8 Backlash Compensation


Operation When the Servo Is OFF

Backlash compensation is not applied when the servo is OFF (i.e., when power is not supplied to motor). Therefore, the reference position POS is moved by only the backlash compensation value.

The relationship between APOS and the motor shaft position is as follows:

• When servo is OFF: APOS = Servomotor shaft position

The following figure shows what happens when the servo is turned OFF after driving the Servomotor in the forward direction from target position TPOS0 to TPOS1. Backlash compensation is not applied when the servo is OFF. (The SERVOPACK manages the position data so that APOS and POS are the same.)



Operation When There Is Overtravel

When there is overtravel (i.e., when driving is prohibited due to an overtravel signal or software limit), the operation is the same as for when the servo is OFF (\blacklozenge Operation When the Servo Is OFF on page 9-79), i.e., backlash compensation is not applied.

Operation When Control Is Changed

Backlash compensation is performed only for position control.

Backlash compensation is not applied when position control is changed to any other control method.

Backlash compensation is applied in the same way as when the servo is ON (\blacklozenge Operation When the Servo Is ON on page 9-78) if any other control method is changed to position control.

Related Monitoring

You can monitor the following values on the operation monitor of the SigmaWin+.

Displayed Value	Unit	Specification
Input Reference Pulse Speed	min ⁻¹	Displays the input reference pulse speed before backlash compensation.
Position Deviation	Reference units	Displays the position deviation for the position reference after backlash compensation.
Input Reference Pulse Counter	Reference units	Displays the input reference pulse counter before back- lash compensation.
Feedback Pulse Counter	Encoder pulses	Displays the number of pulses from the actually driven motor encoder.
Fully-Closed Feedback Pulse Counter	External encoder resolution	Displays the number of pulses of the actually driven exter- nal encoder.
Feedback Pulse Counter	Reference units	Displays the number of pulses from the actually driven encoder in reference units.

9.12.8 Backlash Compensation

MECHATROLINK Monitor Information

This section describes the information that is set for the MECHATROLINK monitor information (monitor 1, monitor 2, monitor 3, and monitor 4) and the backlash compensation operation.

Monitor Code	Abbreviation	Description	Unit	Remarks
0	POS	Reference position in the reference coordi- nate system (after the position reference filter)	Reference units	_
1	MPOS	Reference position	Reference units	_
2	PERR	Position deviation	Reference units	_
3	APOS	Feedback position in machine coordinate system	Reference units	Feedback position with the backlash com- pensation subtracted
4	LPOS	Feedback latch posi- tion in the machine coordinate system	Reference units	Feedback position with the backlash com- pensation subtracted
5	IPOS	Reference position in the reference coordi- nate system (before the position reference filter)	Reference units	-
6	TPOS	Target position in the reference coordinate system	Reference units	-
E	OMN1	Option monitor 1 (selected with Pn824)	-	-
F	OMN2	Option monitor 2 (selected with Pn825)	-	_


Para	ameter	Monitor Information	Output Unit	Remarks
	0003h	Position deviation (lower 32 bits)	Reference units	_
-	0004h	Position deviation (upper 32 bits)	Reference units	_
	000Ah	PG count (lower 32 bits)	Reference units	Count value of the actually driven motor
	000Bh	PG count (upper 32 bits)	Reference units	encoder
	000Ch	FPG count (lower 32 bits)	Reference units	Count value of the actually driven external
	000Dh	FPG count (upper 32 bits)	Reference units	encoder
Pn824 Pn825	0017h	Input reference pulse speed	min ⁻¹	_
	0018h	Position deviation	Reference units	_
	001Ch	Input reference pulse counter	Reference units	_
	001Dh	Feedback pulse counter	Encoder pulses	_
-	001Eh	Fully-closed feedback pulse counter	External encoder resolution	_
	0080h	Previous value of latched feedback posi- tion (LPOS)	Reference units	Feedback position with the backlash compensation subtracted

9.12.8 Backlash Compensation

Related Monitoring Diagrams

The following symbols are used in the related monitoring diagrams.

- [A]: Analog monitor
- [U]: Monitor mode (Un monitor)
- [O]: Output signal
- [T]: Trace data
- [M]: MECHATROLINK monitor information




9.13 Manual Tuning

This section describes manual tuning.

9.13.1 Tuning the Servo Gains

Servo Gains



In order to manually tune the servo gains, you must understand the configuration and characteristic of the SERVOPACK and adjust the servo gains individually. In most cases, if you greatly change any one parameter, you must adjust the other parameters again. To check the response characteristic, you must prepare a measuring instrument to monitor the output waveforms from the analog monitor.

The SERVOPACK has three feedback systems (the position loop, speed loop, and current loop), and the response characteristic must be increased more with the inner loops. If this relationship is not maintained, the response characteristic will suffer and vibration will occur more easily.

A sufficient response characteristic is ensured for the current loop. There is never a need for it to be adjusted by the user.

Outline

You can use manual tuning to set the servo gains in the SERVOPACK to increase the response characteristic of the SERVOPACK. For example, you can reduce the positioning time for position control.

Use manual tuning in the following cases.

- When tuning with autotuning without a host reference or autotuning with a host reference does not achieve the desired results
- When you want to increase the servo gains higher than the gains that resulted from autotuning without a host reference or autotuning with a host reference
- · When you want to determine the servo gains and moment of inertia ratio yourself

You start manual tuning either from the default parameter settings or from the gain settings that resulted from autotuning without a host reference or autotuning with a host reference.

Applicable Tools

You can monitor the servo gains with the SigmaWin+ or with the analog monitor.

Precautions

Vibration may occur while you are tuning the servo gains. We recommend that you enable vibration alarms (Pn310 = $n.\square\square\square$) to detect vibration. Refer to the following section for information on vibration detection.

7.11 Initializing the Vibration Detection Level on page 7-49

Vibration alarms are not detected for all vibration. Also, an emergency stop method is necessary to stop the machine safely when an alarm occurs. You must provide an emergency stop device and activate it immediately whenever vibration occurs.

Tuning Procedure Example (for Position Control or Speed Control)

Step	Description
1	Adjust the first stage first torque reference filter time constant (Pn401) so that vibration does not occur.
2	Increase the Speed loop gain (Pn100) and reduce the speed loop integral time constant (Pn101) as far as possible within the range that does not cause machine vibration.
3	Repeat steps 1 and 2 and return the settings about 10% to 20% from the values that you set.
4	For position control, increase the position loop gain (Pn102) within the range that does not cause vibration.

Information If you greatly change any one servo gain parameter, you must adjust the other parameters again. Do not increase the setting of just one parameter. As a guideline, adjust the settings of the servo gains by approximately 5% each. As a rule, change the servo parameters in the following order.

- To Increase the Response Speed
- 1. Reduce the torque reference filter time constant.
- 2. Increase the speed loop gain.
- 3. Decrease the speed loop integral time constant.
- 4. Increase the position loop gain.
- To Reduce Response Speed and to Stop Vibration and Overshooting
- 1. Reduce the position loop gain.
- 2. Increase the speed loop integral time constant.
- 3. Decrease the speed loop gain.
- 4. Increase the torque filter time constant.

Adjusted Servo Gains

You can set the following gains to adjust the response characteristic of the SERVOPACK.

- Pn100: Speed Loop Gain
- Pn101: Speed Loop Integral Time Constant
- Pn102: Position Loop Gain
- Pn401: First Stage First Torque Reference Filter Time Constant

♦ Position Loop Gain

The position loop gain determines the response characteristic of the position loop in the SER-VOPACK. If you can increase the setting of the position loop gain, the response characteristic will improve and the positioning time will be shortened. However, you normally cannot increase the position loop gain higher than the inherit vibration frequency of the machine system. Therefore, to increase the setting of the position loop gain, you must increase the rigidity of the machine to increase the inherit vibration frequency of the machine.

	Position Loop Gain			Position	
Pn102	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	10 to 20,000	0.1/s	400	Immediately	Tuning

For machines for which a high position loop gain (Pn102) cannot be set, overflow alarms can Information occur during high-speed operation. If that is the case, you can increase the setting of the following parameter to increase the level for alarm detection.

Use the following condition as a guideline for determining the setting.

 $Pn520 \ge \frac{Maximum feed speed [reference units/s]}{2.0} \times 2.0$ Pn102 ÷ 10 (1/s)

If you use a position reference filter, transient deviation will increase due to the filter time constant. When you make the setting, consider deviation accumulation that may result from the filter.

	Position Deviation	Overflow Alarm	Position		
Pn520	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
FIIJZU	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup

Speed Loop Gain

This parameter determines the response characteristic of the speed loop. If the response characteristic of the speed loop is low, it becomes a delay factor for the position loop located outside of the speed loop. This will result in overshooting and vibration in the speed reference. Therefore, setting the speed loop gain as high as possible within the range that will not cause the machine system to vibrate will produce a stable Servo System with a good response characteristic.

	Speed Loop Gain		Speed Positi	on Torque	
Pn100	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion
	10 to 20,000	0.1 Hz	400	Immediately	Tuning

Setting of Pn103 = $\frac{\text{Load moment of inertia at motor shaft }(J_L)}{\text{Servomotor moment of inertia }(L_M)} \times 100(\%)$

The default setting of Pn103 (Moment of Inertia Ratio) is 100. Before you tune the servo, calculate the moment of inertia ratio with the above formula and set Pn103 to the calculation result.

	Moment of Inertia Ratio			Speed Positi	on Torque
Pn103	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion
	0 to 20,000	1%	100	Immediately	Tuning


Speed Loop Integral Time Constant


To enable response to even small inputs, the speed loop has an integral element. The integral element becomes a delay factor in the Servo System. If the time constant is set too high, overshooting will occur, positioning settling time will increase, and the response characteristic will suffer.

	Speed Loop Integral Time Constant			Speed Position		
Pn101	Setting Range	Setting Unit	Default Setting	When Enabled	Classifica- tion	
	15 to 51,200	0.01 ms	2,000	Immediately	Tuning	

◆ Torque Reference Filter

As shown in the following diagram, the torque reference filter contains a first order lag filter and notch filters arranged in series, and each filter operates independently.





* The second stage second torque reference filter is disabled when Pn40F is set to 5,000 (default setting) and it is enabled when Pn40F is set to a value lower than 5,000.

■ Torque Reference Filter

If you suspect that machine vibration is being caused by the Servo Drive, try adjusting the torque reference filter time constant. This may stop the vibration. The lower the value, the better the control response characteristic will be, but there may be a limit depending on the machine conditions.

	First Stage First Torque Reference Filter Time Constant			Speed Posit	ion Torque
Pn401	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 65,535	0.01 ms	100	Immediately	Tuning
	Second Stage Second Torque Reference Filter Frequency			Speed Posit	ion Torque
Pn40F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	100 to 5,000	1 Hz	5000*	Immediately	Tuning
	Second Stage Second Torque Reference Filter Q Value			Speed Posit	ion Torque
Pn410	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 100	0.01	50	Immediately	Tuning

* The filter is disabled if you set the parameter to 5,000.

Notch Filters

The notch filter can eliminate specific frequency elements generated by the vibration of sources such as resonance of the shaft of a ball screw.


The notch filter puts a notch in the gain curve at the specific vibration frequency (called the notch frequency). The frequency components near the notch frequency can be reduced or removed with a notch filter.

Notch filters are set with three parameters for the notch filter frequency, notch filter Q value, and notch filter depth. This section describes the notch filter Q value and notch filter depth.

Notch filter Q Value

The setting of the notch filter Q value determines the width of the frequencies that are filtered for the notch filter frequency. The width of the notch changes with the notch filter Q value. The larger the notch filter Q value is, the steeper the notch is and the narrower the width of frequencies that are filtered is.

The notch filter frequency characteristics for different notch filter Q values are shown below.




Note: The above notch filter frequency characteristics are based on calculated values and may be different from actual characteristics.

· Notch Filter Depth

The setting of the notch filter depth determines the depth of the frequencies that are filtered for the notch filter frequency. The depth of the notch changes with the notch filter depth. The smaller the notch filter depth is, the deeper the notch is, increasing the effect of vibration suppression. However, if the value is too small, vibration can actually increase.

The notch filter is disabled if the notch filter depth, d, is set to 1.0 (i.e., if Pn419 is set to 1,000). The notch filter frequency characteristics for different notch filter depths are shown below.



Note: The above notch filter frequency characteristics are based on calculated values and may be different from actual characteristics.

You can enable or disable the notch filter with Pn408 and Pn416.

F	Parameter	Meaning	When Enabled	Classification
	n.□□□0 (default setting)	Disable first stage notch filter.		
Dn/08	n.0001	Enable first stage notch filter.		
Pn408	n.□0□□ (default setting)	Disable second stage notch filter.		Setup
	n.0100	Enable second stage notch filter.		
	n.□□□0 (default setting)	Disable third stage notch filter.	Immediately	
	n.0001	Enable third stage notch filter.		
Pn416	n.□□0□ (default setting)	Disable fourth stage notch filter.		
	n.0010	Enable fourth stage notch filter.		
	n.□0□□ (default setting)	Disable fifth stade notch filter		
	n.0100	Enable fifth stage notch filter.		

	Eirot Stage Noteh F	ltor Froquency		Speed Posit	ion Torque
Dn 400	First Stage Notch Fi	• •	Default Catting		
Pn409	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 5,000	1 Hz	5,000	Immediately	Tuning
D 404	First Stage Notch Fi			Speed Posit	
Pn40A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 1,000	0.01	70	Immediately	Tuning
	First Stage Notch Fi	•		Speed Posit	
Pn40B	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	0.001	0	Immediately	Tuning
	Second Stage Notc	· · ·		Speed Posit	
Pn40C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 5,000	1 Hz	5,000	Immediately	Tuning
	Second Stage Notc	h Filter Q Value		Speed Posit	ion Torque
Pn40D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 1,000	0.01	70	Immediately	Tuning
	Second Stage Notc	h Filter Depth		Speed Posit	ion Torque
Pn40E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	0.001	0	Immediately	Tuning
	Third Stage Notch F	ilter Frequency		Speed Posit	ion Torque
Pn417	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 5,000	1 Hz	5,000	Immediately	Tuning
	Third Stage Notch F	ilter Q Value		Speed Posit	ion Torque
Pn418	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 1,000	0.01	70	Immediately	Tuning
	Third Stage Notch F	ilter Depth		Speed Posit	ion Torque
Pn419	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	0.001	0	Immediately	Tuning
	Fourth Stage Notch	Filter Frequency		Speed Posit	ion Torque
Pn41A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 5,000	1 Hz	5,000	Immediately	Tuning
	Fourth Stage Notch	Filter Q Value		Speed Posit	ion Torque
Pn41B	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 1,000	0.01	70	Immediately	Tuning
	Fourth Stage Notch	Filter Depth	1	Speed Posit	
Pn41C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	0.001	0	Immediately	Tuning
	Fifth Stage Notch Fi	ilter Frequency		Speed Posit	ion Torque
Pn41D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 5,000	1 Hz	5,000	Immediately	Tuning
	Fifth Stage Notch Fi	ilter Q Value	1	Speed Posit	ion Torque
Pn41E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	50 to 1,000	0.01	70	Immediately	Tuning
	Fifth Stage Notch Fi	ilter Depth	1	Speed Posit	_
Pn41F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 1,000	0.001	0	Immediately	Tuning
		•			

Set the machine vibration frequencies in the notch filter parameters.

 Do not set notch filter frequencies (Pn409, Pn40C, Pn417, Pn41A, and Pn41D) that are close to the speed loop's response frequency. Set a frequency that is at least four times the speed loop gain (Pn100). (However, Pn103 (Moment of Inertia Ratio) must be set correctly. If the setting is not correct, vibration may occur and the machine may be damaged. Change the notch filter frequencies (Pn409, Pn40C, Pn417, Pn41A, and Pn41D) only while the Servomotor is stopped. Vibration may occur if a notch filter frequency is changed during operation.

Guidelines for Manually Tuning Servo Gains

When you manually adjust the parameters, make sure that you completely understand the information in the product manual and use the following conditional expressions as guidelines. The appropriate values of the parameter settings are influenced by the machine specifications, so they cannot be determined universally. When you adjust the parameters, actually operate the machine and use the SigmaWin+ or analog monitor to monitor operating conditions. Even if the status is stable while the Servomotor is stopped, an unstable condition may occur when an operation reference is input. Therefore, input operation references and adjust the servo gains as you operate the Servomotor.

Stable gain: Settings that provide a good balance between parameters.

However, if the load moment of inertia is large and the machine system contains elements prone to vibration, you must sometimes use a setting that is somewhat higher to prevent the machine from vibrating.

Critical gain: Settings for which the parameters affect each other

Depending on the machine conditions, overshooting and vibration may occur and operation may not be stable. If the critical gain condition expressions are not met, operation will become more unstable, and there is a risk of abnormal motor shaft vibration and round-trip operation with a large amplitude. Always stay within the critical gain conditions.

If you use the torque reference filter, second torque reference filter, and notch filters together, the interference between the filters and the speed loop gain will be superimposed. Allow leeway in the adjustments.



The following adjusted value guidelines require that the setting of Pn103 (Moment of Inertia Ratio) is correctly set for the actual machine.

• When $Pn10B = n.\Box\Box0\Box$ (PI Control)

Guidelines are given below for gain settings 1.

The same guidelines apply to gain settings 2 (Pn104, Pn105, Pn106, and Pn412).

- Speed Loop Gain (Pn100 [Hz]) and Position Loop Gain (Pn102 [/s]) Stable gain: Pn102 [/s] $\leq 2\pi \times Pn100/4$ [Hz] Critical gain: Pn102 [/s] $< 2\pi \times Pn100$ [Hz]
- Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn101 [ms] ≥ 4,000/(2π × Pn100 [Hz]) Critical gain: Pn101 [ms] > 1,000/(2π × Pn100 [Hz])
- Speed Loop Gain (Pn100 [Hz]) and First Stage First Torque Reference Filter Time Constant (Pn401 [ms]) Stable gain: Pn401 [ms] ≤ 1,000/(2π × Pn100 [Hz] × 4) Critical gain: Pn401 [ms] < 1,000/(2π × Pn100 [Hz] × 1)
- Speed Loop Gain (Pn100 [Hz]) and Second Stage Second Torque Reference Filter Frequency (Pn40F [Hz])
 Critical gain: Pn40F [Hz] > 4 × Pn100 [Hz]
 Note: Set the second stage second torque reference filter Q value (Pn410) to 0.70.
- Speed Loop Gain (Pn100 [Hz]) and First Stage Notch Filter Frequency (Pn409 [Hz]) (or Second Stage Notch Filter Frequency (Pn40C [Hz])) Critical gain: Pn409 [Hz] > 4 × Pn100 [Hz]
- Speed Loop Gain (Pn100 [Hz]) and Speed Feedback Filter Time Constant (Pn308 [ms]) Stable gain: Pn308 [ms] \leq 1,000/(2 π × Pn100 [Hz] × 4) Critical gain: Pn308 [ms] < 1,000/(2 π × Pn100 [Hz] × 1)

• When $Pn10B = n.\Box\Box1\Box$ (I-P Control)

Guidelines are given below for gain settings 1.

The same guidelines apply to gain settings 2 (Pn104, Pn105, Pn106, and Pn412).

For I-P control, the relationships between the speed loop integral time constant, speed loop gain, and position loop gain are different from the relationships for PI control. The relationship between other servo gains is the same as for PI control.

- Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn100 [Hz] ≥ 320/Pn101 [ms]
- Position Loop Gain (Pn102 [/s]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn102 [/s] ≤ 320/Pn101 [ms]

Information Selecting the Speed Loop Control Method (PI Control or I-P Control)

Usually, I-P control is effective for high-speed positioning and high-speed, high-precision processing applications. With I-P control, you can use a lower position loop gain than for PI control to reduce the positioning time and reduce arc radius reduction. However, if you can use mode switching to change to proportional control to achieve the desired application, then using PI control would be the normal choice.

Decimal Points in Parameter Settings

For the SGD7S SERVOPACKs, decimal places are given for the settings of parameters on the Digital Operator, Panel Operator, and in the manual. For example with Pn100 (Speed Loop Gain), Pn100 = 40.0 is used to indicate a setting of 40.0 Hz. In the following adjusted value guidelines, the decimal places are also given.




Speed Loop Gain (Pn100 [Hz]) and Speed Loop Integral Time Constant (Pn101 [ms]) Stable gain: Pn101 [ms] $\ge 4,000/(2\pi \times Pn100 \text{ [Hz]})$, therefore If Pn100 = 40.0 [Hz], then Pn101 = $4,000/(2\pi \times 40.0) \approx 15.92$ [ms].

Model Following Control

You can use model following control to improve response characteristic and shorten positioning time. You can use model following control only with position control.

Normally, the parameters that are used for model following control are automatically set along with the servo gains by executing autotuning or custom tuning. However, you must adjust them manually in the following cases.

- When the tuning results for autotuning or custom tuning are not acceptable
- When you want to increase the response characteristic higher than that achieved by the tuning results for autotuning or custom tuning
- · When you want to determine the servo gains and model following control parameters yourself



The block diagram for model following control is provided below.

Manual Tuning Procedure

Use the following tuning procedure for using model following control.

Step	Description
1	Friction compensation must also be used. Set the friction compensation parameters. Refer to the following section for the setting procedure.
2	Adjust the servo gains. Refer to the following section for an example procedure. <i>Tuning Procedure Example (for Position Control or Speed Control)</i> on page 9-83 Note: 1. Set the moment of inertia ratio (Pn103) as accurately as possible.
2	 Refer to the guidelines for manually tuning the servo gains and set a stable gain for the position loop gain (Pn102). Guidelines for Manually Tuning Servo Gains on page 9-88
3	Increase the model following control gain (Pn141) as much as possible within the range in which overshooting and vibration do not occur.
4	If overshooting occurs or if the response is different for forward and reverse operation, fine-tune model following control with the following settings: model following control bias in the forward direction (Pn143), model following control bias in the reverse direction (Pn144), and model following control speed feedforward compensation (Pn147).

◆ Related Parameters

Next we will describe the following parameters that are used for model following control.

- Pn140 (Model Following Control-Related Selections)
- Pn141 (Model Following Control Gain)
- Pn143 (Model Following Control Bias in the Forward Direction)
- Pn144 (Model Following Control Bias in the Reverse Direction)
- Pn147 (Model Following Control Speed Feedforward Compensation)

Model Following Control-Related Selections

Set $Pn140 = n.\Box\Box\BoxX$ to specify whether to use model following control.

If you use model following control with vibration suppression, set Pn140 to $n.\Box\Box1\Box$ or Pn140 = $n.\Box\Box2\Box$. When you also perform vibration suppression, adjust vibration suppression with custom tuning in advance.

Note: If you use vibration suppression (Pn140 = n. $\Box \Box \Box \Box$ or Pn140 = n. $\Box \Box \Box \Box$), always set Pn140 to n. $\Box \Box \Box \Box$ (Use model following control).

F	Parameter Function		When Enabled	Classification
	n.□□□0 (default setting)	Do not use model following control		
	n.□□□1 Use model following control.			
Pn140	n.□□0□ (default setting)	Do not perform vibration suppression.	Immediately	Tuning
	n.0010	Perform vibration suppression for a specific frequency.		
	n.0020	Perform vibration suppression for two specific frequencies.		

Model Following Control Gain

The model following control gain determines the response characteristic of the Servo System. If you increase the setting of the model following control gain, the response characteristic will improve and the positioning time will be shortened. The response characteristic of the Servo System is determined by this parameter, and not by Pn102 (Position Loop Gain).

	Model Following Control Gain			Position		
Pn141	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	10 to 20,000	0.1/s	500	Immediately	Tuning	

Information For machines for which a high model following control gain cannot be set, the size of the position deviation in model following control will be determined by the setting of the model following control gain. For a machine with low rigidity, in which a high model following control gain cannot be set, position deviation overflow alarms may occur during high-speed operation. If that is the case, you can increase the setting of the following parameter to increase the level for alarm detection.

Use the following conditional expression for reference in determining the setting.

Pn 520 \geq Maximum feed speed [reference units/s] \times 2.0

Pn 141/10 [1/s]

	Position Deviation	Overflow Alarm	Position		
Pn520	Setting Range Setting Unit De		Default Setting	When Enabled	Classification
111020	1 to 1,073,741,823	1 reference unit	5,242,880	Immediately	Setup

Model Following Control Bias in the Forward Direction and Model Following Control Bias in the Reverse Direction

If the response is different for forward and reverse operation, use the following parameters for fine-tuning.

If you decrease the settings, the response characteristic will be lowered but overshooting will be less likely to occur.

	Model Following Control Bias in the Forward Direction			Position		
Pn143	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	0.1%	1,000	Immediately	Tuning	
	Model Following Control Bias in the Reverse Direction			Position		
Pn144	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	0.1%	1,000	Immediately	Tuning	

Model Following Control Speed Feedforward Compensation

If overshooting occurs even after you adjust the model following control gain, model following control bias in the forward direction, and model following control bias in the reverse direction, you may be able to improve performance by setting the following parameter.

If you decrease the settings, the response characteristic will be lowered but overshooting will be less likely to occur.

	Model Following Co	ontrol Speed Feedfor	Posit	ion	
Pn147	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 10,000	0.1%	1,000	Immediately	Tuning

Model Following Control Type Selection


When you enable model following control, you can select the model following control type. Normally, set Pn14F to n. DDD1 (Use model following control type 2) (default setting). If compatibility with previous models is required, set Pn14F to n. DDD0 (Use model following control type 1).

Parameter		Meaning	When Enabled	Classification
	n.□□□0	Use model following control type 1.		
Pn14F	n.□□□1 (default setting)	Use model following control type 2.	After restart	Tuning

The compatible adjustment functions are used together with manual tuning. You can use these functions to improve adjustment results. These functions allow you to use the same functions as for Σ -III-Series SERVOPACKs to adjust Σ -7-Series SERVOPACKs.

Feedforward

The feedforward function applies feedforward compensation to position control to shorten the positioning time.




	Feedforward		Position		
Pn109	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 100	1%	0	Immediately	Tuning
	Feedforward Filter T	ïme Constant	Position		
Pn10A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 6,400	0.01 ms	0	Immediately	Tuning

Note: If you set the feedforward value too high, the machine may vibrate. As a guideline, use a setting of 80% or less.

Mode Switching (Changing between Proportional and PI Control)

You can use mode switching to automatically change between proportional control and PI control.

Overshooting caused by acceleration and deceleration can be suppressed and the settling time can be reduced by setting the switching condition and switching levels.



1Uning

♦ Related Parameters

Select the switching condition for mode switching with $Pn10B = n.\Box\Box\BoxX$.

	Parameter	Mode Switching	Parameter That Sets the Level		When	Classification
Farameter		Selection	Rotary Servomotor	Linear Servomotor	Enabled	Classification
	n.□□□0 (default setting)	Use the internal torque reference as the condition.	Pn1	0C		
	n.0001	Use the speed ref- erence as the con- dition.	Pn10D	Pn181		Setup
Pn10B	n.0002	Use the accelera- tion reference as the condition.	Pn10E	Pn182	Immediately	
	n.□□□3	Use the position deviation as the condition.	Pn	10F		
	n.0004	Do not use mode switching.	-	-		

Parameters That Set the Switching Levels

Rotary Servomotors

	Mode Switching L	evel for Torque Ref	erence	Speed	Position	
Pn10C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 800	1%	200	Immediately	Tuning	
	Mode Switching L	evel for Speed Refe	erence	Speed	Position	
Pn10D	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 min⁻¹	0	Immediately	Tuning	
	Mode Switching Level for Acceleration			Speed Position		
Pn10E	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 30,000	1 min⁻¹/s	0	Immediately	Tuning	
	Mode Switching L	evel for Position De	eviation	Position		
Pn10F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 reference unit	0	Immediately	Tuning	


• Linear Servomotors

	Mode Switching L	evel for Force Refe	rence	Speed Position		
Pn10C	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 800	1%	200	Immediately	Tuning	
	Mode Switching L	evel for Speed Refe	erence	Speed	Position	
Pn181	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10,000	1 mm/s	0	Immediately	Tuning	
	Mode Switching Level for Acceleration			Speed Position		
Pn182	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 30,000	1 mm/s ²	0	Immediately	Tuning	
	Mode Switching L	evel for Position De	eviation	Position		
Pn10F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 10.000	1 reference unit	0	Immediately	Tuning	

 Using the Internal Torque Reference as the Mode Switching Condition (Default Setting)

When the Internal torque reference equals or exceeds the torque set for the mode switching level for torque reference (Pn10C), the speed loop is changed to P control.


The default setting for the torque reference level is 200%.



■ Using the Speed Reference as the Mode Switching Condition


Rotary Servomotors

When the speed reference equals or exceeds the speed set for the mode switching level for a speed reference (Pn10D), the speed loop is changed to P control.




Linear Servomotors

When the speed reference equals or exceeds the speed set for the mode switching level for a speed reference (Pn181), the speed loop is changed to P control.




- Using the Acceleration as the Mode Switching Condition
- Rotary Servomotors

When the speed reference equals or exceeds the acceleration rate set for the mode switching level for acceleration (Pn10E), the speed loop is changed to P control.



• Linear Servomotors


When the speed reference equals or exceeds the acceleration rate set for the mode switching level for acceleration (Pn182), the speed loop is changed to P control.



Using the Position Deviation as the Mode Switching Condition

When the position deviation equals or exceeds the value set for the mode switching level for position deviation (Pn10F), the speed loop is changed to P control.

This setting is enabled only for position control.



Position Integral

The position integral is the integral function of the position loop. It is used for the electronic cams and electronic shafts when using the SERVOPACK with a Yaskawa MP3000-Series Machine Controller.

	Position Integral Tin	ne Constant	Posit	ion	
Pn11F	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	0 to 50,000	0.1 ms	0	Immediately	Tuning


9.14.1 Mechanical Analysis

9.14 Diagnostic Tools

9.14.1 Mechanical Analysis

Overview


You can connect the SERVOPACK to a computer to measure the frequency characteristics of the machine. This allows you to measure the frequency characteristics of the machine without using a measuring instrument.



The Servomotor is used to cause machine vibration and then the speed frequency characteristics for the motor torque are measured. The measured frequency characteristics can be used to determine the machine resonance.

You determine the machine resonance for use in servo tuning and as reference for considering changes to the machine. The performance of the servo cannot be completely utilized depending on the rigidity of the machine. You may need to consider making changes to the machine. The information can also be used as reference for servo tuning to help you adjust parameters, such as the servo rigidity and torque filter time constant.

You can also use the information to set parameters, such as the notch filters.




9.14.1 Mechanical Analysis

Frequency Characteristics

The Servomotor is used to cause the machine to vibrate and the frequency characteristics from the torque to the motor speed are measured to determine the machine characteristics. For a normal machine, the resonance frequencies are clear when the frequency characteristics are plotted on graphs with the gain and phase (bode plots). The bode plots show the size (gain) of the response of the machine to which the torque is applied, and the phase delay (phase) in the response for each frequency. Also, the machine resonance frequency can be determined from the maximum frequency of the valleys (anti-resonance) and peaks (resonance) of the gain and the phase delay.

For a Servomotor without a load or for a rigid mechanism, the gain and phase change gradually in the bode plots.



① Toolbar

② START Button

Click the **START** Button to start analysis.

3 Measurement and Notch Filter Setting Tab Pages

Measurement Tab Page: Displays detailed information on the results of analysis.

Notch Filter Setting Tab Page: Displays the notch filter frequencies. You can set these values in the parameters.

9.14.2 Easy FFT

The machine is made to vibrate and a resonance frequency is detected from the generated vibration to set notch filters according to the detected resonance frequencies. This is used to eliminate high-frequency vibration and noise.

During execution of Easy FFT, a frequency waveform reference is sent from the SERVOPACK to the Servomotor to automatically cause the shaft to rotate multiple times within 1/4th of a rotation, thus causing the machine to vibrate.


Execute Easy FFT after the servo is turned OFF if operation of the SERVOPACK results in high-frequency noise and vibration.

WARNING

 Never touch the Servomotor or machine during execution of Easy FFT. Doing so may result in injury.



• Use Easy FFT when the servo gain is low, such as in the initial stage of servo tuning. If you execute Easy FFT after you increase the gain, the machine may vibrate depending on the machine characteristics or gain balance.



Easy FFT is built into the SERVOPACK for compatibility with previous products. Normally use autotuning without a host reference for tuning.

Preparations

Always check the following before you execute Easy FFT.

- The parameters must not be write prohibited.
- The main circuit power supply must be ON.
- The test without a motor function must be disabled (Pn00C = $n.\Box\Box\Box$).
- There must be no alarms.
- There must be no hard wire base block (HWBB).
- The servo must be OFF.
- There must be no overtravel.
- An external reference must not be input.

Applicable Tools


The following table lists the tools that you can use to perform EasyFFT.

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn206	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Diagnostic – Easy FFT	Gerating Procedure on page 9-100

Operating Procedure

Use the following procedure for Easy FFT.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Easy FFT in the Menu Dialog Box. The Easy FFT Dialog Box will be displayed. Click the Cancel Button to cancel Easy FFT. You will return to the main window.
- **3.** Click the **OK** Button.



4. Click the Servo ON Button.

Easy FFT AXIS#00	
Servo ON/OFF operation	Servo ON
Servo OFF	
Measurement start / Stopping operation	
Measurement condition	Start
Stimulus signal Frequency	-∎Q
Instruction amplitude 15 (%)	
(1 - 800) Rotation (moving) Forward 💌	7
Measurement result	
Detected resonance frequency	[Hz]
Optimal notch filter frequency	[Hz]
Notch filter selection	
	Measurement complete

 Select the instruction (reference) amplitude and the rotation direction in the Measurement condition Area, and then click the Start Button. The Servomotor shaft will rotate and measurements will start.

🔁 Easy FFT AXIS#00	×
Servo ON/OFF operation	
Servo ON	Servo OFF
Measurement start / Stopping operation	
Measurement condition	
Stimulus signal Frequency	Start I
Instruction amplitude 15 • [%]	
(1 - 800)	Q
Rotation (moving) Forward	
Measurement result	
Detected resonance frequency	[Hz]
Optimal notch filter frequency	[Hz]
Notch filter selection	
	Measurement complete

When measurements have been completed, the measurement results will be displayed.

6. Check the results in the Measurement result Area and then click the Measurement complete Button.

Easy FFT AXIS#00	×
Servo ON/OFF operation	
Servo ON	Servo OFF
Measurement start / Stopping operation	
Measurement condition	
Stimulus signal Frequency	Start
Instruction amplitude 15	
(1 - 800) Rotation (moving) Forward	Q
Measurement result	
Detected resonance frequency 502	[Hz]
Optimal notch filter frequency 502	[Hz]
Notch filter selection The 1st step	
	Measurement complete

7. Click the **Result Writing** Button if you want to set the measurement results in the parameters.

Easy FFT AXIS#00	×			
Notch filter selection				
Pn408:Torque-Related Function Selections digit 0 Notch Filter Selection 1				
0:Disable first stage notch filter.	0:Disable first stage notch filter.			
_				
1:Enable first stage notch filter.	_			
,				
Notch filter frequency				
Pn409:First Stage Notch Filter Frequency				
5000 [Hz] 5 02 [Hz]				
· · · · · · · · · · · · · · · · · · ·				
Please click a button, when you reflect a measurement result in User Param	ieter.			
Result Writing				

This concludes the procedure to set up Easy FFT.

Related Parameters

The following parameters are automatically adjusted or used as reference when you execute Easy FFT.

Do not change the settings of these parameters during execution of Easy FFT.

Parameter Name		Automatic Changes
Pn408	Pn408 Torque-Related Function Selections	
Pn409 First Stage Notch Filter Frequency		Yes
Pn40A First Stage Notch Filter Q Value		No
Pn40C Second Stage Notch Filter Frequency		Yes
Pn40D	Second Stage Notch Filter Q Value	No
Pn456	Sweep Torque Reference Amplitude	No

Yes: The parameter is automatically set.

No: The parameter is not automatically set, but the setting is read during execution.

Monitoring

This chapter provides information on monitoring SERVO-PACK product information and SERVOPACK status. (10)

10.1	Monit	oring Product Information10-2
	10.1.1 10.1.2	Items That You Can Monitor
10.2	Monit	oring SERVOPACK Status10-3
	10.2.1 10.2.2 10.2.3	Servo Drive Status
10.3	Monitori	ing Machine Operation Status and Signal Waveforms 10-7
	10.3.1 10.3.2 10.3.3	Items That You Can Monitor10-7Using the SigmaWin+10-8Using the Analog Monitors10-9
10.4	Monit	oring Product Life
	10.4.1 10.4.2 10.4.3	Items That You Can Monitor10-14Operating Procedure10-15Preventative Maintenance10-15
10.5	Alarm	Tracing
	10.5.1 10.5.2	Data for Which Alarm Tracing Is Performed 10-17 Applicable Tools

10.1.1 Items That You Can Monitor

10.1 Monitoring Product Information

10.1.1 Items That You Can Monitor

Monitor Items				
Information on SERVOPACKs	 Model/Type Serial Number Manufacturing Date Software version (SW Ver.) Remarks 			
Information on Servomotors	 Model/Type Serial Number Manufacturing Date Remarks 			
Information on Encoders	 Model/Type Serial Number Manufacturing Date Software version (SW Ver.) Remarks 			

10.1.2 Operating Procedures

Use the following procedure to display the Servo Drive product information.

• Select *Read Product Information* in the Menu Dialog Box of the SigmaWin+. The Read Product Information Window will be displayed.

Product Information Export						
- 0001-SGD7W-1R6A20/	A					
ERVOPACK	Model/Type	Serial Number	Manufacturing Date	SW Ver.	Remarks	
SERVOPACK	SGD7W-1R6A20A (MECHATROLINK-III interface multi a)		2015.10	F021	[Specification] : Standard	
lotor	Model/Type	Number	Manufacturing Date	SW Ver.	Remarks	
Motor	SGM73-02A7A21	20131204	2013.12		[Resolution] : 16777216 [Pulse/rev]	
Encoder	UTTAI-B24RH		2013.12	0001	[Encoder type] : absolute	
Motor 2	SGMAV-02A3A21	R13092-361-DK500	2010.05		[Resolution] : 1048576 [Pulse/rev]	
Encoder	UTTAH-B20DG	K247-B0AF14J8	2010.04	0004	[Encoder type] : absolute	

Information

With the Digital Operator, you can use Fn011, Fn012, and Fn01E to monitor this information. Refer to the following manual for the differences in the monitor items compared with the SigmaWin+.

Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

10.2.1 Servo Drive Status

10.2 Monitoring SERVOPACK Status

10.2.1 Servo Drive Status

Use the following procedure to display the Servo Drive status.

• Start the SigmaWin+. The Servo Drive status will be automatically displayed when you go online with a SERVOPACK.

001-SGD7S -R90A00A	4		
A	HBB	P-OT	The Serve Drive statue is displaye
POWER	ESTP	N-OT	 The Servo Drive status is displaye

The Servomotor type is displayed.

10.2.2 Monitoring Operation, Status, and I/O

Items That You Can Monitor

The items that you can monitor on the Operation Pane, Status Pane, and I/O Pane are listed below.

Operation Pane

Monitor Items				
 Motor Speed Speed Reference Internal Torque Reference Angle of Rotation 1 (Number of encoder pulses from origin within one encoder rotation) Angle of Rotation 2 (angle from origin within one encoder rotation) Input Reference Pulse Speed Deviation Counter (Position Deviation) Cumulative Load Regenerative Load Power Consumption 	 Consumed Power Cumulative Power Consumption DB Resistor Consumption Power Absolute Encoder Multiturn Data Absolute Encoder Position within One Rotation Absolute Encoder (Lower) Absolute Encoder (Upper) Input Reference Pulse Counter Feedback Pulse Counter Fully Closed Feedback Pulse Counter Total Operating Time 			

Status Pane

Monitor Items			
 Main Circuit Encoder (PGRDY) Motor Power (Request) Motor Power ON Dynamic Brake (DB) Rotation (Movement) Direction Mode Switch Speed Reference (V-Ref) Torque Reference (T-Ref) 	 Position Reference (PULS) Position Reference Direction Surge Current Limiting Resistor Short Relay Regenerative Transistor Regenerative Error Detection AC Power ON Overcurrent Origin Not Passed 		

10.2.2 Monitoring Operation, Status, and I/O

• I/O Pane

	Monitor Items					
Input Signal Status	 P-OT (Forward Drive Prohibit Input Signal) N-OT (Reverse Drive Prohibit Input Signal) /P-CL (Forward External Torque Limit Signal) /N-CL (Reverse External Torque Limit Signal) /G-SEL (Gain Selection Input Signal) /P-DET (Polarity Detection Input Signal) /DEC (Origin Return Deceleration Switch Input Signal) /EXT1 (External Latch Input 1 Signal) /EXT2 (External Latch Input 2 Signal) /EXT3 (External Latch Input 3 Signal) FSTP (Forced Stop Input Signal) /DBANS (Dynamic Brake Answer Input Signal) 	Output Signal Status	 ALM (Servo Alarm Output Signal) /COIN (Positioning Completion Output Signal) /V-CMP (Speed Coincidence Detection Output Signal) /TGON (Rotation Detection Output Signal) /S-RDY (Servo Ready Output Signal) /CLT (Torque Limit Detection Signal) /VLT (Speed Limit Detection Output Signal) /VLT (Speed Limit Detection Output Signal) /WARN (Warning Output Signal) /NEAR (Near Output Signal) PAO (Encoder Divided Pulse Output Phase A Signal) PBO (Encoder Divided Pulse Output Phase B Signal) PCO (Encoder Divided Pulse Output Phase C Signal) /PM (Preventative Maintenance Output Signal) /DBON (Dynamic Brake Operation Request Output Signal) 			

Operating Procedure

Use the following procedure to display the Operation Monitor, Status Monitor, and I/O Monitor for the SERVOPACK.

- Select *Monitor* in the SigmaWin+ Menu Dialog Box.
- The Operation Pane, Status Pane, and I/O Pane will be displayed in the Monitor Window.

*			YASKA	AWA SigmaWin-	- Ver.7	
	Monitor					•
J 📇 💻	Operation					
	Control I/f	- <i>-</i>	Item 🗸	Unit	0001-SV2-	
0001-SV2			1.611	Offic	Axis A	
-020L2 -020L2	POS SPO TRQ CO	ammon	Mctor rotating speed	min-1	0	
POWER ESTP N-OT	SPO Co	ommon	Speed reference	min-1	0	
	POS SPO TRO CO	ammon	Input reference pulse speed	min-1	0	
	PDS SPO TRO CO	ammon	Position error amount	reference ur	0	
	POS SPO TRO CO	ammon .	Accumulated load ratio	%	0	
	PDS SPO TRO CO	ammon	Regenerative load ratio	96	0	
	POS SPO TRO CO	ammon	Power consumed by DB resi	%	0	
	POS SPO TER CO	ommon	Current Alarm State	-	Normal	
	Status I/O Status					
	Control I/F		Item 🗸		0001-SV2·	
			1.em 🕹		Axis A	
	PDS SPO TRO CO	ammon	Dynamic Brake (DB)	ON(ALL)	ON	
	POS SPO TRQ CO	ammon	Origin not Passed	-	OFF	
		ommon ,	/COIN	-	OFF	
	Lo Co	onninon .	/		OFF	
			/V-CMP	-	OFF	
		ommon		-		
	570 CO PD5 570 TR0 Co	ommon ommon	/V-CMP	-	OFF	
	570 CO PD5 570 TR0 Co	ommon ommon ommon	/V-CMP /S-RDY /VLT	-	OFF	

Information

You can flexibly change the contents that are displayed in the Monitor Window. Refer to the following manual for details.

C Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)

10.2.3 I/O Signals Status Monitor

10.2.3 I/O Signals Status Monitor

Use the following procedure to check the status of the I/O signals.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select I/O Signal Allocation in the Menu Dialog Box. The I/O Signal Allocation Window will be displayed.

3. Click the Input Signal Tab.

Signal Allo	ation : 0001											
0001-SGD	75-R70F20A											
Write	Change Method		y List									
	Allocate Sig											
put Signal	Output Sign	nal				- 1	Manual					
	_						4.5 1/0	lignal Connection				
CN1-13	xis Nam	Status				<u> </u>				es and Functions		
CN1-7 CN1-8		H					4.5	I/O S	ignal	Connection	S	
CN1-9 CN1-10	Axis A	н				1	4.5.1	I/O Sig	nal Co	onnector (CN1)	Names and Function	\$
CN1-11 CN1-12		Hi Hi				-		The followi default set		ves the pin numbers, na	mes, and functions the I/O signal pin	s for the
Allocatio	_	User	allocations Pin Number	Polarity	Status			Input S		iven in parentheses.		
P-OT	AUG TREAT	Possible	Always inactive	-	Allow Forward Run			Signal	Pin No.	Name	Function	Reference
N-OT /P-CL		Possible Possible	Always inactive Always inactive	•	Allow Reverse Run No Forward External Torou-			/\$i1* (P-OT)	7	General-purpose Sequence Input 1 (For- ward Drive Prohibit Input)	You can allocate the input signal to use with a parameter. (Shops Servomotor drive (to prevent over- travel) when the moving part of the machine exceeds the range of move- ment.)	page 5-27
/N-CL /DEC	Axis A	Possible Possible	Always inactive CN1-9	Normal	No Forward Reverse Torque Deceleration Limit Switch In			/SI2* (N-OT)	8	General-purpose Sequence Input 2 (Reverse Drive Prohibit Input)		
/EXT1 /EXT2		Possible Possible	CN1-10 CN1-11	Normal Normal	No EXT1 Interrupt Request No EXT2 Interrupt Request			/Si3* (/DEC)	9	General-purpose Sequence Input 3 (Ori- gin Return Deceleration	You can allocate the input signal to use with a parameter, (Connects the deceleration limit switch for	-
/EXT3 FSTP		Possible Possible	CN1+12 Always inactive	Normal	No EXT3 Interrupt Request Emergency stop off			/SI4+ (/EXT1)	10	Switch Input) General-purpose Sequence Input 4 (Exter- nal Latch Input 1)	origin return.)	
								/SI5* (/EXT2)	11	General-purpose Sequence Input 5 (Exter- nal Latch Input 2)	You can allocate the input signals to use with parameters. (Connect the external signals that latch the current feedback pulse counter.)	-
								/Si6* (/EXT3)	12	General-purpose Sequence Input 6 (Exter- nal Latch Input 3)	are content recorded public counter.)	
								/510*	13	General-purpose Sequence Input 0	You can allocate the input signal to use with a parameter. (Used for general-purpose input. You can monitor this signal in the I/O monitor field of MECHATROLINK.)	-
								+24VIN	6	Sequence input Signal Power Supply Input	Inputs the sequence input signal power supply. Allowable voltage range: 24 VDC ±20% The 24-VDC power supply is not provided by Yaskawa.	-
								BAT+	14	Battery for Absolute Encoder (+)	These are the pins to connect the abso- lute encoder backup battery.	

Check the status of the input signals.

4. Click the Output Signal Tab.

tput Signal Monitor	Mode	Forced	Output Mode		
	xis Nam	Status			
CN1-1,2		Hi			
CN1-23,24	Axis A	Hi			
CN1-25,26		н			
	_				
	xis Nam	Allocation		Polarity	Status
/COBN		Possible	Disabled (not use		Positioning Incomplete
/V-CMP		Possible	Disabled (not use		Speed Non-Coincidence
/TGON		Possible	Disabled (not use		Motor Stopped
/S-RDY		Possible	Disabled (not use		Servo Preparation Incomple
/CLT	Axis A	Possible	Disabled (not use		No Torque/Thrust Limit De
/VLT		Possible	Disabled (not use		No Speed Limit Detected
/8K		Possible	CN1-1,2	Normal output	Braking
/WARN		Possible	Disabled (not use		Normal
/NEAR		Possible	Disabled (not use		No Positioning Completion
/PM		Possible	Disabled (not use	-	Preventative Maintenance 0

Check the status of the output signals.

10.2.3 I/O Signals Status Monitor

Information Yo

You can also use the above window to check wiring.

- Checking Input Signal Wiring
 - Change the signal status at the host controller. If the input signal status on the window changes accordingly, then the wiring is correct.
- Checking Output Signal Wiring
- Click the **Force Output Mode** Button. This will force the output signal status to change. If the signal status at the host controller changes accordingly, then the wiring is correct. You cannot use the **Force Output Mode** Button while the servo is ON.
- For details, refer to the following manual.

AC Servo Drive Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)

10.3.1 Items That You Can Monitor


10.3 Monitoring Machine Operation Status and Signal Waveforms

To monitor waveforms, use the SigmaWin+ trace function or a measuring instrument, such as a memory recorder.


10.3.1 Items That You Can Monitor

You can use the SigmaWin+ or a measuring instrument to monitor the shaded items in the following block diagram.





- * This speed is available when fully-closed loop control is being used.
- Linear Servomotors



10.3.2 Using the SigmaWin+

10.3.2 Using the SigmaWin+


This section describes how to trace data and I/O with the SigmaWin+.

Refer to the following manual for detailed operating procedures for the SigmaWin+.

C Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)

Operating Procedure

- 1. Click the Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Trace in the Menu Dialog Box. The Trace Dialog Box will be displayed.



Click this button to display the Trace Setting Dialog Box shown below, and set the data to trace and the trace conditions.



Trace Objects

You can trace the following items.

Data Tracing

Trace Objects				
 Torque Reference Feedback Speed Reference Speed Position Reference Speed Position Error (Deviation) Position Amplifier Error (Deviation) 	 Motor - Load Position Deviation Speed Feedforward Torque Feedforward Effective (Active) Gain Main Circuit DC Voltage External Encoder Speed Control Mode 			

• I/O Tracing

	Trace (Objects	
Input Signals	 P-OT (Forward Drive Prohibit Input Signal) N-OT (Reverse Drive Prohibit Input Signal) /P-CL (Forward External Torque/Force Limit Input Signal) /N-CL (Reverse External Torque/Force Limit Input Signal) /G-SEL (Gain Selection Input Signal) /P-DET (Polarity Detection Input Signal) /DEC (Origin Return Deceleration Switch Input Signal) /EXT1 (External Latch Input 1 Signal) /EXT2 (External Latch Input 3 Signal) /EXT3 (External Latch Input 3 Signal) FSTP (Forced Stop Input Signal) /HWBB1 (Hard Wire Base Block Input 1 Signal) /DBANS (Dynamic Brake Answer Input Signal) 	Output Signals	 ALM (Servo Alarm Output Signal) /COIN (Positioning Completion Output Signal) /V-CMP (Speed Coincidence Detection Output Signal) /TGON (Rotation Detection Output Sig- nal) /S-RDY (Servo Ready Output Signal) /CLT (Torque Limit Detection Output Sig- nal) /VLT (Speed Limit Detection Output Sig- nal) /VLT (Speed Limit Detection Output Sig- nal) /WARN (Warning Output Signal) /WARN (Warning Output Signal) /NEAR (Near Output Signal) /NEAR (Near Output Signal) PAO (Encoder Divided Pulse Output Phase A Signal) PBO (Encoder Divided Pulse Output Phase B Signal) PCO (Encoder Divided Pulse Output Phase C Signal) /DBON (Dynamic Brake Operation Request Output Signal) ACON (Main Circuit ON Signal) PDETCMP (Polarity Detection Com- pleted Signal) DEN (Position Reference Distribution Completed Signal) PSET (Positioning Completion Output
			 Signal) CMDRDY (Command Ready Signal)

10.3.3 Using the Analog Monitors

Connect a measuring instrument, such as a memory recorder, to the analog monitor connector (CN5) on the SERVOPACK to monitor analog signal waveforms. The measuring instrument is not provided by Yaskawa.

Refer to the following section for details on the connection. *4.8.3 Analog Monitor Connector (CN5)* on page 4-39

Setting the Monitor Object

Use $Pn006 = n.\square\squareXX$ and $Pn007 = n.\square\squareXX$ (Analog Monitor 1 and 2 Signal Selections) to set the items to monitor.

Line Color	Signal	Parameter Setting
White	Analog monitor 1	Pn006 = n.□□XX
Red	Analog monitor 2	Pn007 = n.□□XX
Black (2 lines)	GND	-

Dor	ameter		Description	
Par	ameter	Monitor Signal	Output Unit	Remarks
	n.□□00 (default setting of Pn007)	Motor Speed	 Rotary Servomotor: 1 V/1,000 min⁻¹ Linear Servomotor: 1 V/1,000 mm/s 	-
	n.□□01	Speed Reference	 Rotary Servomotor:1 V/1,000 min⁻¹ Linear Servomotor:1 V/1,000 mm/s 	-
	n.□□02 (default setting of Pn006)	Torque Reference	1 V/100% rated torque	_
	n.□□03	Position Deviation	0.05 V/Reference unit	0 V for speed or torque control
	n.□□04	Position Amplifier Devi- ation	Amplifier Devi- 0.05 V/encoder pulse unit	
	n.□□05	Position Command Speed	 Rotary Servomotor:1 V/1,000 min⁻¹ Linear Servomotor:1 V/1,000 mm/s 	-
Pn006 or	n.□□06	Reserved parameter (Do not change.)	_	-
Pn007	n.□□07	Motor - Load Position Deviation	0.01 V/Reference unit	_
	n.□□08	Positioning Completion	Positioning completed: 5 V Positioning not completed: 0 V	Completion is indi- cated by the output voltage.
	n.□□09	Speed Feedforward	 Rotary Servomotor:1 V/1,000 min⁻¹ Linear Servomotor:1 V/1,000 mm/s 	-
	n.□□0A	Torque Feedforward	1 V/100% rated torque	-
	n.ロロ0B	Active Gain*	1st gain: 1 V 2nd gain: 2 V	The gain that is active is indicated by the output voltage.
	n.□□0C	Completion of Position Reference Distribution	Distribution completed: 5 V Distribution not completed: 0 V	Completion is indi- cated by the output voltage.
	n.□□0D	External Encoder Speed	1 V/1,000 min ⁻¹	Value calculated at the motor shaft
	n.□□10	Main Circuit DC Voltage	1 V/100 V (main circuit DC voltage)	_

* Refer to the following section for details.

Changing the Monitor Factor and Offset

You can change the monitor factors and offsets for the output voltages for analog monitor 1 and analog monitor 2. The relationships to the output voltages are as follows:

Analog monitor 1 $= (-1) \times 6$ output voltage	Analog Monitor 1 Signal	Analog Monitor 1	Analog Monitor 1
	Selection (Pn006 = n.□□XX) [×]	Magnification (Pn552) ⁺	Offset Voltage (Pn550)
Analog monitor 2 $= (-1) \times 10^{-1}$	Analog Monitor 2 Signal ×	Analog Monitor 2 ₊	Analog Monitor 2
	Selection (Pn007 = n.□□XX)	Magnification (Pn553)	Offset Voltage (Pn551)

The following parameters are set.


	Analog Monitor 1 Of	fset Voltage	Speed	osition Torque	
Pn550	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	-10,000 to 10,000	0.1 V	0	Immediately	Setup
	Analog Monitor 2 Of	Speed	osition Torque		
Pn551	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	-10,000 to 10,000	0.1 V	0	Immediately	Setup
	Analog Monitor 1 Ma	agnification	Speed Position Torque		
Pn552	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	-10,000 to 10,000	×0.01	100	Immediately	Setup
	Analog Monitor 2 Ma	agnification	Speed	osition Torque	
Pn553	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	-10,000 to 10,000	×0.01	100	Immediately	Setup

• Example of Setting the Item to Monitor to the Motor Speed (Pn006 = $n.\Box\Box00$)


When Pn552 = 100 (Setting Unit: ×0.01)

When Pn552 = 1,000 (Setting Unit: ×0.01)

Analog monitor output voltage (V)



Analog monitor output voltage (V)



Adjusting the Analog Monitor Output

You can manually adjust the offset and gain for the analog monitor outputs for the torque reference monitor and motor speed monitor.

The offset is adjusted to compensate for offset in the zero point caused by output voltage drift or noise in the monitoring system.

The gain is adjusted to match the sensitivity of the measuring system.

The offset and gain are adjusted at the factory. You normally do not need to adjust them.

Adjustment Example

An example of adjusting the output of the motor speed monitor is provided below.

Offset Adju	stment	Gain Adjustment			
Analog monitor output voltage		Analog monitor output voltage 1 [M] Gain adjustment 1000 [min ⁻¹] Motor speed			
Item	Specification	Item	Specification		
Offset Adjustment Range	-2.4 V to 2.4 V	Gain Adjustment Range	100 ±50%		
Adjustment Unit	18.9 mV/LSB	Adjustment Unit	0.4%/LSB		
		 The gain adjustment range is made using a 100% ou put value (gain adjustment of 0) as the reference valu with an adjustment range of 50% to 150%. A setting example is given below. Setting the Adjustment Value to -125 100 + (-125 × 0.4) = 50 [%] Therefore, the monitor output voltage goes to 50% of the original value. Setting the Adjustment Value to 125 100 + (125 × 0.4) = 150 [%] Therefore, the monitor output voltage goes to 50% of the original value. 			

Information • The adjustment values do not use parameters, so they will not change even if the parameter settings are initialized.

- Adjust the offset with the measuring instrument connected so that the analog monitor output value goes to zero. The following setting example achieves a zero output.
 - While power is not supplied to the Servomotor, set the monitor signal to the torque reference.
 - In speed control, set the monitor signal to the position deviation.

Preparations

Always check the following before you adjust the analog monitor output.

• The parameters must not be write prohibited.

♦ Applicable Tools

You can use the following tools to adjust analog monitor outputs.

• Offset Adjustment

Tool	Fn No./Function Name	Operating Procedure Reference
Digital Operator	Fn00C	Ω-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Others – Adjust the Analog Monitor Output	G

10.3.3 Using the Analog Monitors

• Gain Adjustment

Tool	Fn No./Function Name	Operating Procedure Reference			
Digital Operator	Fn00D	Ω-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)			
SigmaWin+ Others – Adjust the Analog Monitor Output		Operating Procedure on page 10-13			

Operating Procedure

Use the following procedure to adjust the analog monitor output.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Adjust the Analog Monitor Output in the Menu Dialog Box. The Adjust the Analog Monitor Output Dialog Box will be displayed.
- 3. Click the Zero Adjustment or Gain Adjustment Tab.

Adjust the Analog Monitor Output AXIS#00
Zero Adjustment Gain Adjustment
Channel CH1
0 -1 Q↓
Monitor Signal Torque reference (1 V/100% rated to

4. While watching the analog monitor, use the +1 and -1 Buttons to adjust the offset. There are two channels: CH1 and CH2. If necessary, click the down arrow on the **Channel** Box and select the channel.

Search Adjust the Analog Monitor Output AXIS#00
Zero Adjustment Gain Adjustment
Analog Monitor Output Offset
Channel CH1
0 offset 0 -1 Q↓
Monitor Signal Torque reference (1 V/100% rated to

This concludes adjusting the analog monitor output.

10.4.1 Items That You Can Monitor

10.4 Monitoring Product Life

10.4.1 Items That You Can Monitor


Monitor Item	Description
SERVOPACK Installation Envi- ronment	 The operating status of the SERVOPACK in terms of the installation environment is displayed. Implement one or more of the following actions if the monitor value exceeds 100%. Lower the surrounding temperature. Decrease the load.
Servomotor Installation Environ- ment	The operating status of the SERVOPACK in terms of the installation environment is displayed. Implement one or more of the following actions if the monitor value exceeds 100%.Lower the surrounding temperature.Decrease the load.
Built-in Fan Service Life Predic- tion	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.
Capacitor Service Life Predic- tion	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.
Surge Prevention Circuit Ser- vice Life Prediction	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.
Dynamic Brake Circuit Service Life Prediction	The unused status of the SERVOPACK is treated as the 100% value. The value decreases each time the main circuit power supply is turned ON and each time the servo is turned OFF. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines.
Built-in Brake Relay Service Life Prediction	The unused status of the built-in brake relay is treated as the 100% value. The value decreases based on the number of operations of the built-in brake relay. Use a monitor value of 0% as a guideline for the replacement period. Refer to the following section for part replacement guidelines. <i>13.1.2 Guidelines for Part Replacement</i> on page 13-2

10.4.2 Operating Procedure

Use the following procedure to display the installation environment and service life prediction monitor dialog boxes.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Life Monitor in the Menu Dialog Box. The Life Monitor Dialog Box will be displayed.

Information With the Digital Operator, you can use Un025 to Un02A to monitor this information.



A value of 100% indicates that the SERVOPACK has not yet been used. The percentage decreases as the SERVOPACK is used and reaches 0% when it is time to replace the SERVOPACK.

10.4.3 Preventative Maintenance

You can use the following functions for preventative maintenance.

- Preventative maintenance warnings
- /PM (Preventative Maintenance Output) signal
- Built-in Brake Relay Life Alarm

The SERVOPACK can notify the host controller when it is time to replace any of the main parts.

Preventative Maintenance Warning

An A.9b0 warning (Preventative Maintenance Warning) is detected when any of the following service life prediction values drops to 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, dynamic brake circuit life, and built-in brake relay life. You can change the setting of Pn00F = $n.\square\square\squareX$ to enable or disable these warnings.

Parameter		Description	When Enabled	Classifi- cation
n.□□□0 Pn00F (default setting)		Do not detect preventative maintenance warnings.	After restart	Setup
n.0001		Detect preventative maintenance warnings.	restart	

Note: Service life prediction of the built-in brake relay is performed as preventative maintenance for SERVOPACKs with built-in Servomotor brake control only when Pn023 is set to n. \Box

10.4.3 Preventative Maintenance

/PM (Preventative Maintenance Output) Signal

The /PM (Preventative Maintenance Output) signal is output when any of the following service life prediction values reaches 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, dynamic brake circuit life, and built-in brake relay life. The /PM (Preventative Maintenance Output) signal must be allocated.

Even if detection of preventive maintenance warnings is disabled (Pn00F = $n.\Box\Box\Box$), the /PM signal will still be output as long as it is allocated.

Classifi- cation	Signal	Connector Pin No.	Signal Status	Description		
Output	/PM		ON (closed)	One of the following service life prediction values reached 10% or less: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, dynamic brake circuit life, and built-in brake relay life.		
	/ PIVI	Must be allocated.	OFF (open)	All of the following service life prediction values are greater than 10%: SERVOPACK built-in fan life, capacitor life, inrush current limiting circuit life, dynamic brake circuit life, and built-in brake relay life.		

Note: You must allocate the /PM signal to use it. Use Pn514 = n.□X□□ (/PM (Preventative Maintenance Output) Signal Allocation) to allocate the signal to connector pins. Refer to the following section for details. *T* 7.1.2 Output Signal Allocations on page 7-6

Built-in Brake Relay Life Alarm

A built-in brake relay life alarm (alarm number: A.232) is detected when the number of built-in brake relay operations has exceeded 30,000 operations. You can use $Pn023 = n.\square\squareX\square$ to enable or disable the built-in brake relay life alarm.

Parameter		Description	When Enabled	Classifi- cation
Pn023 n.□□0□ (default setting) n.□□1□		Detect built-in brake relay life alarm.	rake relay life alarm. After restart	
		Do not detect built-in brake relay life alarm.	Testart	

Note: Built-in brake relay life alarm is used as preventative maintenance for SERVOPACKs with built-in Servomotor brake control only when Pn023 is set to n.



Replace parts immediately after the number of built-in brake relay operations has exceeded 30,000 operations.

10.5.1 Data for Which Alarm Tracing Is Performed

10.5 Alarm Tracing

Alarm tracing records data in the SERVOPACK from before and after an alarm occurs. This data helps you to isolate the cause of the alarm.

You can display the data recorded in the SERVOPACK as a trace waveform on the SigmaWin+.

- Alarms that occur when the power supply is turned ON are not recorded.Alarms that occur during the recording of alarm trace data are not recorded. Information
 - - Alarms that occur while utility functions are being executed are not recorded.
 - Alarms that occur while the data tracing function of the SigmaWin+ is being executed are not recorded.

Data for Which Alarm Tracing Is Performed 10.5.1

Two types of data are recorded for alarm tracing: numeric data and I/O signal ON/OFF data.

Numeric Data	ON/OFF Data
Torque reference	ALM
Feedback speed	Servo ON command (/S-ON)
Reference speed	Proportional control command (/P-CON)
Position reference speed	Forward torque command (/P-CL)
Position deviation	Reverse torque command (/N-CL)
Motor-load position deviation	G-SEL1 signal (/G-SEL1)
Main circuit bus voltage	ACON

10.5.2 Applicable Tools

The following table lists the tools that you can use to perform alarm tracing.

Tool	Fn No./Function Name Operating Procedure Reference			
Digital Operator	You cannot display alarm tracing data from the Digital Operator.			
SigmaWin+	Troubleshooting – Alarm Trace	larm Trace Engineering Tool SigmaWin+ Operation Manual (Manual No.: SIET S800001 34)		

Fully-Closed Loop Control

This chapter provides detailed information on performing fully-closed loop control with the SERVOPACK.


(11)

11.1	Fully-	Closed System 11-2
11.2	SERV	OPACK Commissioning Procedure11-3
11.3	Parame	eter Settings for Fully-Closed Loop Control 11-5
	11.3.1	Control Block Diagram for Fully-Closed
	11.3.2	•
	11.3.3	Setting the Number of External Encoder Scale Pitches
	11.3.4	Setting the PAO, PBO, and PCO (Encoder Divided Pulse Output) Signals 11-7
	11.3.5	External Absolute Encoder Data Reception Sequence
	11.3.6	Electronic Gear Setting 11-8
	11.3.7	Alarm Detection Settings 11-9
	11.3.8	Analog Monitor Signal Settings 11-10
	11.3.9	Setting to Use an External Encoder for Speed Feedback 11-10

11.1 Fully-Closed System

With a fully-closed system, an externally installed encoder is used to detect the position of the controlled machine and the machine's position information is fed back to the SERVOPACK. High-precision positioning is possible because the actual machine position is fed back directly. With a fully-closed system, looseness or twisting of mechanical parts may cause vibration or oscillation, resulting in unstable positioning.

The following figure shows an example of the system configuration.



* The connected devices and cables depend on the type of external linear encoder that is used.

Note: Refer to the following section for details on connections that are not shown above, such as connections to power supplies and peripheral devices.

2.4 Examples of Standard Connections between SERVOPACKs and Peripheral Devices on page 2-17

11.2 SERVOPACK Commissioning Procedure

First, confirm that the SERVOPACK operates correctly with semi-closed loop control, and then confirm that it operates correctly with fully-closed loop control. The commissioning procedure for the SERVOPACK for fully-closed loop control is given below.

Con-**Required Parameter** Step Description Operation trolling Settings Device Set the parameters so that the Check operation of the SERVOPACK operates correctly in • Pn000 (Basic Function entire sequence with semi-closed loop control without a Selections 0) semi-closed loop control load and check the following Pn001 (Application and without a load. points. Set Pn002 to n.0 DD to Function Selections 1) Items to Check specify semi-closed loop control. • Pn002 = n.X□□□ • Power supply circuit · Are there any errors in the SER-(External Encoder wiring VOPACK? Usage) Servomotor wiring Does jogging function correctly Pn20E (Electronic Gear SERVO- Encoder wiring when you operate the SERVO-PACK or Ratio (Numerator)) • Wiring of I/O signal PACK without a load? 1 Pn210 (Electronic Gear host conlines from the host con-• Do the I/O signals turn ON and Ratio (Denominator)) troller troller OFF correctly? • Pn50Å, Pn50B, Pn511, Servomotor rotation · Is power supplied to the Servoand Pn516 (Input Signal motor when the SV_ON (Servo direction, motor speed, Selections) and multiturn data ON) command is sent from the • Pn50E, Pn50F, Pn510, Operation of safety host controller? Pn514, Pn53C, and mechanisms, such as Does the Servomotor operate Pn53D (Output Signal the brakes and the correctly when a position refer-Selections) overtravel mechanisms ence is input by the host controller? Check operation with the Servomotor connected to the machine with semi-closed loop control. Connect the Servomotor to the Items to Check machine. Set the moment of inertia · Initial response of the ratio in Pn103 using autotuning system connected to without a host reference. Pn103 (Moment of Inertia Host con-2 the machine Check that the machine's move-Ratio) troller Movement direction. ment direction, travel distance, and travel distance, and movement speed agree with the references from the host controller. movement speed as specified by the references from the host controller Set the parameters related to fully-• Pn002 = n.X□□□ closed loop control and move the (External Encoder machine with your hand without Usage) turning ON the power supply to the Pn20A (Number of Servomotor. Check the following External Encoder Scale status with the Digital Operator or Pitches) SigmaWin+. Pn20E (Electronic Gear Check the external • Does the fully-closed feedback Ratio (Numerator)) encoder. pulse counter count up when the Pn210 (Electronic Gear Items to Check Servomotor moves in the forward 3 Ratio (Denominator)) Is the signal from the direction? Pn281 (Encoder Output external encoder · Is the travel distance of the Resolution) received correctly? machine visually about the same • Pn51B (Motor-Load as the amount counted by the Position Deviation Overfully-closed feedback pulse flow Detection Level) counter? Pn522 (Positioning Note: The unit for the fully-closed feed-Completed Width) back pulse counter is pulses, • Pn52A (Multiplier per which is equivalent to the exter-Fully-closed Rotation) nal encoder sine wave pitch.

Continued on next page.

	Continued norm provided page.				
Step	Description	Operation	Required Parameter Settings	Con- trolling Device	
4	Perform a program jog- ging operation. Items to Check Does the fully-closed system operate correctly for the SERVOPACK without a load?	Perform a program jogging opera- tion and confirm that the travel dis- tance is the same as the reference value in Pn531. When you perform program jog- ging, start from a low speed and gradually increase the speed.	Pn530 to Pn536 (program jogging-related parame- ters)	SERVO- PACK	
5	Operate the SERVO- PACK. Items to Check Does the fully-closed system operate correctly, including the host con- troller?	Input a position reference and con- firm that the SERVOPACK oper- ates correctly. Start from a low speed and gradu- ally increase the speed.	_	Host con- troller	

Continued from previous page.

11.3.1 Control Block Diagram for Fully-Closed Loop Control


11.3 Parameter Settings for Fully-Closed Loop Control

Parameter to Set	Setting	Position Control	Speed Control	Torque Control	Reference
Pn000 = n.□□□X	Motor direction		\checkmark	\checkmark	
Pn002 = n.X□□□	External encoder usage method		\checkmark	\checkmark	page 11-6
Pn20A	Number of external encoder scale pitches		\checkmark	\checkmark	page 11-7
Pn281	Encoder divided pulse output signals (PAO, PBO, and PCO) from the SERVO- PACK	\checkmark	\checkmark	\checkmark	page 11-7
_	External absolute encoder data reception sequence	\checkmark	\checkmark	\checkmark	page 7-42
Pn20E and Pn210	Electronic gear ratio		-	-	page 6-42
Pn51B	Motor-load position deviation overflow detection level	\checkmark	_	_	page 11-9
Pn52A	Multiplier per fully-closed rotation		-	-	
Pn006/Pn007	Analog monitor signal		\checkmark	\checkmark	page 11-10
Pn22A = n.X□□□	Speed feedback method during fully- closed loop control	\checkmark	-	_	page 11-10

This section describes the parameter settings that are related to fully-closed loop control.

11.3.1 Control Block Diagram for Fully-Closed Loop Control

The control block diagram for fully-closed loop control is provided below.



* The connected device depends on the type of external encoder.

Note: You can use either an incremental or an absolute encoder. If you use an absolute encoder, set Pn002 to n. $\Box 1 \Box \Box$ (Use the absolute encoder as an incremental encoder).

11.3.2 Setting the Motor Direction and the Machine Movement Direction

11.3.2 Setting the Motor Direction and the Machine Movement Direction

You must set the motor direction and the machine movement direction. To perform fully-closed loop control, you must set the motor rotation direction with both $Pn000 = n.\square\square\squareX$ (Direction Selection) and $Pn002 = n.X\square\square\square$ (External Encoder Usage).

	Parameter		Pn002 = n.XDDD (External Encoder Usage)			
i diditicici		n.1⊏		n.3E	100	
Pn000 =n.□□□X (Direction Selection)	n.□□□0	Reference direction	Forward reference	Reverse reference	Forward reference	Reverse reference
		Motor direction	CCW	CW	CCW	CW
		External encoder	Forward movement	Reverse movement	Reverse movement	Forward movement
	n.0001	Reference direction	Forward reference	Reverse reference	Forward reference	Reverse reference
		Motor direction	CW	CCW	CW	CCW
		External encoder	Reverse movement	Forward movement	Forward movement	Reverse movement

• Phase B leads in the divided pulses for a forward reference regardless of the setting of Pn000 = $n.\Box\Box\BoxX$.

• Forward direction: The direction in which the pulses are counted up.

• Reverse direction: The direction in which the pulses are counted down.

Related Parameters

♦ Pn000 = n.□□□X

Refer to the following section for details. 6.5 Motor Direction Setting on page 6-15

◆ Pn002 = n.X□□□

When you perform fully-closed loop control, set Pn002 to $n.1\square\square\square$ or $n.3\square\square\square$.

Parameter		Name	Meaning	When Enabled	Classifi- cation
	n.0□□□ (default set- ting)		Do not use an external encoder.		
Pn002	n.1000	External Encoder Usage	External encoder moves in forward direction for CCW motor rotation.	After restart	Setup
	n.2000		Reserved parameter (Do not change.)		
	n.3000		External encoder moves tion for CCW motor rotat		
	n.4000		Reserved parameter (Do not change.)		

Information


Determine the setting of Pn002 = $n.X\Box\Box\Box$ as described below.

- Set Pn000 to n. DD (Use the direction in which the linear encoder counts up as the forward direction) and set Pn002 to n.1DD (The external encoder moves in the forward direction for CCW motor rotation).
- Manually rotate the motor shaft counterclockwise.
- If the fully-closed feedback pulse counter counts up, do not change the setting of Pn002 (Pn002 = n.1□□□).
- If the fully-closed feedback pulse counter counts down, set Pn002 to n.3

11.3.3 Setting the Number of External Encoder Scale Pitches

Setting the Number of External Encoder Scale Pitches 11.3.3

Set the number of external encoder scale pitches per Servomotor rotation in Pn20A.



If the external encoder is connected directly to the Servomotor, the setting will be 1,500 (30 mm/0.02 mm = 1,500).

Note: 1. If there is a fraction, round off the digits below the decimal point.

2. If the number of external encoder scale pitches per Servomotor rotation is not an integer, there will be deviation in the position loop gain (Kp), feedforward, and position reference speed monitor. This is not relevant for the position loop and it therefore does not interfere with the position accuracy.

Related Parameters

	Number of Externa	I Encoder Scale Pito	Position		
Pn20A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
FIIZUA	4 to 1,048,576	1 scale pitch/revo- lution	32,768	After restart	Setup

Setting the PAO, PBO, and PCO (Encoder Divided Pulse 11.3.4 Output) Signals

Set the position resolution in Pn281 (Encoder Output Resolution). Enter the number of phase A and phase B edges for the setting.


Setting Example

Specifications External encoder scale pitch: 20 µm Ball screw lead: 30 mm Speed:1,600 mm/s

If a single pulse (multiplied by 4) is output for 1 μ m, the setting would be 20.

If a single pulse (multiplied by 4) is output for 0.5 μ m, the setting would be 40.

The encoder divided pulse output would have the following waveform if the setting is 20.



"1" indicates the edge positions. In this example, the set value is 20 and therefore the number of edges is 20.

Note: The upper limit of the encoder signal output frequency (multiplied by 4) is 6.4 Mpps. Do not set a value that would cause the output to exceed 6.4 Mpps.

If the output exceeds the upper limit, an A.511 alarm (Encoder Output Pulse Overspeed) will be output.

11.3.5 External Absolute Encoder Data Reception Sequence

Example If the setting is 20 and the speed is 1,600 mm/s, the output frequency would be 1.6 Mpps $\frac{1600 \text{ mm/s}}{1600 \text{ mm/s}} = 1.600,000 = 1.6 \text{ Mpps}$

$$\frac{1000 \text{ mm/s}}{0.001 \text{ mm}} = 1,600,000 = 1.6 \text{ Mpps}$$

Because 1.6 Mpps is less than 6.4 Mpps, this setting can be used.

Related Parameters

	Encoder Output Re	solution	Position		
Pn281	Setting Range	Setting Unit	Default Setting	When Enabled	Classification
	1 to 4,096	1 edge/pitch	20	After restart	Setup

Note: 1. The maximum setting for the encoder output resolution is 4,096. Pulse output at a linear encoder resolution of 4,096 or higher is not possible.

2. If the setting of Pn281 exceeds the resolution of the external encoder, the A.041 alarm (Encoder Output Pulse Setting Error) will be output.

11.3.5 External Absolute Encoder Data Reception Sequence

Refer to the following section for details.

7.9.4 Reading the Position Data from the Absolute Linear Encoder on page 7-42

With fully-closed loop control, the same sequence as for a Linear Servomotor is used.

11.3.6 Electronic Gear Setting

Refer to the following section for details.

6.15 Electronic Gear Settings on page 6-42

With fully-closed loop control, the same setting as for a Linear Servomotor is used.

11.3.7 Alarm Detection Settings

11.3.7 Alarm Detection Settings

This section describes the alarm detection settings (Pn51B and Pn52A).

Pn51B (Motor-Load Position Deviation Overflow Detection Level)

This setting is used to detect the difference between the feedback position of the Servomotor encoder and the feedback load position of the external encoder for fully-closed loop control. If the detected difference exceeds the setting, an A.d10 alarm (Motor-Load Position Deviation Overflow) will be output.

Pn51B	Motor-Load Positio	n Deviation Overflo	Position		
	Setting Range	Setting Unit	Default Setting When Enabl		Classifica- tion
	0 to 1,073,741,824	1 reference unit	1000	Immediately	Setup

Note: If you set this parameter to 0, A.d10 alarms will not be output and the machine may be damaged.

Pn52A (Multiplier per Fully-closed Rotation)

Set the coefficient of the deviation between the Servomotor and the external encoder per motor rotation.


This setting can be used to prevent the Servomotor from running out of control due to damage to the external encoder or to detect belt slippage.

Setting Example

Increase the value if the belt slips or is twisted excessively.

If this parameter is set to 0, the external encoder value will be read as it is.

If you use the default setting of 20, the second rotation will start with the deviation for the first Servomotor rotation multiplied by 0.8.



Related Parameters

	Multiplier per Fully-	closed Rotation		Position		
Pn52A	Setting Range	Setting Unit	Default Setting	When Enabled	Classification	
	0 to 100	1%	20	Immediately	Setup	

11.3.8 Analog Monitor Signal Settings

11.3.8 Analog Monitor Signal Settings

You can monitor the position deviation between the Servomotor and load with an analog monitor.

Para	Parameter Name		Meaning	When Enabled	Classifi- cation
Pn006	n.□□07		Position deviation between motor and load (output unit: 0.01 V/reference unit).	Immedi-	Sotup
Pn007	n.□□07		Position deviation between motor and load (output unit: 0.01 V/reference unit).	ately	Setup

11.3.9 Setting to Use an External Encoder for Speed Feedback

For fully-closed loop control, you normally set a parameter to specify using the motor encoder speed (Pn22A = $n.0\square\square\square$).

If you will use a high-resolution external encoder, set the parameter to specify using the speed of the external encoder (Pn22A = $n.1\square\square\square$).

Parameter		Meaning	When Enabled	Classification
Pn22A	n.0□□□ (default set- ting)	Use motor encoder speed.	After restart	Setup
	n.1000	Use external encoder speed.		

Note: This parameter cannot be used if Pn002 is set to n.0 [[] (Do not use external encoder).

Safety Functions

This chapter provides detailed information on the safety functions of the SERVOPACK.

(12)

12.1	Introd	uction to the Safety Functions 12-2
	12.1.1 12.1.2	Safety Functions
12.2	Hard \	Wire Base Block (HWBB)12-3
		Risk Assessment12-4Hard Wire Base Block (HWBB) State12-5Resetting the HWBB State12-6Related Commands12-7Detecting Errors in HWBB Signal12-7HWBB Input Signal Specifications12-7Operation without a Host Controller12-8/S-RDY (Servo Ready Output) Signal12-8/BK (Brake Output) Signal12-9Stopping Methods12-9ALM (Servo Alarm) Signal12-9
12.3	EDM1	(External Device Monitor) 12-10
	12.3.1	EDM1 Output Signal Specifications 12-10
12.4	Applica	ations Examples for Safety Functions 12-11
	12.4.1 12.4.2 12.4.3	Connection Example12-11Failure Detection Method12-11Procedure12-12
12.5	Valida	ting Safety Functions
10.0	Campo	ating a Cafaty Eurotian Davias10.11
12.6	Conne	ecting a Safety Function Device 12-14

12.1.1 Safety Functions

12.1 Introduction to the Safety Functions

12.1.1 Safety Functions

Safety functions are built into the SERVOPACK to reduce the risks associated with using the machine by protecting workers from the hazards of moving machine parts and otherwise increasing the safety of machine operation.

Especially when working in hazardous areas inside guards, such as for machine maintenance, the safety function can be used to avoid hazardous moving machine parts.

Refer to the following section for information on the safety function and safety parameters. *Compliance with UL Standards, EU Directives, and Other Safety Standards* on page xxi



Products that display the TÜV mark on the nameplate have met the safety standards.

12.1.2 Precautions for Safety Functions

WARNING To confirm that the HWBB function satisfies the safety requirements of the system, you must conduct a risk assessment of the system. Incorrect use of the safety function may cause injury. • The Servomotor will move if there is an external force (e.g., gravity on a vertical axis) even when the HWBB function is operating. Use a separate means, such as a mechanical brake, that satisfies the safety requirements. Incorrect use of the safety function may cause injury. • While the HWBB function is operating, the Servomotor may move within an electric angle of 180° or less as a result of a SERVOPACK failure. Use the HWBB function for an application only after confirming that movement of the Servomotor will not result in a hazardous condition. Incorrect use of the safety function may cause injury. • The dynamic brake and the brake signal are not safety-related elements. You must design the system so that SERVOPACK failures will not cause a hazardous condition while the HWBB function is operating. Incorrect use of the safety function may cause injury. • Connect devices that satisfy the safety standards for the signals for safety functions. Incorrect use of the safety function may cause injury. The HWBB function does not shut OFF the power to the SERVOPACK or electrically isolate it. Implement measures to shut OFF the power supply to the SERVOPACK before you perform maintenance on it. There is a risk of electric shock. Use an SELV-compliant power supply according to EN/IEC 60950-1 to input 24 VDC to the control power supply input terminals. If you use a power supply that is not SELV compliant, safety functions may be lost if the power

supply fails, which may result in machine damage or injury.

12.2 Hard Wire Base Block (HWBB)

A hard wire base block (abbreviated as HWBB) is a safety function that is designed to shut OFF the current to the motor with a hardwired circuit.

The drive signals to the Power Module that controls the motor current are controlled by the circuits that are independently connected to the two input signal channels to turn OFF the Power Module and shut OFF the motor current.

For safety function signal connections, the input signal is the 0-V common and the output signal is a source output.


This is opposite to other signals described in this manual.

To avoid confusion, the ON and OFF status of signals for the safety function are defined as follows:

ON: The state in which the relay contacts are closed or the transistor is ON and current flows into the signal line.

OFF: The state in which the relay contacts are open or the transistor is OFF and no current flows into the signal line.

The input signal uses the 0-V common. The following figure shows a connection example.



12.2.1 Risk Assessment

12.2.1 Risk Assessment

When using the HWBB, you must perform a risk assessment of the Servo System in advance to confirm that the safety level of the standards is satisfied. Refer to the following section for details on the standards.

G Compliance with UL Standards, EU Directives, and Other Safety Standards on page xxi

Note: To meet performance level e (PLe) in EN ISO 13849-1 and SIL3 in IEC 61508, the EDM1 signal must be monitored by the host controller. If the EDM1 signal is not monitored by the host controller, the level will be safety performance level c (PLc) and SIL1.

The following hazards exist even when the HWBB is operating. These hazards must be included in the risk assessment.


- The Servomotor will move if an external force is applied to it (for example, gravity on a vertical axis). Implement measures to hold the Servomotor, such as installing a separate mechanical brake.
- If a failure occurs such as a Power Module failure, the Servomotor may move within an electric angle of 180°. Ensure safety even if the Servomotor moves.
 - The rotational angle or travel distance depends on the type of Servomotor as follows:
 - Rotary Servomotor: 1/6 rotation max. (rotational angle calculated at the motor shaft)
 - Linear Servomotor: 50 mm max.
- The HWBB does not shut OFF the power to the SERVOPACK or electrically isolate it. Implement measures to shut OFF the power supply to the SERVOPACK before you perform maintenance on it.

12.2.2 Hard Wire Base Block (HWBB) State

12.2.2 Hard Wire Base Block (HWBB) State

The SERVOPACK will be in the following state if the HWBB operates. If the /HWBB1 or /HWBB2 signal turns OFF, the HWBB will operate and the SERVOPACK will enter a HWBB state.

• When HWBB Operates after Servo OFF (Power Not Supplied to Motor)



• When HWBB Operates While Power Is Supplied to Servomotor

/HWBB1 _C /HWBB2	N (normal operation)	OFF (motor current shut-OFF request)
MECHATROLINK-III command	Motion or other command	SMON or other command
Servo command status SV_ON	1	0
Servo command input signal monitor ESTP	0	1
SERVOPACK Status	Operating Status	HWBB state

12.2.3 Resetting the HWBB State

12.2.3 Resetting the HWBB State

Normally, after the SV_OFF (Servo OFF: 32h) command is received and power is no longer supplied to the Servomotor, the /HWBB1 and /HWBB2 signals will turn OFF and the SERVOPACK will enter the HWBB state. If you turn ON the /HWBB1 and /HWBB2 signals in this state, the SERVOPACK will enter a base block (BB) state and will be ready to acknowledge the SV_ON (Servo ON: 31h) command.

/HWBB1 /HWBB2	OFF (motor current shut-OFF request)	ON (normal	operation)
- MECHATROLINK-III command	SMON or other command		SV_ON command
Servo command status SV_ON -	0		1
- Servo command input signal monitor ESTP	1	0	0
- SERVO- PACK Status	HWBB state	BB state	Operating Status

If the /HWBB1 and /HWBB2 signals are OFF and the SV_ON (Servo ON: 31h) command is received, the HWBB state will be maintained even after the /HWBB1 and /HWBB2 signals are turned ON. Send the SV_OFF (Servo OFF: 32h) command to place the SERVOPACK in the BB state and then send the SV_ON (Servo ON: 31h) command.

/HWBB1 /HWBB2	OFF (motor current shut-OFF request)	ON (normal operat	ion)
MECHATROLINK-III command	SV_ON command	SV_OFF command	SV_ON command
Servo command status SV_ON	0	0	1
Servo command input signal monitor ESTP	1	0	0
SERVOPACK Status	HWBB state	BB state	Operating Status

Note: If the SERVOPACK is placed in the BB state while the main circuit power supply is OFF, the HWBB state will be maintained until the SV_OFF (Servo OFF: 32h) command is received.

12.2.4 Related Commands

12.2.4 Related Commands

If the /HWBB1 or /HWBB2 signal turns OFF and the HWBB operates, the ESTP bit in the servo command input signal monitor (SVCMD_IO) will change to 1. The host controller can monitor this bit to determine the status.

If the state changes to the HWBB state during the execution of the next motion command, a command warning occurs. If a warning occurs, clear the alarm to return to normal operating status. After stopping or canceling the motion command, using the sequence of commands to return to the HWBB status is recommended.

Applicable Motion Commands
SV_ON (Servo ON)
INTERPOLATE (Interpolating)
POSING (Positioning)
FEED (Constant Speed Feed)
EX_FEED (External Input Feed Command)
EX_POSING (External Input Positioning)
ZRET (Origin Return)


12.2.5 Detecting Errors in HWBB Signal

If only the /HWBB1 or the /HWBB2 signal is input, an A.Eb1 alarm (Safety Function Signal Input Timing Error) will occur unless the other signal is input within 10 seconds. This makes it possible to detect failures, such as disconnection of an HWBB signal.

• The A.Eb1 alarm (Safety Function Signal Input Timing Error) is not a safety-related element. Keep this in mind when you design the system.

12.2.6 HWBB Input Signal Specifications

If an HWBB is requested by turning OFF the two HWBB input signal channels (/HWBB1 and /HWBB2), the power supply to the Servomotor will be turned OFF within 8 ms.




Note: 1. The OFF status is not recognized if the OFF interval of the /HWBB1 or /HWBB2 signal is 0.5 ms or shorter. 2. You can check the status of the input signals by using monitor displays. 12.2.7 Operation without a Host Controller

12.2.7 Operation without a Host Controller

The HWBB will operate even for operation without a host controller.

However, if the HWBB operates during execution of the following functions, leave the execution mode for the function and then enter it again to restart operation. Operation will not be restarted simply by turning OFF the /HWBB1 and /HWBB2 signals.




12.2.8 /S-RDY (Servo Ready Output) Signal

The SV_ON (Servo ON: 31h) command will not be acknowledged in the HWBB state. Therefore, the Servo Ready Output Signal will turn OFF.

The Servo Ready Output Signal will turn ON if both the /HWBB1 and /HWBB2 signals are ON and the servo is turned OFF (BB state).

An example is provided below for when the main circuit power supply is ON and the SENS_ON (Turn Sensor ON) command is input when there is no servo alarm. (An absolute encoder is used in this example.)



12.2.9 /BK (Brake Output) Signal

12.2.9 /BK (Brake Output) Signal

If the HWBB operates when the /HWBB1 or /HWBB2 signal is OFF, the /BK (Brake) signal will turn OFF. At that time, the setting in Pn506 (Brake Reference - Servo OFF Delay Time) will be disabled. Therefore, the Servomotor may be moved by external force until the actual brake becomes effective after the /BK signal turns OFF.



• The brake signal is not a safety-related element. You must design the system so that a hazardous condition does not occur even if the brake signal fails in the HWBB state. Also, if a Servomotor with a Brake is used, keep in mind that the brake in the Servomotor is used only to prevent the moving part from being moved by gravity or an external force and it cannot be used to stop the Servomotor.

12.2.10 Stopping Methods

If the /HWBB1 or /HWBB2 signal turns OFF and the HWBB operates, the Servomotor will stop according to the stop mode that is set for stopping the Servomotor when the servo turns OFF (Pn001 = $n.\square\square\squareX$). However, if the dynamic brake is enabled (Pn001 = $n.\square\square\square0$ or $n.\square\square\square1$), observe the following precautions.



- The dynamic brake is not a safety-related element. You must design the system so that a hazardous condition does not occur even if the Servomotor coasts to a stop in the HWBB state. Normally, we recommend that you use a sequence that returns to the HWBB state after stopping for a reference.
- If the application frequently uses the HWBB, stopping with the dynamic brake may result in the deterioration of elements in the SERVOPACK. To prevent internal elements from deteriorating, use a sequence in which the HWBB state is returned to after the Servomotor has come to a stop.

12.2.11 ALM (Servo Alarm) Signal

The ALM (Servo Alarm) signal is not output in the HWBB state.

12.3.1 EDM1 Output Signal Specifications

12.3 EDM1 (External Device Monitor)

The EDM1 (External Device Monitor) signal is used to monitor failures in the HWBB. Connect the monitor signal as a feedback signal, e.g., to the Safety Unit.

Note: To meet performance level e (PLe) in EN ISO 13849-1 and SIL3 in IEC 61508, the EDM1 signal must be monitored by the host controller. If the EDM1 signal is not monitored by the host controller, the level will be safety performance level c (PLc) and SIL1.

• Failure Detection Signal for EDM1 Signal

The relationship between the EDM1, /HWBB1, and /HWBB2 signals is shown below.

Detection of failures in the EDM1 signal circuit can be achieved by using the status of the /HWBB1, /HWBB2, and EDM1 signals in the following table. A failure can be detected by checking the failure status, e.g., when the power supply is turned ON.


Signal	Logic			
/HWBB1	ON	ON	OFF	OFF
/HWBB2	ON	OFF	ON	OFF
EDM1	OFF	OFF	OFF	ON

	WA	RN	ING
--	----	----	-----

• The EDM1 signal is not a safety output. Use it only for monitoring for failures.

12.3.1 EDM1 Output Signal Specifications

If an HWBB is requested by turning OFF the two HWBB input signal channels (/HWBB1 and /HWBB2) when the safety function is operating normally, the EDM1 output signal will be turned ON within 8 ms.




12.4.1 Connection Example

12.4 Applications Examples for Safety Functions

This section provides examples of using the safety functions.

12.4.1 Connection Example

In the following example, a Safety Unit is used and the HWBB operates when the guard is opened.



When the guard is opened, both the /HWBB1 and the /HWBB2 signals turn OFF, and the EDM1 signal turns ON. Because the feedback circuit is ON while the guard is closed, the Safety Unit is reset, the /HWBB1 and the / HWBB2 signals turn ON, and the operation is enabled.

Note: The EDM1 signal is used as a source output. Connect the EDM1 so that the current flows from EMD1+ to EMD1-.


12.4.2 Failure Detection Method

If a failure occurs (e.g., the /HWBB1 or the /HWBB2 signal remains ON), the Safety Unit is not reset when the guard is closed because the EDM1 signal remains OFF. Therefore starting is not possible and a failure is detected.

In this case the following must be considered: an error in the external device, disconnection of the external wiring, short-circuiting in the external wiring, or a failure in the SERVOPACK. Find the cause and correct the problem.

12.4.3 Procedure

12.4.3 Procedure



12.5 Validating Safety Functions


When you commission the system or perform maintenance or SERVOPACK replacement, you must always perform the following validation test on the HWBB function after completing the wiring. (It is recommended that you keep the confirmation results as a record.)

- When the /HWBB1 and /HWBB2 signals turn OFF, confirm that the Digital Operator displays **Hbb** and that the Servomotor does not operate.
- Monitor the ON/OFF status of the /HWBB1 and /HWBB2 signals. If the ON/OFF status of the signals do not coincide with the display, the following must be considered: an error in the external device, disconnection of the external wiring, short-circuiting in the external wiring, or a failure in the SERVOPACK. Find the cause and correct the problem.
- Confirm that the EDM1 signal is OFF while in normal operation by using the feedback circuit input display of the connected device.

12.6 Connecting a Safety Function Device

Use the following procedure to connect a safety function device.

1. Remove the Safety Jumper Connector from the connector for the safety function device (CN8).



- 2. Connect the safety function device to the connector for the safety function device (CN8).
- Note: If you do not connect a safety function device, leave the Safety Jumper Connector connected to the connector for the safety function device (CN8). If the SERVOPACK is used without the Safety Jumper Connector connected to CN8, no current will be supplied to the Servomotor and no motor torque will be output. In this case, **Hbb** will be displayed on the Digital Operator.

Maintenance

(13)

This chapter provides information on the meaning of, causes of, and corrections for alarms and warnings.

13.1	Inspec	ctions and Part Replacement 13-2
	13.1.1 13.1.2 13.1.3	Inspections13-2Guidelines for Part Replacement13-2Replacing the Battery13-3
13.2	Alarm	Displays13-5
	13.2.1 13.2.2 13.2.3 13.2.4 13.2.5 13.2.6 13.2.7	List of Alarms13-5Troubleshooting Alarms13-11Resetting Alarms13-43Displaying the Alarm History13-45Clearing the Alarm History13-46Resetting Alarms Detected in Option13-47Modules13-49
13.3	Warnii	ng Displays
	13.3.1 13.3.2	List of Warnings 13-51 Troubleshooting Warnings 13-53
13.4	Monitorin	ng Communications Data during Alarms or Warnings 13-60
13.5	Troublesho	oting Based on the Operation and Conditions of the Servomotor13-61

13.1.1 Inspections

13.1 Inspections and Part Replacement

This section describes inspections and part replacement for SERVOPACKs.

13.1.1 Inspections

Perform the inspections given in the following table at least once every year for the SERVO-PACK. Daily inspections are not required.

Item	Frequency	Inspection	Correction
Exterior	At least once a year	Check for dust, dirt, and oil on the surfaces.	Clean with compressed air or a cloth.
Loose Screws		Check for loose terminal block and connector screws and for other loose parts.	Tighten any loose screws or other loose parts.

13.1.2 Guidelines for Part Replacement

The following electric or electronic parts are subject to mechanical wear or deterioration over time. Use one of the following methods to check the standard replacement period.

- Use the service life prediction function of the SERVOPACK. Refer to the following section for information on service life predictions.
 10.4 Monitoring Product Life on page 10-14
- Use the following table.

Part	Standard Replace- ment Period	Remarks
Cooling Fan	4 years to 5 years	The standard replacement periods given on the left are for
Electrolytic Capacitor	10 years	 the following operating conditions. Surrounding air temperature: Annual average of 30°C Load factor: 80% max. Operation rate: 20 hours/day max.
Inrush Current Limit- ing Circuit Relay	100,000 power ON operations	Power ON frequency: Once an hour
Battery	3 years without power supplied	Surrounding temperature without power supplied: 20°C
Built-in Brake Relay*	30,000 operations	Allowable number of operations: 30 operations per minute max.

* Only SERVOPACKs with built-in Servomotor brake control have a built-in brake relay.

When any standard replacement period is close to expiring, contact your Yaskawa representative. After an examination of the part in question, we will determine whether the part should be replaced.



The parameters of any SERVOPACKs that are sent to Yaskawa for part replacement are reset to the factory settings before they are returned to you. Always keep a record of the parameter settings. And, always confirm that the parameters are properly set before starting operation.

13.1.3 Replacing the Battery

If the battery voltage drops to approximately 2.7 V or less, an A.830 alarm (Encoder Battery Alarm) or an A.930 warning (Absolute Encoder Battery Error) will be displayed.

If this alarm or warning is displayed, the battery must be replaced. Refer to the following section for the battery replacement procedure.

Battery Alarm/Warning Selection

Whether to display an alarm or a warning is determined by the setting of $Pn008 = n.\Box\Box\BoxX$ (Low Battery Voltage Alarm/Warning Selection).

Parameter		Meaning	When Enabled	Classification	
Pn008	n.□□□0 (default setting)	Output alarm (A.830) for low battery voltage.	After restart	Setup	
	n.0001	Output warning (A.930) for low battery voltage.			


• Pn008 = n.□□□0

The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON, and then the battery voltage is monitored for four seconds.

No alarm will be displayed even if the battery voltage drops below the specified value after these four seconds.

• Pn008 = n.□□□1

The ALM (Servo Alarm) signal is output for up to five seconds when the control power supply is turned ON, and then the battery voltage is monitored continuously.



Battery Replacement Procedure

- When Installing a Battery on the Host Controller
- 1. Turn ON only the control power supply to the SERVOPACK.
- 2. Remove the old battery and mount a new battery.
- **3.** Turn OFF the control power supply to the SERVOPACK to clear the A.830 alarm (Encoder Battery Alarm).
- 4. Turn ON the control power supply to the SERVOPACK again.
- 5. Make sure that the alarm has been cleared and that the SERVOPACK operates normally.


13.1.3 Replacing the Battery

When Using an Encoder Cable with a Battery Case


1. Turn ON only the control power supply to the SERVOPACK.




2. Open the cover of the Battery Case.



3. Remove the old battery and mount a new battery.



4. Close the cover of the Battery Case.



- **5.** Turn OFF the power supply to the SERVOPACK to clear the A.830 alarm (Encoder Battery Alarm).
- 6. Turn ON the power supply to the SERVOPACK.
- 7. Make sure that the alarm has been cleared and that the SERVOPACK operates normally.

13.2 Alarm Displays

If an error occurs in the SERVOPACK, an alarm number will be displayed on the panel display. However, if no alarm number appears on the panel display, this indicates a SERVOPACK system error. Replace the SERVOPACK.

If there is an alarm, the display will change in the following order.

Example: Alarm A.E60

$$\overset{\text{Status}}{\longrightarrow} \text{Not lit.} \longrightarrow \textbf{R} \longrightarrow \text{Not lit.} \textcircled{F} \longrightarrow \text{Not lit.} \longrightarrow \textbf{G} \longrightarrow \text{Not lit.} \textcircled{F} \longrightarrow \textbf{Not lit.}$$

This section provides a list of the alarms that may occur and the causes of and corrections for those alarms.

13.2.1 List of Alarms

The list of alarms gives the alarm name, alarm meaning, alarm stopping method, and alarm reset possibility in order of the alarm numbers.

Servomotor Stopping Method for Alarms

Refer to the following section for information on the stopping method for alarms. 6.13.2 Servomotor Stopping Method for Alarms on page 6-38

Alarm Reset Possibility

Yes: You can use an alarm reset to clear the alarm. However, this assumes that the cause of the alarm has been removed.

No: You cannot clear the alarm.

List of Alarms

Alarm Number	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
A.020	Parameter Checksum Error	There is an error in the parameter data in the SERVOPACK.	Gr.1	No
A.021	Parameter Format Error	There is an error in the parameter data format in the SERVOPACK.	Gr.1	No
A.022	System Checksum Error	There is an error in the parameter data in the SERVOPACK.	Gr.1	No
A.024	System Alarm	An internal program error occurred in the SER- VOPACK.	Gr.1	No
A.025	System Alarm	An internal program error occurred in the SER- VOPACK.	Gr.1	No
A.030	Main Circuit Detector Error	There is an error in the detection data for the main circuit.	Gr.1	Yes
A.040	Parameter Setting Error	A parameter setting is outside of the setting range.	Gr.1	No
A.041	Encoder Output Pulse Setting Error	The setting of Pn212 (Number of Encoder Output Pulses) or Pn281 (Encoder Output Resolution) is outside of the setting range or does not satisfy the setting conditions.	Gr.1	No

Continued on next page.

13.2.1 List of Alarms

Servo-Alarm motor Alarm Reset Alarm Name Alarm Meaning Stop-Possi-Number ping ble? Method Parameter Combination The combination of some parameters exceeds A.042 Gr.1 No the setting range. Frror Semi-Closed/Fully-Closed The settings of the Option Module and Pn002 = A.044 Loop Control Parameter n.XDDD (External Encoder Usage) do not Gr 1 No Setting Error match. There is an error in the bank members or bank A.04A Parameter Setting Error 2 Gr.1 No data settings. The capacities of the SERVOPACK and Servomo-A.050 Combination Frror Gr.1 Yes tor do not match. **Unsupported Device** A.051 An unsupported device was connected. Gr.1 No Alarm Motor Type Change The connected motor is a different type of motor A.070 Gr.1 No Detected from the previously connected motor. Linear Encoder Pitch Set-The setting of Pn282 (Linear Encoder Scale Pitch) A.080 Gr.1 No tina Error has not been changed from the default setting. The SV_ON (Servo ON) command was sent from Invalid Servo ON Com-A.0b0 the host controller after a utility function that turns Gr.1 Yes mand Alarm ON the Servomotor was executed. An overcurrent flowed through the power transis-A.100 **Overcurrent Detected** Gr.1 No tor or the heat sink overheated. Motor Overcurrent The current to the motor exceeded the allowable A.101 Gr.1 No Detected current. Built-in Brake Relay Error A.231 The built-in brake relay malfunctioned. Gr.1 No Alarm Built-in Brake Relay Life The number of built-in brake relay operations A.232 Gr.1 No Alarm exceeded the service life of the relay. A.300 **Regeneration Error** Gr.1 There is an error related to regeneration. Yes A.320 A regenerative overload occurred. **Regenerative Overload** Gr.2 Yes • The AC power supply input setting or DC power Main Circuit Power Supply A.330 supply input setting is not correct. Gr.1 Yes Wiring Error • The power supply wiring is not correct. A.400 Overvoltage The main circuit DC voltage is too high. Gr.1 Yes A.410 Undervoltage The main circuit DC voltage is too low. Gr.2 Yes Main-Circuit Capacitor The capacitor in the main circuit has deteriorated A.450 Gr.1 No Overvoltage or is faulty. A.510 Yes Overspeed The motor exceeded the maximum speed. Gr.1 · Rotary Servomotor: The pulse output speed for the setting of Pn212 (Number of Encoder Out-**Encoder Output Pulse** put Pulses) was exceeded. A.511 Gr.1 Yes Overspeed · Linear Servomotor: The motor speed upper limit for the setting of Pn281 (Encoder Output Resolution) was exceeded. Abnormal oscillation was detected in the motor A.520 Vibration Alarm Gr.1 Yes speed. Vibration was detected during autotuning for the A.521 Autotuning Alarm Gr.1 Yes tuning-less function. Maximum Speed Setting The setting of Pn385 (Maximum Motor Speed) is A.550 Gr.1 Yes greater than the maximum motor speed. Error The Servomotor was operating for several sec-A.710 Instantaneous Overload onds to several tens of seconds under a torque Gr 2 Yes that largely exceeded the rating. The Servomotor was operating continuously A.720 Continuous Overload Gr.1 Yes under a torgue that exceeded the rating.

Continued from previous page.

Continued on next page.

13.2.1 List of Alarms

Continued from previous page.

		Continued	ion previo	ous page
Alarm Number	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
A.730 A.731	Dynamic Brake Overload	When the dynamic brake was applied, the rota- tional or linear kinetic energy exceeded the capacity of the Dynamic Brake Resistor.	Gr.1	Yes
A.740	Inrush Current Limiting Resistor Overload	The main circuit power supply was frequently turned ON and OFF.	Gr.1	Yes
A.7A1	Internal Temperature Error 1 (Control Board Tempera- ture Error)	The surrounding temperature of the control PCB is abnormal.	Gr.2	Yes
A.7A2	Internal Temperature Error 2 (Power Board Tempera- ture Error)	The surrounding temperature of the power PCB is abnormal.	Gr.2	Yes
A.7A3	Internal Temperature Sen- sor Error	An error occurred in the temperature sensor cir- cuit.	Gr.2	No
A.7A4	Power Transistor Over- heated (Abnormal power transistor temperature.)	The temperature of the power transistor is abnor- mal.	Gr.2	No
A.7Ab	SERVOPACK Built-in Fan Stopped	The fan inside the SERVOPACK stopped.	Gr.1	Yes
A.810	Encoder Backup AlarmThe power supplies to the encoder all failed and the position data was lost.		Gr.1	No
A.820	Encoder Checksum Alarm There is an error in the checksum results for encoder memory.		Gr.1	No
A.830	Encoder Battery Alarm	The battery voltage was lower than the specified level after the control power supply was turned ON.	Gr.1	Yes
A.840	Encoder Data Alarm	There is an internal data error in the encoder.	Gr.1	No
A.850	Encoder Overspeed	The encoder was operating at high speed when the power was turned ON.	Gr.1	No
A.860	Encoder Overheated	The internal temperature of encoder is too high.	Gr.1	No
A.861	Motor Overheated	The internal temperature of motor is too high.	Gr.1	No
A.862	Overheat Alarm	The input voltage (temperature) for the overheat protection input (TH) signal exceeded the setting of Pn61B (Overheat Alarm Level).	Gr.1	Yes
A.890	Encoder Scale Error	A failure occurred in the linear encoder.	Gr.1	No
A.891	Encoder Module Error	An error occurred in the linear encoder.	Gr.1	No
A.8A0	External Encoder Error	An error occurred in the external encoder.	Gr.1	Yes
A.8A1	External Encoder Module Error	An error occurred in the Serial Converter Unit.	Gr.1	Yes
A.8A2	External Incremental Encoder Sensor Error	An error occurred in the external encoder.	Gr.1	Yes
A.8A3	External Absolute Encoder Position Error	An error occurred in the position data of the external encoder.	Gr.1	Yes
A.8A5	External Encoder Over- speed	An overspeed error occurred in the external encoder.	Gr.1	Yes
A.8A6	External Encoder Over- heated	An overheating error occurred in the external encoder.	Gr.1	Yes
A.b33	Current Detection Error 3	An error occurred in the current detection circuit.	Gr.1	No
A.b6A	MECHATROLINK Commu- nications ASIC Error 1	ASIC error 1 occurred in MECHATROLINK com- munications.	Gr.1	No
A.b6b	MECHATROLINK Commu- nications ASIC Error 2	ASIC error 2 occurred in MECHATROLINK com- munications.	Gr.2	No

Continued on next page.

13.2.1 List of Alarms

Alarm			Servo- motor	Alarm Reset
Number	Alarm Name	Alarm Meaning	Stop- ping Method	Possi- ble?
A.bC0	System Alarm 10	Internal program error 10 occurred in the SER- VOPACK.	Gr.1	No
A.bF0	System Alarm 0	Internal program error 0 occurred in the SERVO- PACK.	Gr.1	No
A.bF1	System Alarm 1	Internal program error 1 occurred in the SERVO- PACK.	Gr.1	No
A.bF2	System Alarm 2	Internal program error 2 occurred in the SERVO- PACK.	Gr.1	No
A.bF3	System Alarm 3	Internal program error 3 occurred in the SERVO- PACK.	Gr.1	No
A.bF4	System Alarm 4	Internal program error 4 occurred in the SERVO- PACK.	Gr.1	No
A.bF5	System Alarm 5	Internal program error 5 occurred in the SERVO- PACK.	Gr.1	No
A.bF6	System Alarm 6	Internal program error 6 occurred in the SERVO- PACK.	Gr.1	No
A.bF7	System Alarm 7	Internal program error 7 occurred in the SERVO- PACK.	Gr.1	No
A.bF8	System Alarm 8	Internal program error 8 occurred in the SERVO- PACK.	Gr.1	No
A.C10	Servomotor Out of Control	The Servomotor ran out of control.	Gr.1	Yes
A.C20	Phase Detection Error	The detection of the phase is not correct.	Gr.1	No
A.C21	Polarity Sensor Error	An error occurred in the polarity sensor.	Gr.1	No
A.C22	Phase Information Dis- agreement	The phase information does not match.	Gr.1	No
A.C50	Polarity Detection Failure	The polarity detection failed.	Gr.1	No
A.C51	Overtravel Detected during Polarity Detection	The overtravel signal was detected during polarity detection.	Gr.1	Yes
A.C52	Polarity Detection Not Completed	The servo was turned ON before the polarity was detected.	Gr.1	Yes
A.C53	Out of Range of Motion for Polarity Detection	The travel distance exceeded the setting of Pn48E (Polarity Detection Range).	Gr.1	No
A.C54	Polarity Detection Failure 2	The polarity detection failed.	Gr.1	No
A.C80	Encoder Clear Error or Multiturn Limit Setting Error	The multiturn data for the absolute encoder was not correctly cleared or set.	Gr.1	No
A.C90	Encoder Communications Error	Communications between the encoder and SER- VOPACK is not possible.	Gr.1	No
A.C91	Encoder Communications Position Data Acceleration Rate Error	An error occurred in calculating the position data of the encoder.	Gr.1	No
A.C92	Encoder Communications Timer Error	An error occurred in the communications timer between the encoder and SERVOPACK.	Gr.1	No
A.CA0	Encoder Parameter Error	The parameters in the encoder are corrupted.	Gr.1	No
A.Cb0	Encoder Echoback Error	The contents of communications with the encoder are incorrect.	Gr.1	No
A.CC0	Multiturn Limit Disagree- ment	Different multiturn limits have been set in the encoder and the SERVOPACK.	Gr.1	No
A.CF1	Reception Failed Error in Feedback Option Module Communications	Receiving data from the Feedback Option Mod- ule failed.	Gr.1	No

Continued from previous page.

13.2.1 List of Alarms

Continued from previous page.

		Continued		us paye.
Alarm Number	Alarm Name	Alarm Meaning	Servo- motor Stop- ping Method	Alarm Reset Possi- ble?
A.CF2	Timer Stopped Error in Feedback Option Module Communications	An error occurred in the timer for communica- tions with the Feedback Option Module.	Gr.1	No
A.d00	Position Deviation Over- flow	The setting of Pn520 (Position Deviation Overflow Alarm Level) was exceeded by the position deviation.	Gr.1	Yes
A.d01	Position Deviation Over- flow Alarm at Servo ON	The servo was turned ON after the position devi- ation exceeded the setting of Pn526 (Position Deviation Overflow Alarm Level at Servo ON) while the servo was OFF.	Gr.1	Yes
A.d02	Position Deviation Over- flow Alarm for Speed Limit at Servo ON	If position deviation remains in the deviation counter, the setting of Pn529 or Pn584 (Speed Limit Level at Servo ON) limits the speed when the servo is turned ON. This alarm occurs if a position reference is input and the setting of Pn520 (Position Deviation Overflow Alarm Level) is exceeded before the limit is cleared.	Gr.2	Yes
A.d10	Motor-Load Position Devi- ation Overflow	There was too much position deviation between the motor and load during fully-closed loop con- trol.	Gr.2	Yes
A.d30	Position Data Overflow	The position feedback data exceeded ±1,879,048,192.	Gr.1	No
A.E02	MECHATROLINK Internal Synchronization Error 1	A synchronization error occurred during MECHATROLINK communications with the SER- VOPACK.	Gr.1	Yes
A.E40	MECHATROLINK Trans- mission Cycle Setting Error	The setting of the MECHATROLINK communica- tions transmission cycle is not correct.	Gr.2	Yes
A.E41	MECHATROLINK Commu- nications Data Size Set- ting Error	The setting of the MECHATROLINK communica- tions data size is not correct.	Gr.2	Yes
A.E42	MECHATROLINK Station Address Setting Error	The setting of the MECHATROLINK station address is not correct.	Gr.2	No
A.E50*	MECHATROLINK Syn- chronization Error	A synchronization error occurred during MECHATROLINK communications.	Gr.2	Yes
A.E51	MECHATROLINK Syn- chronization Failed	Synchronization failed during MECHATROLINK communications.	Gr.2	Yes
A.E60*	Reception Error in MECHATROLINK Commu- nications	Communications errors occurred continuously during MECHATROLINK communications.	Gr.2	Yes
A.E61	Synchronization Interval Error in MECHATROLINK Transmission Cycle	An error occurred in the transmission cycle during MECHATROLINK communications.	Gr.2	Yes
A.E63	MECHATROLINK Syn- chronization Frame Not Received	Synchronization frames were continuously not received during MECHATROLINK communica- tions.	Gr.2	Yes
A.E72	Feedback Option Module Detection Failure	Detection of the Feedback Option Module failed.	Gr.1	No
A.Eb1	Safety Function Signal Input Timing Error	An error occurred in the input timing of the safety function signal.	Gr.1	No
A.EC8	Gate Drive Error 1	An error occurred in the gate drive circuit.	Gr.1	No
A.EC9	Gate Drive Error 2	An error occurred in the gate drive circuit.	Gr.1	No
A.Ed1	Command Execution Tim- eout	A timeout error occurred for a MECHATROLINK command.	Gr.2	Yes

13

Maintenance

13.2.1 List of Alarms

Servo-Alarm motor Alarm Reset Alarm Name Alarm Meaning Stop-Number Possiping ble? Method The voltage was low for more than one second Power Supply Line Open A.F10 for phase R, S, or T when the main power supply Gr.2 Yes Phase was ON. **Dynamic Brake Circuit** A.F30 An error occurred in the dynamic brake circuit. Gr.2 Yes Error Dynamic Brake Operation An error occurred in the settings related to the A.F32 Request Output Signal Gr.1 No Dynamic Brake Operation Request Output signal. Setting Error FL-1* FL-2* FL-3* An internal program error occurred in the SER-FL-4* System Alarm No VOPACK. FL-5* FL-6* FL-7* Digital Operator Commu-CPF00 Communications were not possible between the nications Error 1 Digital Operator (model: JUSP-OP05A-1-E) and No Digital Operator Commu-CPF01 the SERVOPACK (e.g., a CPU error occurred). nications Error 2

* These alarms are not stored in the alarm history. They are only displayed on the panel display.

The causes of and corrections for the alarms are given in the following table. Contact your Yaskawa representative if you cannot solve a problem with the correction given in the table.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage suddenly dropped.	Measure the power supply voltage.	Set the power supply volt- age within the specified range, and initialize the parameter settings.	page 6-10
	The power supply was shut OFF while writing parameter set- tings.	Check the timing of shutting OFF the power supply.	Initialize the parameter settings and then set the parameters again.	page e re
A.020: Parameter	The number of times that parameters were written exceeded the limit.	Check to see if the parameters were fre- quently changed from the host controller.	The SERVOPACK may be faulty. Replace the SER- VOPACK. Reconsider the method for writing the parame- ters.	_
Checksum Error (There is an error in the parameter data in the SER- VOPACK.)	A malfunction was caused by noise from the AC power supply, ground, static elec- tricity, or other source.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, noise may be the cause.	Implement countermea- sures against noise.	page 4-5
	Gas, water drops, or cutting oil entered the SERVOPACK and caused failure of the internal components.	Check the installation conditions.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	A failure occurred in the SERVOPACK.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, the SERVOPACK may have failed.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.021: Parameter For- mat Error (There is an error in the parameter data format in the	The software version of the SERVOPACK that caused the alarm is older than the soft- ware version of the parameters specified to write.	Read the product infor- mation to see if the soft- ware versions are the same. If they are differ- ent, it could be the cause of the alarm.	Write the parameters from another SERVOPACK with the same model and the same software version, and then turn the power OFF and ON again.	page 10-2
data format in the SERVOPACK.)	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The power supply voltage suddenly dropped.	Measure the power supply voltage.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.022: System Check- sum Error (There is an error in the parameter data in the SER- VOPACK.)	The power supply was shut OFF while setting a utility func- tion.	Check the timing of shutting OFF the power supply.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	A failure occurred in the SERVOPACK.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, the SERVOPACK may have failed.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.024: System Alarm (An internal pro- gram error occurred in the SERVOPACK.)	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.025: System Alarm (An internal pro- gram error occurred in the SERVOPACK.)	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.030: Main Circuit Detector Error	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The SERVOPACK and Servomotor capaci- ties do not match each other.	Check the combination of the SERVOPACK and Servomotor capacities.	Select a proper combina- tion of SERVOPACK and Servomotor capacities.	page 1-8
A.040: Parameter Set-	The motor parameter file was not written to the linear encoder. (This applies only when not using a Serial Converter Unit.)	Check to see if the motor parameter file was written to the lin- ear encoder.	Write the motor parame- ter file to the linear encoder.	page 6-17
ting Error (A parameter set- ting is outside of	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
the setting range.)	A parameter setting is outside of the setting range.	Check the setting ranges of the parame- ters that have been changed.	Set the parameters to val- ues within the setting ranges.	-
	The electronic gear ratio is outside of the setting range.	Check the electronic gear ratio. The ratio must be within the fol- lowing range: 0.001 < (Pn20E/Pn210) < 64,000.	Set the electronic gear ratio in the following range: 0.001 < (Pn20E/ Pn210) < 64,000.	page 6-43
A.041: Encoder Output Pulse Setting Error	The setting of Pn212 (Number of Encoder Output Pulses) or Pn281 (Encoder Out- put Resolution) is out- side of the setting range or does not sat- isfy the setting condi- tions.	Check the setting of Pn212 or Pn281.	Set Pn212 or Pn281 to an appropriate value.	page 7-19

Continued from previous page.

			Continued from pro	svious page.
Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The speed of program jogging went below the setting range when the electronic gear ratio (Pn20E/ Pn210) or the Servo- motor was changed.	Check to see if the detection conditions ^{*1} are satisfied.	Decrease the setting of the electronic gear ratio (Pn20E/Pn210).	page 6-43
	The speed of program jogging went below the setting range when Pn533 or Pn585 (Program Jogging Movement Speed) was changed.	Check to see if the detection conditions ^{*1} are satisfied.	Increase the setting of Pn533 or Pn585.	page 8-14
A.042: Parameter Com-	The movement speed of advanced autotun- ing went below the setting range when the electronic gear ratio (Pn20E/ Pn210) or the Servomotor was changed.	Check to see if the detection conditions ^{*2} are satisfied.	Decrease the setting of the electronic gear ratio (Pn20E/Pn210).	page 6-43
bination Error	The combination of Pn001 = n. $\Box\Box\BoxX$ (Motor Stopping Method for Servo OFF and Group 1 Alarms), Pn601 (Dynamic Brake Resistor Allow- able Energy Con- sumption), and PN604 (Dynamic Brake Resistance) is wrong, or the settings of those parameters are wrong.	Check Pn001 = n. □□□ X, Pn601, and Pn604.	 When Not Using a Dynamic Brake Set Pn001 = n. D X to 2 (Coast the motor to a stop without the dynamic brake). Set Pn601 and Pn604 to 0. When Using a Dynamic Brake Set Pn001 = n. D X to 0 (Stop the motor by applying the dynamic brake) or 1 (Stop the motor by applying the dynamic brake and then release the dynamic brake). Set Pn601 and Pn604 according to the specifi- cations of the resistor. 	page 5-9
A.044: Semi-Closed/ Fully-Closed Loop Control Parameter Setting Error	The setting of the Fully-closed Module does not match the setting of Pn002 = n.XDDD (External Encoder Usage).	Check the setting of Pn002 = $n.X\square\square\square$.	Make sure that the setting of the Fully-closed Mod- ule agrees with the setting of Pn002 = $n.X\square\square\square$.	page 11-6
A.04A: Parameter Set-	For 4-byte parameter bank members, there are two consecutive members with nothing registered.	-	Change the number of bytes for bank members to an appropriate value.	_
ting Error 2	The total amount of bank data exceeds 64 (Pn900 × Pn901 > 64).	_	Reduce the total amount of bank data to 64 or less. Continued o	_

Maintenance

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.050: Combination Error	The SERVOPACK and Servomotor capaci- ties do not match each other.	Confirm that the follow- ing condition is met: $1/4 \le$ (Servomotor capacity/SERVOPACK capacity) ≤ 4	Select a proper combina- tion of the SERVOPACK and Servomotor capaci- ties.	page 1-8
(The capacities of the SERVOPACK and Servomotor	A failure occurred in the encoder.	Replace the encoder and check to see if the alarm still occurs.	Replace the Servomotor or encoder.	-
do not match.)	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.051:	The motor parameter file was not written to the linear encoder. (This applies only when not using a Serial Converter Unit.)	Check to see if the motor parameter file was written to the lin- ear encoder.	Write the motor parame- ter file to the linear encoder.	page 6-17
Unsupported Device Alarm	An unsupported Serial Converter Unit or encoder (e.g., an external encoder) is connected to the SERVOPACK.	Check the product combination specifica-tions.	Change to a correct com- bination of models.	_
A.070: Motor Type Change Detected (The connected	A Rotary Servomotor was removed and a Linear Servomotor was connected.	_	Set the parameters for a Linear Servomotor and reset the motor type alarm. Then, turn the power supply to the SER- VOPACK OFF and ON again.	page 13-49
motor is a differ- ent type of motor from the previ- ously connected motor.)	A Linear Servomotor was removed and a Rotary Servomotor was connected.	_	Set the parameters for a Rotary Servomotor and reset the motor type alarm. Then, turn the power supply to the SER- VOPACK OFF and ON again.	page 13-49
A.080: Linear Encoder Pitch Setting Error	The setting of Pn282 (Linear Encoder Scale Pitch) has not been changed from the default setting.	Check the setting of Pn282.	Correct the setting of Pn282.	page 6-16
A.0b0: Invalid Servo ON Command Alarm	The SV_ON (Servo ON) command was sent from the host controller after a util- ity function that turns ON the Servomotor was executed.	-	Turn the power supply to the SERVOPACK OFF and ON again. Or, execute a software reset.	page 7-46

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The Main Circuit Cable is not wired correctly or there is faulty contact.	Check the wiring.	Correct the wiring.	
	There is a short-circuit or ground fault in a Main Circuit Cable.	Check for short-circuits across Servomotor phases U, V, and W, or between the ground and Servomotor phases U, V, and W.	The cable may be short- circuited. Replace the cable.	
A.100: Overcurrent	There is a short-circuit or ground fault inside the Servomotor.	Check for short-circuits across Servomotor phases U, V, and W, or between the ground and Servomotor phases U, V, or W.	The Servomotor may be faulty. Replace the Servo- motor.	page 4-19
Detected (An overcurrent flowed through the power tran- sistor or the heat sink overheated.)	There is a short-circuit or ground fault inside the SERVOPACK.	Check for short-circuits across the Servomotor connection terminals U, V, and W on the SER- VOPACK, or between the ground and termi- nals U, V, or W.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	
	The Regenerative Resistor is not wired correctly or there is faulty contact.	Check the wiring.	Correct the wiring.	page 4-18
	The dynamic brake (DB, emergency stop executed from the SERVOPACK) was frequently activated, or a DB overload alarm occurred.	Check the power con- sumed by the DB resis- tor to see how frequently the DB is being used. Or, check the alarm display to see if a DB overload alarm (A.730 or A.731) has occurred.	Change the SERVOPACK model, operating meth- ods, or the mechanisms so that the dynamic brake does not need to be used so frequently.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The regenerative pro- cessing capacity was exceeded.	Check the regenerative load ratio in the Sig- maWin+ Motion Monitor Tab Page to see how frequently the Regener- ative Resistor is being used.	Recheck the operating conditions and load.	*3
A.100: Overcurrent	The SERVOPACK regenerative resis- tance is too small.	Check the regenerative load ratio in the Sig- maWin+ Motion Monitor Tab Page to see how frequently the Regener- ative Resistor is being used.	Change the regenerative resistance to a value larger than the SERVO- PACK minimum allowable resistance.	
Characted (An overcurrent flowed through the power tran- sistor or the heat	A heavy load was applied while the Ser- vomotor was stopped or running at a low speed.	Check to see if the operating conditions exceed Servo Drive specifications.	Reduce the load applied to the Servomotor. Or, increase the operating speed.	-
sink overheated.)	A malfunction was caused by noise.	Improve the noise envi- ronment, e.g. by improving the wiring or installation conditions, and check to see if the alarm still occurs.	Implement countermea- sures against noise, such as correct wiring of the FG. Use an FG wire size equivalent to the SERVO- PACK's main circuit wire size.	_
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The Main Circuit Cable is not wired correctly or there is faulty contact.	Check the wiring.	Correct the wiring.	
	There is a short-circuit or ground fault in a Main Circuit Cable.	Check for short-circuits across cable phases U, V, and W, or between the ground and cable phases U, V, and W.	The cable may be short- circuited. Replace the cable.	
	There is a short-circuit or ground fault inside the Servomotor.	Check for short-circuits across Servomotor phases U, V, and W, or between the ground and Servomotor phases U, V, or W.	The Servomotor may be faulty. Replace the Servo-motor.	page 4-19
A.101: Motor Overcur- rent Detected (The current to the motor exceeded the	There is a short-circuit or ground fault inside the SERVOPACK.	Check for short-circuits across the Servomotor connection terminals U, V, and W on the SER- VOPACK, or between the ground and termi- nals U, V, or W.	The SERVOPACK may be faulty. Replace the SER- VOPACK.	
allowable cur- rent.)	A heavy load was applied while the Ser- vomotor was stopped or running at a low speed.	Check to see if the operating conditions exceed Servo Drive specifications.	Reduce the load applied to the Servomotor. Or, increase the operating speed.	-
	A malfunction was caused by noise.	Improve the noise envi- ronment, e.g. by improving the wiring or installation conditions, and check to see if the alarm still occurs.	Implement countermea- sures against noise, such as correct wiring of the FG. Use an FG wire size equivalent to the SERVO- PACK's main circuit wire size.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The brake power sup- ply wiring is wrong, disconnected, or bro- ken.	Check the brake power supply wiring.	Wire the brake power supply correctly.	-
A.231: Built-in Brake Relay Error Alarm	A malfunction was caused by noise.	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, noise may be the cause.	Implement countermea- sures against noise.	-
	The built-in brake relay failed.	-	Replace the part. Con- tact your Yaskawa repre- sentative for replacement.	-
A.232: Built-in Brake Relay Life Alarm	The service life of the built-in brake relay was exceeded.	-	Replace the part. Con- tact your Yaskawa repre- sentative for replacement.	_

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	When using the built- in regenerative resis- tor, the jumper between the regener- ative resistor terminals (B2 and B3) was removed from one of the following SERVO- PACKs: SGD7S -1R9D, -3R5D, -5R4D, -8R4D, -120D, or -170D	Check to see if the jumper is connected between power supply terminals B2 and B3. ^{*4}	Correctly connect a jumper.	page 4-18
A.300: Regeneration Error	The External Regener- ative Resistor is not wired correctly, or was removed or discon- nected.	Check the wiring of the External Regenerative Resistor. ^{*4}	Correct the wiring of the External Regenerative Resistor.	
	A failure occurred in the SERVOPACK.	_	While the main circuit power supply is OFF, turn the control power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVO- PACK may be faulty. Replace the SERVO- PACK.	-
	The power supply voltage exceeded the specified range.	Measure the power supply voltage.	Set the power supply volt- age within the specified range.	-
	The external regener- ative resistance value or Regenerative Resistor capacity is too small, or there has been a continuous regeneration state.	Check the operating conditions or the capacity using the Sig- maJunmaSize+ Capac- ity Selection Software or other means.	Change the regenerative resistance value or capac- ity. Reconsider the operating conditions using the Sig- maJunmaSize+ Capacity Selection Software or other means.	*3
	There was a continu- ous regeneration state because a negative load was continu- ously applied.	Check the load applied to the Servomotor during operation.	Reconsider the system including the servo, machine, and operating conditions.	_
A.320: Regenerative Overload	The setting of Pn600 (Regenerative Resis- tor Capacity) is smaller than the capacity of the Exter- nal Regenerative Resistor.	Check to see if a Regenerative Resistor is connected and check the setting of Pn600.	Correct the setting of Pn600.	page 6-53
	The setting of Pn603 (Regenerative Resis- tance) is smaller than the capacity of the External Regenerative Resistor.	Check to see if a Regenerative Resistor is connected and check the setting of Pn603.	Correct the setting of Pn603.	page 6-53
	The external regener- ative resistance is too high.	Check the regenerative resistance.	Change the regenerative resistance to a correct value or use an External Regenerative Resistor of an appropriate capacity.	*3
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	_

Continued from previous page.

Alarm Number:			Continued from pro	svious page.
Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.330: Main Circuit	The Regenerative Resistor was discon- nected when the SERVOPACK power supply voltage was high.	Measure the resistance of the Regenerative Resistor using a mea- suring instrument.	If you are using the Regenerative Resistor built into the SERVO- PACK, replace the SER- VOPACK. If you are using an Exter- nal Regenerative Resis- tor, replace the External Regenerative Resistor.	-
Power Supply Wiring Error (Detected when the main circuit power supply is	DC power was sup- plied when an AC power supply input was specified in the settings.	Check the power sup- ply to see if it is a DC power supply.	Correct the power supply setting to match the actual power supply.	2000 6 52
turned ON.)	AC power was sup- plied when a DC power supply input was specified in the settings.	Check the power sup- ply to see if it is an AC power supply.	Correct the power supply setting to match the actual power supply.	page 6-53
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The power supply voltage exceeded the specified range.	Measure the power supply voltage.	Set the AC/DC power supply voltage within the specified range.	_
	The power supply is not stable or was influenced by a light- ning surge.	Measure the power supply voltage.	Improve the power sup- ply conditions, install a Surge Absorber, and then turn the power supply OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SER- VOPACK.	_
A.400: Overvoltage (Detected in the	The voltage for AC power supply was too high during accelera- tion or deceleration.	Check the power sup- ply voltage and the speed and torque during operation.	Set the AC power supply voltage within the speci- fied range.	-
main circuit power supply section of the SERVOPACK.)	The external regener- ative resistance is too high for the operating conditions.	Check the operating conditions and the regenerative resistance.	Select a regenerative resistance value that is appropriate for the oper- ating conditions and load.	*3
	The moment of inertia ratio or mass ratio exceeded the allow- able value.	Check to see if the moment of inertia ratio or mass ratio is within the allowable range.	Increase the deceleration time, or reduce the load.	_
	A failure occurred in the SERVOPACK.	-	While the main circuit power supply is OFF, turn the control power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVO- PACK may be faulty. Replace the SERVO- PACK. Continued o	-

Continued on next page.

Continued from previous page.

Alarm Number:			Continued from pro	
Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage went below the specified range.	Measure the power supply voltage.	Set the power supply volt- age within the specified range.	-
	The power supply voltage dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.	-
A.410: Undervoltage (Detected in the main circuit power supply	A momentary power interruption occurred.	Measure the power supply voltage.	If you have changed the setting of Pn509 (Momen- tary Power Interruption Hold Time), decrease the setting.	page 7-15
section of the SERVOPACK.)	The SERVOPACK fuse is blown out.	-	Replace the SERVO- PACK and connect a Reactor to the DC Reac- tor terminals (\ominus 1 and \ominus 2) on the SERVOPACK.	-
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	_
A.450: Main-Circuit Capacitor Over- voltage (The capacitor in the main circuit has deteriorated or is faulty.)	A failure occurred in the SERVOPACK.	-	Replace the SERVO- PACK.	-
	The order of phases U, V, and W in the motor wiring is not correct.	Check the wiring of the Servomotor.	Make sure that the Servo- motor is correctly wired.	_
A.510: Overspeed	A reference value that exceeded the over- speed detection level was input.	Check the input refer- ence.	Reduce the reference value. Or, adjust the gain.	
(The motor exceeded the maximum speed.)	The motor exceeded the maximum speed.	Check the waveform of the motor speed.	Reduce the speed refer- ence input gain and adjust the servo gain. Or, reconsider the operating conditions.	
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.511:	The encoder output pulse frequency exceeded the limit.	Check the encoder out- put pulse setting.	Decrease the setting of Pn212 (Number of Encoder Output Pulses) or Pn281 (Encoder Out- put Resolution).	page 7-24
Encoder Output Pulse Overspeed	The encoder output pulse frequency exceeded the limit because the motor speed was too high.	Check the encoder out- put pulse setting and the motor speed.	Reduce the motor speed.	-

Continued	from	previous	page.
0011111000	110111	proviouo	pugo.

Continued from previous page				
Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	Abnormal oscillation was detected in the motor speed.	Check for abnormal motor noise, and check the speed and torque waveforms during oper- ation.	Reduce the motor speed. Or, reduce the setting of Pn100 (Speed Loop Gain).	page 9-82
A.520: Vibration Alarm	The setting of Pn103 (Moment of Inertia Ratio) is greater than the actual moment of inertia or was greatly changed.	Check the moment of inertia ratio or mass ratio.	Set Pn103 (Moment of Inertia Ratio) to an appro- priate value.	page 9-16
	The vibration detec- tion level (Pn312 or Pn384) is not suitable.	Check that the vibra- tion detection level (Pn312 or Pn384) is suitable.	Set a suitable vibration detection level (Pn312 or Pn384).	page 7-49
A.521: Autotuning Alarm (Vibration was detected while executing the custom tuning,	The Servomotor vibrated considerably while performing the tuning-less function.	Check the waveform of the motor speed.	Reduce the load so that the moment of inertia ratio is within the allowable value. Or increase the load level or reduce the rigidity level in the tuning- less level settings.	page 9-13
Easy FFT, or the tuning-less func- tion.)	The Servomotor vibrated considerably while performing cus- tom tuning or Easy FFT.	Check the waveform of the motor speed.	Check the operating pro- cedure of corresponding function and implement corrections.	page 9-42, page 9-99
A.550: Maximum Speed Setting Error	The setting of Pn385 (Maximum Motor Speed) is greater than the maximum speed.	Check the setting of Pn385, and the upper limits of the maximum motor speed setting and the encoder output resolution setting.	Set Pn385 to a value that does not exceed the max- imum motor speed.	page 7-18
	The wiring is not cor- rect or there is a faulty contact in the motor or encoder wiring.	Check the wiring.	Make sure that the Servo- motor and encoder are correctly wired.	page 4-19
	Operation was per- formed that exceeded the overload protec- tion characteristics.	Check the motor over- load characteristics and Run command.	Reconsider the load and operating conditions. Or, increase the motor capacity.	-
A.710: Instantaneous Overload A.720:	An excessive load was applied during operation because the Servomotor was not driven due to mechanical problems.	Check the operation reference and motor speed.	Correct the mechanical problem.	-
Continuous Overload	There is an error in the setting of Pn282 (Lin- ear Encoder Scale Pitch).	Check the setting of Pn282.	Correct the setting of Pn282.	page 6-16
	There is an error in the setting of Pn080 = n.□□X□ (Motor Phase Sequence Selection).	Check the setting of Pn080 = $n.\Box\Box X\Box$.	Set Pn080 = n.□□X□ to an appropriate value.	page 6-21
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	_

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A 700 and	The Servomotor was rotated by an external force.	Check the operation status.	Implement measures to ensure that the motor will not be rotated by an external force.	-
A.730 and A.731: Dynamic Brake Overload (An excessive power consump- tion by the dynamic brake was detected.)	When the Servomo- tor was stopped with the dynamic brake, the rotational or linear kinetic energy exceeded the capac- ity of the dynamic brake resistor.	Check the power con- sumed by the DB resis- tor to see how frequently the DB is being used.	 Reconsider the following: Reduce the Servomotor command speed. Decrease the moment of inertia ratio or mass ratio. Reduce the frequency of stopping with the dynamic brake. 	-
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.740: Inrush Current Limiting Resistor Overload (The main circuit power supply was frequently	The allowable fre- quency of the inrush current limiting resis- tor was exceeded when the main circuit power supply was turned ON and OFF.	_	Reduce the frequency of turning the main circuit power supply ON and OFF.	-
turned ON and OFF.)	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The surrounding tem- perature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surround- ing temperature by improving the SERVO- PACK installation condi- tions.	page 3-6
A 7A1.	An overload alarm was reset by turning OFF the power sup- ply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
A.7A1: Internal Tempera- ture Error 1 (Control Board Temperature Error)	There was an exces- sive load or operation was performed that exceeded the regen- erative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenera- tive load ratio to check the regenerative pro- cessing capacity.	Reconsider the load and operating conditions.	_
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVO- PACK.	Check the SERVOPACK installation conditions.	Install the SERVOPACK according to specifica- tions.	page 3-3, page 3-5
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK. Continued o	-

Continued from previous page.

Continued from previous page				
Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The surrounding tem- perature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surround- ing temperature by improving the SERVO- PACK installation condi- tions.	page 3-6
4.740	An overload alarm was reset by turning OFF the power sup- ply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	_
A.7A2: Internal Tempera- ture Error 2 (Power Board Temperature Error)	There was an exces- sive load or operation was performed that exceeded the regen- erative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenera- tive load ratio to check the regenerative pro- cessing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVO- PACK.	Check the SERVOPACK installation conditions.	Install the SERVOPACK according to specifica- tions.	page 3-3, page 3-5
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
A.7A3: Internal Tempera- ture Sensor Error (An error occurred in the temperature sen- sor circuit.)	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The surrounding tem- perature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environment monitor.	Decrease the surround- ing temperature by improving the SERVO- PACK installation condi- tions.	page 3-6
A.7A4:	An overload alarm was reset by turning OFF the power sup- ply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
A.744: Power Transistor Overheated (Abnormal power transistor tem- perature.)	There was an exces- sive load or operation was performed that exceeded the regen- erative processing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenera- tive load ratio to check the regenerative pro- cessing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orientation is not correct or there is insufficient space around the SERVO- PACK.	Check the SERVOPACK installation conditions.	Install the SERVOPACK according to specifica- tions.	page 3-3, page 3-5
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.7Ab: SERVOPACK Built-in Fan Stopped	The fan inside the SERVOPACK stopped.	Check for foreign matter inside the SERVOPACK.	Remove foreign matter from the SERVOPACK. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SER- VOPACK.	-
	The power to the absolute encoder was turned ON for the first time.	Check to see if the power supply was turned ON for the first time.	Set up the encoder.	
A.810:	The Encoder Cable was disconnected and then connected again.	Check to see if the power supply was turned ON for the first time.	Check the encoder con- nection and set up the encoder.	page 6-47
Encoder Backup Alarm (Detected at the encoder, but only when an abso- lute encoder is used.)	Power is not being supplied both from the control power supply (+5 V) from the SERVOPACK and from the battery power supply.	Check the encoder connector battery and the connector status.	Replace the battery or implement similar mea- sures to supply power to the encoder, and set up the encoder.	
	A failure occurred in the absolute encoder.	_	If the alarm still occurs after setting up the encoder again, replace the Servomotor.	-
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	_
A.820: Encoder Check- sum Alarm (Detected at the encoder.)	A failure occurred in the encoder.	_	 When Using an Absolute Encoder Set up the encoder again. If the alarm still occurs, the Servomotor may be faulty. Replace the Servomotor. When Using a Singleturn Absolute Encoder or Incremental Encoder The Servomotor may be faulty. Replace the Servomotor. The linear encoder may be faulty. Replace the linear encoder. 	page 6-47
	A failure occurred in the SERVOPACK.	_	The SERVOPACK may be faulty. Replace the SER- VOPACK.	_
A.830: Encoder Battery Alarm (The absolute encoder battery voltage was lower	The battery connec- tion is faulty or a bat- tery is not connected.	Check the battery con- nection.	Correct the battery con- nection.	page 4-20
	The battery voltage is lower than the specified value (2.7 V).	Measure the battery voltage.	Replace the battery.	page 13-3
than the speci- fied level.)	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SER- VOPACK.	-

Continued from previous page.

Possible Cause	Confirmation	Correction	Reference
The encoder malfunc- tioned.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
An error occurred in reading data from the linear encoder.	-	The linear encoder is not mounted within an appro- priate tolerance. Correct the mounting of the linear encoder.	-
Excessive speed occurred in the linear encoder.	-	Control the motor speed within the range specified by the linear encoder manufacturer and then turn ON the control power supply.	-
The encoder malfunc- tioned due to noise.	_	Correct the wiring around the encoder by separating the Encoder Cable from the Servomotor Main Cir- cuit Cable or by ground- ing the encoder.	_
The polarity sensor is not wired correctly.	Check the wiring of the polarity sensor.	Correct the wiring of the polarity sensor.	-
The polarity sensor failed.	_	Replace the polarity sen- sor.	-
Rotary Servomotor: The Servomotor speed was 200 min ⁻¹ or higher when the control power supply was turned ON.	Check the motor speed when the power supply is turned ON.	Reduce the Servomotor speed to a value less than 200 min ⁻¹ , and turn ON the control power supply.	-
Linear Servomotor: The Servomotor exceeded the speci- fied speed when the control power supply was turned ON.	Check the motor speed when the power supply is turned ON.	Control the motor speed within the range specified by the linear encoder manufacturer and then turn ON the control power supply.	-
A failure occurred in the encoder.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_
	The encoder malfunc- tioned. An error occurred in reading data from the linear encoder. Excessive speed occurred in the linear encoder. The encoder malfunc- tioned due to noise. The polarity sensor is not wired correctly. The polarity sensor failed. Rotary Servomotor: The Servomotor speed was 200 min ⁻¹ or higher when the control power supply was turned ON. Linear Servomotor: The Servomotor exceeded the speci- fied speed when the control power supply was turned ON. A failure occurred in the encoder.	The encoder malfunctionedAn error occurred in reading data from the linear encoderExcessive speed occurred in the linear encoderExcessive speed occurred in the linear encoderThe encoder malfunc- tioned due to noiseThe polarity sensor is not wired correctly.Check the wiring of the polarity sensor.The polarity sensor failedRotary Servomotor: The Servomotor respeed was 200 min ⁻¹ or higher when the control power supply was turned ON.Check the motor speed when the power supply is turned ON.Linear Servomotor: The Servomotor Was turned ON.Check the motor speed when the power supply is turned ON.Linear Servomotor: The Servomotor Receded the speci- fied speed when the control power supply was turned ON.Check the motor speed when the power supply is turned ON.A failure occurred in the encoderA failure occurred in the encoder	The encoder malfunctionedTurn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder.An error occurred in reading data from the linear encoderThe linear encoder.An error occurred in reading data from the linear encoderThe linear encoder.Excessive speed occurred in the linear encoderControl the motor speed within the range specified by the linear encoderThe encoder malfunctioned due to noiseControl the motor speed within the range specified by the linear encoderThe polarity sensor is not wired correctly.Check the wiring of the polarity sensor.Correct the wiring of the polarity sensor.The polarity sensor failedCorrect the wiring of the polarity sensor.Correct the wiring of the polarity sensor.Rotary Servomotor rigeed was 200 min ⁻¹ or higher when the control power supply is turned ON.Check the motor speed when the power supply is turned ON.Reduce the Servomotor speed to a value less than 200 min ⁻¹ , and turn ON the control power supply is turned ON.Linear Servomotor ride speed was 200 min ⁻¹ at failure occurred in the encoder.Check the motor speed when the power supply is turned ON.Control the motor speed when the power supply is turned ON.A failure occurred in the encoderControl the motor speed when the power supply is turned ON.A failure occurred in the encoderControl the motor speed when the power supply is turned ON.A failure occurred

Maintenance

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The surrounding air temperature around the Servomotor is too high.	Measure the surround- ing air temperature around the Servomotor.	Reduce the surrounding air temperature of the Servomotor to 40°C or less.	_
A.860: Encoder Over-	The Servomotor load is greater than the rated load.	Use the accumulated load ratio to check the load.	Operate the Servo Drive so that the motor load remains within the speci- fied range.	page 10-3
heated (Detected when a Rotary Servomo- tor or absolute linear encoder is connected.) (Detected at the encoder.)	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or absolute linear encoder may be faulty. Replace the Servomotor or absolute linear encoder.	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The surrounding tem- perature around the Servomotor is too high.	Measure the surround- ing temperature around the Servomotor.	Reduce the surrounding air temperature of the Servomotor to 40° or less.	-
A.861: Motor Over- heated	The motor load is greater than the rated load.	Check the load with the accumulated load ratio on the Motion Monitor Tab Page on the Sig- maWin+.	Operate the Servo Drive so that the motor load remains within the speci- fied range.	page 10-3
	A failure occurred in the Serial Converter Unit.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Serial Con- verter Unit may be faulty. Replace the Serial Con- verter Unit.	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The surrounding tem- perature is too high.	Check the surrounding temperature using a thermometer.	Lower the surrounding temperature by improving the installation conditions of the Linear Servomotor or the machine.	-
	The overheat protec- tion input signal line is disconnected or short-circuited.	Check the input voltage with the overheat pro- tection input information on the Motion Monitor Tab Page on the Sig- maWin+.	Repair the line for the overheat protection input signal.	-
A.862:	An overload alarm was reset by turning OFF the power sup- ply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
Overheat Alarm	Operation was per- formed under an excessive load.	Use the accumulated load ratio to check the load during operation.	Reconsider the load and operating conditions.	-
	A failure occurred in the SERVOPACK.	-	The SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The temperature detection circuit in the Linear Servomotor is faulty or the sensor attached to the machine is faulty.	-	The temperature detec- tion circuit in the Linear Servomotor may be faulty or the sensor attached to the machine may be faulty. Replace the Linear Servomotor or repair the sensor attached to the machine.	-
A.890: Encoder Scale Error	A failure occurred in the linear encoder.	-	The linear encoder may be faulty. Replace the linear encoder.	-
A.891: Encoder Module Error	A failure occurred in the linear encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the linear encoder may be faulty. Replace the linear encoder.	-
A.8A0: External Encoder Error	Setting the origin of the absolute linear encoder failed because the motor moved.	Before you set the ori- gin, use the fully-closed feedback pulse counter to confirm that the motor is not moving.	The motor must be stopped while setting the origin position.	page 6-50
	A failure occurred in the external encoder.	-	Replace the external encoder.	-
A.8A1:	A failure occurred in the external encoder.	-	Replace the external encoder.	-
External Encoder Module Error	A failure occurred in the Serial Converter Unit.	_	Replace the Serial Con- verter Unit.	-
A.8A2: External Incre- mental Encoder Sensor Error	A failure occurred in the external encoder.	_	Replace the external encoder.	-
A.8A3: External Abso- lute Encoder Position Error	A failure occurred in the external absolute encoder.	_	The external absolute encoder may be faulty. Refer to the encoder manufacturer's instruc- tion manual for correc- tions.	-

Continued on next page.

Continued from previous page.

Alarm Number:			Continued from pro	
Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.8A5: External Encoder Overspeed	An overspeed error was detected in the external encoder.	Check the maximum speed of the external encoder.	Keep the external encoder below its maxi- mum speed.	-
A.8A6: External Encoder Overheated	An overheating error was detected in the external encoder.	_	Replace the external encoder.	-
A.b33: Current Detec- tion Error 3	A failure occurred in the current detection circuit.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.b6A: MECHATROLINK Communications ASIC Error 1	There is a fault in the SERVOPACK MECHATROLINK communications sec- tion.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.b6b: MECHATROLINK Communications ASIC Error 2	A malfunction occurred in the MECHATROLINK communications sec- tion due to noise.	_	 Implement the following countermeasures against noise. Check the MECHATROLINK Communications Cable and FG wiring. Attach a ferrite core to the MECHATROLINK Communications Cable. 	-
	There is a fault in the SERVOPACK MECHATROLINK communications sec- tion.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bC0: System Alarm 10	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF0: System Alarm 0	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF1: System Alarm 1	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF2: System Alarm 2	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Alarm Number:	Possible Cause	Confirmation	Continued from pro	Reference
Alarm Name	Fossible Cause	Commation		neierence
A.bF3: System Alarm 3	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF4: System Alarm 4	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF5: System Alarm 5	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF6: System Alarm 6	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF7: System Alarm 7	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.bF8: System Alarm 8	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
	The order of phases U, V, and W in the motor wiring is not correct.	Check the Servomotor wiring.	Make sure that the Servo- motor is correctly wired.	-
A.C10:	There is an error in the setting of Pn080 = n. \Box \Box \Box (Motor Phase Sequence Selection).	Check the setting of Pn080 = $n.\Box\Box X\Box$.	Set Pn080 = n.□□X□ to an appropriate value.	page 6-21
Servomotor Out of Control (Detected when the servo is turned ON.)	A failure occurred in the encoder.	_	If the motor wiring is cor- rect and an alarm still occurs after turning the power supply OFF and ON again, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.C20: Phase Detection Error	The linear encoder signal level is too low.	Check the voltage of the linear encoder sig- nal.	Fine-tune the mounting of the scale head. Or, replace the linear encoder.	-
	The count-up direc- tion of the linear encoder does not match the forward direction of the Mov- ing Coil in the motor.	Check the setting of Pn080 = $n.\square\squareX\square$ (Motor Phase Sequence Selection). Check the installation orientation for the linear encoder and Moving Coil.	Change the setting of Pn080 = $n.\Box\Box X\Box$. Correctly reinstall the linear encoder or Moving Coil.	page 6-21
	The polarity sensor signal is being affected by noise.	_	Correct the FG wiring. Implement countermea- sures against noise for the polarity sensor wiring.	-
	The setting of Pn282 (Linear Encoder Scale Pitch) is not correct.	Check the setting of Pn282 (Linear Encoder Scale Pitch).	Check the specifications of the linear encoder and set a correct value.	page 6-16
A.C21:	The polarity sensor is protruding from the Magnetic Way of the motor.	Check the polarity sen- sor.	Correctly reinstall the Moving Coil or Magnetic Way of the motor.	-
Polarity Sensor Error	The polarity sensor is not wired correctly.	Check the wiring of the polarity sensor.	Correct the wiring of the polarity sensor.	-
	The polarity sensor failed.	-	Replace the polarity sen- sor.	_
A.C22: Phase Informa- tion Disagree- ment	The SERVOPACK phase information is different from the lin- ear encoder phase information.	-	Perform polarity detec- tion.	page 6-26

Continued from previous page.

Alarm Number:	Possible Cause	Confirmation	Correction	Reference
Alarm Name	FOSSIBle Gause	Commation		neleience
	The parameter set- tings are not correct.	Check the linear encoder specifications and feedback signal status.	The settings of Pn282 (Linear Encoder Scale Pitch) and Pn080 = n.□□X□ (Motor Phase Sequence Selection) may not match the installa- tion. Set the parameters to correct values.	page 6-16, page 6-21
	There is noise on the scale signal.	Check to make sure that the frame grounds of the Serial Converter Unit and Servomotor are connected to the FG terminal on the SER- VOPACK and that the FG terminal on the SER- VOPACK is connected to the frame ground on the power supply. And, confirm that the shield is properly pro- cessed on the Linear Encoder Cable. Check to see if the detection reference is repeatedly output in one direction.	Implement appropriate countermeasures against noise for the Linear Encoder Cable.	_
A.C50: Polarity Detec- tion Failure	An external force was applied to the Moving Coil of the motor.	_	The polarity cannot be properly detected if the detection reference is 0 and the speed feedback is not 0 because of an external force, such as cable tension, applied to the Moving Coil. Imple- ment measures to reduce the external force so that the speed feedback goes to 0. If the external force cannot be reduced, increase the setting of Pn481 (Polarity Detection Speed Loop Gain).	_
	The linear encoder resolution is too low.	Check the linear encoder scale pitch to see if it is within 100 µm.	If the linear encoder scale pitch is 100 μm or higher, the SERVOPACK cannot detect the correct speed feedback. Use a linear encoder scale pitch with higher resolution. (We rec- ommend a pitch of 40 μm or less.) Or, increase the setting of Pn485 (Polarity Detection Reference Speed). However, increasing the setting of Pn485 will increase the Servomotor movement range that is required for polarity detection.	_

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.C51: Overtravel Detected during Polarity Detection	The overtravel signal was detected during polarity detection.	Check the overtravel position.	Wire the overtravel sig- nals. Execute polarity detection at a position where an overtravel sig- nal would not be detected.	page 4-32
A.C52: Polarity Detec- tion Not Com- pleted	The servo was turned ON when using an absolute linear encoder, Pn587 was set to n. DDD (Do not detect polarity), and the polarity had not been detected.	_	When using an absolute linear encoder, set Pn587 to n.	-
A.C53: Out of Range of Motion for Polar- ity Detection	The travel distance exceeded the setting of Pn48E (Polarity Detection Range) in the middle of detec- tion.	_	Increase the setting of Pn48E (Polarity Detection Range). Or, increase the setting of Pn481 (Polarity Detection Speed Loop Gain).	-
A.C54: Polarity Detec- tion Failure 2	An external force was applied to the Servo- motor.	_	Increase the setting of Pn495 (Polarity Detection Confirmation Force Refer- ence). Increase the setting of Pn498 (Polarity Detec- tion Allowable Error Range). Increasing the allowable error will also increase the motor tem- perature.	-
A.C80: Encoder Clear	A failure occurred in the encoder.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	-
Error or Multiturn Limit Setting Error	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

	Continued from previous page				
Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference	
	There is a faulty con- tact in the connector or the connector is not wired correctly for the encoder.	Check the condition of the encoder connector.	Reconnect the encoder connector and check the encoder wiring.	page 4-19	
	There is a cable dis- connection or short- circuit in the encoder. Or, the cable imped- ance is outside the specified values.	Check the condition of the Encoder Cable.	Use the Encoder Cable within the specified specifications.	-	
A.C90: Encoder Commu- nications Error	One of the following has occurred: corro- sion caused by improper tempera- ture, humidity, or gas, a short-circuit caused by entry of water drops or cutting oil, or faulty contact in con- nector caused by vibration.	Check the operating environment.	Improve the operating environmental, and replace the cable. If the alarm still occurs, replace the SERVOPACK.	page 3-2	
	A malfunction was caused by noise.	_	Correct the wiring around the encoder by separating the Encoder Cable from the Servomotor Main Cir- cuit Cable or by ground- ing the encoder.	page 4-5	
	A failure occurred in the SERVOPACK.	_	Connect the Servomotor to another SERVOPACK, and turn ON the control power supply. If no alarm occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-	
	Noise entered on the signal lines because the Encoder Cable is bent or the sheath is damaged.	Check the condition of the Encoder Cable and connectors.	Check the Encoder Cable to see if it is installed correctly.	page 4-8	
A.C91: Encoder Commu- nications Posi- tion Data Acceleration Rate	The Encoder Cable is bundled with a high- current line or installed near a high- current line.	Check the installation condition of the Encoder Cable.	Confirm that there is no surge voltage on the Encoder Cable.	-	
Error	There is variation in the FG potential because of the influ- ence of machines on the Servomotor side, such as a welder.	Check the installation condition of the Encoder Cable.	Properly ground the machine to separate it from the FG of the encoder.	-	

Continued on next page.

Alarm Number: **Possible Cause** Confirmation Correction Reference Alarm Name Noise entered on the Implement countermeasignal line from the sures against noise for the page 4-5 encoder. encoder wiring. Reduce machine vibra-Excessive vibration or Check the operating tion. shock was applied to conditions. Correctly install the Serthe encoder. vomotor or linear encoder. Turn the power supply to A.C92: the SERVOPACK OFF and Encoder Commu-ON again. If an alarm still A failure occurred in nications Timer occurs, the Servomotor or _ the encoder. Error linear encoder may be faulty. Replace the Servomotor or linear encoder. Turn the power supply to the SERVOPACK OFF and A failure occurred in ON again. If an alarm still the SERVOPACK. occurs, the SERVOPACK may be faulty. Replace the SERVOPACK. Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still A failure occurred in occurs, the Servomotor or the encoder. linear encoder may be faulty. Replace the Servo-A.CA0: Encoder Paramemotor or linear encoder. ter Error Turn the power supply to the SERVOPACK OFF and A failure occurred in ON again. If an alarm still the SERVOPACK. occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.

Continued from previous page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The encoder is wired incorrectly or there is faulty contact.	Check the wiring of the encoder.	Make sure that the encoder is correctly wired.	page 4-19
	The specifications of the Encoder Cable are not correct and noise entered on it.	-	Use a shielded twisted- pair wire cable or a screened twisted-pair cable with conductors of at least 0.12 mm ² .	-
	The Encoder Cable is too long and noise entered on it.	-	 Rotary Servomotors: The Encoder Cable wir- ing distance must be 50 m max. Linear Servomotors: The Encoder Cable wir- ing distance must be 20 m max. 	-
A.Cb0: Encoder Echo- back Error	There is variation in the FG potential because of the influ- ence of machines on the Servomotor side, such as a welder.	Check the condition of the Encoder Cable and connectors.	Properly ground the machine to separate it from the FG of the encoder.	-
	Excessive vibration or shock was applied to the encoder.	Check the operating conditions.	Reduce machine vibra- tion. Correctly install the Ser- vomotor or linear encoder.	-
	A failure occurred in the encoder.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the Servomotor or linear encoder may be faulty. Replace the Servo- motor or linear encoder.	_
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.CC0: Multiturn Limit	The multiturn limit of the encoder is differ- ent from that of the SERVOPACK. Or, the multiturn limit of the SERVOPACK has been changed.	Check the setting of Pn205 in the SERVO- PACK.	Change the setting if the alarm occurs.	page 7-38
Disagreement	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK. Continued o	-

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
	The cable between the Serial Converter Unit and SERVOPACK is not wired correctly or there is a faulty contact.	Check the wiring of the external encoder.	Correctly wire the cable between the Serial Con- verter Unit and SERVO- PACK.	page 4-21
A.CF1: Reception Failed Error in Feed-	A specified cable is not being used between Serial Con- verter Unit and SER- VOPACK.	Check the wiring speci- fications of the external encoder.	Use a specified cable.	-
back Option Module Commu- nications	The cable between the Serial Converter Unit and SERVOPACK is too long.	Measure the length of the cable that connects the Serial Converter Unit.	The length of the cable between the Serial Con- verter Unit and SERVO- PACK must be 20 m or less.	-
	The sheath on cable between the Serial Converter Unit and SERVOPACK is bro- ken.	Check the cable that connects the Serial Converter Unit.	Replace the cable between the Serial Con- verter Unit and SERVO- PACK.	-
A.CF2: Timer Stopped Error in Feed-	Noise entered the cable between the Serial Converter Unit and SERVOPACK.	_	Correct the wiring around the Serial Converter Unit, e.g., separate I/O signal lines from the Main Circuit Cables or ground.	-
back Option Module Commu- nications	A failure occurred in the Serial Converter Unit.	he Serial Converter – Jnit.		-
	A failure occurred in the SERVOPACK.	-	Replace the SERVO- PACK.	-
	The Servomotor U, V, and W wiring is not correct.	Check the wiring of the Servomotor's Main Cir- cuit Cables.	Make sure that there are no faulty contacts in the wiring for the Servomotor and encoder.	-
	The position com- mand speed is too fast.	Reduce the position command speed and try operating the SER- VOPACK.	Reduce the position refer- ence speed or the refer- ence acceleration rate, or reconsider the electronic gear ratio.	page 6-43
A.d00: Position Devia- tion Overflow (The setting of Pn520 (Position Deviation Over- flow Alarm Level) was exceeded by the position devi- ation.)	The acceleration of the position reference is too high.	Reduce the reference acceleration and try operating the SERVO- PACK.	Reduce the acceleration of the position reference using a MECHATROLINK command. Or, smooth the position reference accel- eration by selecting the position reference filter (ACCFIL) using a MECHATROLINK com- mand.	_
	The setting of Pn520 (Position Deviation Overflow Alarm Level) is too low for the operating conditions.	Check Pn520 (Position Deviation Overflow Alarm Level) to see if it is set to an appropriate value.	Optimize the setting of Pn520.	page 9-8
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-

Continued from previous page.

Continued from previous page.				
Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.d01: Position Devia- tion Overflow Alarm at Servo ON	The servo was turned ON after the position deviation exceeded the setting of Pn526 (Position Deviation Overflow Alarm Level at Servo ON) while the servo was OFF.	Check the position deviation while the servo is OFF.	Optimize the setting of Pn526 (Position Deviation Overflow Alarm Level at Servo ON).	
A.d02: Position Devia- tion Overflow Alarm for Speed Limit at Servo ON	If position deviation remains in the devia- tion counter, the set- ting of Pn529 or Pn584 (Speed Limit Level at Servo ON) limits the speed when the servo is turned ON. This alarm occurs if a position reference is input and the set- ting of Pn520 (Posi- tion Deviation Overflow Alarm Level) is exceeded.	_	Optimize the setting of Pn520 (Position Deviation Overflow Alarm Level). Or, adjust the setting of Pn529 or Pn584 (Speed Limit Level at Servo ON).	page 9-8
A.d10: Motor-Load Posi- tion Deviation	The motor direction and external encoder installation orientation are backward.	Check the motor direc- tion and the external encoder installation ori- entation.	Install the external encoder in the opposite direction, or change the setting of Pn002 = n.XDDD (External Encoder Usage) to reverse the direction.	page 11-6
Overflow	There is an error in the connection between the load (e.g., stage) and external encoder coupling.	Check the coupling of the external encoder.	Check the mechanical coupling.	-
A.d30: Position Data Overflow	The position data exceeded ±1,879,048,192.	Check the input refer- ence pulse counter.	Reconsider the operating specifications.	-
A.E02:	The MECHATROLINK transmission cycle fluctuated.	_	Remove the cause of transmission cycle fluctu- ation at the host control- ler.	-
MECHATROLINK Internal Synchro- nization Error 1	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.E40: MECHATROLINK Transmission Cycle Setting Error	The setting of MECHATROLINK transmission cycle is outside of the speci- fied range.	Check the setting of the MECHATROLINK trans- mission cycle.	Set the MECHATROLINK transmission cycle to an appropriate value.	-
A.E41: MECHATROLINK Communications Data Size Setting Error	The number of trans- mission bytes set on DIP switch S3 is not correct.	Check the MECHATROLINK com- munications data size of the host controller.	Reset DIP switch S3 to change the number of transmission bytes to an appropriate value.	page 6-12

Continued on next page.

13

13-37

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
A.E42: MECHATROLINK	The station address is outside of the setting range.	Check rotary switches S1 and S2 to see if the station address is between 03 and EF.	Check the setting of the station address of the host controller, and reset rotary switches S1 and S2 to change the address to an appropriate value between 03 and EF.	page 6-12
Station Address Setting Error	Two or more stations on the communica- tions network have the same address.	Check to see if two or more stations on the communications net- work have the same address.	Check the setting of the station address of the host controller, and reset rotary switches S1 and S2 to change the address to an appropriate value between 03 and EF.	
A.E50 ^{*5} :	The WDT data in the host controller was not updated normally.	Check to see if the WDT data is being updated at the host controller.	Correctly update the WDT data at the host controller.	_
MECHATROLINK Synchronization Error	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_
A.E51: MECHATROLINK Synchronization	The WDT data at the host controller was not updated correctly at the start of syn- chronous communi- cations, so synchronous commu- nications could not be started.	Check to see if the WDT data is being updated in the host controller.	Correctly update the WDT data at the host controller.	-
Failed	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_
	MECHATROLINK wir- ing is not correct.	Check the MECHATROLINK wir- ing.	Correct the MECHATROLINK Com- munications Cable wiring.	-
A.E60 ^{*5} : Reception Error in MECHATROLINK Communications	A MECHATROLINK data reception error occurred due to noise.	-	Implement countermea- sures against noise. (Check the MECHATROLINK Com- munications Cable and FG wiring, and implement measures such as attach- ing a ferrite core to the MECHATROLINK Com- munications Cable.)	-
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK. Continued o	-

Continued from previous page.

	Continued from previous page.				
Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference	
A.E61: Synchronization	The MECHATROLINK transmission cycle fluctuated.	Check the setting of the MECHATROLINK trans- mission cycle.	Remove the cause of transmission cycle fluctu- ation at the host control- ler.	-	
Interval Error in MECHATROLINK Transmission Cycle	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-	
	MECHATROLINK wir- ing is not correct.	Check the Servomotor wiring.	Correct the MECHATROLINK Com- munications Cable wiring.	-	
A.E63: MECHATROLINK Synchronization Frame Not Received	A MECHATROLINK data reception error occurred due to noise.	_	Implement countermea- sures against noise. (Check the MECHATROLINK Com- munications Cable and FG wiring, and implement measures such as attach- ing a ferrite core to the MECHATROLINK Com- munications Cable.)	-	
	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-	
	There is a faulty con- nection between the SERVOPACK and the Feedback Option Module.		Correctly connect the Feedback Option Module.	-	
A.E72: Feedback Option Module Detec- tion Failure	The Feedback Option Module was discon- nected.	_	Reset the Option Module configuration error and turn the power supply to the SERVOPACK OFF and ON again.	page 13-47	
	A failure occurred in the Feedback Option Module.	-	Replace the Feedback Option Module.	-	
	A failure occurred in the SERVOPACK.		Replace the SERVO- PACK.	_	
A.Eb1: Safety Function Signal Input Tim- ing Error	The delay between activation of the /HWBB1 and /HWBB2 input sig- nals for the HWBB was ten second or longer.	Measure the time delay between the /HWBB1 and /HWBB2 signals.	The output signal circuits or devices for /HWBB1 and /HWBB2 or the SER- VOPACK input signal cir- cuits may be faulty. Alternatively, the input sig- nal cables may be discon- nected. Check to see if any of these items are faulty or have been dis- connected.	_	
	A failure occurred in the SERVOPACK.	-	Replace the SERVO- PACK.	-	

Continued on next page.

Continued from previous page.

Alarm Number:	Possible Cause	Confirmation	Confirmation Correction			
Alarm Name				Reference		
A.EC8: Gate Drive Error 1 (An error occurred in the gate drive circuit.) A.EC9: Gate Drive Error 2 (An error occurred in the gate drive circuit.)	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-		
		Check the motor status when the command is executed.	Execute the SV_ON or SENS_ON command only when the motor is not operating.	-		
A.Ed1: Command Exe- cution Timeout	A timeout error occurred for a MECHATROLINK command.	 For fully-closed loop control, check the status of the external encoder when the command is exe- cuted. For other types of control, check the status of the linear encoder when the command is exe- cuted. 	Execute the SENS_ON command only when an external encoder (e.g., a linear encoder) is con- nected.	_		
A.F10:	The three-phase power supply wiring is not correct.	Check the power sup- ply wiring.	Make sure that the power supply is correctly wired.	page 4-11		
Power Supply Line Open Phase (The voltage was low for more than one second for	he voltage was power supply is unbalanced.		Balance the power supply by changing phases.	-		
phase R, S, or T when the main power supply was ON.)	A failure occurred in the SERVOPACK.	-	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-		

Continued from previous page.

	Continued from previous page				
Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference	
	The relay or Magnetic Contactor used in the dynamic brake circuit failed.	 Check to see if the relay works. Check to see if the contacts in the Magnetic Contactor have welded together. 	The relay or Magnetic Contactor may be faulty. Replace the relay or Mag- netic Contactor.	_	
	The operating time of the relay or Magnetic Contactor used in the dynamic brake circuit was excessive.	Check to see if the operating time of the relay and Magnetic Contactor contacts (open to closed, closed to open) is less than 140 ms.	Replace the relay or Mag- netic Contactor with a component that has an operating time less than 140 ms. (Recommended: Less than 130 ms)	-	
4 500	The cable used in the dynamic brake circuit is broken. Check to see if the cable used in the dynamic brake circuit broken.		Replace the broken cable.	-	
A.F30: Dynamic Brake Circuit Error (An error occurred in the	Dynamic brake circuit wiring is not correct.	Check the wiring of the relay and Magnetic Contactor used in the dynamic brake circuit.	Wire the relay and Mag- netic Contactor correctly.	-	
dynamic brake circuit.)	There is a mistake in the allocation setting for the /DBANS	Check the terminal that was allocated the / DBANS signal and the setting of Pn515 = n. $\Box X \Box \Box$ (/DBANS (Dynamic Brake Answer Input) Signal Allocation).	 Wire the terminal that was allocated the / DBANS signal correctly. Set Pn515 = n. \[DXDD] x \[DD] x 	-	
	(Dynamic Brake Answer Input) signal.	Check the operation of the Magnetic Contac- tor's auxiliary contacts and the logic of the / DBANS signal.	Correct the operation of the magnetic contactor's auxiliary contacts and the logic of the /DBANS sig- nal to be consistent.	-	
	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVO- PACK.	-	
A.F32: Dynamic Brake Operation Request Output Signal Setting Error (An error occurred in the settings related to	The /DBON (Dynamic Brake Operation Request Output) sig- nal and another out- put signal are both allocated to the same CN1 output signal ter- minal.	Check the parameters related to output signals (Pn50E to Pn510, Pn514, Pn53C, and Pn53D).	Set the parameters related to output signals (Pn50E to Pn510, Pn514, Pn53C, and Pn53D) cor- rectly so that the /DBON signal and another output signal are not allocated to the same CN1 output sig- nal terminal.	_	
the Dynamic Brake Operation Request Output signal.)	The /DBON (Dynamic Brake Operation Request Output) sig- nal is being used with the polarity reversed.	Check the related parameters (Pn512 and Pn513) that change the polarity of the /DBON signal.	Set the polarity of the / DBON signal correctly with Pn512 and Pn513.	-	

Continued on next page.

Continued from previous page.

Alarm Number: Alarm Name	Possible Cause	Confirmation	Correction	Reference
FL-1*5:System AlarmFL-2*5:System AlarmFL-3*5:System AlarmFL-4*5:System AlarmFL-5*5:System AlarmFL-6*5:System AlarmFL-6*5:System AlarmFL-7*5:System Alarm	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_
CPF00: Digital Operator	There is a faulty con- tact between the Digi- tal Operator and the SERVOPACK.	Check the connector contact.	Disconnect the connec- tor and insert it again. Or, replace the cable.	_
Communications Error 1	A malfunction was caused by noise.	_	Keep the Digital Operator or the cable away from sources of noise.	-
CPF01: Digital Operator Communications	A failure occurred in the Digital Operator.	_	Disconnect the Digital Operator and then con- nect it again. If an alarm still occurs, the Digital Operator may be faulty. Replace the Digital Oper- ator.	-
*1. Detection Conditio	A failure occurred in the SERVOPACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	_

Rotary Servomotor
 If either of the following conditions is detected, an alarm will occur.

	5							
	er resolution		< •	Pn20E				
6	6 × 10 ⁵		-	Pn210				
 Maximum motor speed [m] 	imum motor speed [min ⁻¹] × <u>Encoder resolu</u> Approx. 3.66 ×		solution	Pn20E				
Maximan meter opeca [m			prox. 3.66 × 10 ¹² Pn210					
Linear Servomotor If either of the following	g condition	s is	; det	ected, a	n ala	arm will occur		
Pn585 [mm/s]		Reso	olution of S	Serial	Converter Unit	_	Pn20E
Linear encoder pitc	h [μm]	×			10		2	Pn210
Pn385 [100 mm Linear encoder pitc		×	Res			Converter Unit 10 ×10 ⁵	2	Pn20E Pn210

 *2. Detection Conditions • Rotary Servomotor If either of the following conditions is detected, an alarm will occur.
• Rated motor speed [min ⁻¹] $\times 1/3 \times \frac{\text{Encoder resolution}}{6 \times 10^5} \leq \frac{\text{Pn20E}}{\text{Pn210}}$
• Maximum motor speed [min ⁻¹] × $\frac{\text{Encoder resolution}}{\text{Approx. } 3.66 \times 10^{12}} \ge \frac{\text{Pn20E}}{\text{Pn210}}$
 Linear Servomotor If either of the following conditions is detected, an alarm will occur.
$\frac{\text{Rated motor speed [mm/s] \times 1/3}}{\text{Linear encoder pitch [µm]}} \times \frac{\text{Resolution of Serial Converter Unit}}{10} \leq \frac{\text{Pn20E}}{\text{Pn210}}$
$\label{eq:result} \begin{array}{c c} & \underline{Pn385} \left[100 \text{ mm/s} \right] \\ \hline \\ \hline \\ Linear encoder pitch \left[\mu m \right] \end{array} \hspace{0.5cm} \times \hspace{0.5cm} \begin{array}{c} \underline{Resolution \ of \ Serial \ Converter \ Unit} \\ \hline \\ \hline \\ Approx. \ 6.10 \times 10^{\circ} \end{array} \hspace{0.5cm} \geq \hspace{0.5cm} \frac{Pn20E}{Pn210} \end{array}$
*3. Refer to the following manual for details.

Ω Σ-7-Series Peripheral Device Selection Manual (Manual No.: SIEP S800001 32)

- *4. The SERVOPACK will fail if the External Regenerative Resistor or Regenerative Resistor Unit is connected while the jumper is connected between the B2 and B3 terminals.
- *5. These alarms are not stored in the alarm history. They are only displayed on the panel display.

13.2.3 Resetting Alarms

If there is an ALM (Servo Alarm) signal, use one of the following methods to reset the alarm after eliminating the cause of the alarm.



Be sure to eliminate the cause of an alarm before you reset the alarm. If you reset the alarm and continue operation without eliminating the cause of the alarm, it may result in damage to the equipment or fire.

Resetting Alarms with the SigmaWin+

Use the following procedure to reset alarms with the SigmaWin+.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Display Alarm in the Menu Dialog Box. The Alarm Display Dialog Box will be displayed.

13.2.3 Resetting Alarms

3. Click the Reset axes Button.

Axis = AXIS#0001A : SGD7S-2	2R8A20A	A.C.90 : Encoder Com		
	211011201		munications Erro	Ala
			imunications erro	
rm diagnosis Alarm History				
Additional Additionation and				
			Cause	≥ 1/5 🔳 🕨
Cause				_
Contact fault of encoder connect	ctor or incorr	ect encoder wiring.		A
				-
Investigated actions				
Investigated actions Check the encoder connector c	ontact status	s.		*
-	ontact status	ş.		Å
-	contact status	ŝ.		A T
Check the encoder connector c Corrective actions			prectly wired	
Check the encoder connector c			prrectly wired.	4 7
Check the encoder connector c Corrective actions			prrectly wired.	4
Check the encoder connector c Corrective actions			prrectly wired.	4 7 4
Check the encoder connector c Corrective actions Re-insert the encoder connecto			prrectly wired.	4
Check the encoder connector of Corrective actions Re-insert the encoder connecto Monitor at occurrence of alarm	or and confirm	n that the encoder is c	prrectly wired.	* * *
Check the encoder connector c Corrective actions Re-insert the encoder connecto Monitor at occurrence of alarm Name	or and confirm	n that the encoder is co	prrectly wired.	4 7 7 7 8
Check the encoder connector c Corrective actions Re-insert the encoder connecto Monitor at occurrence of alarm Name Motor rotating speed	value	n that the encoder is co	prrectly wired.	4 7 7 7

The alarm will be reset, and the alarm display will be cleared.

This concludes the procedure to reset alarms.

Resetting Alarms by Sending the ALM_CLR (Clear Warning or Alarm) Command

Refer to the following manual for details.

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

Resetting Alarms Using the Digital Operator

Press the **ALARM RESET** Key on the Digital Operator. Refer to the following manual for details on resetting alarms.

Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)

13.2.4 Displaying the Alarm History

The alarm history displays up to the last ten alarms that have occurred in the SERVOPACK.

Note: The following alarms are not displayed in the alarm history: A.E50 (MECHATROLINK Synchronization Error), A.E60 (Reception Error in MECHATROLINK Communications), and FL-1 to FL-7.

Preparations

No preparations are required.

Applicable Tools

The following table lists the tools that you can use to display the alarm history.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn000	Ω-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Troubleshooting – Display Alarm	Operating Procedure on page 13-45

Operating Procedure

Use the following procedure to display the alarm history.

- 1. Click the <u>I</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Display Alarm in the Menu Dialog Box. The Alarm Display Dialog Box will be displayed.

3. Click the Alarm History Tab.

The following display will appear and you can check the alarms that occurred in the past.

larm diagn AXIS#0		form Clear	Accumulated operation time Total operation time to the point at which the alarm occurred is displayed in increments of 100 ms
01 02 03 04 05 06 07 08 09 4	A CCD Waltern Lind Diagreement A CCD Waltern Lind Diagreement A CCD is Encoder Clear Error of Waltern Lind Setting Error A Sto Is Encoder Clear Error or Waltern Lind Setting Error A Sto Is Encoder Clear Error or Waltern Lind Setting Error A Sto Is Encoder Clear Error or Waltern Lind Setting Error A Sto Is Encoder Clear Error or Waltern A Sto Is Encoder Clear Error or Maltern A Sto Is Encoder Clear Error or Maltern A Sto Is Encoder Clear Error or Maltern A Sto Is Encoder Sectup Aarm A Sto Is Prover Supply Lind Open Phase	58.05.29.8 56:13.55.3 55:52.55.3 55:42.55.1 55:44.10.1 55:45:19.1 55:45:19.1 55:45:19.9 55:44.37.2 55:34.04.2 *	from when the control power supply and main cir- cuit power supply turned ON. For 24-hour, 365-day operation, measurements are possible for approximately 13 years.
L	T		 Alarm number: Alarm name Alarms in order of occurrence (Older alarms have higher numbers.)

Information 1. If the same alarm occurs consecutively within one hour, it is not saved in the alarm history. If it occurs after an hour or more, it is saved.

2. You can clear the alarm history by clicking the **Clear** Button. The alarm history is not cleared when alarms are reset or when the SERVOPACK main circuit power is turned OFF.

This concludes the procedure to display the alarm history.

13.2.5 Clearing the Alarm History

13.2.5 Clearing the Alarm History

You can clear the alarm history that is recorded in the SERVOPACK.

The alarm history is not cleared when alarms are reset or when the SERVOPACK main circuit power is turned OFF. You must perform the following procedure.

Preparations

Always check the following before you clear the alarm history.

• The parameters must not be write prohibited.

Applicable Tools

The following table lists the tools that you can use to clear the alarm history.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn006	Ω-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Troubleshooting – Display Alarm	Operating Procedure on page 13-46

Operating Procedure

Use the following procedure to reset the alarm history.

- 1. Click the <u>Servo</u> Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Display Alarm in the Menu Dialog Box. The Alarm Display Dialog Box will be displayed.
- 3. Click the Alarm History Tab.
- 4. Click the Clear Button.

The alarm history will be cleared.

No.	Name	Accumulated o	-
			- 1
01	A.CC0 : Multiturn Limit Disagreement	58:05:29.8	-11
02 03	A.CC0 : Multiturn Limit Disagreement	56:13:55.3	-11
03	A.C80 : Encoder Clear Error or Multiturn Limit Setting Error A.810 : Encoder Backup Alarm	55:52:55.1 55:48:10.1	
04	A.610 : Encoder Backup Alarm A.C80 : Encoder Clear Error or Multiturn Limit Setting Error	55:46:10.1	-
05	A.830 : Encoder Clear Error or Multiturn Limit Setting Error A.830 : Encoder Battery Alarm	55:45:19.1	-11
07	A.810 : Encoder Backup Alarm	55:45:18.9	-11
08	A.C90 : Encoder Communications Error	55:44:37.2	- 44
09	A.F10 : Power Supply Line Open Phase	55:34:04.2	۰.
4			

This concludes the procedure to reset the alarm history.

13.2.6 Resetting Alarms Detected in Option Modules

13.2.6 Resetting Alarms Detected in Option Modules

If any Option Modules are attached to the SERVOPACK, the SERVOPACK detects the presence and models of the connected Option Modules. If it finds any errors, it outputs alarms.

You can delete those alarms with this operation.

- **Information** This operation is the only way to reset alarms for Option Modules. The alarms are not reset when you reset other alarms or when you turn OFF the power supply to the SERVOPACK.
 - Always remove the cause of an alarm before you reset the alarm.

Preparations

Always check the following before you clear an alarm detected in an Option Module.

• The parameters must not be write prohibited.

Applicable Tools

The following table lists the tools that you can use to reset Option Module configuration errors.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn014	Ω Σ-7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)
SigmaWin+	Troubleshooting – Display Alarm	Operating Procedure on page 13-47

Operating Procedure

Use the following procedure to reset alarms detected in Option Modules.

- 1. Click the *P* Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- 2. Select Display Alarm in the Menu Dialog Box. The Display Alarm Dialog Box will be displayed.
- 3. Click the Reset axes Button.

Alarm Display				
Alarm Axis	2R8A20A		Reset axes. View	I
Alarm diagnosis Alarm History				
Cause			C C	ause 1/4 🔳
Faulty connection between the	SERVOPAC	CK and Safety (ption Module.	*
				-
Investigated actions		D1 01(1 0 - 1	to Online Madula	
Check the connection between	the SERVU	PACK and Sate	ty Option Module.	^
ļ				Ŧ
Corrective actions				
Reconnect the Safety Option Me	odule.			*
				-
Monitor at occurrence of alarm				
Name	Val	Unit		
Motor rotating speed	val	min-1		î
Speed reference	-	min-1		
Internal torgue reference	-	%		
Input reference pulse speed	-	min-1		-
The diagonosis results si The real cause may not b			the alarm.	


The Reset Option Module Configuration Error Dialog Box will be displayed.

13.2.6 Resetting Alarms Detected in Option Modules


4. Select the Clear Check Box for the Option Module for which to reset the alarm and then click the Execute Button.

📴 Reset Option N	Reset Option Module Configuration Error AXIS#0001A					
Selec	n Module error was detected t the Clear check box of the the Execute button to clear th	Option Module and then				
	Safety Option Failed to detect Feedback Option Normally detected	Clear				
		Execute				

5. Read the precaution and then click the OK Button.



6. Read the precaution and then click the OK Button.



7. Turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to reset alarms detected in Option Modules.

13.2.7 Resetting Motor Type Alarms

The SERVOPACK automatically determines the type of Servomotor that is connected to it. If the type of Servomotor that is connected is changed, an A.070 alarm (Motor Type Change Detected) will occur the next time the SERVOPACK is started. If an A.070 alarm occurs, you must set the parameters to match the new type of Servomotor.

An A.070 alarm is reset by executing the Reset Motor Type Alarm utility function.

- Information 1. This utility function is the only way to reset an A.070 alarm (Motor Type Change Detected). The errors are not reset when you reset alarms or turn OFF the power supply to the SER-VOPACK.
 - 2. If an A.070 alarm occurs, first set the parameters according to the newly connected Servomotor type and then execute the Reset Motor Type Alarm utility function.

Preparations

Always check the following before you reset a motor type alarm.

• The parameters must not be write prohibited.

Applicable Tools


The following table lists the tools that you can use to clear the motor type alarm.

Tool	Fn No./Function Name	Reference
Digital Operator	Fn021	$\bigcap \Sigma -7-Series Digital Operator Operating Manual (Manual No.: SIEP S800001 33)$
SigmaWin+	Troubleshooting – Reset Motor Type Alarm	Operating Procedure on page 13-49

Operating Procedure

Use the following procedure to reset Motor Type alarm.

- 1. Click the <u>J</u> Servo Drive Button in the workspace of the Main Window of the SigmaWin+.
- **2.** Select Reset Motor Type Alarm in the Menu Dialog Box. The Reset Motor Type Alarm Dialog Box will be displayed.
- 3. Click the Reset Button.



4. Read the precaution and then click the OK Button.



13.2.7 Resetting Motor Type Alarms

5. Read the precaution and then click the OK Button.

📽 Reset Motor Type Alarm
The motor type alarm was reset. When the power supply is turned on next time, the setting is reflected. Reconnect to SigmaWin+ after turning on the power supply again.
ОК

6. Turn the power supply to the SERVOPACK OFF and ON again.

This concludes the procedure to reset Motor Type alarms.

13.3 Warning Displays

If a warning occurs in the SERVOPACK, a warning number will be displayed on the panel display. Warnings are displayed to warn you before an alarm occurs.

This section provides a list of warnings and the causes of and corrections for warnings.

13.3.1 List of Warnings

The list of warnings gives the warning name and warning meaning in order of the warning numbers.

Warning Number	Warning Name	Meaning	Resetting
A.900	Position Deviation Overflow	The position deviation exceeded the percentage set with the following formula: $(Pn520 \times Pn51E/100)$	Required.
A.901	Position Deviation Overflow Alarm at Servo ON	The position deviation when the servo was turned ON exceeded the percentage set with the following formula: $(Pn526 \times Pn528/100)$	Required.
A.910	Overload	This warning occurs before an overload alarm (A.710 or A.720) occurs. If the warning is ignored and operation is continued, an alarm may occur.	Required.
A.911	Vibration	Abnormal vibration was detected during motor opera- tion. The detection level is the same as A.520. Set whether to output an alarm or a warning by setting Pn310 (Vibration Detection Selection).	Required.
A.912	Internal Temperature Warning 1 (Control Board Temperature Error)	The surrounding temperature of the control PCB is abnormal.	Required.
A.913	Internal Temperature Warning 2 (Power Board Temperature Error)	The surrounding temperature of the power PCB is abnormal.	Required.
A.920	Regenerative Overload	This warning occurs before an A.320 alarm (Regenera- tive Overload) occurs. If the warning is ignored and operation is continued, an alarm may occur.	Required.
A.921	Dynamic Brake Over- load	This warning occurs before an A.731 alarm (Dynamic Brake Overload) occurs. If the warning is ignored and operation is continued, an alarm may occur.	Required.
A.923	SERVOPACK Built-in Fan Stopped	The fan inside the SERVOPACK stopped.	Required.
A.930	Absolute Encoder Bat- tery Error	This warning occurs when the voltage of absolute encoder's battery is low.	Required.
A.93B	Overheat Warning	The input voltage (temperature) for the overheat protec- tion input (TH) signal exceeded the setting of Pn61C (Overheat Warning Level).	Required.
A.942	Speed Ripple Com- pensation Information Disagreement	The speed ripple compensation information stored in the encoder does not agree with the speed ripple com- pensation information stored in the SERVOPACK.	Required.
A.94A	Data Setting Warning 1 (Parameter Number Error)	There is an error in the parameter number for a Data Setting Warning 1 (Parameter Number) command.	Automatically reset.*
A.94b	Data Setting Warning 2 (Out of Range)	The command data is out of range.	Automatically reset.*
A.94C	Data Setting Warning 3 (Calculation Error)	A calculation error was detected.	Automatically reset.*

Continued on next page.

13.3.1 List of Warnings

Continued from previous page.

Warning Number	Warning Name	Meaning	Resetting
A.94d	Data Setting Warning 4 (Parameter Size)	The data sizes do not match.	Automatically reset.*
A.94E	Data Setting Warning 5 (Latch Mode Error)	A Latch Mode error was detected.	Required.
A.95A	Command Warning 1 (Unsatisfied Com- mand Conditions)	A command was sent when the conditions for sending a command were not satisfied.	Automatically reset.*
A.95b	Command Warning 2 (Unsupported Com- mand)	An unsupported command was sent.	Automatically reset.*
A.95d	Command Warning 4 (Command Interfer- ence)	There was command interference, particularly latch command interference.	Automatically reset.*
A.95E	Command Warning 5 (Subcommand Not Possible)	The subcommand and main command interfere with each other.	Automatically reset.*
A.95F	Command Warning 6 (Undefined Command)	An undefined command was sent.	Automatically reset.*
A.960	MECHATROLINK Communications Warning	A communications error occurred during MECHATROLINK communications.	Required.
A.971	Undervoltage	This warning occurs before an A.410 alarm (Undervolt- age) occurs. If the warning is ignored and operation is continued, an alarm may occur.	Required.
A.97A	Command Warning 7 (Phase Error)	A command that cannot be executed in the current phase was sent.	Automatically reset.*
A.97b	Data Clamp Out of Range	The set command data was clamped to the minimum or maximum value of the allowable setting range.	Automatically reset.*
A.9A0	Overtravel	Overtravel was detected while the servo was ON.	Required.
A.9b0	Preventative Mainte- nance Warning	One of the consumable parts has reached the end of its service life.	Required.

* If using the commands for the MECHATROLINK-III standard servo profile, the warning will automatically be cleared after the correct command is received. If you use MECHATROLINK-II-compatible profile commands, send an ALM_CLR (Clear Warning or Alarm) command to clear the warning.

Note: Use Pn008 = n.□X□□ (Warning Detection Selection) to control warning detection. However, the following warnings are not affected by the setting of Pn008 = n.□X□□ and other parameter settings are required in addition to Pn008 = n.□X□□.

Warning	Parameters That Must Be Set to Select Warning Detection	Reference
A.911	$Pn310 = n.\Box\Box\BoxX$ (Vibration Detection Selection)	page 7-49
A.923	$_{-}$ (Not affected by the setting of Pn008 = n.□X□□.)	-
A.930	Pn008 = n.	page 13-3
A.942	Pn423 = n. DDXD (Speed Ripple Compensation Information Dis- agreement Warning Detection Selection)	page 9-60
A.94A to A.960 and A.97A to A.97b	Pn800=n.□□X□ (Warning Check Masks)	page 14-3
A.971	Pn008 = $n.\Box \Box X \Box$ (Function Selection for Undervoltage) (Not affected by the setting of Pn008 = $n.\Box X \Box \Box$.)	page 7-16
A.9A0	$Pn00D = n.X\square\square\square$ (Overtravel Warning Detection Selection) (Not affected by the setting of $Pn008 = n.\squareX\square\square$.)	page 6-30
A.9b0	Pn00F = n.	page 10-15

The causes of and corrections for the warnings are given in the following table. Contact your Yaskawa representative if you cannot solve a problem with the correction given in the table.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The Servomotor U, V, and W wiring is not correct.	Check the wiring of the Servomotor's Main Cir- cuit Cables.	Make sure that there are no faulty connections in the wiring for the Servomotor and encoder.	-
	A SERVOPACK gain is too low.	Check the SERVO- PACK gains.	Increase the servo gain, e.g., by using autotuning without a host reference.	page 9-24
A.900: Position Deviation Overflow	The acceleration of the position ref- erence is too high.	Reduce the reference acceleration and try operating the SERVO- PACK.	Reduce the acceleration of the position reference using a MECHATROLINK com- mand. Or, smooth the posi- tion reference acceleration by selecting the position reference filter (ACCFIL) using a MECHATROLINK command.	-
	The excessive position deviation alarm level (Pn520 × Pn51E/100) is too low for the operating condi- tions.	Check excessive posi- tion deviation alarm level (Pn520 × Pn51E/ 100) to see if it is set to an appropriate value.	Optimize the settings of Pn520 and Pn51E.	page 9-8
	A failure occurred in the SERVO- PACK.	_	Turn the power supply to the SERVOPACK OFF and ON again. If an alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.	-
A.901: Position Deviation Overflow Alarm at Servo ON	The position devi- ation when the servo was turned ON exceeded the percentage set with the following formula: (Pn526 × Pn528/ 100)	-	Optimize the setting of Pn528 (Position Deviation Overflow Warning Level at Servo ON).	-

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The wiring is not correct or there is a faulty contact in the motor or encoder wiring.	Check the wiring.	Make sure that the Servo- motor and encoder are cor- rectly wired.	-
	Operation was performed that exceeded the overload protec- tion characteris- tics.	Check the motor over- load characteristics and Run command.	Reconsider the load and operating conditions. Or, increase the motor capacity.	-
A.910: Overload (warning before an A.710 or A.720 alarm occurs)	An excessive load was applied during operation because the Ser- vomotor was not driven because of mechanical prob- lems.	Check the operation reference and motor speed.	Remove the mechanical problem.	_
	The overload warning level (Pn52B) is not suitable.	Check that the overload warning level (Pn52B) is suitable.	Set a suitable overload warning level (Pn52B).	page 6-40
	A failure occurred in the SERVO- PACK.	_	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-
	Abnormal vibra- tion was detected during motor operation.	Check for abnormal motor noise, and check the speed and torque waveforms during oper- ation.	Reduce the motor speed. Or, reduce the servo gain with custom tuning.	page 9-42
A.911: Vibration	The setting of Pn103 (Moment of Inertia Ratio) is greater than the actual moment of inertia or was greatly changed.	Check the moment of inertia ratio or mass ratio.	Set Pn103 (Moment of Iner- tia Ratio) to an appropriate value.	page 9-16
	The vibration detection level (Pn312 or Pn384) is not suitable.	Check that the vibration detection level (Pn312 or Pn384) is suitable.	Set a suitable vibration detection level (Pn312 or Pn384).	page 7-49

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environ- ment monitor.	Decrease the surrounding temperature by improving the SERVOPACK installa- tion conditions.	page 3-6
	An overload alarm was reset by turn- ing OFF the power supply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
A.912: Internal Tempera- ture Warning 1 (Control Board Tem- perature Error)	There was an excessive load or operation was performed that exceeded the regenerative pro- cessing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenera- tive load ratio to check the regenerative pro- cessing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orien- tation is not cor- rect or there is insufficient space around the SER- VOPACK.	Check the SERVO- PACK installation con- ditions.	Install the SERVOPACK according to specifications.	page 3-3, page 3-5
	A failure occurred in the SERVO- PACK.	-	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-
	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat. Or, check the operating status with the SERVOPACK installation environ- ment monitor.	Decrease the surrounding temperature by improving the SERVOPACK installa- tion conditions.	page 3-6
	An overload alarm was reset by turn- ing OFF the power supply too many times.	Check the alarm display to see if there is an overload alarm.	Change the method for resetting the alarm.	-
A.913: Internal Tempera- ture Warning 2 (Power Board Tem- perature Error)	There was an excessive load or operation was performed that exceeded the regenerative pro- cessing capacity.	Use the accumulated load ratio to check the load during operation, and use the regenera- tive load ratio to check the regenerative pro- cessing capacity.	Reconsider the load and operating conditions.	-
	The SERVOPACK installation orien- tation is not cor- rect or there is insufficient space around the SER- VOPACK.	Check the SERVO- PACK installation con- ditions.	Install the SERVOPACK according to specifications.	page 3-3, page 3-5
	A failure occurred in the SERVO- PACK.	-	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-

Continued on next page.

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
	The power supply voltage exceeded the specified range.	Measure the power supply voltage.	Set the power supply volt- age within the specified range.	-
A.920: Regenerative Over- load (warning before an A.320 alarm occurs)	There is insuffi- cient external regenerative resis- tance, Regenera- tive Resistor capacity, or SER- VOPACK capac- ity, or there has been a continuous regeneration state.	Check the operating conditions or the capacity using the Sig- maJunmaSize+ Capac- ity Selection Software or another means.	Change the regenerative resistance value, regenera- tive resistance capacity, or SERVOPACK capacity. Reconsider the operating conditions using the Sigma- JunmaSize+ Capacity Selection Software or other means.	-
	There was a con- tinuous regenera- tion state because a negative load was continuously applied.	Check the load applied to the Servomotor during operation.	Reconsider the system including the servo, machine, and operating conditions.	-
	The Servomotor was rotated by an external force.	Check the operation status.	Implement measures to ensure that the motor will not be rotated by an exter- nal force.	-
A.921: Dynamic Brake Overload (warning before an A.731 alarm occurs)	When the Servo- motor was stopped with the dynamic brake, the rotational or linear kinetic energy exceeded the capacity of the Dynamic Brake Resistor.	Check the power con- sumed by the DB resis- tor to see how frequently the DB is being used.	 Reconsider the following: Reduce the Servomotor command speed. Decrease the moment of inertia or mass. Reduce the frequency of stopping with the dynamic brake. 	-
	A failure occurred in the SERVO- PACK.	_	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-
A.923: SERVOPACK Built- in Fan Stopped	The fan inside the SERVOPACK stopped.	Check for foreign mat- ter inside the SERVO- PACK.	Remove foreign matter from the SERVOPACK. If an alarm still occurs, the SER- VOPACK may be faulty. Replace the SERVOPACK.	-
A.930: Absolute Encoder Battery Error (The absolute encoder battery voltage was lower than the spec- ified level.) (Detected only when an abso-	The battery con- nection is faulty or a battery is not connected.	Check the battery con- nection.	Correct the battery connec- tion.	page 4-20
	The battery volt- age is lower than the specified value (2.7 V).	Measure the battery voltage.	Replace the battery.	page 13-3
lute encoder is con- nected.)	A failure occurred in the SERVO- PACK.	-	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-

Continued from previous page.

Warning Number:	Possible Cause	Confirmation	Continued from pre	Reference
Warning Name	FOSSIBle Gause	Commation		nelelelice
	The surrounding temperature is too high.	Check the surrounding temperature using a thermostat.	Lower the surrounding tem- perature by improving the installation conditions of the Linear Servomotor or the machine.	-
	Operation was performed under an excessive load.	Use the accumulated load ratio to check the load during operation.	Reconsider the load and operating conditions.	-
A.93B: Overheat Warning	A failure occurred in the SERVO- PACK.	-	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-
	The temperature detection circuit in the Linear Servo- motor is faulty or the sensor attached to the machine is faulty.	_	The temperature detection circuit in the Linear Servo- motor may be faulty or the sensor attached to the machine may be faulty. Replace the Linear Servo- motor or repair the sensor attached to the machine.	-
	The speed ripple	-	Reset the speed ripple compensation value on the SigmaWin+.	page 9-60
A.942: Speed Ripple Com- pensation Informa- tion Disagreement	compensation information stored in the encoder does not agree with the speed ripple compensa-	_	Set Pn423 to n. D 1 D (Do not detect A.942 alarms). However, changing the set- ting may increase the speed ripple.	page 9-60
tion Disagreement	tion information stored in the SER- VOPACK.	_	Set Pn423 to n. DDD (Disable speed ripple com- pensation). However, changing the setting may increase the speed ripple.	page 9-60
A.94A: Data Setting Warn- ing 1 (Parameter Number Error)	An invalid param- eter number was used.	Check the command that caused the warn-ing.	Use the correct parameter number.	page 13- 60
A.94b: Data Setting Warn- ing 2 (Out of Range)	The set com- mand data was clamped to the minimum or maxi- mum value of the setting range.	Check the command that caused the warn- ing.	Set the parameter within the setting range.	page 13- 60
A.94C: Data Setting Warn- ing 3 (Calculation Error)	The calculation result of the set- ting is not correct.	Check the command that caused the warn-ing.	Set the parameter within the setting range.	page 13- 60
A.94d: Data Setting Warn- ing 4 (Parameter Size)	The parameter size set in the command is not correct.	Check the command that caused the warn-ing.	Set the correct parameter size.	page 13- 60
A.94E: Data Setting Warn- ing 5 (Latch Mode Error)	A Latch Mode error was detected.	Check the command that caused the warn- ing.	Change the setting of Pn850 or the LT_MOD data for the LTMOD_ON com- mand sent by the host con- troller to an appropriate value. (The applies when using the MECHATROLINK-II-com- patible profile.)	page 13- 60

Continued on next page.

Continued from previous page.

Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
A.95A: Command Warning 1 (Unsatisfied Com- mand Conditions)	The command conditions are not satisfied.	Check the command that caused the warn- ing.	Send the command after the command conditions are satisfied.	page 13- 60
A.95b: Command Warning 2 (Unsupported Command)	An unsupported command was received.	Check the command that caused the warn-ing.	Do not send unsupported commands.	page 13- 60
A.95d: Command Warning 4 (Command Inter- ference)	The command sending condi- tions for latch- related com- mands was not satisfied.	Check the command that caused the warn- ing.	Send the command after the command conditions are satisfied.	page 13- 60
A.95E: Command Warning 5 (Subcommand Not Possible)	The command sending condi- tions for subcom- mands was not satisfied.	Check the command that caused the warn- ing.	Send the command after the conditions are satisfied.	page 13- 60
A.95F: Command Warning 6 (Undefined Com- mand)	An undefined command was sent.	Check the command that caused the warn- ing.	Do not send undefined commands.	page 13- 60
	The MECHATROLINK Communications Cable is not wired correctly.	Check the wiring condi- tions.	Correct the MECHATROLINK Commu- nications Cable wiring.	page 4-38
A.960: MECHATROLINK Communications Warning	A MECHATROLINK data reception error occurred due to noise.	Confirm the installation conditions.	 Implement the following countermeasures against noise. Check the MECHATROLINK Communications Cable and FG wiring and implement countermeasures to prevent noise from entering. Attach a ferrite core to the MECHATROLINK Communications Cable. 	_
	A failure occurred in the SERVO- PACK.	_	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-
	For a 400-V SER- VOPACK, the AC power supply volt- age dropped below 280 V.	Measure the power supply voltage.	Set the power supply volt- age within the specified range.	-
A 071.	The power supply voltage dropped during operation.	Measure the power supply voltage.	Increase the power supply capacity.	-
A.971: Undervoltage	A momentary power interrup- tion occurred.	Measure the power supply voltage.	If you have changed the setting of Pn509 (Momen- tary Power Interruption Hold Time), decrease the setting.	page 7-15
	The SERVOPACK fuse is blown out.	-	Replace the SERVOPACK and connect a Reactor.	page 4-18
	A failure occurred in the SERVO- PACK.	_	The SERVOPACK may be faulty. Replace the SERVO- PACK.	-

Continued from previous page.

				lites pager
Warning Number: Warning Name	Possible Cause	Confirmation	Correction	Reference
A.97A: Command Warning 7 (Phase Error)	A command that cannot be exe- cuted in the cur- rent phase was sent.	-	Send the command after the command conditions are satisfied.	-
A.97b: Data Clamp Out of Range	The set com- mand data was clamped to the minimum or maxi- mum value of the setting range.	-	Set the command data within the setting ranges.	-
A.9A0: Overtravel (Over- travel status was detected.)	Overtravel was detected while the servo was ON.	Check the status of the overtravel signals on the input signal monitor.	 Even if an overtravel signal is not shown by the input signal monitor, momentary overtravel may have been detected. Take the following precautions. Do not specify move- ments that would cause overtravel from the host controller. Check the wiring of the overtravel signals. Implement countermea- sures against noise. 	page 6-30
A.9b0: Preventative Mainte- nance Warning	One of the con- sumable parts has reached the end of its service life.	-	Replace the part. Contact your Yaskawa representa- tive for replacement.	page 10- 15

13.4 Monitoring Communications Data during Alarms or Warnings

You can monitor the command data that is received when an alarm or warning occurs, such as a data setting warning $(A.94\Box)$ or a command warning $(A.95\Box)$ by using the following parameters. The following is an example of the data when an alarm or warning has occurred in the normal state.

Command Data during Alarms and Warnings: Pn890 to Pn8A6 Response Data during Alarms and Warnings: Pn8A8 to Pn8BE

Command Byte	Command Data Storage When an Alarm or Warning Occurs		
Sequence	CMD	RSP	
0	Pn890 = n.□□□□□□XX	Pn8A8 = n.00000XX	
1	Pn890 = n.□□□□XX□□	Pn8A8 = n.DDDDXXDD	
2	Pn890 = n.□□XX□□□□	Pn8A8 = n.DDXXDDDD	
3	Pn890 = n.XX□□□□□□	Pn8A8 = n.XXDDDDDD	
4 to 7	Pn892	Pn8AA	
8 to 11	Pn894	Pn8AC	
12 to 15	Pn896	Pn8AE	
16 to 19	Pn898	Pn8B0	
20 to 23	Pn89A	Pn8B2	
24 to 27	Pn89C	Pn8B4	
28 to 31	Pn89E	Pn8B6	
32 to 35	Pn8A0	Pn8B8	
36 to 39	Pn8A2	Pn8BA	
40 to 43	Pn8A4	Pn8BC	
44 to 47	Pn8A6	Pn8BE	

Note: 1. Data is stored in little endian byte order and displayed in the hexadecimal.

2. Refer to the following manual for command details.

Σ-7-Series MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

13.5 Troubleshooting Based on the Operation and Conditions of the Servomotor

This section provides troubleshooting based on the operation and conditions of the Servomotor, including causes and corrections.

Problem	Possible Cause	Confirmation	Correction	Reference
	The control power supply is not turned ON.	Measure the voltage between control power supply terminals.	Turn OFF the Servo System. Correct the wiring so that the con- trol power supply is turned ON.	-
	The main circuit power sup- ply is not turned ON.	Measure the voltage across the main circuit power input terminals.	Turn OFF the Servo System. Correct the wiring so that the main circuit power supply is turned ON.	-
	The I/O signal connector (CN1) pins are not wired cor- rectly or are disconnected.	Turn OFF the Servo Sys- tem. Check the wiring condition of the I/O signal connector (CN1) pins.	Correct the wiring of the I/O signal connec- tor (CN1) pins.	page 4-29, page 10-5
	The wiring for the Servomo- tor Main Circuit Cables or Encoder Cable is discon- nected.	Check the wiring condi- tions.	Turn OFF the Servo System. Wire the cable correctly.	_
Servomotor	There is an overload on the Servomotor.	Operate the Servomotor with no load and check the load status.	Turn OFF the Servo System. Reduce the load or replace the Ser- vomotor with a Servo- motor with a larger capacity.	-
Does Not Start	The type of encoder that is being used does not agree with the setting of $Pn002 = n.\Box X \Box \Box$ (Encoder Usage).	Check the type of the encoder that is being used and the setting of $Pn002 = n.\Box X \Box \Box$.	Set Pn002 = $n.\Box X \Box \Box$ according to the type of the encoder that is being used.	page 7-32
	There is a mistake in the input signal allocations (Pn50A, Pn50B, Pn511, and Pn516).	Check the input signal allocations (Pn50A, Pn50B, Pn511, and Pn516).	Correctly allocate the input signals (Pn50A, Pn50B, Pn511, and Pn516).	page 7-4, page 10-5
	The SV_ON command was not sent.	Check the commands sent from the host con-troller.	Send the SV_ON com- mand from the host controller.	-
	The SENS_ON (Turn ON Sensor) command was not sent.	Check the commands sent from the host con- troller.	Send the commands to the SERVOPACK in the correct sequence.	-
	The P-OT (Forward Drive Prohibit) or N-OT (Reverse Drive Prohibit) signal is still OFF.	Check the P-OT and N- OT signals.	Turn ON the P-OT and N-OT signals.	page 10-5
	The safety input signals (/HWBB1 or /HWBB2) were not turned ON.	Check the /HWBB1 and /HWBB2 input signals.	Turn ON the /HWBB1 and /HWBB2 input sig- nals. If you are not using the safety func- tion, connect the Safety Jumper Connector (provided as an acces- sory) to CN8.	page 10-5

Continued on next page.

	Continued from previous page.			
Problem	Possible Cause	Confirmation	Correction	Reference
	The FSTP (Forced Stop Input) signal is still OFF.	Check the FSTP signal.	 Turn ON the FSTP signal. If you will not use the function to force the motor to stop, set Pn516 = n. DDX (FSTP (Forced Stop Input) Signal Allocation) to disable the signal. 	page 10-5
Servomotor Does Not	A failure occurred in the SER- VOPACK.	-	Turn OFF the Servo System. Replace the SERVOPACK.	-
Start		Check the setting of Pn080 =n.□□□X (Polar- ity Sensor Selection).	Correct the parameter setting.	page 6-23
	The polarity detection was not executed.	Check the inputs to the SV_ON (Servo ON) com- mand.	 If you are using an incremental linear encoder, send the SV_ON command from the host controller. If you are using an absolute linear encoder, execute polarity detection. 	page 6-24
	There is a mistake in the Servomotor wiring.	Turn OFF the Servo Sys- tem. Check the wiring.	Wire the Servomotor correctly.	-
	There is a mistake in the wir- ing of the encoder or Serial Converter Unit.	Turn OFF the Servo Sys- tem. Check the wiring.	Wire the Serial Con- verter Unit correctly.	-
	There is a mistake in the lin- ear encoder wiring.	Turn OFF the Servo System. Check the wiring.	Wire the cable cor- rectly.	-
Servomotor Moves Instanta-	The setting of Pn282 (Linear Encoder Scale Pitch) is not correct.	Check the setting of Pn282.	Correct the setting of Pn282.	page 6-16
neously, and Then Stops	The count-up direction of the linear encoder does not match the forward direction of the Moving Coil in the motor.	Check the directions.	Change the setting of Pn080 = $n.\square\squareX\square$ (Motor Phase Sequence Selection). Place the linear encoder and motor in the same direction.	page 6-21
	Polarity detection was not performed correctly.	Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between $\pm 10^{\circ}$.	Correct the settings for the polarity detection- related parameters.	_
Servomotor Speed Is Unstable	There is a faulty connection in the Servomotor wiring.	The connector connec- tions for the power line (U, V, and W phases) and the encoder or Serial Converter Unit may be unstable. Turn OFF the Servo System. Check the wiring.	Tighten any loose ter- minals or connectors and correct the wiring.	-

Continued from previous pa				vious page.
Problem	Possible Cause	Confirmation	Correction	Reference
	A failure occurred in the SER- VOPACK.	-	Turn OFF the Servo System. Replace the SERVOPACK.	-
Servomotor Moves with- out a Refer- ence Input	The count-up direction of the linear encoder does not match the forward direction of the Moving Coil in the motor.	Check the directions.	Change the setting of Pn080 = $n.\Box\Box X\Box$ (Motor Phase Sequence Selection). Match the linear encoder direction and Servomotor direction.	page 6-21
	Polarity detection was not performed correctly.	Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between $\pm 10^{\circ}$.	Correct the settings for the polarity detection- related parameters.	-
Dynamic Brake Does Not Operate	The setting of Pn001 = n.	Check the setting of Pn001 = $n.\Box\Box\BoxX$.	Set Pn001 = n.□□□X correctly.	-
	The Dynamic Brake Resistor is disconnected.	Check the moment of inertia, motor speed, and dynamic brake frequency of use. If the moment of inertia, motor speed, or dynamic brake frequency of use is excessive, the dynamic brake resis- tance may be discon- nected.	Turn OFF the Servo System. Replace the SERVOPACK. To pre- vent disconnection, reduce the load.	_
	There was a failure in the dynamic brake drive circuit.	-	There is a defective component in the dynamic brake circuit. Turn OFF the Servo System. Replace the SERVOPACK.	-

Continued from previous page.

Continued on next page.

Continued from previous page.

Problem	Possible Cause	Confirmation	Continued from pre	Reference
FIODIeIII	Fossible Cause	Commation	Reduce the load so	nelelelice
	The Servomotor vibrated considerably while perform- ing the tuning-less function with the default settings.	Check the waveform of the motor speed.	that the moment of inertia ratio or mass ratio is within the allow- able value, or increase the load level or reduce the rigidity level in the tuning-less level set- tings. If the situation is not improved, disable the tuning-less function (i.e., set Pn170 to n.□□□0) and execute autotuning either with or without a host refer- ence.	page 9-12
		Turn OFF the Servo Sys- tem. Check to see if there are any loose mounting screws.	Tighten the mounting screws.	_
	The machine mounting is not secure.	Turn OFF the Servo Sys- tem. Check to see if there is misalignment in the coupling.	Align the coupling.	-
		Turn OFF the Servo Sys- tem. Check to see if the coupling is balanced.	Balance the coupling.	-
Abnormal Noise from Servomotor	The bearings are defective.	Turn OFF the Servo Sys- tem. Check for noise and vibration around the bear- ings.	Replace the Servomo- tor.	_
	There is a vibration source at the driven machine.	Turn OFF the Servo Sys- tem. Check for any for- eign matter, damage, or deformation in the machine's moving parts.	Consult with the machine manufacturer.	-
	Noise interference occurred because of incorrect I/O Sig- nal Cable specifications.	Turn OFF the Servo Sys- tem. Check the I/O Signal Cables to see if they sat- isfy specifications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm ² (stranded wire).	Use cables that satisfy the specifications.	-
	Noise interference occurred because an I/O Signal Cable is too long.	Turn OFF the Servo Sys- tem. Check the lengths of the I/O Signal Cables.	The I/O Signal Cables must be no longer than 3 m.	-
	Noise interference occurred because of incorrect Encoder Cable specifications.	Turn OFF the Servo Sys- tem. Check the Encoder Cable to see if it satisfies specifications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm ² (stranded wire).	Use cables that satisfy the specifications.	_

Continued from	m previous page.
----------------	------------------

Problem	Possible Cause	Confirmation	Correction	Reference
	Noise interference occurred because the Encoder Cable is too long.	Turn OFF the Servo Sys- tem. Check the length of the Encoder Cable.	 Rotary Servomotors: The Encoder Cable length must be 50 m max. Linear Servomotors: Make sure that the Serial Converter Unit cable is no longer than 20 m and that the Linear Encoder Cable and the Sensor Cable are no longer than 15 m each. 	-
	Noise interference occurred because the Encoder Cable is damaged.	Turn OFF the Servo Sys- tem. Check the Encoder Cable to see if it is pinched or the sheath is damaged.	Replace the Encoder Cable and correct the cable installation envi- ronment.	-
	The Encoder Cable was sub- jected to excessive noise interference.	Turn OFF the Servo Sys- tem. Check to see if the Encoder Cable is bundled with a high-current line or installed near a high-cur- rent line.	Correct the cable lay- out so that no surge is applied by high-current lines.	-
Abnormal Noise from Servomotor	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Turn OFF the Servo Sys- tem. Check to see if the machines are correctly grounded.	Properly ground the machines to separate them from the FG of the encoder.	-
	There is a SERVOPACK pulse counting error due to noise.	Check to see if there is noise interference on the signal line from the encoder.	Turn OFF the Servo System. Implement countermeasures against noise for the encoder wiring.	-
	The encoder was subjected to excessive vibration or shock.	Turn OFF the Servo Sys- tem. Check to see if vibration from the machine occurred. Check the Servomotor installa- tion (mounting surface precision, securing state, and alignment). Check the linear encoder installation (mounting sur- face precision and secur- ing method).	Reduce machine vibra- tion. Improve the mounting state of the Servomotor or linear encoder.	-
	A failure occurred in the encoder.	-	Turn OFF the Servo System. Replace the Servomotor.	-
	A failure occurred in the Serial Converter Unit.	-	Turn OFF the Servo System. Replace the Serial Converter Unit.	-
	A failure occurred in the linear encoder.	-	Turn OFF the Servo System. Replace the linear encoder.	-

			Continued from pre	vious page.
Problem	Possible Cause	Confirmation	Correction	Reference
	The servo gains are not bal- anced.	Check to see if the servo gains have been cor- rectly tuned.	Perform autotuning without a host reference.	page 9-24
Servomotor	The setting of Pn100 (Speed Loop Gain) is too high.	Check the setting of Pn100. The default setting is Kv = 40.0 Hz.	Set Pn100 to an appro- priate value.	-
Vibrates at Frequency of Approx. 200 to 400	The setting of Pn102 (Posi- tion Loop Gain) is too high.	Check the setting of Pn102. The default setting is Kp = 40.0/s.	Set Pn102 to an appro- priate value.	-
Hz.	The setting of Pn101 (Speed Loop Integral Time Con- stant) is not appropriate.	Check the setting of Pn101. The default setting is Ti = 20.0 ms.	Set Pn101 to an appro- priate value.	-
	The setting of Pn103 (Moment of Inertia Ratio or Mass Ratio) is not appropri- ate.	Check the setting of Pn103.	Set Pn103 to an appro- priate value.	-
	The servo gains are not bal- anced.	Check to see if the servo gains have been cor- rectly tuned.	Perform autotuning without a host refer- ence.	page 9-24
	The setting of Pn100 (Speed Loop Gain) is too high.	Check the setting of Pn100. The default setting is Kv = 40.0 Hz.	Set Pn100 to an appro- priate value.	-
Large Motor Speed	The setting of Pn102 (Posi- tion Loop Gain) is too high.	Check the setting of Pn102. The default setting is Kp = 40.0/s.	Set Pn102 to an appro- priate value.	-
Overshoot on Starting and Stop- ping	The setting of Pn101 (Speed Loop Integral Time Con- stant) is not appropriate.	Check the setting of Pn101. The default setting is Ti = 20.0 ms.	Set Pn101 to an appro- priate value.	-
6A	The setting of Pn103 (Moment of Inertia Ratio or Mass Ratio) is not appropri- ate.	Check the setting of Pn103.	Set Pn103 to an appro- priate value.	-
	The torque reference is satu- rated.	Check the waveform of the torque reference.	Use the mode switch.	-
	The force limits (Pn483 and Pn484) are set to the default values.	The default values of the force limits and Pn483 = 30% and Pn484 = 30%.	Set Pn483 and Pn484 to appropriate values.	page 7-27

			Continued from pre	vious page.
Problem	Possible Cause	Confirmation	Correction	Reference
	Noise interference occurred because of incorrect Encoder Cable specifications.	Turn OFF the Servo Sys- tem. Check the Encoder Cable to see if it satisfies specifications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm ² (stranded wire).	Use cables that satisfy the specifications.	-
	Noise interference occurred because the Encoder Cable is too long.	Turn OFF the Servo Sys- tem. Check the length of the Encoder Cable.	 Rotary Servomotors: The Encoder Cable length must be 50 m max. Linear Servomotors: Make sure that the Serial Converter Unit cable is no longer than 20 m and that the Linear Encoder Cable and the Sensor Cable are no longer than 15 m each. 	-
Absolute Encoder Position Deviation Error (The	Noise interference occurred because the Encoder Cable is damaged.	Turn OFF the Servo Sys- tem. Check the Encoder Cable to see if it is pinched or the sheath is damaged.	Replace the Encoder Cable and correct the cable installation envi- ronment.	-
position that was saved in the host con- troller when the power	The Encoder Cable was sub- jected to excessive noise interference.	Turn OFF the Servo Sys- tem. Check to see if the Encoder Cable is bundled with a high-current line or installed near a high-cur- rent line.	Correct the cable lay- out so that no surge is applied by high-current lines.	-
was turned OFF is dif- ferent from the posi- tion when	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Turn OFF the Servo Sys- tem. Check to see if the machines are correctly grounded.	Properly ground the machines to separate them from the FG of the encoder.	-
the power was next turned ON.)	There is a SERVOPACK pulse counting error due to noise.	Turn OFF the Servo Sys- tem. Check to see if there is noise interference on the I/O signal line from the encoder or Serial Converter Unit.	Implement counter- measures against noise for the encoder or Serial Converter Unit wiring.	-
	The encoder was subjected to excessive vibration or shock.	Turn OFF the Servo Sys- tem. Check to see if vibration from the machine occurred. Check the Servomotor installation (mounting sur- face precision, securing state, and alignment). Check the linear encoder installation (mounting sur- face precision and secur- ing method).	Reduce machine vibra- tion. Improve the mounting state of the Servomotor or linear encoder.	-
	A failure occurred in the encoder.	-	Turn OFF the Servo System. Replace the Servomotor or linear encoder.	-
	A failure occurred in the SER- VOPACK.	_	Turn OFF the Servo System. Replace the SERVOPACK.	-

Continued on next page.

Maintenance

Continued from previous page.

Problem	Possible Cause	Confirmation	Continued from pre	Reference
Absolute Encoder Position		Check the error detec- tion section of the host controller.	Correct the error detec- tion section of the host controller.	-
Deviation Error (The position that was		Check to see if the host controller is executing data parity checks.	Perform parity checks for the multiturn data or absolute encoder posi- tion data.	-
saved in the host con- troller when the power was turned OFF is dif- ferent from the posi- tion when the power was next turned ON.)	Host controller multiturn data or absolute encoder position data reading error	Check for noise interfer- ence in the cable between the SERVO- PACK and the host con- troller.	Implement counter- measures against noise and then perform parity checks again for the multiturn data or abso- lute encoder position data.	-
		Check the external power supply (+24 V) voltage for the input signals.	Correct the external power supply (+24 V) voltage for the input signals.	_
	The P-OT/N-OT (Forward Drive Prohibit or Reverse Drive Prohibit) signal was input. The P-OT/N-OT (Forward Drive Prohibit or Reverse Drive Prohibit) signal mal-	Check the operating con- dition of the overtravel limit switches.	Make sure that the overtravel limit switches operate correctly.	-
		Check the wiring of the overtravel limit switches.	Correct the wiring of the overtravel limit switches.	page 6-27
		Check the settings of the overtravel input signal allocations (Pn50A/Pn50B).	Set the parameters to correct values.	page 6-27
		Check for fluctuation in the external power supply (+24 V) voltage for the input signals.	Eliminate fluctuation from the external power supply (+24 V) voltage for the input signals.	_
Overtravel		Check to see if the opera- tion of the overtravel limit switches is unstable.	Stabilize the operating condition of the over- travel limit switches.	-
Occurred	functioned.	Check the wiring of the overtravel limit switches (e.g., check for cable damage and loose screws).	Correct the wiring of the overtravel limit switches.	-
	There is a mistake in the allo- cation of the P-OT or N-OT (Forward Drive Prohibit or	Check to see if the P-OT signal is allocated in Pn50A = $n.X\Box\Box\Box$.	If another signal is allo- cated in Pn50A =n.X□□□, allocate the P-OT signal instead.	
	Reverse Drive Prohibit) signal in Pn50A = $n.X\square\square\square$ or Pn50B = $n.\square\square\squareX$.	Check to see if the N-OT signal is allocated in Pn50B = $n.\Box\Box\BoxX$.	If another signal is allo- cated in Pn50B =n.□□□X, allocate the N-OT signal instead.	page 6-27
	The selection of the Servo- motor stopping method is	Check the servo OFF stopping method set in Pn001 = $n.\Box\BoxX$ or Pn001 = $n.\Box\BoxX\Box$.	Select a Servomotor stopping method other than coasting to a stop.	page 6-28
	not correct.	Check the torque control stopping method set in Pn001 = $n.\Box\BoxX$ or Pn001 = $n.\Box\BoxX\Box$.	Select a Servomotor stopping method other than coasting to a stop.	paye 0-20

			Continued from pre	
Problem	Possible Cause	Confirmation	Correction	Reference
Improper Stop Posi- tion for	The limit switch position and dog length are not appropriate.	-	Install the limit switch at the appropriate position.	-
Overtravel (OT) Signal	The overtravel limit switch position is too close for the coasting distance.	-	Install the overtravel limit switch at the appropriate position.	-
	Noise interference occurred because of incorrect Encoder Cable specifications.	Turn OFF the Servo Sys- tem. Check the Encoder Cable to see if it satisfies specifications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm ² (stranded wire).	Use cables that satisfy the specifications.	-
	Noise interference occurred because the Encoder Cable is too long.	Turn OFF the Servo Sys- tem. Check the length of the Encoder Cable.	 Rotary Servomotors: The Encoder Cable length must be 50 m max. Linear Servomotors: Make sure that the Serial Converter Unit cable is no longer than 20 m and that the Linear Encoder Cable and the Sensor Cable are no longer than 15 m each. 	_
Position	Noise interference occurred because the Encoder Cable is damaged.	Turn OFF the Servo Sys- tem. Check the Encoder Cable to see if it is pinched or the sheath is damaged.	Replace the Encoder Cable and correct the cable installation envi- ronment.	-
Deviation (without Alarm)	The Encoder Cable was sub- jected to excessive noise interference.	Turn OFF the Servo Sys- tem. Check to see if the Encoder Cable is bundled with a high-current line or installed near a high-cur- rent line.	Correct the cable lay- out so that no surge is applied by high-current lines.	-
	There is variation in the FG potential because of the influence of machines on the Servomotor side, such as a welder.	Turn OFF the Servo Sys- tem. Check to see if the machines are correctly grounded.	Properly ground the machines to separate them from the FG of the encoder.	-
	There is a SERVOPACK pulse counting error due to noise.	Turn OFF the Servo Sys- tem. Check to see if there is noise interference on the I/O signal line from the encoder or Serial Converter Unit.	Implement counter- measures against noise for the encoder wiring or Serial Converter Unit wiring.	-
	The encoder was subjected to excessive vibration or shock.	Turn OFF the Servo Sys- tem. Check to see if vibration from the machine occurred. Check the Servomotor installation (mounting sur- face precision, securing state, and alignment). Check the linear encoder installation (mounting sur- face precision and secur- ing method).	Reduce machine vibra- tion. Improve the mounting state of the Servomotor or linear encoder.	-

und from provid ntin \sim

Continued on next page.

			Continued from pre	vious page.
Problem	Possible Cause	Confirmation	Correction	Reference
	The coupling between the machine and Servomotor is not suitable.	Turn OFF the Servo Sys- tem. Check to see if posi- tion offset occurs at the coupling between machine and Servomotor.	Correctly secure the coupling between the machine and Servomotor.	-
Position Deviation (without Alarm)	Noise interference occurred because of incorrect I/O Sig- nal Cable specifications.	Turn OFF the Servo Sys- tem. Check the I/O Signal Cables to see if they sat- isfy specifications. Use shielded twisted-pair cables or screened twisted-pair cables with conductors of at least 0.12 mm ² (stranded wire).	Use cables that satisfy the specifications.	-
, anny	Noise interference occurred because an I/O Signal Cable is too long.	Turn OFF the Servo Sys- tem. Check the lengths of the I/O Signal Cables.	The I/O Signal Cables must be no longer than 3 m.	-
	An encoder fault occurred. (The pulse count does not change.)	-	Turn OFF the Servo System. Replace the Servomotor or linear encoder.	-
	A failure occurred in the SER- VOPACK.	_	Turn OFF the Servo System. Replace the SERVOPACK.	-
	The surrounding air tempera- ture is too high.	Measure the surrounding air temperature around the Servomotor.	Reduce the surround- ing air temperature to 40°C or less.	-
	The surface of the Servomo- tor is dirty.	Turn OFF the Servo Sys- tem. Visually check the surface for dirt.	Clean dirt, dust, and oil from the surface.	-
Servomotor Overheated	There is an overload on the Servomotor.	Check the load status with a monitor.	If the Servomotor is overloaded, reduce the load or replace the Servo Drive with a SERVOPACK and Ser- vomotor with larger capacities.	-
	Polarity detection was not performed correctly.	Check to see if electrical angle 2 (electrical angle from polarity origin) at any position is between ±10°.	Correct the settings for the polarity detection- related parameters.	-

Continued from previous page.

Parameter Lists

14

14.1List of Servo Parameters14-214.1.1Interpreting the Parameter Lists14-214.1.2List of Servo Parameters14-314.2List of MECHATROLINK-III Common Parameters14-4814.2.1Interpreting the Parameter Lists14-4814.2.2List of MECHATROLINK-III CommonParameters14-49

This chapter provides information on the parameters.

14.1.1 Interpreting the Parameter Lists

14.1 List of Servo Parameters

14.1.1 Interpreting the Parameter Lists

	 Al Ri Li Rotato al 	The parameter otary: The para near: The para ary Servomoto Il Servomotors pret the terms ails.	is used for both F ameter is used meter is used r terms are use . If you are usin accordingly. F	ch the parameter a Rotary Servomotors ar for only Rotary Sei for only Linear Sen ed for parameters t ng a Linear Servom Refer to the followir for Rotary Servor on page vi	nd Linear Serv rvomotors. vomotors. hat are app notor, you ne ng section fo	licable eed to or	that wil followir • The and • The	estart" indicate I be effective a Ig is executed. power supply i ON again. CONFIG comr ftware reset is	fter one c s turned (nand is se	of the OFF ent.
Parameter No.	Size	1	lame	Setting Range	Setting Unit	Default Setting	Applica- ble Motors	Why n Enabled	Classi- fication	Refer- ence
	2	Basic Funct	ion Selections	0000h to 10B1h	-	0000h	All	After restart	Setup	-
	If there are differences in the parameters for Rotary Servomotor and Linear Servomotor, information is provided for both. • Top row: For Rotary Servomotors • Bottom row: For Linear Servomotors Rotation Direction Selection							details. on on pag	letails.	
Pn000		n.000X	X Use CCW as the forward direction. Use the direction in which the linear encoder counts up as the forward direction.						-	
МЗ			1 Us	Use CW as the forward direction. (Reverse Rotation Mode) Use the direction in which the linear encoder counts down as the forward direction. (Reverse Movement Mode)						page 6-15
Symbols are provided when a parameter is valid only for a specific profile.										
• <u>M</u> 2	•		lid only for a MEC	HATROLINK-III standar	d servo profile.	·			1	
• <u>M</u> 2	•		lid only for a MEC		d servo profile. artup Selec	tion When			Referer	nce

14.1.2 List of Servo Parameters

The following table lists the parameters.

Note: Do not change the following parameters from their default settings. • Reserved parameters

- Parameters not given in this manualParameters that are not valid for the Servomotor that you are using, as given in the parameter table

Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence
Pn000	2	Basic Fund tions 0	ction Selec)-	0000h to 10B1h	-	0000h	All	After restart	Setup	-
		n.000X		nt Di Use Use War Use	rection Selection Direction Selection se CCW as the forward direction. se the direction in which the linear encoder counts up as the for- ard direction. se CW as the forward direction. (Reverse Rotation Mode) se the direction in which the linear encoder counts down as the rward direction. (Reverse Movement Mode)						ence
		n.00X0	Reserve	d par	ameter (Do no	ot change)				
		n.¤X¤¤	Reserve	d par	rameter (Do no	ot change)				
			Rotary/L nected	inea	r Servomotor S	Startup Se	election W	hen Encoder	Is Not Con-	Refere	ence
		n.X000 0			en an encoder ary Servomoto		nected, st	art as SERVC	PACK for		2 1 4
			1		en an encoder Servomotor.	is not cor	nected, st	art as SERVC	PACK for Lin	- page (5-14

Continued on next page.

Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
2	2	Application Selections			0000h to 1142h	_	0000h	All	After restart	Setup	-	
	Ī		Motor St	onni	ng Method fo	r Servo Ol	F and Gr	oup 1 Alarms		Refere	ence	
		n.000X	0		p the motor by							
			1	Sto	p the motor by dynamic brake	the apply	,		then release	page 6	6-37	
	_		2	Coa	ast the motor t	o a stop w	vithout the	dynamic brak	ке.			
		Overtrav	el St	opping Metho	d				Refere	ence		
	n.I		0		bly the dynamic ping method				op (use the			
			1				stop using the torque set in Pn406 as then servo-lock the motor.					
Pn001		n.□□X□	2		elerate the mo maximum toro				in Pn406 as	page 6	6-28	
			3	Dec Pn3	elerate the mo 0A and then s	otor to a st ervo-lock	op using t the motor.	he deceleratio	on time set in			
				4		elerate the mo 0A and then le			he deceleratio	on time set in		
	Ī		Main Cir	cuit l	Power Supply	AC/DC In	put Select	ion		Refere	ence	
			0		ut AC power as L3 terminals (ng the L1, L2	,		
		ľ	n.¤X¤¤	1	and	ut DC power as \ominus 2 terminals verter or the s	s or the B ⁻	$\stackrel{\cdot}{\ominus}$ and $\stackrel{\cdot}{\ominus}$ 2		0	page 6	5-13
	Ī	n.X000	Reserved	d pai	ameter (Do no	ot change.	.)					

Continued from previous page.

Continued	from	previous	page.
0011111000	110111	proviouo	pugo.

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refe enc	
	2	Application Selections	1 Function 2	0000h to 4213h	-	0011h	-	After restart	Setup	_	
			MECHAT Option	ROLINK Commar	d Positior	and Spee	ed Control	Applicable Motors	Refere	ence	
			0	Reserved parame	ter (Do no						
		n.🗆🗆 🛛 X	1	Use TLIM as the	orque limit						
			2	Reserved parame	· ·	0,		All	*1		
			3	Use P_TLIM or N P_CL or N_CL in							
		n.DDXD	Torque C	ontrol Option	Applicable Motors Refer		ence				
			0	Reserved parame							
			1	Use the speed lim speed limit.	All	*1					
n002			Encoder	Usage	Applicable Motors	Refere	ence				
		n.¤X¤¤	0	Use the encoder tions.	All						
			1	Use the encoder	coder.		page 7	page 7-32			
			2	Use the encoder encoder.	Rotary						
			External Encoder Usage					Applicable Motors	Refere	ence	
			0	Do not use an ex	ernal enco						
			0								
		n.X000	1	The external enco tion for CCW mot			ward direc-				
		n.XDDD			or rotation		ward direc-	Rotary	page -	11-6	
		n.X000	1	tion for CCW mot	or rotation ter (Do not oder moves	t change.) s in the rev		Rotary	page -	11-6	

		A	Continued from previous									
	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence				
Applicatior Selections		0000h to 105Fh	-	0002h	All	Immedi- ately	Setup	page 10-9				
	Analog Monitor 1 Signal Selection											
		Motor speed (1	V/1,000 m	nin ⁻¹)								
	00	Motor speed (1		,								
	01 -	Speed reference (1 V/1,000 min ⁻¹)										
		Speed reference	e (1 V/1,00	0 mm/s)								
	02	Torque reference			. ,							
		Force reference										
	03	Position deviation	`		,	0.05.1//						
	04	Position amplifier deviation (after electronic gear) (0.05 V/encoder pulse unit) Position amplifier deviation (after electronic gear) (0.05 V/linear encoder										
n.□□XX		pulse unit)										
	05	Position reference speed (1 V/1,000 min ⁻¹)										
		Position reference speed (1 V/1,000 mm/s)										
	06	Reserved parameter (Do not change.)										
	07	Load-motor position deviation (0.01 V/reference unit)										
	08	Positioning completion (positioning completed: 5 V, positioning not com- pleted: 0 V)										
	09	Speed feedforward (1 V/1,000 min ⁻¹)										
		Speed feedforward (1 V/1,000 mm/s)										
	0A -	Torque feedforward (1 V/100% rated torque)										
		Force feedforward (1 V/100% rated force)										
				0B	Active gain (1st gain: 1 V, 2nd gain: 2 V)							
	0C	Completion of position reference distribution (completed: 5 V, not completed: 0 V)										
	0D	External encoder speed (1 V/1,000 min ⁻¹ : value at the motor shaft)										
	0E	Reserved parameter (Do not change.)										
	OF	Reserved parameter (Do not change.)										
	10	Main circuit DC voltage										
	11 to 5F	Reserved param	ieters (Do	not chang	e.)							
	Reserved p	arameter (Do no	ot change.)								
	Reserved p	arameter (Do no	ot change.)								
		11 to 5F X□□ Reserved p	11 to 5F Reserved param XDD Reserved parameter (Do not	11 to 5F Reserved parameters (Do XDD Reserved parameter (Do not change.	11 to 5F Reserved parameters (Do not change) XDD Reserved parameter (Do not change.)	11 to 5F Reserved parameters (Do not change.) XDD Reserved parameter (Do not change.)	11 to 5F Reserved parameters (Do not change.) XDD Reserved parameter (Do not change.)	11 to 5F Reserved parameters (Do not change.) XDD Reserved parameter (Do not change.)				

Continued from previous page.

Continued from previous page.

Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence		
	2	Application Selections		0000h to 105Fh	_	0000h	All	Immedi- ately	Setup	page 10-9		
	Ī		Analog Mo									
				Motor speed (1		nin ⁻¹)						
			00	Motor speed (1		,						
				Speed reference	,	,						
			01	Speed reference	、 ,	,						
				Torque reference	、 ,	,	raue)					
			02				. ,					
			03	Force reference (1 V/100% rated force) Position deviation (0.05 V/reference unit)								
				Position amplifie	r deviatior	n (after eleo	ctronic gear) (0.05 V/enco	der pulse	unit)		
			04	Position amplifier deviation (after electronic gear) (0.05 V/linear encoder pulse unit)								
			05	Position reference speed (1 V/1,000 min ⁻¹)								
			05	Position reference speed (1 V/1,000 mm/s)								
			06	Reserved parameter (Do not change.)								
Pn007		n.□□XX	07	Load-motor position deviation (0.01 V/reference unit)								
			08	Positioning completion (positioning completed: 5 V, positioning not completed: 0 V)								
			09	Speed feedforw	ard (1 V/1	,000 min ⁻¹)						
				Speed feedforward (1 V/1,000 mm/s)								
			0A	Torque feedforward (1 V/100% rated torque)								
				Force feedforward (1 V/100% rated force)								
					0B	Active gain (1st gain: 1 V, 2nd gain: 2 V) Completion of position reference distribution (completed: 5 V, not com-						
			0C	Completion of p pleted: 0 V)	osition ref	erence dis	tribution (com	pleted: 5 V,	not com-			
			0D	External encoder speed (1 V/1,000 min ⁻¹ : value at the motor shaft)								
			0E	Reserved parameter (Do not change.)								
			OF	Reserved parameter (Do not change.)								
			10	Main circuit DC voltage								
			11 to 5F	Reserved param	eters (Do	not chang	e.)					
		n.¤X¤¤	Reserved	parameter (Do no	ot change.	.)						
	n.X□□□ Reserved parameter (Do not change.)											

Continued on next page.

									tinued fron	i previou.	s pug			
Parameter No.	Size	١	Name		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refei ence			
	2	Applicatio Selections	n Function 8 8		0000h to 7121h	-	4000h	Rotary	After restart	Setup	١			
			-		Voltage Alarm	, v				Refere	ence			
		n.DDDX	0 Output alarm (A.830) for low battery voltage.								3-2			
			1	Out	tput warning (A	.930) for I	ow battery	voltage.		13				
			Function	Sel	ection for Und	ervoltage				Refere	ence			
Pn008			0	Do	not detect und	lervoltage.								
-11000		n.🗆 🗆 X 🗆	1	1 Detect undervoltage warning and limit torque at host controller.										
			2	Det Pn₄	ect undervolta 125 (i.e., only ir	ge warning n SERVOP	g and limit ACK).	torque with P	n424 and		_ page 7-16			
		n.¤X¤¤	Warning Detection Selection								ence			
			0	0 Detect warnings.										
			1 Do not detect warnings except for A.971.											
	n.XDDD Reserved parameter (Do not change.)													
	_	Applicatio	n Function		0000h to				After					
	2	Selections	s 9		0121h	-	0010h	All	restart	Tuning	-			
	n.DDDX Reserved parameter (Do not change.)													
	Current Control Mode Selection									Refere	nce			
		n.🗆 🗆 X 🗆	0 Use current control mode 1.											
Pn009			1 Use current control mode 2								-74			
			2 Reserved parameter (Do not change.)											
			Speed D	Speed Detection Method Selection										
		n.¤X¤¤	0 Use speed detection 1.											
			0				1 Use speed detection 2.							
					1	on 2.				page 9	-75			

Continued from previous page.

Continued from previous page.

			Continued from previous pag												
Parameter No.	Size	Na	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence					
	2	Application Selections		0000h to 1044h	-	0001h	All	After restart	Setup	-					
			Motor Stop	ping Method fo	r Group 2	Alarms			Refer	ence					
				pply the dynami opping method				op (use the							
			1 tł	ne maximum toro	elerate the motor to a stop using the torque set in Pn406 as naximum torque. Use the setting of Pn001 = $n.\Box\Box\BoxX$ for the s after stopping.										
		n.DDDX		ecelerate the mo				t in Pn406 as	page	page 6-39					
			3 P	ecelerate the me n30A. Use the s copping.						-					
				ecelerate the monotonic tension of			he decelerati	on time set ir	٦						
Pn00A			Stopping M	lethod for Force	ed Stops				Refer	ence					
		n.□□X□		pply the dynami opping method				op (use the		page 7-57					
			1 tł	ecelerate the mo ne maximum toro atus after stopp	que. Use tl	top using t ne setting (the torque set of Pn001 = n.	t in Pn406 as DDDX for th	ie						
				ecelerate the mo				t in Pn406 as	page						
			3 P	ecelerate the me n30A. Use the s copping.											
				ecelerate the me n30A and then I			he decelerati	on time set ir	٦						
		n. Reserved parameter (Do not change.)													
		n.XDDD Reserved parameter (Do not change.)													
	2	Application Selections		0000h to 1121h	-	0000h	All	After restart	Setup	-					
	-		Operator Pa	r Parameter Display Selection											
		n.000X	0 Display only setup parameters.							Reference					
		-	1 Display all parameters.							page 6-4					
Pn00B			Motor Stopp	otor Stopping Method for Group 2 Alarms											
TIUUB			0 St	op the motor by	setting th	e speed re	ference to 0.								
		n.DDXD	Apply the dynamic brake or coast the motor to a stop (use the stopping method set in $Pn001 = n.\Box\Box\BoxX$).							6-39					
			2 Se	et the stopping n	nethod wit	h Pn00A =	= n.□□□X.								
		n.¤X¤¤	Reserved pa	rameter (Do no	t change.)										
		n.XDDD	Reserved pa	rameter (Do no	t change.)									

		Continued from previous page.											
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence			
	2	Application Selections	r Function	0000h to 0131h	-	0000h	_	After restart	Setup	page 8-20			
				0.0				Tootart					
		n.000X	Function Sel	ection for Test	without a	Motor			Applical Motor				
		11.000X	+	able tests with able tests with					All				
			Encoder Res	olution for Tes	ts without	a Motor			Applical Motor				
Pn00C			0 Use	e 13 bits.									
		n.¤¤X¤		e 20 bits.					Rotar	/			
				e 22 bits.					-				
			3 Use	e 24 bits.									
		n.¤X¤¤		O Use an incremental encoder.									
		11.0700		0 Use an incremental encoder.1 Use an absolute encoder.									
			I Use										
		n.XDDD	Reserved pa										
	2	Application Selections		0000h to 2001h	-	0000h	All	Immedi-	Setup	page 6-30			
		Selections		200111				ately		0-30			
		n.DDDX	Reserved parameter (Do not change.)										
		n.□□X□ Reserved parameter (Do not change.)											
Pn00D		n.¤X¤¤	Reserved pa	rameter (Do no	ot change.)							
				arning Detecti									
		n.XDDD		not detect ove		rnings.							
				served parame	0	change)							
			2 110			i onangoi,							
Pn00E	2	Reserved (Do not ch		-	-	0000h	All	_	_	-			
	2	Application Selections	n Function F	0000h to 2011h	-	0000h	All	After restart	Setup	_			
				Reference	<u>م</u>								
		n.🗆 🗆 🗆 X	,										
Pn00F				page 10-15									
		n.DDXD	Reserved pa	rameter (Do no	ot change.)							
		n.¤X¤¤	Reserved pa	rameter (Do no	ot change.)							
		n.XDDD	Reserved pa	rameter (Do no	ot change.)							
Pn021	2	Reserved p	parameter (Do e.)	-	-	0000	All	_	_	_			
	I		,	Continue	1								

Continued from previous page.

_								tinued from		1 0
Size	١	Name		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence
2	Applicatio Selections	n Function 3 22	1	0000h to 0011h	-	0000h	All	After restart	Setup	-
		Overtrav	el Re	lease Method	Selection				Refere	nce
		0	Over	rtravel exists w	hile the P-	OT or N-C	T signal is be	eing input.		
	1.000	1	curre	ent position of	the workp				page 6	5-31
r	n.00X0	Reserved	d para	ameter (Do no	t change.)					
r	n.0X00	Reserved	d para	ameter (Do no	t change.)					
r	n.XDDD	Reserved	d para	ameter (Do no	t change.)					
_	Applicatio	n Function	1	0000h to				After		
2				0011h	-	0000h	All	restart	Setup	-
_		Т								
			1	, .					Refere	ence
	n.🗆 🗆 🗆 X								page 6	6-36
- 1			Do	not use the bu	lit-in drake	e relay.				
		Built-in I	Brake	e Relay Life Ala	arm Enabl	e Selectio	n		Refere	ence
	n.🗆 🗆 X 🗆	0			,				page	
		1	Do	not detect buil	t-in brake	relay life al	arm.		15	•
	n.¤X¤¤	Reserve	d par	ameter (Do no	ot change.)				
1	n.XDDD	Reserve	d par	ameter (Do no	ot change.)				
			- 1			/				
2			(Do	0000h to 2111h	-	0000h	-	_	-	_
2			1	0000h to 1111h	-	0000h	Linear	After restart	Setup	-
		Polarity S	Senso	or Selection					Refere	ence
r	n.000X	0	Use	polarity senso	r.				nage f	5-23
		1	Do r	not use polarity	sensor.				page	
		Motor Ph	nase \$	Sequence Sele	ection				Refere	ence
r	n.00X0	0				se sequen	ce of U, V, an	d W.	h	 3_01
		1	Set	a phase-B lead	d as a pha	se sequen	ce of U, V, an	d W.	paye (-21
r	n.0X00	Reserved	d para	ameter (Do no	t change.)					
		Calculati	on M	ethod for Max	imum Spe	ed or Enc	oder Output	Pulses	Refere	ence
	n.X000	0 Calculate the encoder output pulse setting for a fixed maximum speed.								
r			0000	Ju.					page '	
	2 r r r 2 2 2	2 Application Selections n.□□□X n.□□X□ n.□□X□□ n.□ n.□□X□□ n.□ 2 Application Selections 2 Application Selections 1 □ 2 Application Selections 1 □ 2 Application Selections 1 □ 2 Reserved not change 2 Application Selections	2 Application Function Selections 22 n.□□□□X Overtrave n.□□□X□ Reserved n.□□X□□ Reserved n.□□□□X Reserved n.□□□□X Reserved n.□□□□X Reserved n.□□□□X Reserved n.□□□□X 0 n.□□□□X 0 n.□□□□X 0 n.□□□□X 0 n.□□□□X Reserved n.□□□□ Reserved 1 0	2 Application Function Selections 22 N.□□□□X Overtravel Re 0 Over 1 Curr n.□□X□ Reserved para n.□X□□ Reserved para n.□□X□ Reserved para n.□□□X□ Reserved para n.□□□X□ Reserved para n.□□□X□ Reserved para n.□□□X□ 0 1 Do n.□□□X□ 0 0 Use n.□□□X□ 0 0 Use 1 Do 1 Do 1 Do 1 Do	2 Application Function Selections 22 0000 to 0011h 1 0 0vertravel Release Method 0 0 0 0 0vertravel exists w 0vertravel exists w 1 0 1 0 0vertravel exists w 0vertravel exists w 0 vertravel exists w 0 vertravel exists w 0 1 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 1 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 0 1 0 0 2 1	Name Range Unit 2 Application Function Selections 22 0000h to 0011h - 1 Overtravel Release Method Selection 0 0 Overtravel exists while the P- current position of the workp nal or N-OT signal. 1 Implication Function 0 Overtravel exists while the P- current position of the workp nal or N-OT signal. 1 Reserved parameter (Do not change.) 1 Do not use the built-in brake relay. 1 Do not use the built-in brake relay. 1 Do not detect built-in brake relay lift 1 Do not detect built-in brake relay lift 1 Do not detect built-in brake relay lift 1 Do not detect built-in brake relay. 1 Delect	Name Range Unit Setting 2 Application Function Selections 22 0000h to 0011h – 0000h 0 Overtravel Release Method Selection – 0000h 0 Overtravel exists while the P-OT or N-C 1 Overtravel exists while the P-OT or N-C Current position of the workpiece is sep nal or N-OT signal. n.□□X□ Reserved parameter (Do not change.) n.□X□□ Reserved parameter (Do not change.) n.□X□□ Reserved parameter (Do not change.) n.□□X□ Reserved parameter (Do not change.) n.□□□X□ Reserved parameter (Do not change.) 1 Do not use the built-in brake relay. 1 Do not use the built-in brake relay. 1 Do not detect built-in brake relay life alarm. 1 Do not detect built-in brake relay life alarm. 1 Do not detect built-in brake relay life alarm. 1 Do not detect built-in brake relay life alarm. 1 Do not detect built-in brake relay life alarm. 1 Do not detect built-in brake relay life alarm. 1 Do not detect built-in brake relay life alarm. 1 Do not detect built-in brake relay life alarm. 1 </td <td>Name Range Unit Setting Motors 2 Application Function selections 22 0000n to 0011h - 0000h All 1 Overtravel Release Method Selection 0 0 Overtravel exists while the P-OT or N-OT signal is to 0 Overtravel exists while the P-OT or N-OT signal is to 0 1 Overtravel exists while the P-OT or N-OT signal. n. Implication Function 0 Overtravel exists while the P-OT or N-OT signal is in 0 n. Implication Function Reserved parameter (Do not change.) Implication Function Implication Function 0000h to 0011h 0 0000h to 0011h Implication Function 1 Do not use the built-in brake relay. 1 Do not use the built-in brake relay. Implication Function 0 Implication Function 0 Use the built-in brake relay. 1 Do not use the built-in brake relay. 1 Do not use the built-in brake relay. Implication Function Implication Function 0 Implication Function Implication Function<td>Built-in Bailt-in Control on the second parameter (Do not change.) Control on the second parameter (Do not change.) All After restart 2 Application Function 0000h to 001h 0 - 0000h All After restart 0 Overtravel Release Method Selection 0 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 Overtravel exists while the P-OT or N-OT signal is being input. 1 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 1 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 1 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 1 1 Corrent position of the workpiece is separated from the P-OT signal and the ourrent position of the workpiece is separated from the P-OT signal and the ourrent position function 0 1 Reserved parameter (Do not change.) Intervention 0 0 After restart 1 Do not use the built-in brake relay. 1 Do not detect built-in brake relay. Into not change.) Intor</td><td>Built-in Brake Relay Usage Selection All After restart Setup 2 Application Function 0000h to 0011h - 0000h All After restart Setup n.DDDX Overtravel Release Method Selection Refere Refere Refere 0 Overtravel exists while the P-OT or N-OT signal is being input. page 6 n.DDDX Reserved parameter (Do not change.) nal or N-OT signal. page 6 Refere page 6 n.DDXD Reserved parameter (Do not change.) </td></td>	Name Range Unit Setting Motors 2 Application Function selections 22 0000n to 0011h - 0000h All 1 Overtravel Release Method Selection 0 0 Overtravel exists while the P-OT or N-OT signal is to 0 Overtravel exists while the P-OT or N-OT signal is to 0 1 Overtravel exists while the P-OT or N-OT signal. n. Implication Function 0 Overtravel exists while the P-OT or N-OT signal is in 0 n. Implication Function Reserved parameter (Do not change.) Implication Function Implication Function 0000h to 0011h 0 0000h to 0011h Implication Function 1 Do not use the built-in brake relay. 1 Do not use the built-in brake relay. Implication Function 0 Implication Function 0 Use the built-in brake relay. 1 Do not use the built-in brake relay. 1 Do not use the built-in brake relay. Implication Function Implication Function 0 Implication Function Implication Function <td>Built-in Bailt-in Control on the second parameter (Do not change.) Control on the second parameter (Do not change.) All After restart 2 Application Function 0000h to 001h 0 - 0000h All After restart 0 Overtravel Release Method Selection 0 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 Overtravel exists while the P-OT or N-OT signal is being input. 1 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 1 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 1 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 1 1 Corrent position of the workpiece is separated from the P-OT signal and the ourrent position of the workpiece is separated from the P-OT signal and the ourrent position function 0 1 Reserved parameter (Do not change.) Intervention 0 0 After restart 1 Do not use the built-in brake relay. 1 Do not detect built-in brake relay. Into not change.) Intor</td> <td>Built-in Brake Relay Usage Selection All After restart Setup 2 Application Function 0000h to 0011h - 0000h All After restart Setup n.DDDX Overtravel Release Method Selection Refere Refere Refere 0 Overtravel exists while the P-OT or N-OT signal is being input. page 6 n.DDDX Reserved parameter (Do not change.) nal or N-OT signal. page 6 Refere page 6 n.DDXD Reserved parameter (Do not change.) </td>	Built-in Bailt-in Control on the second parameter (Do not change.) Control on the second parameter (Do not change.) All After restart 2 Application Function 0000h to 001h 0 - 0000h All After restart 0 Overtravel Release Method Selection 0 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 Overtravel exists while the P-OT or N-OT signal is being input. 1 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 1 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 1 0 Overtravel exists while the P-OT or N-OT signal is being input. 0 1 1 Corrent position of the workpiece is separated from the P-OT signal and the ourrent position of the workpiece is separated from the P-OT signal and the ourrent position function 0 1 Reserved parameter (Do not change.) Intervention 0 0 After restart 1 Do not use the built-in brake relay. 1 Do not detect built-in brake relay. Into not change.) Intor	Built-in Brake Relay Usage Selection All After restart Setup 2 Application Function 0000h to 0011h - 0000h All After restart Setup n.DDDX Overtravel Release Method Selection Refere Refere Refere 0 Overtravel exists while the P-OT or N-OT signal is being input. page 6 n.DDDX Reserved parameter (Do not change.) nal or N-OT signal. page 6 Refere page 6 n.DDXD Reserved parameter (Do not change.)

Continued on next page.

14

14-11

		Continued from previous page.								
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Application Selections		0000h to 1111h	-	0000h	All	After restart	Setup	page 7-21
		n.000X	0	Pulse Output Sele Output phase-C p	oulses only					
Pn081			1	Output phase-C p	Duises in D	oth the for	ward and reve	erse direction	IS.	
		n.□□X□		parameter (Do no						
	-	n.□X□□	1	parameter (Do no		,				
		n.XOOO	Reserved	parameter (Do no	ot change.	.)				
Pn100	2	Speed Loc	op Gain	10 to 20,000	0.1 Hz	400	All	Immedi- ately	Tuning	page 9-82
Pn101	2	Speed Loc Time Cons		15 to 51,200	0.01 ms	2000	All	Immedi- ately	Tuning	page 9-82
Pn102	2	Position Lo	oop Gain	10 to 20,000	0.1/s	400	All	Immedi- ately	Tuning	page 9-82
Pn103	2		f Inertia Rat	io 0 to 20,000	1%	100	All	Immedi- ately	Tuning	page 9-82
Pn104	2	Second Sp Gain	•	10 to 20,000	0.1 Hz	400	All	Immedi- ately	Tuning	page 9-66
Pn105	2	•	ne Constar		0.01 ms	2000	All	Immedi- ately	Tuning	page 9-66
Pn106	2	Second Po Gain	osition Loop	0 10 to 20,000	0.1/s	400	All	Immedi- ately	Tuning	page 9-66
Pn109	2	Feedforwa		0 to 100	1%	0	All	Immedi- ately	Tuning	page 9-93
Pn10A	2	Constant	rd Filter Tin	0 to 6,400	0.01 ms	0	All	Immedi- ately	Tuning	page 9-93
	2	Gain Appli tions	cation Sele	c- 0000h to 5334h	-	0000h	All	-	Setup	-
										_
			Mode Sw	itching Selection				When Enabled	Refere	ence
				Use the internal to (level setting: Pn1		ence as th	e condition			
			1	Use the speed ref ting: Pn10D).						
		n.000X		Use the speed ref ting: Pn181).	erence as	the condit	ion (level set-			
				Use the accelerat setting: Pn10E).	ion referen	ce as the	condition (leve	l Immedi- ately	page §	9-94
Pn10B				Use the accelerat setting: Pn182).	ion referen	ce as the	condition (leve	el .		
				Use the position of ting: Pn10F).	deviation a	s the cond	lition (level set	-		
			4	Do not use mode	switching.					
			Speed Lo	op Control Metho	od			When Enabled	Refere	ence
		n.DDXD		PI control				After		
			-	I-P control Reserved parame	tors (Do pr	at change)	restart	page §	9-89
				and 3 Reserved parameters (Do not change.)						
		n.¤X¤¤	Reserved	parameter (Do no	ot change.)				
		n.XDDD	Reserved	parameter (Do no	ot change)				

Continued from previous page

	Continued from previous pa								s page.
Parameter No.	Size	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn10C	2	Mode Switching Level for Torque Reference	0 to 800	1%	200	All	Immedi- ately	Tuning	page 9-94
Pn10D	2	Mode Switching Level for Speed Reference	0 to 10,000	1 min ⁻¹	0	Rotary	Immedi- ately	Tuning	page 9-94
Pn10E	2	Mode Switching Level for Acceleration	0 to 30,000	1 min ⁻¹ /s	0	Rotary	Immedi- ately	Tuning	page 9-94
Pn10F	2	Mode Switching Level for Position Deviation	0 to 10,000	1 refer- ence unit	0	All	Immedi- ately	Tuning	page 9-94
Pn11F	2	Position Integral Time Constant	0 to 50,000	0.1 ms	0	All	Immedi- ately	Tuning	page 9-96
Pn121	2	Friction Compensation Gain	10 to 1,000	1%	100	All	Immedi- ately	Tuning	page 9-66, page 9-70
Pn122	2	Second Friction Com- pensation Gain	10 to 1,000	1%	100	All	Immedi- ately	Tuning	page 9-66, page 9-70
Pn123	2	Friction Compensation Coefficient	0 to 100	1%	0	All	Immedi- ately	Tuning	page 9-70
Pn124	2	Friction Compensation Frequency Correction	-10,000 to 10,000	0.1 Hz	0	All	Immedi- ately	Tuning	page 9-70
Pn125	2	Friction Compensation Gain Correction	1 to 1,000	1%	100	All	Immedi- ately	Tuning	page 9-70
Pn131	2	Gain Switching Time 1	0 to 65,535	1 ms	0	All	Immedi- ately	Tuning	page 9-66
Pn132	2	Gain Switching Time 2	0 to 65,535	1 ms	0	All	Immedi- ately	Tuning	page 9-66
Pn135	2	Gain Switching Waiting Time 1	0 to 65,535	1 ms	0	All	Immedi- ately	Tuning	page 9-66
Pn136	2	Gain Switching Waiting Time 2	0 to 65,535	1 ms	0	All	Immedi- ately	Tuning	page 9-66
	2	Automatic Gain Switch- ing Selections 1	0000h to 0052h	-	0000h	All	Immedi- ately	Tuning	page 9-66
	1								

Continued from previous page	Continued	from	previous	page
------------------------------	-----------	------	----------	------

			Gain Sw	ritchi	ng Selection						
			0	The	e manual gain s e gain is switche s (SVCMD_IO).		lly with G-	SEL in the se	rvo comman	d output s	ig-
		n.🗆🗆 🗆 X	1	Res	served paramet	er (Do no	t change.)				
			2	The sat	e automatic gai e gain settings isfied. The gain n A is not satisfi	1 switch a settings 2	utomatical	ly to 2 when			
Pn139			Gain Sw	vitchi	ng Condition A						
			0	1	DIN (Positioning		ion Output) signal turns	ON		
			1	-	OIN (Positioning						
		n.DDXD	2	-	EAR (Near Outp			,			
			3	-	EAR (Near Outp	, 0					
			4	Pos	sition reference	filter outp	out is 0 and	position refe	rence input i	s OFF.	
			5	Pos	sition reference	input is C	N.				
		n.OXOO	Beserve	d na	rameter (Do no	t change)				
			11636176	u pa		t change	•)				
		n.X000	Reserve	d pa	rameter (Do no	t change	.)				
Pn13D	2	Current Ga	ain Level		100 to 2,000	1%	2000	All	Immedi- ately	Tuning	page 9-74

Continued on next page.

	Continued									s page.
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Model Folletrol-Relate	owing Con- d Selections	0000h to 1121h	-	0100h	All	Immedi- ately	Tuning	_
					I	I	<u> </u>			
			Model Follo	wing Control Se	election				Referer	ice
		n.🗆 🗆 🗆 X	0 Do 1	not use model f	ollowing c	ontrol.			page 9-	90
			1 Use	model following	g control.				page e	
	[Vibration Su	ppression Sele	ction				Referen	ice
		n.DDXD	+	not perform vibr					_	
			+	orm vibration su				,	page 9-	90
D.140			2 Perf	orm vibration su	uppressior	n for two s	pecific freque	ncies.		
Pn140				ppression Adju					Referen	ice
		n.¤X¤¤	0 tio	not adjust vibr n of autotuning st reference, an	without a	host refere			- page 9-	30
			1 au	ljust vibration su totuning withou ence, and custo	t a host re				page 9-	
			Speed Feed	forward (VFF)/1	Forque Fee	edforward	(TFF) Selecti	on	Referer	ice
		n.X000		not use model ard together.	following	control an	d speed/torqu	ue feedfor-		
				e model followi gether.	ng control	and speed	d/torque feed	forward	- page 9-	33
		-		-						
Pn141	2	Model Foll trol Gain	owing Con-	10 to 20,000	0.1/s	500	All	Immedi- ately	Tuning	page 9-90
Pn142	2	Model Foll trol Gain C	owing Con- Correction	500 to 2,000	0.1%	1000	All	Immedi- ately	Tuning	page 9-66
Pn143	2		owing Con- the Forward	0 to 10,000	0.1%	1000	All	Immedi- ately	Tuning	page 9-90
Pn144	2		owing Con- the Reverse	0 to 10,000	0.1%	1000	All	Immedi- ately	Tuning	page 9-90
Pn145	2	Vibration S Frequency	Suppression 1	10 to 2,500	0.1 Hz	500	All	Immedi- ately	Tuning	page 9-59
Pn146	2	Vibration S Frequency	Suppression 1	10 to 2,500	0.1 Hz	700	All	Immedi- ately	Tuning	page 9-59
Pn147	2		owing Con- Feedforward ation	0 to 10,000	0.1%	1000	All	Immedi- ately	Tuning	page 9-90
Pn148	2	Second M ing Contro	odel Follow- I Gain	10 to 20,000	0.1/s	500	All	Immedi- ately	Tuning	page 9-66
Pn149	2		odel Follow- I Gain Correc-	500 to 2,000	0.1%	1000	All	Immedi- ately	Tuning	page 9-66
Pn14A	2	Vibration S Frequency	Suppression 2	10 to 2,000	0.1 Hz	800	All	Immedi- ately	Tuning	page 9-59
Pn14B	2	Vibration S Correction	Suppression 2	10 to 1,000	1%	100	All	Immedi- ately	Tuning	page 9-59

Continued from previous page.

Continued from previous page.

	Continued from previous page									s page.
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Control-Re tions	lated Selec-	0000h to 0021h	-	0021h	All	After restart	Tuning	-
		-1			L				1	
			Model Follow	ving Control Ty	pe Select	ion			Refere	ence
		n.🗆🗆 🛛 X		e model followir	0	21			page 9	9-92
			1 Use	e model followin	ng control	type 2.			pago	
Pn14F			-	ype Selection					Refere	ence
		n.🗆🗆 X 🗆		tuning-less ty						. 10
				tuning-less ty tuning-less ty					page 9	9-13
						\				
		n.¤X¤¤	Reserved par	rameter (Do no	ot change.)				
		n.XDDD	Reserved par	ameter (Do no	ot change.)				
			0	00001.14				Las es ell'		
	2		ance Con- d Selections	0000h to 0011h	-	0010h	All	Immedi- ately	Tuning	-
			Anti-Resonar	nce Control Se	election				Refere	ence
		n.🗆🗆 X	0 Do	not use anti-re	sonance c	ontrol.) 51
			1 Use	anti-resonanc	e control.				page 9	9-01
			Anti-Resonar	nce Control Ad	ljustment	Selection			Refere	ence
Pn160		n.00X0	0 tion	not adjust anti- of autotuning rence, and cus	without a l	host refere			st	
			1 auto	ust anti-resona otuning withou e, and custom	t a host re				- page 9	9-32
		n.¤X¤¤	Reserved par	ameter (Do no	ot change.)				
				•	-	,				
		n.XOOO	Reserved par	ameter (Do no	ot change.)				
Pn161	2	Anti-Resor quency	nance Fre-	10 to 20,000	0.1 Hz	1000	All	Immedi- ately	Tuning	page 9-51
Pn162	2	Anti-Resor Correction		1 to 1,000	1%	100	All	Immedi- ately	Tuning	page 9-51
Pn163	2	Anti-Resor ing Gain	ance Damp-	0 to 300	1%	0	All	Immedi- ately	Tuning	page 9-51
Pn164	2	Anti-Resor Time Cons rection	ance Filter tant 1 Cor-	-1,000 to 1,000	0.01 ms	0	All	Immedi- ately	Tuning	page 9-51
Pn165	2	Anti-Resor Time Cons rection	ance Filter tant 2 Cor-	-1,000 to 1,000	0.01 ms	0	All	Immedi- ately	Tuning	page 9-51
Pn166	2	Anti-Resor ing Gain 2	ance Damp-	0 to 1,000	1%	0	All	Immedi- ately	Tuning	page 9-54

Continued on next page.

							Cor	tinued from	n previou	s page.	
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Tuning-less Related Se	s Function- elections	0000h to 2711h	-	1401h	All	_	Setup	page 9-12	
						I				I	
			Tuning-less	Selection					Whe Enab		
		n.□□□X		sable tuning-les		•			Afte		
			1 En	able tuning-less	s function.				Whe		
		n.00X0	Speed Cont						Enab		
Pn170				e for speed cor		se host co	ntroller for po	sition contro	Afte I. resta		
			Rigidity Lev	el					Whe		
		n.¤X¤¤		et the rigidity lev	ol				Enab Imme		
			0.07 36		ei.				ate	У	
		n.X000	Tuning-less	Load Level					Whe Enab		
			0 to 2 Se	t the load level	for the tun	iing-less fu	nction.		Imme atel		
			· · · · ·								
Pn181	2	for Speed		erence 0.10.10,000 1 mm/s 0 Linear ately							
Pn182	2	Mode Swit for Acceler	ching Level ation	0 to 30,000	1 mm/s ²	0	Linear	Immedi- ately	Tuning	page 9-94	
Pn205	2	Multiturn L	imit	0 to 65,535	1 rev	65535	Rotary	After restart	Setup	page 7-37	
	2	Position Control tion Select	ontrol Func- ions	0000h to 2210h	-	0010h	All	After restart	Setup	-	
		n.DDDX	Reserved pa	arameter (Do no	ot change.)					
		n.🗆🗆 X 🗆	Reserved pa	arameter (Do no	ot change.	.)					
		n.¤X¤¤	Reserved pa	arameter (Do no	ot change.)					
Pn207			/COIN (Posi	tioning Comple	tion Outp	ut) Signal	Output Timin	g	Refe		
			0 sa	utput when the a me or less than idth).							
		n.X000	1 or	utput when the a less than the se d the reference	etting of Pi	n522 (Posi	tioning Comp	leted Width)	page	7-12	
			2 or	utput when the a less than the se d the reference	etting of Pi	n522 (Posi [,]					
		1	1 scale								
Pn20A	4	Number of Encoder S	External cale Pitches	4 to 1,048,576	pitch/ revolu- tion	32768	Rotary	After restart	Setup	page 11-7	
Pn20E	4	Electronic (Numerato	Gear Ratio r)	1 to 1,073,741,824	1	16	All	After restart	Setup	page 6-43	
Pn210	4		Gear Ratio	1 to 1,073,741,824	1	1	All	After restart	Setup	page 6-43	
Pn212	4	Number of Output Pul	Encoder	16 to 1,073,741,824	1 P/Rev	2048	Rotary	After restart	Setup	page 7-24	
		Supuri u		1,010,141,024	1			rootart		1 27	

Continued from previous page.

	Continued from previous page.									
Parameter No.	Size	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
	2	Fully-closed Control Selections	0000h to 1003h	_	0000h	Rotary	After restart	Setup	page 11-10	
		n.□□□X Reserved p	parameter (Do n	ot change.	.)					
Pn22A		n.□□X□ Reserved p	parameter (Do n	ot change)					
		n.□X□□ Reserved p	parameter (Do no	ot change)					
			d Control Speed		k Selectio	n				
			lse motor encod	•						
			lse external enco	oder speed						
	2	Position Control Expan sion Function Selection		-	0000h	All	After restart	Setup	page 9-76	
Pn230		n. DDDX 0 C	Compensation D Compensate forw Compensate reve	ard referer						
		n.□□X□ Reserved p	parameter (Do n	ot change.	.)					
		n.□X□□ Reserved p	parameter (Do n	ot change.)					
		n.XDDD Reserved p	parameter (Do no	ot change.)					
Pn231	4	Backlash Compensatic	n -500,000 to 500,000	0.1 ref- erence units	0	All	Immedi- ately	Setup	page 9-76	
Pn233	2	Backlash Compensa- tion Time Constant	0 to 65,535	0.01 ms	0	All	Immedi- ately	Setup	page 9-77	
Pn281	2	Encoder Output Resolution	^{I-} 1 to 4,096	1 edge/ pitch	20	All	After restart	Setup	page 7-25	
Pn282	4	Linear Encoder Scale Pitch	0 to 6,553,600	0.01 μm	0	Linear	After restart	Setup	page 6-16	
Pn304	2	Jogging Speed	0 to 10,000	Rotary: 1 min ⁻¹	500	Rotary	Immedi- ately	Setup	page 8-7	
Pn305	2	Soft Start Acceleration Time	0 to 10,000	1 ms	0	All	Immedi- ately	Setup	*1	
Pn306	2	Soft Start Deceleration Time	0 to 10,000	1 ms	0	All	Immedi- ately	Setup	*1	
Pn308	2	Speed Feedback Filter Time Constant	0 to 65,535	0.01 ms	0	All	Immedi- ately	Setup	page 9-89	
Pn30A	2	Deceleration Time for Servo OFF and Forced Stops	0 to 10,000	1 ms	0	All	Immedi- ately	Setup	page 6-29	
Pn30C	2	Speed Feedforward Average Movement Time	0 to 5,100	0.1 ms	0	All	Immedi- ately	Setup	_	

Continued on next page.

							Con	tinued from	n previou	s page.
Parameter No.	Size	Nam	e	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Vibration Dete Selections	ection	0000h to 0002h	-	0000h	All	Immedi- ately	Setup	page 7-49
		Vil		ection Selection						
		n.000X		not detect vibr						
Pn310				put a warning	. ,					
	_		2 Out	put an alarm (/	4.520) IT VI	oration is o	detected.			
		n.DDXD Re	eserved par	ameter (Do no	ot change.)				
		n.¤X¤¤ Re	eserved par	rameter (Do no	ot change.)				
		n.XDDD Re	eserved par	ameter (Do no	ot change.)				
	-									
Pn311	2	Vibration Dete sitivity	ction Sen-	50 to 500	1%	100	All	Immedi- ately	Tuning	page 7-49
Pn312	2	Vibration Dete Level	ection	0 to 5,000	1 min ⁻¹	50	Rotary	Immedi- ately	Tuning	page 7-49
Pn316	2	Maximum Mot	tor Speed	0 to 65,535	1 min ⁻¹	10000	Rotary	After restart	Setup	page 7-18
Pn324	2	Moment of Ine culation Startin		0 to 20,000	1%	300	All	Immedi- ately	Setup	page 9-31
Pn383	2	Jogging Spee	d	0 to 10,000	1 mm/s	50	Linear	Immedi- ately	Setup	page 8-7
Pn384	2	Vibration Dete Level	ection	0 to 5,000	1 mm/s	10	Linear	Immedi- ately	Tuning	page 7-49
Pn385	2	Maximum Mot	tor Speed	1 to 100	100 mm/s	50	Linear	After restart	Setup	page 7-18
Pn401	2	First Stage Fir Reference Filte Constant		0 to 65,535	0.01 ms	100	All	Immedi- ately	Tuning	page 9-85
Pn402	2	Forward Torqu	ue Limit	0 to 800	1%*2	800	Rotary	Immedi- ately	Setup	page 7-27
Pn403	2	Reverse Torqu	ie Limit	0 to 800	1%*2	800	Rotary	Immedi- ately	Setup	page 7-27
Pn404	2	Forward Exter Limit	nal Torque	0 to 800	1%*2	100	All	Immedi- ately	Setup	page 7-28
Pn405	2	Reverse Extern Limit	nal Torque	0 to 800	1% ^{*2}	100	All	Immedi- ately	Setup	page 7-28
Pn406	2	Emergency St	op Torque	0 to 800	1%*2	800	All	Immedi- ately	Setup	page 6-29
Pn407	2	Speed Limit d Torque Contro		0 to 10,000	1 min ⁻¹	10000	Rotary	Immedi- ately	Setup	page 7-14

Continued from previous page.

							CON	tinued from	i previou	s page
Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
2			-	0000h to 1111h	-	0000h	All	_	Setup	_
				L						
		Notch Fil	ter S	Selection 1				When Enabled	Refere	nce
	n.UUUX	0		-				Immedi- ately	page 9	9-85
		Speed Li	mit \$	Selection				When Enabled	Refere	nce
		0	sett	ing of Pn407 a	is the spe	ed limit.				
	n.□□X□		sett	ing of Pn480 a	is the spe	ed limit.		After restart	page 7	'-14
		1 -	spe Use	ed and the set the smaller of	ting of Pn the overs	407 as the peed alarr	speed limit. n detection	_		
		Notch Fil				480 as the	speed limit.	When	Refere	nce
	n.¤X¤¤	0			0					9-85
		Friction C	Com	pensation Fun	ction Sele	ection		When Enabled	Refere	nce
	n.XDDD	0						Immedi- ately	page 9	9-70
2	First Stage Frequency	Notch Filt	er	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 9-85
2	First Stage Q Value	Notch Filt	er	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 9-85
2	First Stage Depth	Notch Filt	er	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 9-85
2			Fil-	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 9-85
2		0	Fil-	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 9-85
2	Second State ter Depth	age Notch	Fil-	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 9-85
2	Torque Ref	erence Filt	d er	100 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 9-85
2				50 to 100	0.01	50	All	Immedi- ately	Tuning	page 9-85
2		erence Filt	er	0 to 65,535	0.01 ms	100	All	Immedi- ately	Tuning	page 9-66
	2 2 2 2 2 2 2 2 2 2 2 2 2	o 2 Torque-Rel tion Select 2 n.□□□□X n.□□□□X	2 Torque-Related Function Selections Intervention Selections Notch Fil 0 1 0 1 Image: Speed Line 0 Image: Speed Line 0 Image: Speed Line 0 Image: Speed Line 0 Image: Image: Speed Line 0 Image: Im	2 Torque-Related Function Selections Image: n.□□□X Notch Filter S 0 Disa 1 Ena 2 First Stage Notch Filter <t< td=""><td>2 Torque-Related Func- tion Selections 0000 to 1111h n.□□□X Notch Filter Selection 1 0 Disable first stage 1 Enable first stage 1 n.□□X□ 0 Disable first stage 1 Enable first stage Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a 1 Ise the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a 1 Ise the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a 1 Ise the smaller of setting of Pn407 a 0 Disable second stage Disable first or constant n.□X□□ 0 Disable first or constant n.X□□ 0 Disable firction constant</td><td>2 Torque-Related Function Selections 0000 to 1111h - 1 0 Disable first stage notch filte 0 Disable first stage notch filte 1 Enable first stage notch filte 0 Disable first stage notch filte 1 Enable first stage notch filte 0 Use the smaller of the maxim setting of Pn407 as the speed 1 Use the smaller of the overs speed and the setting of Pn 1 1 1 Use the smaller of the overs speed and the setting of Pn 1 Use the smaller of the overs speed and the setting of Pn 1 Enable second stage notch 1 Enable second stage notch 1 Enable second stage notch 1 Enable friction compensation 1 Enable friction compensation 1 Enable friction compensatio 2 First Stage Notch Filter 3 50 to 5,000 1 Hz 2 First Stage Notch Filter 50 to 1,000 0.01 2 Second Stage Notch Filter 50 to 1,000 0.01 2 Second Stage Notch Filter Sol to 1,000 0.01</td><td>2 Torque-Related Function Selections 0000h to 1111h - 0000h n.□□□X 0 Disable first stage notch filter. 1 Enable first stage notch filter. 1 Enable first stage notch filter. 1 Enable first stage notch filter. n.□□X□ 0 Disable first stage notch filter. n.□□X□ 0 Use the smaller of the maximum motor setting of Pn407 as the speed limit. Use the smaller of the overspeed alarr speed and the setting of Pn407 as the speed limit. Use the smaller of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the use of the use of the use of the overspeed alarr speed and the setting of Pn407 as the use of the use the use of the use of the</td><td>90 Name Setting Range Setting Unit Default Setting Applicable Motors 2 Torque-Related Func- tion Selections 0000h to 1111h – 0000h All n.□□□N Notch Filter Selection 1 0 – 0000h All n.□□DN 0 Disable first stage notch filter. – 0000h All n.□□DN 0 Disable first stage notch filter. – 0000h All n.□□DN 0 Disable first stage notch filter. – 0000h All n.□DN 0 Use the smaller of the maximum motor speed and the setting of Ph407 as the speed limit. Use the smaller of the overspeed alarm detection speed and the setting of Ph407 as the speed limit. 1 Estice Selection 2 – 0 Disable second stage notch filter. 1 Enable Second stage notch filter. 1 Enable friction compensation. – 1 Enable friction compensation. 1 Enable friction compensation. – 2 First Stage Notch Filter Frequency 50 to 1,000 0.011 70 All</td><td>B Name Setting Range Default Unit Applicable Setting Motors Enabled Enabled 2 Torque-Related Func- tion Selections 0000h to 1111h - 0000h All - n.□□DX Notch Filter Selection 1 0000h to 1 - 0000h to 1 - 0000h All - n.□□DXD 0 Disable first stage notch filter. Immedi- ately Immedi- ately When Enabled n.□□DXD 0 Disable first stage notch filter. Immedi- ately Immedi- ately Immedi- ately Immedi- ately n.□DXD 0 Use the smaller of the waximum motor speed and the setting of Ph407 as the speed limit. When Enabled 1 Use the smaller of the warspeed alarm detection speed and the setting of Ph407 as the speed limit. When Enabled n.□DXDD Notch Filter Selection 2 When Enabled When Enabled n.□DXDD Notch Filter Selection 2 When Enabled When Enabled n.□DXDD 0 Disable firction compensation. Immedi- ately 1 Enable Second stage notch filter. Immedi- ately</td><td>Name Setting Range Setting Unit Default Setting Applicable Motors When Enabled Classi- fication 2 Torque-Related Func- tion Selections 0000h to 1111h - 0000h All - Setup n.DDDX Notch Filter Selection 1 Immedi- 1 Enabled Refere 0 Disable first stage notch filter. Immedi- ately Immedi- tately page 5 0 Disable first stage notch filter. Immedi- ately Men Enabled Refere 0 Disable first stage notch filter. Immedi- setting of Ph407 as the speed limit. Men Enabled After restart page 7 1 Use the smaller of the overspeed alarm detection speed and the setting of Ph400 as the speed limit. Men Enabled After restart page 7 1 Use the smaller of the overspeed alarm detection speed and the setting of Ph400 as the speed limit. Immedi- ately page 6 1 Enable fiction compensation. Immedi- ately Immedi- ately page 6 1 Enable fiction compensation. Immedi- ately Immedi- ately Tuning 1 Enable</td></t<>	2 Torque-Related Func- tion Selections 0000 to 1111h n.□□□X Notch Filter Selection 1 0 Disable first stage 1 Enable first stage 1 n.□□X□ 0 Disable first stage 1 Enable first stage Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a 1 Ise the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a 1 Ise the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a Use the smaller of setting of Pn407 a 1 Ise the smaller of setting of Pn407 a 0 Disable second stage Disable first or constant n.□X□□ 0 Disable first or constant n.X□□ 0 Disable firction constant	2 Torque-Related Function Selections 0000 to 1111h - 1 0 Disable first stage notch filte 0 Disable first stage notch filte 1 Enable first stage notch filte 0 Disable first stage notch filte 1 Enable first stage notch filte 0 Use the smaller of the maxim setting of Pn407 as the speed 1 Use the smaller of the overs speed and the setting of Pn 1 1 1 Use the smaller of the overs speed and the setting of Pn 1 Use the smaller of the overs speed and the setting of Pn 1 Enable second stage notch 1 Enable second stage notch 1 Enable second stage notch 1 Enable friction compensation 1 Enable friction compensation 1 Enable friction compensatio 2 First Stage Notch Filter 3 50 to 5,000 1 Hz 2 First Stage Notch Filter 50 to 1,000 0.01 2 Second Stage Notch Filter 50 to 1,000 0.01 2 Second Stage Notch Filter Sol to 1,000 0.01	2 Torque-Related Function Selections 0000h to 1111h - 0000h n.□□□X 0 Disable first stage notch filter. 1 Enable first stage notch filter. 1 Enable first stage notch filter. 1 Enable first stage notch filter. n.□□X□ 0 Disable first stage notch filter. n.□□X□ 0 Use the smaller of the maximum motor setting of Pn407 as the speed limit. Use the smaller of the overspeed alarr speed and the setting of Pn407 as the speed limit. Use the smaller of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the overspeed alarr speed and the setting of Pn407 as the use of the use of the use of the use of the overspeed alarr speed and the setting of Pn407 as the use of the use the use of the use of the	90 Name Setting Range Setting Unit Default Setting Applicable Motors 2 Torque-Related Func- tion Selections 0000h to 1111h – 0000h All n.□□□N Notch Filter Selection 1 0 – 0000h All n.□□DN 0 Disable first stage notch filter. – 0000h All n.□□DN 0 Disable first stage notch filter. – 0000h All n.□□DN 0 Disable first stage notch filter. – 0000h All n.□DN 0 Use the smaller of the maximum motor speed and the setting of Ph407 as the speed limit. Use the smaller of the overspeed alarm detection speed and the setting of Ph407 as the speed limit. 1 Estice Selection 2 – 0 Disable second stage notch filter. 1 Enable Second stage notch filter. 1 Enable friction compensation. – 1 Enable friction compensation. 1 Enable friction compensation. – 2 First Stage Notch Filter Frequency 50 to 1,000 0.011 70 All	B Name Setting Range Default Unit Applicable Setting Motors Enabled Enabled 2 Torque-Related Func- tion Selections 0000h to 1111h - 0000h All - n.□□DX Notch Filter Selection 1 0000h to 1 - 0000h to 1 - 0000h All - n.□□DXD 0 Disable first stage notch filter. Immedi- ately Immedi- ately When Enabled n.□□DXD 0 Disable first stage notch filter. Immedi- ately Immedi- ately Immedi- ately Immedi- ately n.□DXD 0 Use the smaller of the waximum motor speed and the setting of Ph407 as the speed limit. When Enabled 1 Use the smaller of the warspeed alarm detection speed and the setting of Ph407 as the speed limit. When Enabled n.□DXDD Notch Filter Selection 2 When Enabled When Enabled n.□DXDD Notch Filter Selection 2 When Enabled When Enabled n.□DXDD 0 Disable firction compensation. Immedi- ately 1 Enable Second stage notch filter. Immedi- ately	Name Setting Range Setting Unit Default Setting Applicable Motors When Enabled Classi- fication 2 Torque-Related Func- tion Selections 0000h to 1111h - 0000h All - Setup n.DDDX Notch Filter Selection 1 Immedi- 1 Enabled Refere 0 Disable first stage notch filter. Immedi- ately Immedi- tately page 5 0 Disable first stage notch filter. Immedi- ately Men Enabled Refere 0 Disable first stage notch filter. Immedi- setting of Ph407 as the speed limit. Men Enabled After restart page 7 1 Use the smaller of the overspeed alarm detection speed and the setting of Ph400 as the speed limit. Men Enabled After restart page 7 1 Use the smaller of the overspeed alarm detection speed and the setting of Ph400 as the speed limit. Immedi- ately page 6 1 Enable fiction compensation. Immedi- ately Immedi- ately page 6 1 Enable fiction compensation. Immedi- ately Immedi- ately Tuning 1 Enable

Continued on next page.

						Con	tinued fron	n previou	s page
Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
2	Torque-Rel tion Select	ated Func- ions 2	0000h to 1111h	-	0000h	All	Immedi- ately	Setup	page 9-87
Ī		Notch Filter	Selection 3						
	n.🗆🗆 🗆 X		0						
ļ			0						
	n.🗆 🗆 X 🗆			ge notch fi	lter.				
		1 Ena	able fourth stag	je notch fil	ter.				
		Notch Filter	Selection 5						
	n.¤X¤¤		0						
1									
	n.X000	Reserved pa	rameter (Do no	ot change.)				
2	Third Stage Frequency	e Notch Filter	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 9-87
2	Third Stage Q Value	e Notch Filter	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 9-87
2	Third Stage Depth	e Notch Filter	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 9-87
2			50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 9-87
2	Fourth Starter Q Value	ge Notch Fil-	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 9-87
2	Fourth Stat ter Depth	ge Notch Fil-	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 9-87
2	Fifth Stage Frequency	Notch Filter	50 to 5,000	1 Hz	5000	All	Immedi- ately	Tuning	page 9-87
2	Fifth Stage Q Value	Notch Filter	50 to 1,000	0.01	70	All	Immedi- ately	Tuning	page 9-87
2	Fifth Stage Depth	Notch Filter	0 to 1,000	0.001	0	All	Immedi- ately	Tuning	page 9-86
2			0000h to 1111h	-	0000h	Rotary	-	Setup	page 9-64
		Speed Rippl	e Compensatio	on Functio	n Selectio	'n		Whe Enab	
	n.🗆🗆 🗆 X							Imme	
		1 Ena	able speed ripp	le comper	nsation.			ate	IY
				on Informa	tion Disag	greement War	ning Detec-	- Whe Enab	
	n.□□X□			-				Afte	
		1 Do	not detect A.9	42 alarms.					
				on Enable	Condition	Selection		Enab	
								Afte	
ļ	n.X000		•	ot change.)				
2	cuit Voltage	e Drop	0 to 100	1%*2	50	All	Immedi- ately	Setup	page 7-17
	Dologoo Ti	me for Torque		1			Immedi-	1	page 7-17
	2	2 Torque-Reition Select n.□□□□X In.□□ n.□□□X□ In.□□X□ n.□□X□□ In.□ n.□□X□□ In.□ n.□□X□□ In.□ 2 Third Stage Q Value 2 Third Stage Q Value 2 Fourth Sta ter Frequency 2 Fourth Stage Q Value 3 Speed Rip sation Select 4 In.□□□X□ 5 Speed Rip 6 In.□□□X□ 1 In.□□□X□ 1 In.□□X□□ 1 In.□□□ 1 In.□□□ 1 In.□□	2 Torque-Related Func- n.□□□□X 0 n.□□□X□ 0 n.□□X□ 0 n.□□X□ 0 n.□□X□ 0 n.□□X□ 0 n.□□X□ 0 n.□□X□ 0 n.□X□□ Reserved pate n.□X□□ Reserved pate n.□ Reserved pate 1 Ena n.□ Reserved pate 1 Ena 2 Fourth Stage Notch Filter 2 Fourth Stage Notch Filter 2 Fourth Stage Notch Filter 2 Fifth Stage Notch Filter 0	2 Torque-Related Func- tion Selections 2 0000h to 1111h 0 Disable third stage 1 Enable third stage 1 0 Disable third stage 1 Enable third stage 1 0 Disable fourth stage 1 Enable fourth stage 1 0 Disable fourth stage 1 Enable fourth stage 1 0 Disable fourth stage 1 Enable fifth stage 1 0 Disable fifth stage 1 Enable fifth stage 1 0 Disable fifth stage 1 Enable fifth stage 1 Enable fifth stage 50 to 5,000 2 Third Stage Notch Filter Frequency 50 to 1,000 2 Fourth Stage Notch Filter Depth 50 to 1,000 2 Fourth Stage Notch Filter Value 50 to 1,000 2 Fifth Stage Notch Filter Frequency 50 to 1,000 2 Fifth Stage Notch Filter Depth 0 to 1,000 2 Speed Ripple Compensation 1 0 0 Disable speed ripp 1	2 Torque-Related Func- tion Selections 2 0000 to 1111h - n.□□□X 0 Disable third stage notch filt 1 Enable third stage notch filt 1 n.□□X 0 Disable fourth stage notch filt 1 Enable fourth stage notch filt 1 n.□□X□ 0 Disable fourth stage notch filt 1 Enable fourth stage notch filt 1 n.□X□□ 0 Disable fifth stage notch filt 1 Enable fifth stage notch filt 1 n.□X□□ Reserved parameter (Do not change. 2 Third Stage Notch Filter Frequency 50 to 5,000 1 Hz 2 Third Stage Notch Filter Frequency 50 to 1,000 0.01 2 Fourth Stage Notch Filter Value 0 to 1,000 0.01 2 Fourth Stage Notch Filter Value 50 to 5,000 1 Hz 2 Fourth Stage Notch Filter Value 50 to 1,000 0.01 2 Fourth Stage Notch Filter Frequency 50 to 1,000 0.01 2 Fifth Stage Notch Filter Popth 50 to 1,000 0.01 2 Fifth Stage Notch Filter O Value 50 to 1,000 0.01 2 Fifth Stage Notch Filter O Q Value 0 to 1,000 0.01	2 Torque-Related Func- tion Selections 2 0000h to 1111h - 0000h n.□□□X 0 Disable third stage notch filter. 0000h n.□□□X 0 Disable third stage notch filter. 1 n.□□X□ 0 Disable fourth stage notch filter. n.□□X□ 0 Disable fourth stage notch filter. n.□X□□ 0 Disable furth stage notch filter. n.□X□□ 0 Disable fifth stage notch filter. n.□X□□ Reserved parameter (Do not change.) 2 Third Stage Notch Filter Frequency 50 to 5,000 1 Hz 5000 2 Third Stage Notch Filter O value 50 to 5,000 1 Hz 5000 2 Third Stage Notch Filter O value 50 to 5,000 1 Hz 5000 2 Fourth Stage Notch Filter O value 50 to 5,000 1 Hz 5000 2 Fourth Stage Notch Filter O value 50 to 5,000 1 Hz 5000 2 Fifth Stage Notch Filter O value 50 to 5,000 1 Hz 5000 2 Fifth Stage Notch Filter 50 to 1,000 0.01 70 2 Fifth Stage No	Name Setting Range Default Unit Applicable Setting Applicable Motors 2 Torcue-Related Func- tion Selections 2 0000h to 1111h - 0000h All n.□□□X Notch Filter Selection 3 0 0 Disable third stage notch filter. - n.□□X Notch Filter Selection 4 0 - - - - n.□□X□ Notch Filter Selection 4 0 - - - - n.□UX□ Notch Filter Selection 5 0 - - - - n.□U□0 Reserved parameter (Do not change.) - - - - 1 Enable fifth stage notch filter. - - - - - 1 Enable fifth stage notch filter. - - - - - 1 Enable fifth stage notch filter. - 1 - - - 1 Enable fifth stage notch filter - 0 to 1,000 0.001 0 All 2 Third Stage Notch Filter - <t< td=""><td>Name Setting Range Default Unit Applicable Setting Mather Motors Mene Enabled Motors 2 Torque-Related Fuc- tion Selections 2 0000 fm - 0000 fm All Immedi- ately n.□□□X 0 Disable third stage notch filter. - 0000 fm All Immedi- ately n.□□X0 0 Disable fourth stage notch filter. -</td><td>dia Name Pange Unit Setting Motors Enabled fraction 2 Torque-Related Func- too Selections 2 0000h to 1111h - 0000h All Immedi- ately Setup n.□□X□ 0 Disable third stage notch filter. - <</td></t<>	Name Setting Range Default Unit Applicable Setting Mather Motors Mene Enabled Motors 2 Torque-Related Fuc- tion Selections 2 0000 fm - 0000 fm All Immedi- ately n.□□□X 0 Disable third stage notch filter. - 0000 fm All Immedi- ately n.□□X0 0 Disable fourth stage notch filter. -	dia Name Pange Unit Setting Motors Enabled fraction 2 Torque-Related Func- too Selections 2 0000h to 1111h - 0000h All Immedi- ately Setup n.□□X□ 0 Disable third stage notch filter. - <

							Con	itinued from	n previou	s page.
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn426	2	Torque Fee Average M Time		0 to 5,100	0.1 ms	0	All	Immedi- ately	Setup	_
Pn427	2	Speed Rip sation Ena	ple Compen- ble Speed	0 to 10,000	1 min ⁻¹	0	Rotary	Immedi- ately	Tuning	page 9-64
Pn456	2	Sweep Tor ence Ampl		1 to 800	1%	15	All	Immedi- ately	Tuning	page 9-102
	2	Notch Filte Selections	r Adjustment 1	0000h to 0101h	-	0101h	All	Immedi- ately	Tuning	page 9-15, page 9-32
	-		Notch Filter	Adjustment Se	lection 1					
		n.000X	0 tun	not adjust the i ing without a h ing.						
Pn460				ust the first sta hout a host refe						
P11460		n.🗆🗆 X 🗆	Reserved pa	rameter (Do no	ot change.)				
		n.DXDD	0 fun aut 1 tior	Adjustment Se not adjust the ction is enabled otuning with a just the second n is enabled or otuning with a	second sta d or during host refere I stage not during exe	execution ence, and tch filter au ecution of a	of autotuning custom tuning itomatically w autotuning wit	g without a h g. hen the tunir thout a host	ost referer	nce,
		n.XOOO		rameter (Do no				, 		
	-					1				
	2	Gravity Co Related Se	mpensation- elections	0000h to 0001h	-	0000h	All	After restart	Setup	page 9-72
Pn475		n.000X	0 Dis	pensation Selec able gravity col able gravity cor	mpensatic					
		n.DDXD	Reserved par	ameter (Do not	change.)					
		n.¤X¤¤	Reserved par	ameter (Do not	change.)					
		n.X000	Reserved par	ameter (Do not	change.)					
Pn476	2	Gravity Co Torque	mpensation	-1,000 to 1,000	0.1%	0	All	Immedi- ately	Tuning	page 9-72
Pn480	2	Speed Lim Force Con	it during trol	0 to 10,000	1 mm/s	10000	Linear	Immedi- ately	Setup	page 7-14
Pn481	2	Polarity De Speed Loc	etection op Gain	10 to 20,000	0.1 Hz	400	Linear	Immedi- ately	Tuning	Ι
Pn482	2	Polarity De Speed Loc Time Cons	p Integral	15 to 51,200	0.01 ms	3000	Linear	Immedi- ately	Tuning	_
Pn483	2	Forward Fo	orce Limit	0 to 800	1% ^{*2}	30	Linear	Immedi- ately	Setup	page 7-27
Pn484	2	Reverse Fo	orce Limit	0 to 800	1%*2	30	Linear	Immedi- ately	Setup	page 7-27
Pn485	2	ence Spee		0 to 100	1 mm/s	20	Linear	Immedi- ately	Tuning	-
Pn486	2	Polarity De ence Acce Deceleration		0 to 100	1 ms	25	Linear	Immedi- ately	Tuning	-

							Con	tinued from	n previou	s page.
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn487	2	Polarity De stant Spee	etection Con- ed Time	0 to 300	1 ms	0	Linear	Immedi- ately	Tuning	-
Pn488	2	Polarity De ence Waiti	etection Refer- ng Time	50 to 500	1 ms	100	Linear	Immedi- ately	Tuning	-
Pn48E	2	Polarity De Range	etection	1 to 65,535	1 mm	10	Linear	Immedi- ately	Tuning	-
Pn490	2	Polarity De Level	etection Load	0 to 20,000	1%	100	Linear	Immedi- ately	Tuning	-
Pn495	2		etection Con- orce Refer-	0 to 200	1%	100	Linear	Immedi- ately	Tuning	-
Pn498	2	Polarity De able Error	tection Allow- Range	0 to 30	1 deg	10	Linear	Immedi- ately	Tuning	-
Pn49F	2	Speed Rip sation Ena	ple Compen- ble Speed	0 to 10,000	1 mm/s	0	Linear	Immedi- ately	Tuning	page 9-64
Pn502	2	Rotation D	etection Level	1 to 10,000	1 min ⁻¹	20	Rotary	Immedi- ately	Setup	page 7-8
Pn503	2	Speed Coi Detection Width	ncidence Signal Output	0 to 100	1 min ⁻¹	10	Rotary	Immedi- ately	Setup	page 7-10
Pn506	2	Brake Refe OFF Delay	erence-Servo Time	0 to 50	10 ms	0*3	All	Immedi- ately	Setup	page 6-32
Pn507	2	Brake Refe put Speed	erence Out- Level	0 to 10,000	1 min ⁻¹	100	Rotary	Immedi- ately	Setup	page 6-32
Pn508	2	Servo OFF mand Wait	-Brake Com- ing Time	10 to 100	10 ms	50	All	Immedi- ately	Setup	page 6-32
Pn509	2	Momentar ruption Ho	y Power Inter- Id Time	20 to 50,000	1 ms	20	All	Immedi- ately	Setup	page 7-15
	2	Input Signa 1	al Selections	0000h to FFF2h	-	1881h	All	After restart	Setup	-
		n.000X	Reserved par	rameter (Do no rameter (Do no	ot change.)				
		n.¤X¤¤	•	rameter (Do no	Ū	,				
			· · ·	rd Drive Prohit	, 0			placed)	Refere	ence
				forward drive		•	3	,	_	
				forward drive			0	,		
				forward drive			•	,	-	
Pn50A				forward drive			0	,		

Enable forward drive when CN1-11 input signal is ON (closed).

Enable forward drive when CN1-12 input signal is ON (closed).

Enable forward drive when CN1-13 input signal is OFF (open). Enable forward drive when CN1-7 input signal is OFF (open).

Enable forward drive when CN1-8 input signal is OFF (open).

Enable forward drive when CN1-9 input signal is OFF (open).

Enable forward drive when CN1-10 input signal is OFF (open).

Enable forward drive when CN1-11 input signal is OFF (open).

Enable forward drive when CN1-12 input signal is OFF (open).

Set the signal to always prohibit forward drive.

Set the signal to always enable forward drive.

5 6

7

8

9

A B

С

D

Е

F

n.XDDD

Continued on next page.

page 6-28

Continued from previous page.

arameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Ref end
	2	Input Signa	al Selectior	าร	0000h to	-	8882h	All	After	Setup	-
		2			FFFFh		000211		restart	Octup	
	L i		N-OT (Be	everse	Drive Prohil	oit) Signal	Allocation	1		Refere	ence
			0					out signal is O	N (closed).		
			1	Enab	le reverse dri	ve when C	CN1-7 inpu	it signal is ON	I (closed).		
			2	Enab	le reverse dri	ve when C	CN1-8 inpu	it signal is ON	I (closed).		
			3	Enab	le reverse dri	ve when C	CN1-9 inpu	it signal is ON	l (closed).		
			4					out signal is O	, ,		
			5					out signal is O			
			6					out signal is O	N (closed).		
		n.🗆 🗆 🗆 X	7		he signal to a					page (6-28
			8		he signal to a	-			EE (anon)		
			A					out signal is O it signal is OF			
			B					it signal is OF	,		
			C					it signal is OF			
			D					out signal is O			
			E	Enab	le reverse dri	ve when C	CN1-11 inp	out signal is O	FF (open).		
			F	Enab	le reverse dri	ve when C	CN1-12 inp	out signal is O	FF (open).		
50B		n.DDXD	Reserved	l para	meter (Do no	ot change	.)				
50B			/P-CL (Fo	orwar	d External To	orque Limi	t Input) Sig	gnal Allocatic	n	Refere	ence
			0	Activ	e when CN1	-13 input s	signal is ON	V (closed).			
			1		e when CN1-		,	, ,			
			2		e when CN1-		-				
			3		e when CN1-		-				
			4 5		e when CN1		-				
			6		e when CN1- e when CN1-		-				
		n.¤X¤¤	7		signal is alwa						
			8		signal is alwa	-				page	7-28
			9		e when CN1-			F (open).			
			A		e when CN1-						
			В	Activ	e when CN1-	-8 input sig	gnal is OFF	open).			
			С	Activ	e when CN1-	9 input si	gnal is OFF	⁻ (open).			
			D	Activ	e when CN1-	10 input s	signal is OF	F (open).			
			E		e when CN1-		-				
			F	Activ	e when CN1-	12 input s	signal is OF	FF (open).			
			/N-CL (R			-		gnal Allocatic		Refere	ence
		n.XDDD						-CL (Forward	— · ·	1	

Continued on next page.

Parameter				-	-			tinued from		
No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence
	2	Output Sig tions 1	inal Selec-	0000h to 6666h	-	0000h	All	After restart	Setup	-
			/COIN (Po	ositioning Comple	tion Outp	ut) Signal	Allocation		Refere	ence
			0	Disabled (the abo	ve signal c	output is no	ot used).			
			1	Output the signal						
		n.🗆🗆 🗆 X		Output the signal						
				Output the signal					page 7	7-11
			-	Output the signal					_	
				Output the signal			CN1-30 outp	ut terminal.	_	
Pn50E			6	Reserved parame	ter (Do no	t change.)				
			/V-CMP (Speed Coincidend	ce Detecti	on Output) Signal Alloc	ation	Refere	ence
		n.□□X□	0 to 6	The allocations ar tion) signal allocat		e as the /C	OIN (Position	ing Comple-	page 7	7-10
			/TGON (F	otation Detection	Output) S	Signal Allo	cation		Refere	ence
		n.¤X¤¤	0 to 6	The allocations ar tion) signal allocat		e as the /C	OIN (Position	ing Comple-	page	7-8
			/S-RDY (S	Servo Ready) Sigr	al Allocat	ion			Refere	ence
		n.XDDD	0 to 6	The allocations ar tion) signal allocat		e as the /C	OIN (Position	ing Comple-	page	7-9
			,							
	2	Output Sig								
		tions 2	inal Selec-	0000h to 6666h	-	0100h	All	After restart	Setup	-
	2		1	6666h						-
	2		/CLT (Tore	6666h	. ,	Signal All	ocation		Setup	- ence
	2		/CLT (Toro	6666h que Limit Detectio Disabled (the abo	ve signal c	Signal All	ocation ot used).	restart		ence
	2		/CLT (Tore 0 1	6666h que Limit Detectio Disabled (the abo Output the signal	ve signal c from the C	Signal All output is no CN1-1 or C	ocation ot used). N1-2 output	restart terminal.		ence
	2		/CLT (Tore 0 1 2	6666h que Limit Detectio Disabled (the abo Output the signal Output the signal	ve signal c from the C from the C	Signal All output is no CN1-1 or C CN1-23 or	ocation ot used). N1-2 output CN1-24 outp	restart terminal. ut terminal.	Refere	
		tions 2	/CLT (Tore 0 1 2 3	G6666h Que Limit Detection Disabled (the aborn Output the signal Output the signal Output the signal	ve signal c from the C from the C from the C	Signal All butput is no CN1-1 or C CN1-23 or CN1-25 or	ocation ot used). N1-2 output CN1-24 outp CN1-26 outp	terminal. ut terminal. ut terminal.		
		tions 2	/CLT (Tore 0 1 2 3 4	Geech Gue Limit Detection Disabled (the aborn Output the signal Output the signal Output the signal Output the signal	ve signal c from the C from the C from the C from the C	Signal All butput is no CN1-1 or C CN1-23 or CN1-25 or CN1-27 or	ocation ot used). N1-2 output CN1-24 outp CN1-26 outp CN1-28 outp	terminal. ut terminal. ut terminal. ut terminal. ut terminal.	Refere	
2-505		tions 2	/CLT (Tore 0 1 2 3	G6666h Que Limit Detection Disabled (the aborn Output the signal Output the signal Output the signal	ve signal c from the C from the C from the C from the C from the C	Signal All output is no CN1-1 or C CN1-23 or CN1-25 or CN1-27 or CN1-29 or	ocation ot used). N1-2 output CN1-24 outp CN1-26 outp CN1-28 outp	terminal. ut terminal. ut terminal. ut terminal. ut terminal.	Refere	
Pn50F		tions 2	/CLT (Tore 0 1 2 3 4 5 6	Geech Gue Limit Detection Disabled (the aborn Output the signal Output the signal Output the signal Output the signal Output the signal	ve signal c from the C from the C from the C from the C from the C ter (Do no	Signal All output is no CN1-1 or C CN1-23 or CN1-25 or CN1-27 or CN1-29 or t change.)	ocation ot used). N1-2 output CN1-24 outp CN1-26 outp CN1-28 outp	terminal. ut terminal. ut terminal. ut terminal. ut terminal.	Refere	7-31
Pn50F		tions 2	/CLT (Tore 0 1 2 3 4 5 6 VLT (Spe	6666h Que Limit Detection Disabled (the abor Output the signal Output the signal Output the signal Output the signal Output the signal Reserved parame	ve signal c from the C from the C from the C from the C from the C ter (Do no n) Signal <i>i</i> e the same	Signal All putput is no CN1-1 or C CN1-23 or CN1-25 or CN1-27 or CN1-29 or t change.)	ocation bt used). N1-2 output CN1-24 outp CN1-26 outp CN1-28 outp CN1-30 outp	restart terminal. ut terminal. ut terminal. ut terminal. ut terminal.	page 7	7-31 ence
Pn50F		nX.	/CLT (Tore 0 1 2 3 4 5 6 /VLT (Spe 0 to 6	6666h Que Limit Detection Disabled (the aborn Output the signal Output the signal Output the signal Output the signal Output the signal Reserved parame End Limit Detection The allocations ar	ve signal c from the C from the C from the C from the C from the C ter (Do no n) Signal <i>i</i> e the sam- cations.	Signal All output is no CN1-1 or C CN1-23 or CN1-25 or CN1-27 or CN1-29 or t change.) Allocation e as the /C	ocation bt used). N1-2 output CN1-24 outp CN1-26 outp CN1-28 outp CN1-30 outp	restart terminal. ut terminal. ut terminal. ut terminal. ut terminal.	page a	7-31
Pn50F		n.DDX	/CLT (Tore 0 1 2 3 4 5 6 7 VLT (Spe 0 to 6	6666h Que Limit Detection Disabled (the aborn Output the signal Output the signal Output the signal Output the signal Output the signal Output the signal Reserved parame ed Limit Detection The allocations ar Output) signal alloc	ve signal c from the C from the C from the C from the C from the C ter (Do no n) Signal <i>i</i> e the same cations.	Signal All putput is no CN1-1 or C CN1-23 or CN1-25 or CN1-27 or CN1-29 or t change.) Allocation e as the /C	ocation bt used). N1-2 output CN1-24 outp CN1-26 outp CN1-28 outp CN1-30 outp CN1-30 outp	terminal. ut terminal. ut terminal. ut terminal. ut terminal. mit Detection	Page Page Page Page Page Page Page Page	7-31 ence
Pn50F		nX.	/CLT (Torr 0 1 2 3 4 5 6 7 VLT (Spe 0 to 6 /BK (Brak 0 to 6	6666h Que Limit Detection Disabled (the aborn Output the signal Output the signal Output the signal Output the signal Output the signal Output the signal Reserved parame ed Limit Detection The allocations ar Output) signal alloc a Output) Signal alloc The allocations ar	ve signal c from the C from the C from the C from the C from the C from the C ter (Do no n) Signal <i>i</i> e the same cations.	Signal All putput is no CN1-1 or C CN1-23 or CN1-25 or CN1-27 or CN1-29 or t change.) Allocation e as the /C	ocation bt used). N1-2 output CN1-24 outp CN1-26 outp CN1-28 outp CN1-30 outp CN1-30 outp	terminal. ut terminal. ut terminal. ut terminal. ut terminal. mit Detection	Refere	7-31 ence 7-13 ence 5-33

Continued from previous page.

Continued from previous page.

Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Output Sig tions 3	nal Selec-		0000h to 0666h	-	0000h	All	After restart	Setup	-
Pn510		n.000X	/NEAR (1 0 1 2 3 4 5 6	Disi Out Out Out Out	Output) Signa abled (the abov put the signal put the signal put the signal put the signal put the signal served parame	ve signal c from the C from the C from the C from the C from the C	output is no CN1-1 or C CN1-23 or (CN1-25 or (CN1-27 or (CN1-29 or (N1-2 output 1 CN1-24 outpu CN1-26 outpu CN1-28 outpu	ut terminal. ut terminal. ut terminal.	page	
	I	n.00X0 n.0X00	Reserved	d pai	rameter (Do no rameter (Do no rameter (Do no	ot change)				
	_		1.000110			2 on ango	·/				

Continued on next page.

	_							tinued fror		
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refe ence
	2	Input Sign 5	al Selectior	ns 0000h to FFFFh	_	6543h	All	After restart	Setup	page 7-4
			/DFC (Or	gin Return Decel	eration Sw	vitch Input	Signal Alloc	ation		
			0	Active when CN1		• •	•			
			1	Active when CN1	•	•	, ,			
			2	Active when CN1		, ,	,			
			3	Active when CN1		-				
			4	Active when CN1		, ,	,			
			5	Active when CN1	•	•	, ,			
			6	Active when CN1		0	, ,			
		n.000X	7	The signal is alwa		ignan is or	(00300).			
			8	The signal is alwa	,					
			9	Active when CN1			E (open)			
			A	Active when CN1	•	•				
			В	Active when CN1		•				
			C	Active when CN1		-				
			D	Active when CN1		, ,				
n511			E	Active when CN1	•	•				
11011			F	Active when CN1		-				
					•	<u> </u>	,			_
			· · · ·	ternal Latch Inpu	, 0		1			
			0 to 3	The signal is alwa	-					
			4	Active when CN1		0	, ,			
			5	Active when CN1		0	, ,			
		n.🗆 🗆 X 🗆	6	Active when CN1	•	•	, ,			
			D	Active when CN1	•	0	· · · /			
			E	Active when CN1		-				
			F	Active when CN1	•	0	F (open).			
			7 to C	The signal is alwa	ys inactive					
			/EXT2 (E	ternal Latch Inpu	t 2) Signa	Allocation	ı			
		n.¤X¤¤	0 to F	The allocations an cations.	e the sam	e as the /E	XT1 (External	Latch Input	1) signal a	allo-
			/EXT3 (E	ternal Latch Inpu	t 3) Signa	Allocation	ı			
		n.XDDD	0 to F	The allocations an cations.	e the sam	e as the /E	XT1 (External	Latch Input	1) signal a	allo-

Continued from previous page.

Continued from previous page.

								Cor	ntinued fror	n previou	s page
Parameter No.	Size	N	lame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence
	2	Output Sig Settings	gnal Inverse	e	0000h to 1111h	-	0000h	All	After restart	Setup	page 7-6
								.			_
				-	I Inversion for		nd CN1-2	Ierminals			
		n.□□□X	0		signal is not in signal is inver						
				me	signal is inver	leu.					
			· ·	•	I Inversion for		and CN1-2	4 Terminals			
Pn512		n.🗆 🗆 X 🗆	0		signal is not ir						
111012	_		1	The	signal is inver	ted.					
			Output S	Signal	I Inversion for	CN1-25 a	and CN1-2	6 Terminals			
		n.¤X¤¤	0	The	signal is not ir	nverted.					
			1	The	signal is inver	ted.					
			Output S	Signal	I Inversion for	CN1-27 a	and CN1-2	8 Terminals			
		n.XDDD	0	The	signal is not ir	nverted.					
			1	The	signal is inver	ted.					
	2	Output Sig	gnal Inverse	Э	0000h to	_	0000h	All	After	Setup	_
	_	Settings 2			0011h				restart		
			Output Sid	anal	Inversion for (CN1-29 ar	nd CN1-30) Terminals		Refer	ence
	r	n.000X		-	gnal is not inve						
Pn513			1 Th	he sig	gnal is inverted	d.				page	7-6
		n.00X0	Reserved	nara	meter (Do not	change)				, P	
			neserveu	para		change.)					
	r	n.OXOO	Reserved	para	meter (Do not	t change.)					
	r	n.XOOO	Reserved	para	meter (Do not	t change.)					
	-										
	2	Output Sig	gnal Selec-		0000h to	_	0000h	A II	After	Satura	_
	2	tions 4			0666h	-	0000h	All	restart	Setup	-
	r	1.000X	Reserved	para	meter (Do not	t change.)					
				· .	`						
	r	1.00X0	Reserved	para	meter (Do not	t change.)					
			/PM (Prev	rentat	tive Maintena	nce Outpu	ıt) Signal A	Allocation		Refere	ence
D 544			0 1	Disat	oled (the above	e signal ou	itput is not	used).			
Pn514			1 (Outp	ut the signal fr	rom the Cl	N1-1 or CN	V1-2 output t	erminal.		
	r	n.0X00			ut the signal fr						
					ut the signal fr					page 1	0-16
					ut the signal fr					_	
					ut the signal fr			N1-30 outpu	it terminal.	_	
			6 I	Rese	rved paramete	er (Do not	change.)				
	r	n.X000	Reserved	para	meter (Do not	t change.)					

_				-				itinued fron	· · · · · · · · · · · · · · · · · · ·	
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence
	2	Input Signa 6	al Selections	0000h to FFFFh	-	8888h	All	After restart	Setup	_
		n.000X	Reserved p	parameter (Do no	ot change.)				
		n.🗆🗆 X 🗆	Reserved p	parameter (Do no	ot change)				
			/DBANS (D	ynamic Brake A	nswer Inp	ut) Signal	Allocation			
			0	Detect DB circui signal is ON.	t error whe	en CN1-13	input signal is	ON (closed) while /DE	BON
			1	Detect DB circui signal is ON.	t error whe	en CN1-7 i	nput signal is	ON (closed)	while /DB	ION
			2	Detect DB circui signal is ON.						
			3	Detect DB circui signal is ON.	t error whe	en CN1-9 i	nput signal is	ON (closed)	while /DB	ION
			4	Detect DB circui signal is ON.	t error whe	en CN1-10	input signal is	SON (closed) while /DE	BON
			5	Detect DB circui signal is ON.	t error whe	en CN1-11	input signal is	SON (closed) while /DE	BON
Pn515			6	Detect DB circui signal is ON.) while /DE	BON
		n.¤X¤¤	7	Disable DB circu	it error de	tection usi	ng the /DBAN	IS signal.		
			8	Disable DB circu	it error de	tection usi	ng the /DBAN	IS signal.		
			9	Detect DB circui signal is ON.	t error whe	en CN1-13	input signal i	s OFF (open)) while /DE	BON
			А	Detect DB circui signal is ON.	t error whe	en CN1-7	nput signal is	OFF (open)	while /DB	ON
			В	Detect DB circui signal is ON.	t error whe	en CN1-8 i	nput signal is	OFF (open)	while /DB	ON
			С	Detect DB circui signal is ON.	t error whe	en CN1-9 i	nput signal is	OFF (open)	while /DB	ON
			D	Detect DB circui signal is ON.	t error whe	en CN1-10	input signal i	s OFF (open)) while /DE	BON
			E	Detect DB circui signal is ON.	t error whe	en CN1-11	input signal i	s OFF (open) while /DE	SON
			F	Detect DB circui signal is ON.	t error whe	en CN1-12	input signal i	s OFF (open) while /DE	BON
		n.XDDD	Reserved r	parameter (Do no	ot change)				
	-					,				

Continued from previous page.

Continued from previous page.

	-							tinued from		
Parameter No.	Size	Ν	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence
	2	Input Sign 7	al Selections	0000h to FFFFh	-	8888h	All	After restart	Setup	-
Pn516		n.DDDX	FSTP (Force 0 f 1 f 2 f 3 f 4 f 5 f 6 f 7 5 8 6 9 f A f B f C f		CN1-13 CN1-7 ir CN1-8 ir CN1-9 ir CN1-9 ir CN1-10 CN1-11 CN1-12 Ilways pro- Ilways ena CN1-13 CN1-7 ir CN1-8 ir CN1-9 ir	ation input signal aput signal aput signal input signal input signa input signa hibit drive able drive (a input signal aput signal aput signal	al is ON (closed is ON (closed is ON (closed is ON (closed al is OFF (open is OFF (open is OFF (open is OFF (open	restart ed). d). d). ed). j. j. j. j. j. j.	Refere	
	1 3	n.00X0	F [Enable drive wher Enable drive wher arameter (Do not arameter (Do not	CN1-12 change.)	input signa	× 1	7		
		n.XOOO	Reserved p	arameter (Do not	change.)					
	2	Output Sig tions 8	gnal Selec-	0000h to 0060h	-	0000h	All	After restart	Setup	page 7-4
		n.DDDX	Reserved	parameter (Do no	ot change.	.)				
Pn51A		n.00X0	/DBON (D) 0 1 2 3 4 5 6	namic Brake Op Disabled (the abo Output the signa Output the signa Output the signa Output the signa Output the signa Reserved param	ove signal I from the I from the I from the I from the I from the	output is r CN1-1 or CN1-23 or CN1-25 or CN1-27 or CN1-29 or	not used). CN1-2 outpur CN1-24 out CN1-26 out CN1-28 out CN1-28 out	t terminal. put terminal. put terminal. put terminal.		
		n.¤X¤¤		Darameter (Do no		0	/			
Pn51B	4	n.XDDD Motor-Loa Deviation	d Position	O to	t change	.) 1000	Rotary	Immedi-	Setup	page
Pn51B Pn51E	4	Motor-Loa Deviation Detection	d Position Overflow Level veviation Ove	0 to 1,073,741,824	1 refer-	,	Rotary	Immedi- ately Immedi- ately	Setup	page 11-9 page 9-9

14

									tinued fron		o pago
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn522	4	Positioning Width	Complete	ed	0 to 1,073,741,824	1 refer- ence unit	7	All	Immedi- ately	Setup	page 7-11
Pn524	4	Near Signa	al Width		1 to 1,073,741,824	1 refer- ence unit	107374 1824	All	Immedi- ately	Setup	page 7-13
Pn526	4	Position De flow Alarm Servo ON		ver-	1 to 1,073,741,823	1 refer- ence unit	5242880	All	Immedi- ately	Setup	page 9-10
Pn528	2	Position De flow Warnin Servo ON			10 to 100	1%	100	All	Immedi- ately	Setup	page 9-10
Pn529	2	Speed Lim Servo ON	it Level at		0 to 10,000	1 min ⁻¹	10000	Rotary	Immedi- ately	Setup	page 9-10
Pn52A	2	Multiplier p closed Rot	er Fully- ation		0 to 100	1%	20	Rotary	Immedi- ately	Tuning	page 11-9
Pn52B	2	Overload V	Varning Le	evel	1 to 100	1%	20	All	Immedi- ately	Setup	page 6-40
Pn52C	2	Base Curre at Motor O Detection		ıg	10 to 100	1%	100	All	After restart	Setup	page 6-41
	2	Program Je Related Se			0000h to 0005h	-	0000h	All	Immedi- ately	Setup	page 8-14
			Program	Jog	ging Operatior	n Pattern					
			0		uiting time in Pr vements in Pn5		prward by t	ravel distance	e in Pn531) >	< Number	of
			1		uiting time in Pr vements in Pn5		everse by t	ravel distance	e in Pn531) >	< Number	of
			2	mov (Wa	iting time in Pr vements in Pn5 iting time in Pr vements in Pn5	536 1535 → Re	-		,		
Pn530		n.□□□X	3	mov (Wa	iiting time in Pr vements in Pn iiting time in Pr vements in Pn	536 1535 → Fo	-		,		
			4		uiting time in Pr Pn535 → Rever 536						
			5		uiting time in Pr Pn535 → Forwa 536						ime
	-										
		n.DDXD	Reserve	d par	rameter (Do no	ot change)				
		n.00X0			rameter (Do no rameter (Do no						
			Reserve	d par	•	ot change.)				
		n.¤X¤¤	Reserve	d par	rameter (Do no	ot change.)				
Pn531		n.¤X¤¤	Reserve	d par	rameter (Do no	ot change.)	All	Immedi- ately	Setup	
Pn531 Pn533		n.DXDD n.XDDD	Reserver	d par d par	rameter (Do no rameter (Do no 1 to	ot change. ot change. 1 refer- ence)	All		Setup	s in
	4	n. 🗆 X 🗆 🗆 n. X 🗆 🗖 Program Ju Distance	Reserve	d par d par avel	rameter (Do no rameter (Do no 1 to 1,073,741,824	1 refer- ence unit Rotary:) 32768		ately Immedi-		page 8-14
Pn533	4	n. DX DD n. XD DD Program Ju Distance Program Ju ment Spee Program Ju eration/De	Reserver	d par d par avel	rameter (Do no rameter (Do no 1 to 1,073,741,824 1 to 10,000	1 refer- ence unit Rotary: 1 min ⁻¹)) 32768 500	Rotary	ately Immedi- ately Immedi-	Setup	page 8-14 page 8-14 page

Continued from previous page.

						Cor	itinued from	1 previou	s page
Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence
2	ZONE Outp Selections	out Signal 1	0000h to 6666h	-	0000h	All	After restart	Setup	-
		ZONE Tab	ole Entry 1 (/ZONE	E0) Signal	Allocation	I		Refere	ence
		0	Disabled (the abo	ve signal c	output is no	ot used).			
	n.🗆 🗆 🗆 X					•			
		-	1 0					page /	-64
		-							
					Allegation			Defer	222
	n.🗆🗆 X 🗆			, 0			Table Entry ⁻	1)	
								page 7	7-64
		ZONE Tat	ble Entry 3 (/ZONE	E2) Signal	Allocation	I		Refere	ence
	n.¤X¤¤			, 0			Table Entry ⁻	D .	
		0100	signal allocations.					page	-04
		ZONE Tat	ble Entry 4 (/ZONE	E3) Signal	Allocation	l		Refere	ence
	n.XOOO			e the same	e as the /Z0	ONE0 (ZONE	Table Entry) page 7	7-64
			olgital allocations.						
2			0000h to 0006h	-	0000h	All	After restart	Setup	-
		/nZONE (2	ZONE n Signal Οι	utput) Sigr	nal Allocati	ion		Refere	ence
			,	Ŭ		,			
	n.🗆🗆 🛛 X					•		page 7	7-65
			· · · · · · · · · · · · · · · · · · ·						00
		6	Reserved parame	ter (Do not	t change.)				
	n.DDXD	Reserved	parameter (Do no	ot change.)				
	n.¤X¤¤	Reserved	parameter (Do no	ot change.	.)				
	n.XDDD	Reserved	parameter (Do no	ot change.)				
					,				
0	Analog Mo	nitor 1 Offs		0.1.1/	0	All	Immedi-	Sotup	page
	Voltage						ately Immedi-	Geruh	10-1
2		nitor 2 Offs		0.1 V	0	All	ot oli ·	Setup	pag
2 2	Voltage Analog Mo		10,000 g10,000 to	0.1 V × 0.01	100	All	ately Immedi-	Setup Setup	10-1 pag
	Voltage Analog Mo nification Analog Mo	nitor 1 Maç	10,000 10,000 to 10,000 10,000 to				Immedi- ately Immedi-		page 10-1 page 10-1 page 10-1
2	Voltage Analog Mo nification	nitor 1 Mag nitor 2 Mag nsumption	10,000 g10,000 to 10,000	× 0.01	100	All	Immedi- ately	Setup	10-1 page 10-1 page
2	Voltage Analog Mo nification Analog Mo nification Power Cor	nitor 1 Mag nitor 2 Mag nsumption nit Time ibration	10,000 j- -10,000 to 10,000 j- -10,000 to 10,000	× 0.01 × 0.01	100	All	Immedi- ately Immedi- ately Immedi-	Setup Setup	10-1 page 10-1
2 2 2 2	Voltage Analog Mo nification Analog Mo nification Power Cor Monitor Un Residual V	nitor 1 Mag nitor 2 Mag nsumption nit Time ibration Width	10,000 j- -10,000 to 10,000 j- -10,000 to 10,000 j- 10,000 to 10,000 1 to 1,440	× 0.01 × 0.01 1 min	100 100 1	All All All	Immedi- ately Immedi- ately Immedi- ately Immedi-	Setup Setup Setup	10-1 page 10-1 page 10-1 -
	2	2 ZONE Out Selections 2 ZONE Out Selections 1 n.□□□X 1 n.□□X□ 1 n.□□X□ 2 ZONE Out Selections 2 ZONE Out Selections 1 n.□□□X 2 Analog Mo Voltage	2 ZONE Output Signal Selections 1 Selections 1 0 1 2 1 2 3 4 5 6 n.□□X□ ZONE Tate 0 0 n.□□X□ ZONE Tate 0 0 n.□X□□ ZONE Tate 0 0 n.□X□□ ZONE Tate 0 0 n.□X□□ ZONE Tate 0 0 0 0 1 2 2 ZONE Output Signal Selections 2 2 ZONE Output Signal Selections 2 1 2 1 2 3 4 5 6 n.□□□X□ Reserved n.□□X□ Reserved	2 ZONE Output Signal Selections 1 0000 to 6666h 0 Disabled (the aborent 1 0000 to 6666h 0 Disabled (the aborent 1 0000 to 6666h 1 Output the signal 2 0000 to 6666h 1 Output the signal 3 0000 to 1 2 Output the signal 4 0000 to 6 1 Output the signal 5 0000 to 6 1 Output the signal 6 Reserved parame 1 0 to 6 The allocations are signal allocations. 2 ZONE Output Signal 0 to 6 The allocations are signal allocations. 2 ZONE Output Signal 0 to 6 The allocations are signal allocations. 2 ZONE Output Signal 0 to 6 The allocations are signal allocations. 2 ZONE Output Signal 2 00000 to 0006h 1 Output the signal 3 Output the signal 4 3 Output the signal 5	2 ZONE Output Signal 0000 h to 6666h - 8 2 ZONE Table Entry 1 (/ZONE0) Signal 0 Disabled (the above signal of 1 0 0 Disabled (the above signal from the O 2 Output the signal from the O 2 1 Output the signal from the O 3 Output the signal from the O 3 1 Output the signal from the O 5 Output the signal from the O 6 1 Output the signal from the O 6 Reserved parameter (Do not 1 O to 6 The allocations are the same signal allocations. 1 O to 6 The allocations are the same signal allocations. 1 O to 6 The allocations are the same signal allocations. 1 O to 6 The allocations are the same signal allocations. 2 ZONE Output Signal O000h to - - 2 ZONE Output Signal O000h to - - 2 ZONE Output Signal O000h to - - 2 ZONE Output Signal Output the signal from the O - 1 Output the	2 ZONE Output Signal Selections 1 0000h to 6666h - 0000h 0 Disabled (the above signal output is no 1 0utput the signal from the CN1-1 or C 2 0utput the signal from the CN1-23 or 3 0utput the signal from the CN1-25 or 4 1 Output the signal from the CN1-25 or 4 0utput the signal from the CN1-25 or 4 0utput the signal from the CN1-25 or 6 1 0 0 6 Reserved parameter (Do not change.) 1 0 0 6 Reserved parameter (Do not change.) 1 0 to 6 The allocations are the same as the /Z0 signal allocations. 1 0 to 6 The allocations are the same as the /Z0 signal allocations. 1 0 to 6 The allocations are the same as the /Z0 signal allocations. 1 0 to 6 The allocations are the same as the /Z0 signal allocations. 2 ZONE Output Signal Selections 2 0000h to 0006h - 0000h 1 0 to 6 The allocations are the same as the /Z0 signal allocations. - 2 ZONE Output Signal 0 0000h to 0 - 0000h 1 0 to 6 The allocations are the same as the	Solution Name Setting Range Name Setting Name Default Setting Applicable Motors 2 ZONE Output Signal 0000h to Selections 1 0000h to 6666h - 0000h All 2 ZONE Output Signal 0000h to Selections 1 - 0000h All 1 Output the signal from the CN1-1 or CN1-2 output 2 0utput the signal from the CN1-25 or CN1-26 output 4 0utput the signal from the CN1-27 or CN1-28 outp 5 1 Output the signal from the CN1-29 or CN1-30 outp 6 Reserved parameter (Do not change.) 1 Output the signal from the CN1-29 or CN1-30 outp 6 The allocations are the same as the /ZONE0 (ZONE signal allocations. 1 Output Table Entry 2 (/ZONE1) Signal Allocation 0 to 6 The allocations are the same as the /ZONE0 (ZONE signal allocations. 1 ZONE Table Entry 4 (/ZONE3) Signal Allocation 0 to 6 The allocations are the same as the /ZONE0 (ZONE signal allocations. 2 ZONE Output Signal Selections 2 0000h to 0006h - 0000h All 2 ZONE Output Signal Selections 2 0000h to 0006h - 0000h All 2 ZONE Output Signal Output the signal from the CN1-20 or CN1-20 output	Bit Name Setting Range Default Unit Applicable Setting When Motors Enabled Enabled 2 ZONE Cutput Signal 0000h to 6666h - 0000h All After restart 2 ZONE Table Entry 1 (/ZONE0) Signal Allocation - 0000h All After restart 0 Disabled (the above signal output is not used). - 0.000h to 0.000h to 1.000tput the signal from the CN1-23 or CN1-24 output terminal. 2 Output the signal from the CN1-25 or CN1-26 output terminal. - 0.000h to 0.000h to cN1-29 or CN1-28 output terminal. 3 Output the signal from the CN1-29 or CN1-28 output terminal. - 0.000h to cN1-29 or CN1-28 output terminal. 6 Reserved parameter (Do not change.) - The allocations are the same as the /ZONE0 (ZONE Table Entry * signal allocations. n.DDD 0 to 6 The allocations are the same as the /ZONE0 (ZONE Table Entry * signal allocations. - 2 ZONE Table Entry 4 (/ZONE3) Signal Allocation - - n.DDD 0 to 6 The allocations are the same as the /ZONE0 (ZONE Table Entry * signal allocations. 2 ZONE Table Entry 4 (/ZONE3) Signal Allocation	Bit Number Range Unit Setting Motors Enabled fication 2 ZONE Output Signal 0000h to Belections 1 - 0000h All After restart Setup 0 Disabled (the above signal output is not used). - 0.000h All After restart Setup 0 Disabled (the above signal output is not used). - 0.000h All Refere 0 Output the signal from the CN1-23 or CN1-26 output terminal. - 0.000h - <t< td=""></t<>

	Continued from previous page.										
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence	
Pn582	2	Speed Coi Detection S Width	ncidence Signal Output	0 to 100	1 mm/s	10	Linear	Immedi- ately	Setup	page 7-10	
Pn583	2	Brake Refe put Speed	erence Out- Level	0 to 10,000	1 mm/s	10	Linear	Immedi- ately	Setup	page 6-32	
Pn584	2	Speed Lim Servo ON	it Level at	0 to 10,000	1 mm/s	10000	Linear	Immedi- ately	Setup	page 9-10	
Pn585	2	Program J ment Spee	ogging Move- d	1 to 10,000	1 mm/s	50	Linear	Immedi- ately	Setup	page 8-14	
Pn586	2	Motor Run Ratio	ning Cooling	0 to 100	1%/ Max. speed	0	Linear	Immedi- ately	Setup	_	
	2		tection Selection for inear Encoder	0000h to 0001h	_	0000h	Linear	Immedi- ately	Setup	_	
			Polarity Dete	ction Selectior	n for Abso	lute Linea	r Encoder		Referen	ice	
	1	n.DDDX		ot detect polar	ity.				page 6-	24	
Pn587			1 Dete	ct polarity.					1 0		
		n.DDXD	Reserved par	rameter (Do no	ot change.)					
		n.									
	n.XDDD Reserved parameter (Do not change.)										
Pn600	2	Regenerati Capacity ^{*4}	ve Resistor	Depends on model. ^{*5}	10 W	0	All	Immedi- ately	Setup	page 6-53	
Pn601 ^{*6}	2	Dynamic B tor Allowat Consumpt		0 to 65,535	10 J	0	All	After restart	Setup	page 6-53	
Pn603	2	Regenerat tance	ve Resis-	0 to 65,535	10 m Ω	0	All	Immedi- ately	Setup	page 6-53	
Pn604 ^{*7}	2	Dynamic E tance	rake Resis-	0 to 65,535	10 m Ω	0	All	After restart	Setup	page 6-53	
	2	Overheat F Selections	Protection	0000h to 0003h	_	0000h	All	After restart	Setup	page 7-67	
			Overheat Pro	tection Select	ions						
				able overheat p				. *9			
	r	n.DDDX	Mor	overheat protenitor a negative					nachine ar	nd	
Pn61A			∠ use	overheat prote	ection.						
				nitor a positive overheat prote		out from a	sensor attact	ned to the m	lachine an	u	
	1	n.DDXD	Reserved par	ameter (Do no	t change.)					
	r	n.¤X¤¤	Reserved par	ameter (Do no	t change.)					
		n.X000	Reserved par	ameter (Do no	t change.)					
	n.XDDD Reserved parameter (Do not change.)										
Pn61B*9	2	Overheat A	Alarm Level	0 to 500	0.01 V	250	All	Immedi- ately	Setup	page 7-67	
Pn61C*9	2	Overheat V	Varning Level	0 to 100	1%	100	All	Immedi- ately	Setup	page 7-67	
Pn61D*9	2	Overheat A Time	larm Filter	0 to 65,535	1 s	0	All	Immedi- ately	Setup	page 7-67	
	I	1			I		1	Continue	1	I	

Continued from previous page.

								tinued fron	n previou	s page.				
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence				
	2	Communic trols	ations Con-	0000h to 1FF3h	-	1040h	All	Immedi- ately	Setup	-				
		- W		I	1	r.		1	1	I				
	.		MEQUATO					•						
				OLINK Commun	ications C	neck Mas	k for Debugg	ing						
				not mask. ore MECHATRO		munication	o orroro (A EG	20)		_				
		n.🗆🗆 X	-	ore WDT errors		nunication	IS EITOIS (A.LC	JOJ.						
			3 Igr	ore both MECHA		communio	cations errors	(A.E60) and	WDT	_				
				heck Masks						-				
			-	not mask.										
			1 Igr	ore data setting	warnings (A.94 □).				_				
			2 Igr	ore command w	arnings (A	.95□).				_				
			3 Igr	ore both A.94	and A.95 E	J warnings	8.			_				
			4 Igr	ore communicat	ions warni	ngs (A.96 E	⊐).			-				
Pn800			5 Igr	ore both A.94	e both A.94□ and A.96□ warnings.									
			6 Igr											
		n.🗆🗆 X 🗆	7 Igr											
			8 Igr	ore data setting	warnings (A.97A and	I A.97b).			_				
			9 Igr	ore A.94 D , A.97	A, and A.	97b warnir	igs.			_				
			A Igr	ore A.95 □ , A.97	A, and A.	97b warnir	igs.			_				
				ore A.94 D , A.95			0			_				
				ore A.96 □ , A.97			8			_				
				ore A.94 D , A.96			-			_				
				lore A.95□, A.96			-			_				
			F Ignore A.94□, A.95□, A.96□, A.97A, and A.97b warnings.											
		n.¤X¤¤												
		n.XDDD	Automatic Warning Clear Selection for Debugging ^{*10}											
		M3 ^{*10}	0 Re	tain warnings for	debuggin	g.								
			1 Automatically clear warnings (MECHATROLINK-III specification).											
	2	Application Selections Limits)	Function 6 (Software	0000h to 0103h	_	0003h	All	Immedi- ately	Setup	page 7-26				
		ů.		i.										
	-		Software L	imit Selection										
			0 En	able both forwar	d and reve	rse softwa	re limits.			_				
		n.🗆🗆 🗆 X	1 Dis	able forward sof	tware limit									
			2 Dis	able reverse sof	ware limit.					_				
Pn801			3 Dis	able both forwar	d and reve	erse softwa	are limits.			_				
		n.🗆🗆 X 🗆	Reserved	parameter (Do no	ot change	.)								
			Software L	imit Check for F	leferences					1				
		n.¤X¤¤	0 Do	not perform soft	ware limit	checks for	r references.			-				
			1 Pe	rform software lir	nit checks	for referer	nces.			_				
		n.XDDD	Reserved	parameter (Do no	ot change	.)				l				
Pn803	2	Origin Ran	ge	0 to 250	1 refer- ence unit	10	All	Immedi- ately	Setup	*1				
					GIN	1	1	1	1	I				

Continued on next page.

Parameter Lists

	Continued from previous									s page.
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
				-1,073,741,823	1 refer-	107374		Immedi-		
Pn804	4	Forward So	oftware Limit	to 1,073,741,823	ence unit	1823	All	ately	Setup	page 7-26
Pn806	4	Povorso S	oftware Limit	-1,073,741,823 to	1 refer- ence	-10737	All	Immedi-	Setup	page
FIIOUU	4	nevelse of		1,073,741,823	unit	41823	Ali	ately	Setup	page 7-26
Pn808	4	Absolute E Offset	ncoder Origin	-1,073,741,823 to	1 refer- ence	0	All	Immedi- ately *11	Setup	page 6-50
		Oliset		1,073,741,823	unit 10,000			ately "		0-50
Pn80A	2	First Stage eration Co	Linear Accel- nstant	1 to 65,535	refer- ence units/s ²	100	All	Immedi- ately ^{*12}	Setup	*1
					10,000					
Pn80B	2	Second St Acceleration	age Linear on Constant	1 to 65,535	refer- ence units/s ²	100	All	Immedi- ately ^{*12}	Setup	*1
D=000	0	Acceleratio	on Constant	0 to 05 505	100 ref-	0	A 11	Immedi-	Oature	*1
Pn80C	2	Switching		0 to 65,535	erence units/s	0	All	ately *12	Setup	*1
Pn80D	0	First Stage	Linear	1 to 65 505	10,000 refer-	100	All	Immedi-	Setup	*1
PN80D	2		on Constant	1 to 65,535	ence units/s ²	100	All	ately *12	Setup	*1
					10,000			Les es ell'		
Pn80E	2	Second St Deceleration	age Linear on Constant	1 to 65,535	refer- ence	100	All	Immedi- ately ^{*12}	Setup	*1
					units/s ² 100 ref-					
Pn80F	2	Deceleration Switching	on Constant Speed	0 to 65,535	erence units/s	0	All	Immedi- ately ^{*12}	Setup	*1
D.010	0	Exponentia	al Accelera-	0.1.05.505	100 ref-	0	A 11	Immedi-	0.1	
Pn810	2		eration Bias	0 to 65,535	erence units/s	0	All	ately *13	Setup	*1
Pn811	2		al Accelera- eration Time	0 to 5,100	0.1 ms	0	All	Immedi- ately ^{*13}	Setup	*1
Pn812	2	Movement Time	Average	0 to 5,100	0.1 ms	0	All	Immedi- ately *13	Setup	*1
Pn814	4	External Po Final Trave		-1,073,741,823 to 1,073,741,823	1 refer- ence unit	100	All	Immedi- ately	Setup	*1
	2	Origin Retu tings	ırn Mode Set-	0000h to 0001h	-	0000h	All	Immedi- ately	Setup	*14
		0					<u> </u>			ļ
			Origin Return	Direction						
	r	n.000X		n in forward di	rection.					_
Pn816			1 Retur	n in reverse dir	rection.					_
M2 ^{*15}	r	1.00X0	Reserved par	ameter (Do no	ot change.)				
	r	1.0X00	Reserved par	ameter (Do no	ot change.)				-
	- 2	n.X000		ameter (Do no						
			neserveu par		r onange.	1				_
Pn817		Origin App	roach Speed		100 ref-			Immedi-		
*16	2	1		0 to 65,535	erence units/s	50	All	ately *12	Setup	*1
Pn818 *17	2	Origin App 2	roach Speed	0 to 65,535	100 ref- erence units/s	5	All	Immedi- ately ^{*12}	Setup	*1
Pn819	4	Final Trave Origin Retu	l Distance for Irn	-1,073,741,823 to	1 refer- ence	100	All	Immedi- ately	Setup	*1
				1,073,741,823	unit		<u> </u>	Continuc	L	Ļ

Continued norri previous page	Continued from pr	evious p	age.
-------------------------------	-------------------	----------	------

								itinued fron	· ·	Refer-		
Parameter No.	Size	N	Name Setting Range Setting Unit Default Setting Applicable Motors When Enabled Classi- fication nput Signal Monitor 0000h to 7777 to 77777 to 7777 to 7777 to 7777 to 7777 to 7777 to 7777 to 7777 to 7777 to 77777 to 77777 to 77777 to 7777 to 77777 to 7777 to 77777 to 77777 to									
	2	Input Sign Selections	al Monitor	0000h to 7777h	-	0000h	All	Immedi- ately	Setup	*14		
				I	1		I					
			IO12 Signal M	Mapping								
			0 Do no	ot map.						_		
				tor CN1-13 inp						_		
				tor CN1-7 inpu						_		
		n.🗆🗆 🗆 X		tor CN1-8 inpu						-		
D=01E				tor CN1-9 inpu						-		
Pn81E M2 ^{*15}				tor CN1-10 inp						-		
IVIZ				tor CN1-11 inp tor CN1-12 inp						-		
			IO13 Signal N	13 Signal Mapping								
		n.□□X□		nappings are tl	he same a	s the IO12	signal mappi	ngs.		_		
			IO14 Signal N	Mapping								
		n.¤X¤¤	0 to 7 The r	mappings are tl	he same a	s the IO12	signal mappi	ngs.		-		
		n.XDDD	IO15 Signal N	Mapping								
		0 to 7 The mappings are the same as the IO12 signal mappings.										
	2	Command tions	Data Alloca-	0000h to 1111h	-	0010h	All	After restart	Setup	*14		
				1	1		I	L				
			Option Field	Allocation								
		n.🗆🗆 🗆 X	0 Disab	ole option field	allocation.					_		
Pn81F			1 Enab	le option field a	allocation.					_		
M2 ^{*15}			Position Con	trol Command	TFF/TLIN	1 Allocatio	n					
		n.🗆🗆 X 🗆	0 Disab	ole allocation.								
			1 Enab	le allocation.						_		
		n.¤X¤¤	Reserved par	rameter (Do no	ot change.)						
		n.XDDD	Reserved par	rameter (Do no	ot change.)						
Pn820	4	Forward L	atching Area	-2,147,483,648 to 2,147,483,647	1 refer- ence unit	0	All	Immedi- ately	Setup	*1		
Pn822	4	Reverse L	atching Area	-2,147,483,648 to 2,147,483,647	1 refer- ence unit	0	All	Immedi- ately	Setup	*1		

Continued on next page.

							Cor	itinued fro	om previou	s page			
Parameter No.	Size		Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence			
	2	Option N tion	Ionitor 1 Selec-	0000h to FFFFh	-	0000h	-	Immedi- ately	Setup	*1			
					1								
		Setting			Monitor			Ap	plicable M	otors			
	Н	ligh-Speed	d Monitor Regio	า									
	C	000h	Motor speed [c	verspeed dete	ction spee	ed/100000	0h]		All				
		001h	Speed reference			speed/100	0000h]		All				
		002h	Torque [maxim	1					All				
		003h	Position deviati						All				
		004h	Position deviati		, .				All				
		00Ah	Encoder count	,					All				
		00Bh	Encoder count						All				
		000Ch	FPG count (low	, :									
	_	00Dh	FPG count (upp	, 1	rerence un	itsj			All				
		•	Monitor Regior						A11				
		010h	Un000: Motor :						All				
	C	011h	Un001: Speed						All				
	C	012h	Un002: Torque						All				
		013h	Number of enc	n003: Rotational Angle 1 [encoder pulses] Imber of encoder pulses from origin within one encoder rotation splayed in decimal									
		01011	Un003: Rotatio Linear encoder	layed in decir	nal	All							
		014h	Un004: Rotatio Electrical angle		All								
n824 M3 ^{*10}		01411											
1010	C	015h	Un005: Input S		All								
	C	016h	Un006: Output	Signal Monito	r				All				
	C	017h	Un007: Input F	eference Spee	ed [min ⁻¹]				All				
	C	018h	Un008: Positio	n Deviation [ret	ference un	its]			All				
	C	019h	Un009: Accum	ulated Load R	atio [%]				All				
	C	01Ah	Un00A: Regene	erative Load R	atio [%]				All				
	C	01Bh	Un00B: Dynam	ic Brake Resis	tor Power	Consump	tion [%]		All				
	C	01Ch	Un00C: Input F	Reference Puls	e Counter	[reference	units]		All				
	C	01Dh	Un00D: Feedba	ack Pulse Cou	nter [enco	der pulses			All				
	C	01Eh	Un00E: Fully-cl resolution]	osed Loop Fee	edback Pu	lse Counte	r [external en	coder	Rotary				
	C	023h	Initial multiturn	data [Rev]					Rotary				
	C	024h	Initial incremen	tal data [pulses	5]				Rotary				
	C	025h	Initial absolute	position data (lower 32 b	its) [pulses	5]		Linear				
	C	026h	Initial absolute	position data (upper 32 k	oits) [pulse	s]		Linear				
	C	040h	Un025: SERVC	PACK Installat	ion Enviro	nment Mo	nitor		All				
	C	041h	Un026: Servon	notor Installatio	n Environi	ment Moni ⁻	or		All				
	C	042h	Un027: Built-in	Fan Remainin	g Life Rati	0			All				
	C	043h	Un028: Capaci		All								
	C	044h	Un029: Surge I	Prevention Circ	uit Remai	ning Life R	atio		All				
	C	045h	Un02A: Dynam		All								
	C	046h	Un032: Instant	aneous Power					All				
	C	047h	Un033: Power	Consumption					All				
	C	048h	Un034: Cumula		All								
	C	04Bh	Un036: Built-in	Brake Relav F	Remaining	Life Ratio			All				

Continued from previous page.

Continued from previous page.

Parameter No.	Size	Ν	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors		/hen abled	Classi- fication	Refer- ence
	-	Setting Communic:	ations Module	Only	Monitor				Applic	able Mot	ors
		0080h	1	e of latched fee	dback po	sition (LPC	S1) [reference	Э		All	
Pn824 M3 *10	-	0081h	Previous value units]	e of latched fee	dback po	sition (LPC	S2) [reference	Э		All	
	_	0084h	Continuous La	atch Status (EX	(STATUS)					All	
		All Areas	1								
	_	Other values	Reserved para	Reserved parameters (Do not change.) All							
	2	Option Mo tion	onitor 2 Selec-	0000h to FFFFh	-	0000h	All		medi- ately	Setup	*1
Pn825	-	0000h to 0084h	The settings	are the same	as those f	or the Opti	on Monitor 1	Sele	ction.		
Pn827	2	Linear Deo Constant	celeration 1 for Stopping	1 to 65,535	10,000 refer- ence units/s ²	100	All		medi- əly ^{*12}	Setup	*1
Pn829	2	SVOFF Wa SVOFF at to Stop)	aiting Time (for Deceleration	0 to 65,535	10 ms	0	All		medi- əly ^{*12}	Setup	*1
				1	1		1	С	ontinue	ed on nex	t page.

								Con	tinued fron	n previou	s page.
Parameter No.	Size	N	lame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2	Option Fie 1	ld Alloca	tions	0000h to 1E1Eh	-	1813h	All	After restart	Setup	*14
	_										
			ACCFI	L Alloc	ation (Option)						_
			0		ate bits 0 and						
			1	Alloca	ate bits 1 and 2	2 to ACCF	IL.				_
			2	Alloca	ate bits 2 and	3 to ACCF	IL.				_
			3		ate bits 3 and						
			4		ate bits 4 and						
			5		ate bits 5 and						
		n.🗆 🗆 🗆 X	6		ate bits 6 and						_
			7		ate bits 7 and						
			8		ate bits 8 and						_
			9		ate bits 9 and						_
Pn82A			A		ate bits 10 and		-				_
M2 *15			B		ate bits 11 and						_
			C	Allocate bits 12 and 13 to ACCFIL.							
			D	Allocate bits 13 and 14 to ACCFIL. Allocate bits 14 and 15 to ACCFIL.							
	_		E	Alloca	ate bits 14 and	15 to AC	CHIL.				
			ACCFI	L Alloc	ation Enable/I	Disable Se	election				
		n.🗆🗆 X 🗆	0	Disab	le ACCFIL allo	cation.					
	_		1	Enab	le ACCFIL allo	cation.					
											-
		n.¤X¤¤		1	ation (Option)			0.5.11			
	_		0 to E	The s	ettings are the	same as	for the AC	UHIL allocatio	ns.		_
			G_SEL	Alloca	ation Enable/D	isable Sel	ection				
		n. XDDD	0	Disab	le G_SEL allo	cation.					
			1	Enab	le G_SEL alloc	ation.					

								tinued fron	n previou	s page.		
Parameter No.	Size	١	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	Option Fie	eld Allocations	0000h to 1F1Fh	_	1D1Ch	All	After restart	Setup	*14		
		2						restart	•			
										_		
			V_PPI Alloca							_		
				ate bit 0 to V_F						_		
				ate bit 1 to V_F ate bit 2 to V_F						_		
				ate bit 2 to V_I ate bit 3 to V_I						_		
				ate bit 4 to V_F								
				ate bit 5 to V_F						_		
				ate bit 6 to V_F						_		
		n.🗆🗆 🛛 X	7 Alloc	ate bit 7 to V_F	PPI.							
			8 Alloc	ate bit 8 to V_F	PPI.					_		
			9 Alloc	ate bit 9 to V_F	PPI.					_		
			A Alloc	ate bit 10 to V	_PPI.					_		
Pn82B				ate bit 11 to V								
M2 *15				ate bit 12 to V								
				ate bit 13 to V	-					_		
				ate bit 14 to V	-					_		
			F Alloc	ate bit 15 to V	_PPI.					_		
			V_PPI Alloca	tion Enable/Di	sable Sele	ection						
		n.🗆🗆 X 🗆	0 Disa	ole V_PPI alloc	ation.							
			1 Enab	le V_PPI alloca	ition.							
			P_PI_CLR Allocation (Option)									
		n.🗆X🗆 🗆						_				
			0 to F The settings are the same as for the V_PPI allocations.									
			P_PI_CLR A	location Enabl	e/Disable	Selection				_		
		n.XDDD	P_PI_CLR Allocation Enable/Disable Selection 0 Disable P_PI_CLR allocation.									
			1 Enat	le P_PI_CLR a	llocation.							
										_		
					1			A (1 -				
	2	Option Fie	eld Allocations	0000h to 1F1Fh	-	1F1Eh	All	After restart	Setup	*14		
										I		
			P_CL Allocat	tion (Option)								
		n.DDDX		settings are the	same as	for the V_F	PPI allocations	5.		-		
			P_CL Alloca	tion Enable/Dis	able Sele	ction						
Pn82C		n.🗆🗆 X 🗆	0 Disa	ole P_CL alloca	ation.							
M2 *15			1 Enat	ole P_CL alloca	tion.							
										-		
		n.¤X¤¤	N_CL Alloca		00000.05	for the V/		2				
			0 to F The	settings are the	same as	ior the V_F	-ri allocations	5.				
			N CL Alloca	tion Enable/Dis	sable Sele	ction				-		
		n.X000		ole N_CL alloca						-		
				le N_CL alloca						_		
										_		

Continued on next page.

							Con	tinued fron	n previou	s page.		
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence		
	2	Option Fie 4	ld Allocatio	ns 0000h to 1F1Ch	_	0000h	All	After restart	Setup	*14		
Pn82D M2 ^{*15}		n.□□□X	0 A 1 A 2 A 3 A 4 A 5 A 6 A 7 A 8 A 9 A A A B A	L1 Allocation (Op locate bits 0 to 3 locate bits 1 to 4 locate bits 2 to 5 locate bits 3 to 6 locate bits 3 to 6 locate bits 4 to 7 locate bits 5 to 8 locate bits 7 to 10 locate bits 7 to 10 locate bits 8 to 1 locate bits 9 to 13 locate bits 9 to 13 locate bits 10 to locate bits 12 to	to BANK_ to BANK_ to BANK_ to BANK_ to BANK_ to BANK_ 0 to BANK 1 to BANK 2 to BANK 2 to BANK 13 to BAN	SEL1. SEL1. SEL1. SEL1. SEL1. _SEL1. _SEL1. _SEL1. K_SEL1. K_SEL1.						
		n.00X0	0 D	L1 Allocation Enaisable BANK_SEL	1 allocatio 1 allocatior	n.	on			-		
			0 to F T	ne settings are the	e same as	for the V_F	PPI allocations	S.		_		
			LT_DISAE	LE Allocation En	able/Disat	ole Selecti	on					
		n.XDDD		isable LT_DISABL						_		
			1 E	nable LT_DISABLI	E allocation	۱.				_		

Continued from previous page.

							Con	itinued from	n previou	s page.				
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence				
	2	Option Fie 5	ld Allocations	0000h to 1D1Fh	-	0000h	All	After restart	Setup	*14				
	Ι.	n.DDDX	Reserved pa	rameter (Do no	t change	١								
					-					_				
		n.DDXD	Reserved pa	rameter (Do no	ot change.	.)								
			OUT_SIGNA	L Allocation (O	ption)									
			0 Alloc	ate bits 0 to 2	to OUT_SI	GNAL.								
			1 Alloc	ate bits 1 to 3	to OUT_SI	GNAL.				_				
				ate bits 2 to 4						_				
				ate bits 3 to 5						_				
Dm00E				ate bits 4 to 6						_				
Pn82E M2 ^{*15}				ate bits 5 to 7										
1012		n.¤X¤¤		ate bits 6 to 8	_					_				
				ate bits 7 to 9 ate bits 8 to 10						-				
				ate bits 9 to 10										
				ate bits 10 to 1	-					_				
				ate bits 11 to 1	-	-				-				
			C Alloc											
			D Allocate bits 13 to 15 to OUT_SIGNAL.											
			D Allocate bits 13 to 15 to OUT_SIGNAL. OUT_SIGNAL Allocation Enable/Disable Selection											
		n.X000		0 Disable OUT_SIGNAL allocation.										
				ble OUT_SIGNA										
	-													
								A. (1						
	2	Motion Se	ttings	0000h to 0001h	-	0000h	All	After restart	Setup	*1				
		1							1					
			Linear Accel	eration/Decele	ration Cor	nstant Sele	ection							
				Pn80A to Pn80	F and Pn8	327. (The s	ettings of Pn	334 to Pn840) are					
D . 000		n.🗆🗆 🗆 X	ignoi	rea.) Pn834 to Pn84	0 (Tho co	ttings of P	n801 to Dn80	E and Dng?	7 aro	_				
Pn833			1 ignor		U. (The se	tungs of P			are					
		n.DDXD	Reserved pa	rameter (Do no	ot change)				-				
			•			,				-				
		n.¤X¤¤	Reserved pa	rameter (Do no	ot change.	.)								
		n.XDDD	Reserved pa	rameter (Do no	ot change.)				I				
										-				
					10,000									
Pn834	4		Linear Accel-	1 to	refer-	100	All	Immedi-	Setup	*1				
1 1100-4		eration Co	nstant 2	20,971,520	ence units/s ²	100	<i>F</i> AII	ately *12	UCTUP	1				
					10,000					-				
Pn836	4		age Linear	1 to	refer-	100	All	Immedi-	Setup	*1				
		Acceleratio	on Constant 2	20,971,520	ence units/s ²		, w	ately *12	Cotop					
		Appelant			1 refer-			Immodi						
Pn838	4	Acceleration Switching	on Constant Speed 2	0 to 2,097,152,000	ence	0	All	Immedi- ately *12	Setup	*1				
					unit/s 10,000			,						
Pn83A	4	First Stage		1 to	refer-	100	All	Immedi-	Setup	*1				
1 100/4		Deceleratio	on Constant 2	20,971,520	ence units/s ²	100	7411	ately *12	UCTUP					
					unit5/5									

Continued on next page.

								Con	tinued fron	n previou	s page.
Parameter No.	Size	N	ame		Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn83C	4	Second St Deceleratio			1 to 20,971,520	10,000 refer- ence units/s ²	100	All	Immedi- ately ^{*12}	Setup	*1
Pn83E	4	Deceleration Switching			0 to 2,097,152,000	1 refer- ence unit/s	0	All	Immedi- ately ^{*12}	Setup	*1
Pn840	4	Linear Dec Constant 2			1 to 20,971,520	10,000 refer- ence units/s ²	100	All	Immedi- ately ^{*12}	Setup	*1
Pn842 *16	4	Second Or Approach			0 to 20,971,520	100 ref- erence units/s	0	All	Immedi- ately ^{*12}	Setup	*1
Pn844 *17	4	Second Or Approach	rigin Speed 2		0 to 20,971,520	100 ref- erence units/s	0	All	Immedi- ately ^{*12}	Setup	*1
Pn846	2	POSING C Scurve Acc Deceleration	celeratio		0 to 50	1%	0	All	Immedi- ately ^{*12}	Setup	_
Pn850	2	Number of Sequences			0 to 8	_	0	All	Immedi- ately	Setup	*1
Pn851	2	Continuou Sequence	s Latch Count		0 to 255	_	0	All	Immedi- ately	Setup	*1
	2	Latch Sequence Settings	equence 1 to 4		0000h to 3333h	-	0000h	All	Immedi- ately	Setup	*1
				.							-
			Latch a	Phas	nce 1 Signal S	election					
		n.000X	1		signal						-
		/	2		signal						-
			3		signal						-
5			Latch	Seque	nce 2 Signal S	election					-
Pn852		n.DDXD		r .	settings are the		those for t	he Latch Seq	uence 1 Siar	nal Selec-	
			0 to 3	tion.							_
			Latch S	Seque	nce 3 Signal S	election					[
		n.¤X¤¤	0 to 3	The stion.	settings are the	same as	those for t	he Latch Seq	uence 1 Sigr	nal Selec-	_
			Latch S	Seque	nce 4 Signal S	election					Ī.
		n.XDDD	0 to 3 The settings are the same as those for the Latch Sequence 1 Signal Selec- tion.								

Continued from previous page.

Parameter							Cor	1	· · · · · · · · · · · · · · · · · · ·	_	
No.	Size	N	lame	Setting Range		Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer ence	
Pn853	2	Latch Seq Settings	uence 5 te	o 8 0000h to 3333h		0000h	All	Immedi- ately	Setup	*1	
			Latch Sequence 5 Signal Selection								
		n.000X	0	Phase C						_	
				EXT1 signal						_	
				EXT2 signal						_	
			3	EXT3 signal						_	
			Latch Sequence 6 Signal Selection								
		n.□□X□	0 to 3 The settings are the same as those for the Latch Sequence 5 Signal Selec- tion.								
			Latch Sequence 7 Signal Selection								
		n.¤X¤¤		The settings are tion.	the same as	those for t	he Latch Seq	uence 5 Sigr	nal Selec-	_	
			Latch Sequence 8 Signal Selection								
		n.XDDD	1010.3	The settings are the same as those for the Latch Sequence 5 Signal Selec-							
		1									
	2	SVCMD_IC Monitor Al	O Input Sig locations	gnal 0000h to 1 1717h	D _	0000h	All	Immedi- ately	Setup	*1	
	2	SVCMD_IC Monitor Al	locations	gnal 0000h to 1 1717h gnal Monitor All					Setup	*1	
	2	SVCMD_IC Monitor Al	Input Sig	1 1717h	ocation for C	N1-13 (SV	CMD_IO)	ately	Setup	*1	
	2	SVCMD_IC Monitor Al	Input Signature	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I	ocation for C O_STS1) to C O_STS2) to C	N1-13 (SV N1-13 inp N1-13 inp	CMD_IO) ut signal mon ut signal mon	ately itor. itor.	Setup	*1	
	2	Monitor Al	Input Signature	gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I	ocation for C O_STS1) to C O_STS2) to C O_STS3) to C	N1-13 (SV 2N1-13 inp 2N1-13 inp 2N1-13 inp	CMD_IO) ut signal mon ut signal mon ut signal mon	itor. itor. itor.	Setup	*1	
	2	n.DDX	Input Sig 0 1 2 3	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 26 (I Allocate bit 27 (I	ocation for C O_STS1) to C O_STS2) to C O_STS3) to C O_STS4) to C	N1-13 (SV CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp	CMD_IO) ut signal mon ut signal mon ut signal mon ut signal mon	ately iitor. iitor. iitor. iitor.	Setup	*1	
	2	Monitor Al	Input Sig 0 1 2 3 4	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 27 (I Allocate bit 28 (I	ocation for C O_STS1) to C O_STS2) to C O_STS3) to C O_STS4) to C O_STS5) to C	N1-13 (SV CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp	CMD_IO) ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon	ately iitor. iitor. iitor. iitor. iitor.	Setup	*1	
	2	Monitor Al	Input Sig 0 1 2 3 4 5	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 28 (I Allocate bit 28 (I Allocate bit 28 (I	ocation for C O_STS1) to C O_STS2) to C O_STS3) to C O_STS4) to C O_STS5) to C O_STS6) to C	N1-13 (SV CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp	CMD_IO) ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon	ately itor. iitor. iitor. iitor. iitor. iitor.	Setup	*1	
Pn860	2	Monitor Al	Input Sig 0 1 2 3 4 5 6	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 27 (I Allocate bit 28 (I	ocation for C O_STS1) to C O_STS2) to C O_STS3) to C O_STS4) to C O_STS5) to C O_STS6) to C O_STS7) to C	N1-13 (SV CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp	CMD_IO) ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon	ately iitor. iitor. iitor. iitor. iitor. iitor. iitor.	Setup	*1	
	2	Monitor Al	Input Signations 0 1 2 3 4 5 6 7 CN1-13	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 28 (I Allocate bit 29 (I Allocate bit 30 (I Allocate bit 31 (I	ocation for C O_STS1) to C O_STS2) to C O_STS3) to C O_STS4) to C O_STS5) to C O_STS5) to C O_STS6) to C O_STS7) to C O_STS7) to C O_STS8) to C	N1-13 (SV CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp CN1-13 inp	CMD_IO) ut signal mon ut signal mon	ately iitor. iitor. iitor. iitor. iitor. iitor. iitor.	Setup	*1	
	2	Monitor Al	Input Sig 0 1 2 3 4 5 6 7 CN1-13 0	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 28 (I Allocate bit 29 (I Allocate bit 30 (I Allocate bit 31 (I Input Signal Me Disable allocatio	ocation for C 0_STS1) to C 0_STS2) to C 0_STS3) to C 0_STS4) to C 0_STS5) to C 0_STS5) to C 0_STS6) to C 0_STS6) to C 0_STS6) to C 0_STS6) to C 0_STS7) to C 0_STS8) to C 0_STS80 to C	N1-13 (SV N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp (N1-13 inp /Disable S input sign	CMD_IO) ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon election al monitor.	ately iitor. iitor. iitor. iitor. iitor. iitor. iitor.	Setup	*1	
	2	n.DDDX	Input Sig 0 1 2 3 4 5 6 7 CN1-13 0	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 28 (I Allocate bit 29 (I Allocate bit 30 (I Allocate bit 31 (I	ocation for C 0_STS1) to C 0_STS2) to C 0_STS3) to C 0_STS4) to C 0_STS5) to C 0_STS5) to C 0_STS6) to C 0_STS6) to C 0_STS6) to C 0_STS6) to C 0_STS7) to C 0_STS8) to C 0_STS80 to C	N1-13 (SV N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp (N1-13 inp /Disable S input sign	CMD_IO) ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon election al monitor.	ately iitor. iitor. iitor. iitor. iitor. iitor. iitor.	Setup	*1	
	2	Monitor Al	Input Signations 0 1 2 3 4 5 6 7 CN1-13 0 1	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 28 (I Allocate bit 29 (I Allocate bit 30 (I Allocate bit 31 (I Input Signal Me Disable allocatio	ocation for C 0_STS1) to C 0_STS2) to C 0_STS3) to C 0_STS4) to C 0_STS5) to C 0_STS5) to C 0_STS6) to C 0_STS7) to C 0_STS8) to C 0_STS80 to C 0_STS80 to C 0_STS80 to C 0_STS80 to C	N1-13 (SV N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp (N1-13 inp /Disable S input signa	CMD_IO) ut signal mon ut signal mon al monitor.	ately iitor. iitor. iitor. iitor. iitor. iitor. iitor.	Setup	*1	
	2	n.DDDX	Input Signations 0 1 2 3 4 5 6 7 0 1 0 1 0 1	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 28 (I Allocate bit 29 (I Allocate bit 30 (I Allocate bit 31 (I Input Signal Mo Disable allocatio	ocation for C 0_STS1) to C 0_STS2) to C 0_STS3) to C 0_STS4) to C 0_STS5) to C 0_STS5) to C 0_STS6) to C 0_STS6) to C 0_STS6) to C 0_STS6) to C 0_STS7) to C 0_STS8) to C 0 0_STS8) to C 0	N1-13 (SV 2N1-13 inp 2N1-13 inp	CMD_IO) ut signal mon ut signal mon al monitor. al monitor.	ately iitor. iitor. iitor. iitor. iitor. iitor. iitor.	Setup	*1	
	2	Monitor Al	Input Signations 0 1 2 3 4 5 6 7 CN1-13 0 1 0 1	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 28 (I Allocate bit 29 (I Allocate bit 30 (I Allocate bit 30 (I Allocate bit 31 (I Input Signal Mo Disable allocatio Enable allocatio	ocation for C O_STS1) to C O_STS2) to C O_STS3) to C O_STS4) to C O_STS5) to C O_STS5) to C O_STS6) to C O_STS7) to C O_STS8) to C O_STS8 to C O_STS9 to C	N1-13 (SV N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp (Disable S input signa input signa N1-7 (SVC the CN1-1	CMD_IO) ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon ut signal mon election al monitor. CMD_IO) 3 allocations.	ately iitor. iitor. iitor. iitor. iitor. iitor. iitor.	Setup	*1	
	2	Monitor Al	Input Signations 0 1 2 3 4 5 6 7 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1	1 1717h gnal Monitor All Allocate bit 24 (I Allocate bit 25 (I Allocate bit 26 (I Allocate bit 27 (I Allocate bit 28 (I Allocate bit 29 (I Allocate bit 30 (I Allocate bit 31 (I Input Signal Mo Disable allocatio Enable allocatio Input Signal Monitor All The settings are	ocation for C 0_STS1) to C 0_STS2) to C 0_STS3) to C 0_STS4) to C 0_STS5) to C 0_STS5) to C 0_STS6) to C 0_STS6) to C 0_STS6) to C 0_STS6) to C 0_STS7) to C 0_STS8) to C 0_STS80 to C<	N1-13 (SV N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp N1-13 inp (Disable S input signa N1-7 (SVC the CN1-1	CMD_IO) ut signal mon ut signal mon election al monitor. al monitor. SMD_IO) 3 allocations. lection	ately iitor. iitor. iitor. iitor. iitor. iitor. iitor.	Setup	*1	

Continued on next page.

	Continued from previous pa									s page.
Parameter No.	Size	N	lame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn861 M3 ^{*10}	2	SVCMD_IC Monitor Al	O Input Signal locations 2	0000h to 1717h	-	0000h	All	Immedi- ately	Setup	*1
		n.DDDX	Input Signal N	Monitor Alloca	tion for C	N1-8 (SVC	MD_IO)			I
		11.000	0 to 7 The settings are the same as the CN1-13 allocations.							_
				Signal Monito	r Enable/D	isable Sel	lection			
		n.🗆 🗆 🛛		le allocation fo						-
										-
		n.¤X¤¤		Monitor Alloca ettings are the						
										-
		n.XDDD		Signal Monitor						
				e allocation fo						_
	2		O Input Signal locations 3	0000h to 1717h	-	0000h	All	Immedi- ately	Setup	*1
	Monitor Allocations 3 1717h - 000011 All ately Setup									
		n.DDDX	Input Signal Monitor Allocation for CN1-10 (SVCMD_IO)							
			0 to 7 The settings are the same as the CN1-13 allocations.							
		n.DDXD	CN1-10 Input Signal Monitor Enable/Disable Selection							I
Pn862				le allocation fo		. 0				-
M3 *10										
		n.DXDD Input Signal Monitor Allocation for CN1-11 (SVCMD_IO) 0 to 7 The settings are the same as the CN1-13 allocations.								
			CN1-11 Input	Signal Monito	or Enable	/Disable S	election			-
		n.XDDD		le allocation fo						
			1 Enabl	e allocation fo	r CN1-11	input signa	al monitor.			_
								las as s el:		
Pn863	2		O Input Signal locations 4	0000h to 1717h	-	0000h	All	Immedi- ately	Setup	*1
		n.DDDX	Input Signal Monitor Allocation for CN1-12 (SVCMD_IO)0 to 7The settings are the same as the CN1-13 allocations.							
			CN1-12 Input Signal Monitor Enable/Disable Selection							
		n.🗆 🗆 X 🗆		Signal Monitor						
				e allocation fo						-
	n.□X□□ Reserved parameter (Do not change.)									-
		n.XDDD			-					-
	n.X□□□ Reserved parameter (Do not change.)									
	Continued on peyt									+

Continued from previous page.

	Continued from previous									s page.
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn868 M3 *10	2	SVCMD_IC nal Monitor 1	Output Sig- Allocations	0000h to 1717h	_	0000h	All	Immedi- ately	Setup	*1
		n.□□□X	0 Alloca 1 Alloca 2 Alloca 3 Alloca 4 Alloca 5 Alloca 6 Alloca 7 Alloca CN1-1/CN1-2	Output Signal Monitor Allocation for CN1-1 and CN1-2 (SVCMD_IO) 0 Allocate bit 24 (IO_STS1) to CN1-1/CN1-2 output signal monito 1 Allocate bit 25 (IO_STS2) to CN1-1/CN1-2 output signal monito 2 Allocate bit 26 (IO_STS3) to CN1-1/CN1-2 output signal monito 3 Allocate bit 27 (IO_STS4) to CN1-1/CN1-2 output signal monito 4 Allocate bit 28 (IO_STS5) to CN1-1/CN1-2 output signal monito 5 Allocate bit 29 (IO_STS6) to CN1-1/CN1-2 output signal monito 6 Allocate bit 30 (IO_STS7) to CN1-1/CN1-2 output signal monito 7 Allocate bit 31 (IO_STS8) to CN1-1/CN1-2 output signal monito 7 Allocate bit 31 (IO_STS8) to CN1-1/CN1-2 output signal monito						-
		n.□□X□ 0 Disable allocation for CN1-1/CN1-2 output signal monitor. 1 Enable allocation for CN1-1/CN1-2 output signal monitor. n.□X□□ Output Signal Monitor Allocation for CN1-23 and CN1-24 (SVCMD_IO) 0 to 7 The settings are the same as the CN1-1/CN1-2 allocations.								-
		NDDD CN1-23/CN1-24 Output Signal Monitor Enable/Disable Selection 0 Disable allocation for CN1-23/CN1-24 output signal monitor. 1 Enable allocation for CN1-23/CN1-24 output signal monitor.								-
	2	SVCMD_IC nal Monitor 2	Output Sig- Allocations	0000h to 1717h	-	0000h	All	Immedi- ately	Setup	*1
Pn869 M3 *10		n.OOOX	Output Signal Monitor Allocation for CN1-25 and CN1-26 (SVCMD_IO) 0 to 7 The settings are the same as the CN1-1/CN1-2 allocations.							
		n.DDXD	CN1-25/CN1-26 Output Signal Monitor Enable/Disable Selection 0 Disable allocation for CN1-25/CN1-26 output signal monitor. 1 Enable allocation for CN1-25/CN1-26 output signal monitor.							
		Output Signal Monitor Allocation for CN1-27 and CN1-28 (SVCMD_IO) 0 to 7 The settings are the same as the CN1-1/CN1-2 allocations.								
		n.X000	0 Disab	-28 Output Signal Signa	or CN1-27,	/CN1-28 o	utput signal n	nonitor.		

14.1.2 List of Servo Parameters

							Cor	tinued fron	n previou	s page.
Parameter No.	Size	N	ame	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
	2) Output Sig- r Allocations	0000h to 1717h	_	0000h	All	Immedi- ately	Setup	*1
		n.000X		I Monitor Alloc settings are the				- ,	1	
Pn86A M3 ^{*10}		n.00X0	0 Disab	-30 Output Sig ble allocation fo le allocation fo	r CN1-29,	/CN1-30 o	utput signal r	nonitor.		-
		n.🗆X🗆	Reserved par	rameter (Do no	ot change.)				
		n.XDDD	Reserved par	rameter (Do no	ot change.)				I
Pn880	2	Station Add tor (for mai read only)	dress Moni- intenance,	03h to EFh	_	-	All	_	Setup	page 6-12
Pn881	2	Count Mor	nission Byte hitor [bytes] nance, read	17, 32, 48	_	-	All	-	Setup	page 6-12
Pn882	2	ting Monito	on Cycle Set- or [× 0.25 μs] nance, read	Oh to FFFFh	_	_	All	-	Setup	page 6-12
Pn883	2	Setting Mo mission cy	ations Cycle nitor [trans- cles] (for ce, read only)	0 to 32	_	_	All	-	Setup	page 6-12
	2	Communic trols 2	ations Con-	0000h to 0001h	-	0000h	All	Immedi- ately	Setup	*1
Pn884 M3 ^{*10}	n		0 Mainta MECH 1 Apply 1 Reserved para	NK Communic in the status s ATROLINK cor the holding bra meter (Do not meter (Do not	et by the E nmunication ke when a change.) change.)	BRK_ON or ons error o	r BRK_OFF co ccurs.	ommand wh		Jrs.
	<u>n</u>	.X000 F	Reserved para	imeter (Do not	cnange.)					
Pn88A	2	Monitor	OLINK ror Counter nance, read	0 to 65,535	_	0	All	_	Setup	_
Pn890 to Pn8A6	4	tor during A	Data Moni- Alarm/Warn- nance, read	Oh to FFFFFFFFh	-	Oh	All	-	Setup	page 13-60
Pn8A8 to Pn8BE	4	during Alar	Data Monitor m/Warning nance, read	Oh to FFFFFFFFh	_	Oh	All	_	Setup	page 13-60
Pn900	2	Number of Banks	Parameter	0 to 16	-	0	All	After restart	Setup	*1
Pn901	2	Number of Bank Mem	Parameter bers	0 to 15	_	0	All	After restart	Setup	*1
Pn902 to Pn910	2	Parameter ber Definiti	Bank Mem- on	0000h to 08FFh	_	0000h	All	After restart	Setup	*1

14.1.2 List of Servo Parameters

Continued from previous page.

Parameter No.	Size	Name	Setting Range	Setting Unit	Default Setting	Applicable Motors	When Enabled	Classi- fication	Refer- ence
Pn920 to Pn95F	2	Parameter Bank Data (Not saved in nonvolatile memory.)	0000h to FFFFh	_	0000h	All	Immedi- ately	Setup	*1

*1. Refer to the following manual for details.

Ω Σ-7-Series AC Servo Drive MECHATROLINK-III Communications Standard Servo Profile Command Manual (Manual No.: SIEP S800001 31)

*2. Set a percentage of the motor rated torque.

*3. The default setting is 32 for a SERVOPACK with built-in Servomotor brake control.

- *4. Normally set this parameter to 0. If you use an External Regenerative Resistor, set the capacity (W) of the External Regenerative Resistor.
- *5. The upper limit is the maximum output capacity (W) of the SERVOPACK.

*6. SGD7S-210D to 370D SERVOPACKs require three Dynamic Brake Resistors. For this parameter setting, enter the total value of resistor capacity of the three resistors.

- *7. SGD7S-210D to 370D SERVOPACKs require three Dynamic Brake Resistors. For this parameter setting, enter the resistance of one Dynamic Brake Resistor multiplied by $\sqrt{3}$.
- *8. The SGLFW2 is the only Yaskawa Linear Servomotor that supports this function.

*9. Enabled only when Pn61A is set to n. DDD2 or n. DDD3.

*10.This parameter is valid only when the MECHATROLINK-III standard servo profile is used.

*11. The parameter setting is enabled after SENS_ON command execution is completed.

*12.Change the setting when the reference is stopped (i.e., while DEN is set to 1). If you change the setting during operation, the reference output will be affected.

*13. The settings are updated only if the reference is stopped (i.e., only if DEN is set to 1).

*14.Refer to the following manual for details.

Ω Σ-7-Series AC Servo Drive MECHATROLINK-II Communications Command Manual (Manual No.: SIEP S800001 30)

*15.This parameter is valid only when the MECHATROLINK-II-compatible profile is used.

- *16.The setting of Pn842 is valid while Pn817 is set to 0.
- *17.The setting of Pn844 is valid while Pn818 is set to 0.

14

14.2.1 Interpreting the Parameter Lists

14.2 List of MECHATROLINK-III Common Parameters

14.2.1 Interpreting the Parameter Lists

- The types of Servomotors to which the parameter applies.
- All: The parameter is used for both Rotary Servomotors and Linear Servomotors.
 Rotary: The parameter is used for only Rotary Servomotors.
- Linear: The parameter is used for only Linear Servomotors.
- Rotary Servomotor terms are used for parameters that are

applicable to all Servomotors. If you are using a Linear Servomotor, you need to interpret the terms accordingly. Refer to the following section for details.

					\geq		/		
Parameter No.	Size	Name	Setting Range	Setting Unit [Resolution]	Defaunt Setting	Applicable Motors	When Enabled	Classi- fication	
61 PnAC2	4	Speed Loop Gain	1,000 to 2,000,000	0.001 Hz [0.1 Hz]	40000	All	Immedi- ately	Tuning	

You can set the parameter in increments of the setting unit. However, if a unit is given in square brackets,

.

Indicates when a change to the

"After restart" indicates parameters

that will be effective after one of the

• The power supply is turned OFF

The CONFIG command is sent.

• A software reset is executed.

parameter will be effective.

following is executed.

and ON again.

the setting is automatically converted to the

resolution given in the square brackets.

14.2.2 List of MECHATROLINK-III Common Parameters

The following table lists the common MECHATROLINK-III parameters. These common parameters are used to make settings from the host controller via MECHATROLINK communications. Do not change the settings with the Digital Operator or any other device.

Parameter No.	Size	Nar	ne	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
	4	Encoder Ty tion (read c	rpe Selec- only)	Oh to 1h	-	-	All	-	_
01		0000h	Absolute	opendor					
PnA02		0000h		tal encoder					
	4	Motor Type (read only)	Selection	0h to 1h	-	-	All	_	
02			T						
PnA04		0000h	-	ervomotor					
		0001h	Linear Se	ervomotor					
	4	Semi-close closed Sele (read only)	d/Fully- ection	0h to 1h	-	_	All	_	_
03									
PnA06		0000h	Semi-clo	sed					iatio
		0001h	Fully-clos	sed					nform
04 PnA08	4	Rated Moto (read only)	or Speed	Oh to FFFFFFFh	x10^PnA0C min ⁻¹	_	All	_	Device information
05 PnA0A	4	Maximum (Speed (rea		Oh to FFFFFFFh	x10^PnA0C min ⁻¹	_	All	_	
06 PnA0C	4	Speed Mul (read only)	tiplier	-1,073,741,823 to 1,073,741,823	_	-	All	_	-
07 PnA0E	4	Rated Torq (read only)	ue	Oh to FFFFFFFh	x10^PnA12 N∙m	-	All	-	
08 PnA10	4	Maximum (Torque (rea		Oh to FFFFFFFh	x10^PnA12 N•m	-	All	-	
09 PnA12	4	Torque Mul (read only)	tiplier	-1,073,741,823 to 1,073,741,823	-	-	All	_	
0A PnA14	4	Resolution (read only)		Oh to FFFFFFFh	1 pulse/rev	_	Rotary	-	
0B PnA16	4	Scale Pitch	1	0 to 65,536,000	1 nm [0.01 μm]	0	Linear	After restart ^{*1}	
0C PnA18	4	Pulses per Pitch (read		Oh to FFFFFFFh	1 pulse/ pitch	-	Linear	-	

Continued on next page.

14

Parameter No.321 PnA42222 PnA44223 PnA46224 PnA482	Size 4 4 4 4	Narr Electronic G (Numerator) Electronic G		Setting Range	Setting Unit	Default	Applicable	When	Classi-
PnA42 22 PnA44 23 PnA46 24	4	(Numerator)	ear Ratio		[Resolution]	Setting	Motors	Enabled	fication
PnA44 23 PnA46 24		Electronic G)	1 to 1,073,741,824	-	16	All	After restart	
PnA46 24	1	(Denominate		1 to 1,073,741,824	_	1	All	After restart	
	4	Absolute Er Origin Offse		-1,073,741,823 to 1,073,741,823	1 reference unit	0	All	Immedi- ately ^{*1}	
	4	Multiturn Lir Setting	mit	0 to 65,535	1 Rev	65535	Rotary	After restart	
	4	Limit Setting	g	0h to 33h	-	0000h	All	After restart	-
		Bit 0	P-OT	(0: Enabled, 1: Di	sabled)				SUC
		Bit 1		(0: Enabled, 1: D					catic
25		Bit 2	Rese						Machine specifications
PnA4A		Bit 3	Rese	rved.					spe
		Bit 4	P-SC	T (0: Disabled, 1:	Enabled)				ne
		Bit 5		T (0: Disabled, 1:					achi
		Bits 6 to 31		•	,				Š
				-1,073,741,823					_
26 PnA4C	4	Forward So Limit	ftware	to 1,073,741,823	1 reference unit	10737418 23	All	Immedi- ately	
27 PnA4E	4	Reserved pa (Do not cha	arameter .nge.)	-	-	0	All	Immedi- ately	
28 PnA50	4	Reverse So [.] Limit	ftware	-1,073,741,823 to 1,073,741,823	1 reference unit	-1073741 823	All	Immedi- ately	
29 PnA52	4	Reserved pa (Do not cha	arameter inge.)	-	-	0	All	Immedi- ately	-
	4	Speed Unit Selection ^{*2}		Oh to 4h	-	Oh	All	After restart	
		0000h	Reference	e units/s					
41		0001h	Reference	e units/min					
PnA82		0002h	Percenta	ge (%) of rated spe	ed*3				
		0003h	min ^{-1*3}						
		0004h		n motor speed/400)00000h*4				S
									ting
42 PnA84	4	Speed Base Selection ^{*3,} (Set the value from the foll formula: Sp selection (4 \times 10 ⁿ)	*4 ue of n lowing eed unit	-3 to 3	_	0	All	After restart	Unit settings
	4	Position Un Selection	it	Oh	-	Oh	All	After restart	
43									
PnA86		0000h	Reference	e units					

Continued from previous page.

-					a			om previoi	
Parameter No.	Size	Nai	ne	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
44 PnA88	4	Position Ba Selection (Set the va from the fo formula: Po selection (4 × 10 ⁿ)	lue of n Ilowing osition uni		-	0	All	After restart	
	4	Acceleration	on Unit	Oh	_	Oh	All	After restart	
45 PnA8A		0000h	Referenc	e units/s ²					
46 PnA8C	4	Acceleratic Unit Select (Set the va from the fo formula: Ac unit selecti PnA8A) ×	ion lue of n llowing celeratior on (45	4 to 6	_	4	All	After restart	
	4	Torque Uni Selection	t	1h to 2h	-	1h	All	After restart	-
47 PnA8E		0001h	Percent	age (%) of rated tore	que				
THACE		0002h		m torque/40000000					
48 PnA90	4	Torque Bas Selection ^{*5} (Set the va from the fo formula: To selection (2 × 10 ⁿ)	lue of n llowing orque unit	-5 to 0	_	0	All	After restart	Unit settings
	4	Supported tems (read		-	-	0601011F h	All	_	
		Speed Uni							
		Bit 0	F	leference units/s (1:	Enabled)				
		Bit 1		eference units/min	,				
		Bit 2	F	ercentage (%) of rat	ted speed (1: E	Enabled)			
		Bit 3	n	nin ⁻¹ (rpm) (1: Enable	ed)				
		Bit 4	N		ad/100000b/	1: Enabled)			
				laximum motor spe					1
		Bits 5 to 7	F	laximum motor spe reserved (0: Disable					
40		Position U	F	leserved (0: Disable	d).	,			
		Position Un Bit 8	F nits F	leserved (0: Disable leference units (1: E	d). nabled)				
		Position U Bit 8 Bits 9 to 1	F nits 5 F	leserved (0: Disable	d). nabled)				
49 PnA92		Position U Bit 8 Bits 9 to 1 Acceleration	Finits F 5 F 5 Dn Units	leserved (0: Disable leference units (1: E leserved (0: Disable	d). nabled) d).				
		Position Un Bit 8 Bits 9 to 1 Acceleration Bit 16	F nits 5 F 5 F on Units	leserved (0: Disable leference units (1: E leserved (0: Disable leference units/s ² (1	d). nabled) d). : Enabled)				
		Position Un Bit 8 Bits 9 to 1 Acceleration Bit 16 Bit 17	nits F 5 F 5 P n Units F n n	leference units (1: E leserved (0: Disable leserved (0: Disable leference units/s ² (1 ns (acceleration time	d). nabled) d). : Enabled) e required to re		peed) (0: Disa	bled)	
		Position U Bit 8 Bits 9 to 1 Acceleratio Bit 16 Bit 17 Bits 18 to	Finits F5 F 500 Units F 000 Units R 000 Units F 000 F 000 F	leserved (0: Disable leference units (1: E leserved (0: Disable leference units/s ² (1	d). nabled) d). : Enabled) e required to re		need) (0: Disa	bled)	
		Position U Bit 8 Bits 9 to 1 Acceleration Bit 16 Bit 17 Bits 18 to Torque Uni	F nits 5 F 5 F 5 F 5 F 7 n 23 F its	Reserved (0: Disable Reference units (1: E Reserved (0: Disable Reference units/s ² (1 Ins (acceleration time Reserved (0: Disable	d). nabled) d). : Enabled) e required to re		peed) (0: Disa	bled)	
		Position Un Bit 8 Bits 9 to 1 Acceleration Bit 16 Bit 17 Bits 18 to Torque Uni Bit 24	Finits F 5 F 5 F 0n Units F 23 F its N	Reserved (0: Disable Reference units (1: E Reserved (0: Disable Reference units/s ² (1 Ins (acceleration time Reserved (0: Disable II-m (0: Disabled)	d). nabled) d). : Enabled) e required to re d).	ach rated sp	peed) (0: Disa	bled)	
49 PnA92		Position Un Bit 8 Bits 9 to 1 Acceleration Bit 16 Bit 17 Bits 18 to Torque Uni Bit 24 Bit 25	Finits F 5 F 5 F 5 F 7 n 23 F 23 F 1ts N F	leference units (1: E leference units (1: E leserved (0: Disabled leference units/s ² (1 ns (acceleration time leserved (0: Disabled) l·m (0: Disabled) lercentage (%) of rat	d). nabled) d). : Enabled) e required to re d). :ed torque (1: E	ach rated sp	beed) (0: Disa	bled)	
		Position Un Bit 8 Bits 9 to 1 Acceleration Bit 16 Bit 17 Bits 18 to Torque Uni Bit 24	Fon Units Fon Units Pan Units Fon Units Fon Units Fon Units Fon Units N N	Reserved (0: Disable Reference units (1: E Reserved (0: Disable Reference units/s ² (1 Ins (acceleration time Reserved (0: Disable II-m (0: Disabled)	d). nabled) d). : Enabled) e required to re d). :ed torque (1: E 200000h	ach rated sp	beed) (0: Disa	bled)	

14

Parameter No.	Size	Na	me	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Class ficatio
61 PnAC2	4	Speed Loc	op Gain	1,000 to 2,000,000	0.001 Hz [0.1 Hz]	40000	All	Immedi- ately	
62 PnAC4	4	Speed Loc Time Cons	p Integral tant	150 to 512,000	1 μs [0.01 ms]	20000	All	Immedi- ately	
63 PnAC6	4	Position Lo	oop Gain	1,000 to 2,000,000	0.001/s [0.1/s]	40000	All	Immedi- ately	
64 PnAC8	4	Feedforwa pensation	rd Com-	0 to 100	1%	0	All	Immedi- ately	
65 PnACA	4	Position Lo gral Time (0 to 5,000,000	1 μs [0.1 ms]	0	All	Immedi- ately	
66 PnACC	4	Positioning pleted Wid		0 to 1,073,741,824	1 reference unit	7	All	Immedi- ately	
67 PnACE	4	Near Signa	al Width	1 to 1,073,741,824	1 reference unit	10737418 24	All	Immedi- ately	
81 PnB02	4	Exponentia ation/Dece Time Cons	leration	0 to 510,000	1 μs [0.1 ms]	0	All	Immedi- ately ^{*6}	
82 PnB04	4	Movement Time	Average	0 to 510,000	1 μs [0.1 ms]	0	All	Immedi- ately ^{*6}	
83 PnB06	4	External Po Final Trave		-1,073,741,823 to 1,073,741,823	1 reference unit	100	All	Immedi- ately	
84 PnB08	4	Origin Approach Speed		Oh to 3FFFFFFFh	10 ⁻³ min ⁻¹	× 5,000h reference units/s con- verted to 10 ⁻³ min ⁻¹	All	Immedi- ately	-
85 PnB0A	4	Origin Retu Speed	urn Creep	Oh to 3FFFFFFFh	10 ⁻³ min ⁻¹	× 500h reference units/s con- verted to 10 ⁻³ min ⁻¹	All	Immedi- ately	Tuning
86 PnB0C	4	Final Trave for Origin F		-1,073,741,823 to 1,073,741,823	1 reference unit	100	All	Immedi- ately	
	4	Fixed Mon tion 1	itor Selec-	0h to Fh	-	1h	All	Immedi- ately	
			1						
		0000h	APOS						
		0001h	CPOS						
		0002h	PERR						
		0003h	LPOS1						
		0004h	LPOS2						
		0005h	FSPD						
87		0006h	CSPD						
PnB0E		0007h	TRQ						
		0008h	ALARM						
		0009h	MPOS						
		000Ah	Reserved	(undefined value).					
		000Bh	Reserved	(undefined value).					
		000Ch	CMN1 (co	ommon monitor 1)					
		000Dh	CMN2 (co	ommon monitor 2)	-	-			
		000Eh	OMN1 (o	ptional monitor 1)					
		000Fh	OMN2 (or	otional monitor 2)					

Parameter No.	Size	Nan	ne	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
	4	Fixed Monit tion 2	tor Selec-	Oh to Fh	_	Oh	All	Immedi- ately	-
88 PnB10		0000h to 000Fh	The settin	gs are the same a	s those for Fixe	ed Monitor S	Selection 1.		Command-related parameters

Continued from previous page.

_							Continued fr		
Parameter No.	Size	Nar	ne	Setting Range	e Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi ficatio
	4	SEL_MON		0h to 9h	_	0h	All	Immedi-	
	4	Monitor Se 0000h 0001h 0002h 0003h 0004h 0005h	TPOS (targ IPOS (refe POS_OFF TSPD (targ SPD_LIM TRQ_LIM SV_STAT (Monitor De Byte 1: Cu 00h: Pha 01h: Pha 02h: Pha 03h: Pha Byte 2: Cu 00h: Pos 01h: Spe	get position in rence position SET (offset set get speed) (speed limit) (torque limit) (servo actual o escription urrent commun use 0 use 1 use 2 use 3 urrent control n ition control m	ode de	ate system) dinate syste	m)	ately	
			Byte 3: Re	que control mo eserved pansion signal					
			Bit	Name	Description	Value	e Settin	g	
			Bit 0	LT_RDY1	Processing statu latch detection f	or	Latch dete not yet pro cessed.		ters
89					LT_REQ1 in SVC D_CTRL region	CM- 1	Processing detection i progress.		parame
PnB12		0006h	Bit 1	LT_RDY1	Processing statulatch detection f	or	Latch dete not yet pro cessed.		Command-related parameters
					LT_REQ2 in SVC D_CTRL region	CM-	Processing detection i progress.		ommano
						0	Phase C		0
			Bits 2 and 3	LT_SEL1R	Latch signal	1	External in signal 1 External in	·	
						2	signal 2 External in signal 3		
						0	Phase C		
			Bits 4			1	External in signal 1		
			and 5	LT_SEL2R	Latch signal	2	External in signal 2		
			Bit 6	Reserved (0		3	External in signal 3	put	
			-						
		0007h	Reserved.						
		0008h	INIT_PGP		Lower 32 bits verted to 64- Upper 32 bits	bit position	reference dat	а	
		0009h	INIT_PGP0	OS (High)	verted to 64-	bit position	reference dat	a	

Continued from previous page.

Continued from previous page.

Parameter No.	Size	Name	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
	4	SEL_MON (CMN2) Monitor Selection 2	0h to 9h	-	Oh	All	Immedi- ately	
8A PnB14		0000h to 0009h The set	ings are the same as	those for SEL	_MON Monit	tor Selection	1.	
8B PnB16	4	Origin Detection Width	0 to 250	1 reference unit	10	All	Immedi- ately	
8C PnB18	4	Forward Torque Lir	nit 0 to 800	1%	100	All	Immedi- ately	
8D PnB1A	4	Reverse Torque Lir	nit 0 to 800	1%	100	All	Immedi- ately	
8E PnB1C	4	Zero Speed Detec- tion Range	1,000 to 10,000,000	10 ⁻³ min ⁻¹	20000	All	Immedi- ately	()
8F PnB1E	4	Speed Coincidence Signal Detection Width	e 0 to 100,000	10 ⁻³ min ⁻¹	10000	All	Immedi- ately	ameters
	4	Servo Command Control Field Enabl Disable Selections (read only)	e/ _	_	0FFF3F3F h	All	_	elated par
90 PnB20		(read only) Bit 0 Bit 1 Bits 2 and 3 Bits 4 and 5 Bits 6 and 7 Bit 8 Bit 9 Bits 10 and 11 Bits 12 and 13 Bits 14 and 15 Bits 20 to 23 Bits 24 to 27 Bits 28 to 31	CMD_PAUSE (1: En CMD_CANCEL (1: En STOP_MODE (1: En ACCFIL (1: Enabled) Reserved (0: Disable LT_REQ1 (1: Enable LT_REQ2 (1: Enable LT_SEL2 (1: Enable Reserved (0: Disable SEL_MON1 (1: Enat SEL_MON2 (1: Enat Reserved (0: Disable	Enabled) abled) ed). d) d) d) d) ed). ed). ed(). eled) bled)				Command-related parameters

					(Continued fr	rom previo	us page.
Parameter No.	Size	Name	Setting Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
	4	Servo Status Field Enable/Disable Selections (read only)	-	-	0FFF3F33 h	All	-	
		Bit 0	CMD_PAUSE_CMP	(1: Enabled)				
		Bit 1	CMD_CANCEL_CMI	P (1: Enabled)				
		Bit 2 and 3	Reserved (0: Disable	ed).				
		Bits 4 and 5	ACCFIL (1: Enabled)					
		Bits 6 and 7	Reserved (0: Disable	ed).				
01		Bit 8	L_CMP1 (1: Enabled	(k				
91 PnB22		Bit 9	L_CMP2 (1: Enabled	(k				
		Bit 10	POS_RDY (1: Enable	ed)				
			PON (1: Enabled)					
		Bit 12	M_RDY (1: Enabled)					
		Bit 13	SV_ON (1: Enabled)					ters
		Bits 14 and 15	Reserved (0: Disable	ed).				ame
		Bits 16 to 19	SEL_MON1 (1: Enab	oled)				oara
		Bits 20 to 23	SEL_MON2 (1: Enab	oled)				pe
		Bits 24 to 27	SEL_MON3 (1: Enab	oled)				elat
		Bits 28 to 31	Reserved (0: Disable	ed).				and-r
	4	Output Bit Enable/ Disable Selections (read only)	_	_	01FF01F0 h	All	_	Command-related parameters
		Bits 0 to 3	Reserved (0: Disable	ed).				
		Bit 4	V_PPI (1: Enabled)					
		Bit 5	P_PPI (1: Enabled)					
92		Bit 6	P_CL (1: Enabled)					
PnB24		Bit 7	N_CL (1: Enabled)					
		Bit 8	G_SEL (1: Enabled)					
		Bits 9 to 11	G_SEL (0: Disabled)					
		Bits 12 to 15 Bits 16 to 19	Reserved (0: Disable	,				
		Bits 20 to 24	BANK_SEL (1: Enab SO1 to SO5 (1: Enab					
		Bits 20 to 24	Reserved (0: Disable	,				
		טונט בט נט ט ו	I IESEI VEU (U. DISADIE	50/.				
								I

Continued from previous page.

Parameter No.	Size	Name	Sett	ing Range	Setting Unit [Resolution]	Default Setting	Applicable Motors	When Enabled	Classi- fication
	4	Input Bit Enable/Di able Selections (rea only)		-	_	FF0FFEFE h	All	_	
93 PnB26	4		Reserve DEC (1: P-OT (1: N-OT (1) EXT1 (1: EXT2 (1: EXT3 (1: EXT3 (1: EXT3 (1: EXT3 (1: EXT3 (1: EXT3 (1: EXT3 (1: Reserve BRK_ON P-SOT (N-SOT (DEN (1: NEAR (1) PSET (1) ZPOINT T_LIM (1) V_CMP ZSPD (1) Reserve	d (0: Disable Enabled) Enabled) Enabled) Enabled) Enabled) Enabled) d (0: Disable (1: Enabled) 1: Enabled) 1: Enabled) (1: Ol_STSE	ed). d)	h			Command-related parameters

Continued from previous page.

 $\ast 1.$ The parameter setting is enabled after SENS_ON command execution is completed.

*2. When using fully-closed loop control, set the reference units/s.

*3. If you set the Speed Unit Selection (parameter 41) to either 0002h or 0003h, set the Speed Base Unit Selection (parameter 42) to a number between -3 and 0.

*4. If you set the Speed Unit Selection (parameter 41) to 0004h, set the Speed Base Unit Selection (parameter 42) to 0.

*5. If you set the Torque Unit Selection (parameter 47) to 0002h, set the Torque Base Unit Selection (parameter 48) to 0.

*6. Change the setting when the reference is stopped (i.e., while DEN is set to 1). If you change the setting during operation, the reference output will be affected.

14.3 Parameter Recording Table

Use the following table to record the settings of the parameters.

Parameter No.	Default Setting	Name	When Enabled
Pn000	0000h	Basic Function Selections 0	After restart
Pn001	0000h	Application Function Selec- tions 1	After restart
Pn002	0011h	Application Function Selec- tions 2	After restart
Pn006	0002h	Application Function Selec- tions 6	Immediately
Pn007	0000h	Application Function Selec- tions 7	Immediately
Pn008	4000h	Application Function Selec- tions 8	After restart
Pn009	0010h	Application Function Selec- tions 9	After restart
Pn00A	0001h	Application Function Selec- tions A	After restart
Pn00B	0000h	Application Function Selec- tions B	After restart
Pn00C	0000h	Application Function Selec- tions C	After restart
Pn00D	0000h	Application Function Selec- tions D	Immediately
Pn00F	0000h	Application Function Selec- tions F	After restart
Pn022	0000h	Application Function Selec- tions 22	After restart
Pn023	0000h	Application Function Selec- tion 23	After restart
Pn040	0000h	Reserved parameter	-
Pn080	0000h	Application Function Selec- tions 80	After restart
Pn081	0000h	Application Function Selec- tions 81	After restart
Pn100	400	Speed Loop Gain	Immediately
Pn101	2000	Speed Loop Integral Time Constant	Immediately
Pn102	400	Position Loop Gain	Immediately
Pn103	100	Moment of Inertia Ratio	Immediately
Pn104	400	Second Speed Loop Gain	Immediately
Pn105	2000	Second Speed Loop Inte- gral Time Constant	Immediately
Pn106	400	Second Position Loop Gain	Immediately
Pn109	0	Feedforward	Immediately
Pn10A	0	Feedforward Filter Time Constant	Immediately
Pn10B	0000h	Gain Application Selections	*1
Pn10C	200	Mode Switching Level for Torque Reference	Immediately
Pn10D	0	Mode Switching Level for Speed Reference	Immediately
Pn10E	0	Mode Switching Level for Acceleration	Immediately

Parameter No.	Default Setting	Name	When Enabled
Pn10F	0	Mode Switching Level for Position Deviation	Immediately
Pn11F	0	Position Integral Time Con- stant	Immediately
Pn121	100	Friction Compensation Gain	Immediately
Pn122	100	Second Friction Compen- sation Gain	Immediately
Pn123	0	Friction Compensation Coefficient	Immediately
Pn124	0	Friction Compensation Fre- quency Correction	Immediately
Pn125	100	Friction Compensation Gain Correction	Immediately
Pn131	0	Gain Switching Time 1	Immediately
Pn132	0	Gain Switching Time 2	Immediately
Pn135	0	Gain Switching Waiting Time 1	Immediately
Pn136	0	Gain Switching Waiting Time 2	Immediately
Pn139	0000h	Automatic Gain Switching Selections 1	Immediately
Pn13D	2000	Current Gain Level	Immediately
Pn140	0100h	Model Following Control- Related Selections	Immediately
Pn141	500	Model Following Control Gain	Immediately
Pn142	1000	Model Following Control Gain Correction	Immediately
Pn143	1000	Model Following Control Bias in the Forward Direc- tion	Immediately
Pn144	1000	Model Following Control Bias in the Reverse Direc- tion	Immediately
Pn145	500	Vibration Suppression 1 Frequency A	Immediately
Pn146	700	Vibration Suppression 1 Frequency B	Immediately
Pn147	1000	Model Following Control Speed Feedforward Com- pensation	Immediately
Pn148	500	Second Model Following Control Gain	Immediately
Pn149	1000	Second Model Following Control Gain Correction	Immediately
Pn14A	800	Vibration Suppression 2 Frequency	Immediately
Pn14B	100	Vibration Suppression 2 Correction	Immediately
Pn14F	0021h	Control-Related Selections	After restart
Pn160	0010h	Anti-Resonance Control- Related Selections	Immediately
Pn161	1000	Anti-Resonance Frequency	Immediately
Pn162	100	Anti-Resonance Gain Cor- rection	Immediately

14

	Continued from previous page.		
Parameter No.	Default Setting	Name	When Enabled
Pn163	0	Anti-Resonance Damping Gain	Immediately
Pn164	0	Anti-Resonance Filter Time Constant 1 Correction	Immediately
Pn165	0	Anti-Resonance Filter Time Constant 2 Correction	Immediately
Pn166	0	Anti-Resonance Damping Gain 2	Immediately
Pn170	1401h	Tuning-less Function- Related Selections	*1
Pn181	0	Mode Switching Level for Speed Reference	Immediately
Pn182	0	Mode Switching Level for Acceleration	Immediately
Pn205	65535	Multiturn Limit	After restart
Pn207	0010h	Position Control Function Selections	After restart
Pn20A	32768	Number of External Encoder Scale Pitches	After restart
Pn20E	16	Electronic Gear Ratio (Numerator)	After restart
Pn210	1	Electronic Gear Ratio (Denominator)	After restart
Pn212	2048	Number of Encoder Output Pulses	After restart
Pn22A	0000h	Fully-closed Control Selec- tions	After restart
Pn230	0000h	Position Control Expansion Function Selections	After restart
Pn231	0	Backlash Compensation	Immediately
Pn233	0	Backlash Compensation Time Constant	Immediately
Pn281	20	Encoder Output Resolution	After restart
Pn282	0	Linear Encoder Scale Pitch	After restart
Pn304	500	Jogging Speed	Immediately
Pn305	0	Soft Start Acceleration Time	Immediately
Pn306	0	Soft Start Deceleration Time	Immediately
Pn308	0	Speed Feedback Filter Time Constant	Immediately
Pn30A	0	Deceleration Time for Servo OFF and Forced Stops	Immediately
Pn30C	0	Speed Feedforward Aver- age Movement Time	Immediately
Pn310	0000h	Vibration Detection Selec- tions	Immediately
Pn311	100	Vibration Detection Sensi- tivity	Immediately
Pn312	50	Vibration Detection Level	Immediately
Pn316	10000	Maximum Motor Speed	After restart
Pn324	300	Moment of Inertia Calcula- tion Starting Level	Immediately
Pn383	50	Jogging Speed	Immediately
Pn384	10	Vibration Detection Level	Immediately

	Continued from previous page.			
Parameter No.	Default Setting	Name	When Enabled	
Pn385	50	Maximum Motor Speed	After restart	
Pn401	100	First Stage First Torque Reference Filter Time Con- stant	Immediately	
Pn402	800	Forward Torque Limit	Immediately	
Pn403	800	Reverse Torque Limit	Immediately	
Pn404	100	Forward External Torque Limit	Immediately	
Pn405	100	Reverse External Torque Limit	Immediately	
Pn406	800	Emergency Stop Torque	Immediately	
Pn407	10000	Speed Limit during Torque Control	Immediately	
Pn408	0000h	Torque-Related Function Selections	*1	
Pn409	5000	First Stage Notch Filter Fre- quency	Immediately	
Pn40A	70	First Stage Notch Filter Q Value	Immediately	
Pn40B	0	First Stage Notch Filter Depth	Immediately	
Pn40C	5000	Second Stage Notch Filter Frequency	Immediately	
Pn40D	70	Second Stage Notch Filter Q Value	Immediately	
Pn40E	0	Second Stage Notch Filter Depth	Immediately	
Pn40F	5000	Second Stage Second Torque Reference Filter Fre- quency	Immediately	
Pn410	50	Second Stage Second Torque Reference Filter Q Value	Immediately	
Pn412	100	First Stage Second Torque Reference Filter Time Con- stant	Immediately	
Pn416	0000h	Torque-Related Function Selections 2	Immediately	
Pn417	5000	Third Stage Notch Filter Frequency	Immediately	
Pn418	70	Third Stage Notch Filter Q Value	Immediately	
Pn419	0	Third Stage Notch Filter Depth	Immediately	
Pn41A	5000	Fourth Stage Notch Filter Frequency	Immediately	
Pn41B	70	Fourth Stage Notch Filter Q Value	Immediately	
Pn41C	0	Fourth Stage Notch Filter Depth	Immediately	
Pn41D	5000	Fifth Stage Notch Filter Fre- quency	Immediately	
Pn41E	70	Fifth Stage Notch Filter Q Value	Immediately	
Pn41F	0	Fifth Stage Notch Filter Depth	Immediately	

Parameter Lists

Parameter No.	Default Setting	Name	When Enabled
Pn423	0000h	Speed Ripple Compensa- tion Selections	*1
Pn424	50	Torque Limit at Main Circuit Voltage Drop	Immediately
Pn425	100	Release Time for Torque Limit at Main Circuit Voltage Drop	Immediately
Pn426	0	Torque Feedforward Aver- age Movement Time	Immediately
Pn427	0	Speed Ripple Compensa- tion Enable Speed	Immediately
Pn456	15	Sweep Torque Reference Amplitude	Immediately
Pn460	0101h	Notch Filter Adjustment Selections 1	Immediately
Pn475	0000h	Gravity Compensation- Related Selections	After restart
Pn476	0	Gravity Compensation Torque	Immediately
Pn480	10000	Speed Limit during Force Control	Immediately
Pn481	400	Polarity Detection Speed Loop Gain	Immediately
Pn482	3000	Polarity Detection Speed Loop Integral Time Con- stant	Immediately
Pn483	30	Forward Force Limit	Immediately
Pn484	30	Reverse Force Limit	Immediately
Pn485	20	Polarity Detection Refer- ence Speed	Immediately
Pn486	25	Polarity Detection Refer- ence Acceleration/Deceler- ation Time	Immediately
Pn487	0	Polarity Detection Con- stant Speed Time	Immediately
Pn488	100	Polarity Detection Refer- ence Waiting Time	Immediately
Pn48E	10	Polarity Detection Range	Immediately
Pn490	100	Polarity Detection Load Level	Immediately
Pn495	100	Polarity Detection Confir- mation Force Reference	Immediately
Pn498	10	Polarity Detection Allowable Error Range	Immediately
Pn49F	0	Speed Ripple Compensa- tion Enable Speed	Immediately
Pn502	20	Rotation Detection Level	Immediately
Pn503	10	Speed Coincidence Detec- tion Signal Output Width	Immediately
Pn506	0	Brake Reference-Servo OFF Delay Time	Immediately
Pn507	100	Brake Reference Output Speed Level	Immediately
Pn508	50	Servo OFF-Brake Com- mand Waiting Time	Immediately

Parameter No.	Default Setting	Name	When Enabled
Pn509	20	Momentary Power Interrup- tion Hold Time	Immediately
Pn50A	1881h	Input Signal Selections 1	After restart
Pn50B	8882h	Input Signal Selections 2	After restart
Pn50E	0000h	Output Signal Selections 1	After restart
Pn50F	0100h	Output Signal Selections 2	After restart
Pn510	0000h	Output Signal Selections 3	After restart
Pn511	6543h	Input Signal Selections 5	After restart
Pn512	0000h	Output Signal Inverse Set- tings	After restart
Pn513	0000h	Output Signal Inverse Set- tings 2	After restart
Pn514	0000h	Output Signal Selections 4	After restart
Pn515	8888h	Input Signal Selections 6	After restart
Pn516	8888h	Input Signal Selections 7	After restart
Pn51A	0000h	Output Signal Selections 8	After restart
Pn51B	1000	Motor-Load Position Devia- tion Overflow Detection Level	Immediately
Pn51E	100	Position Deviation Over- flow Warning Level	Immediately
Pn520	5242880	Position Deviation Over- flow Alarm Level	Immediately
Pn522	7	Positioning Completed Width	Immediately
Pn524	1073741824	Near Signal Width	Immediately
Pn526	5242880	Position Deviation Over- flow Alarm Level at Servo ON	Immediately
Pn528	100	Position Deviation Over- flow Warning Level at Servo ON	Immediately
Pn529	10000	Speed Limit Level at Servo ON	Immediately
Pn52A	20	Multiplier per Fully-closed Rotation	Immediately
Pn52B	20	Overload Warning Level	Immediately
Pn52C	100	Base Current Derating at Motor Overload Detection	After restart
Pn530	0000h	Program Jogging-Related Selections	Immediately
Pn531	32768	Program Jogging Travel Distance	Immediately
Pn533	500	Program Jogging Move- ment Speed	Immediately
Pn534	100	Program Jogging Accelera- tion/Deceleration Time	Immediately
Pn535	100	Program Jogging Waiting Time	Immediately
Pn536	1	Program Jogging Number of Movements	Immediately
Pn53C	0000h	ZONE Output Signal Selec- tions 1	After restart
Pn53D	0000h	ZONE Output Signal Selec- tions 2	After restart

Parameter Lists

14

	Continued from previous page.			
Parameter No.	Default Setting	Name	When Enabled	
Pn550	0	Analog Monitor 1 Offset Voltage	Immediately	
Pn551	0	Analog Monitor 2 Offset Voltage	Immediately	
Pn552	100	Analog Monitor 1 Magnifi- cation	Immediately	
Pn553	100	Analog Monitor 2 Magnifi- cation	Immediately	
Pn55A	1	Power Consumption Moni- tor Unit Time	Immediately	
Pn560	400	Residual Vibration Detec- tion Width	Immediately	
Pn561	100	Overshoot Detection Level	Immediately	
Pn581	20	Zero Speed Level	Immediately	
Pn582	10	Speed Coincidence Detec- tion Signal Output Width	Immediately	
Pn583	10	Brake Reference Output Speed Level	Immediately	
Pn584	10000	Speed Limit Level at Servo ON	Immediately	
Pn585	50	Program Jogging Move- ment Speed	Immediately	
Pn586	0	Motor Running Cooling Ratio	Immediately	
Pn587	0000h	Polarity Detection Execu- tion Selection for Absolute Linear Encoder	Immediately	
Pn600	0	Regenerative Resistor Capacity	Immediately	
Pn601	0	Dynamic Brake Resistor Allowable Energy Con- sumption	After restart	
Pn603	0	Regenerative Resistance	Immediately	
Pn604	0	Dynamic Brake Resistance	After restart	
Pn61A	0000h	Overheat Protection Selec- tions	After restart	
Pn61B	250	Overheat Alarm Level	Immediately	
Pn61C	100	Overheat Warning Level	Immediately	
Pn61D	0	Overheat Alarm Filter Time	Immediately	
Pn800	1040h	Communications Controls	Immediately	
Pn801	0003h	Application Function Selec- tions 6 (Software Limits)	Immediately	
Pn803	10	Origin Range	Immediately	
Pn804	1073741823	Forward Software Limit	Immediately	
Pn806	-1073741823	Reverse Software Limit	Immediately	
Pn808	0	Absolute Encoder Origin Offset	Immedi- ately ^{*2}	
Pn80A	100	First Stage Linear Accelera- tion Constant	Immedi- ately ^{*3}	
Pn80B	100	Second Stage Linear Acceleration Constant	Immedi- ately ^{*3}	
Pn80C	0	Acceleration Constant Switching Speed	Immedi- ately ^{*3}	

Doromotor			When
Parameter No.	Default Setting	Name	Enabled
Pn80D	100	First Stage Linear Decelera- tion Constant	Immedi- ately ^{*3}
Pn80E	100	Second Stage Linear Deceleration Constant	Immedi- ately ^{*3}
Pn80F	0	Deceleration Constant Switching Speed	Immedi- ately ^{*3}
Pn810	0	Exponential Acceleration/ Deceleration Bias	Immedi- ately ^{*3}
Pn811	0	Exponential Acceleration/ Deceleration Time Constant	Immedi- ately ^{*3}
Pn812	0	Movement Average Time	Immedi- ately ^{*3}
Pn814	100	External Positioning Final Travel Distance	Immedi- ately ^{*3}
Pn816	0000h	Origin Return Mode Set- tings	Immedi- ately ^{*3}
Pn817	50	Origin Approach Speed 1	Immedi- ately ^{*3}
Pn818	5	Origin Approach Speed 2	Immedi- ately ^{*3}
Pn819	100	Final Travel Distance for Origin Return	Immedi- ately ^{*3}
Pn81E	0000h	Input Signal Monitor Selec- tions	Immediately
Pn81F	0010h	Command Data Allocations	After restart
Pn820	0	Forward Latching Area	Immediately
Pn822	0	Reverse Latching Area	Immediately
Pn824	0000h	Option Monitor 1 Selection	Immediately
Pn825	0000h	Option Monitor 2 Selection	Immediately
Pn827	100	Linear Deceleration Con- stant 1 for Stopping	Immedi- ately ^{*3}
Pn829	0	SVOFF Waiting Time (for SVOFF at Deceleration to Stop)	Immediately
Pn82A	1813h	Option Field Allocations 1	After restart
Pn82B	1D1Ch	Option Field Allocations 2	After restart
Pn82C	1F1Eh	Option Field Allocations 3	After restart
Pn82D	0000h	Option Field Allocations 4	After restart
Pn82E	0000h	Option Field Allocations 5	After restart
Pn833	0000h	Motion Settings	After restart
Pn834	100	First Stage Linear Accelera- tion Constant 2	Immedi- ately ^{*3}
Pn836	100	Second Stage Linear Acceleration Constant 2	Immedi- ately ^{*3}
Pn838	0	Acceleration Constant Switching Speed 2	Immedi- ately ^{*3}
Pn83A	100	First Stage Linear Decelera- tion Constant 2	Immedi- ately ^{*3}
Pn83C	100	Second Stage Linear Deceleration Constant 2	Immedi- ately ^{*3}
Pn83E	0	Deceleration Constant Switching Speed 2	Immedi- ately ^{*3}

Parameter Lists

No.Default SettingNameFeabledPn840100Linear Deceleration Constant 2 for Stopping attely 3Immedi- attely 3Pn8420Second Origin Aproach Speed 1Immedi- attely 3Pn8440Second Origin Aproach Speed 2Immedi- attely 3Pn8460Acceleration/Deceleration RateImmedi- attely 3Pn8460Acceleration/Deceleration RateImmedi- attely 3Pn8500Number of Latch SequencesImmediately sequencesPn8510Continuous Latch Sequence for a Stat- tingsImmediately sequencesPn8520000hLatch Sequence 5 to 8 Set- tingsImmediately ImmediatelyPn8630000hSVCMD_10 Input Signal Monitor Allocations 1Immediately ImmediatelyPn8640000hSVCMD_10 Input Signal Monitor Allocations 3ImmediatelyPn8630000hSVCMD_10 Input Signal Monitor Allocations 4ImmediatelyPn8640000hSVCMD_10 Input Signal Monitor Allocations 3ImmediatelyPn8630000hSVCMD_10 Output Signal Monitor Allocations 4ImmediatelyPn8640000hSVCMD_10 Output Signal Monitor Allocations 4ImmediatelyPn8640000hSVCMD_10 Output Signal Monitor Allocations 4ImmediatelyPn8650000hSVCMD_10 Output Signal Monitor Allocations 4ImmediatelyPn8660000hSVCMD_10 Output Signal Monitor Allocations 6ImmediatelyPn8680000h </th <th>Parameter</th> <th></th> <th></th> <th>When</th>	Parameter			When
Pn840 100 stant 2 for Stopping ataly ⁷³ Pn842 0 Second Origin Approach Speed 1 Immedi- ataly ⁷³ Pn844 0 Second Origin Approach Speed 2 Immedi- ataly ⁷³ Pn844 0 Second Origin Approach Acceleration/Decidention Immedi- ataly ⁷³ Pn846 0 Acceleration/Decidention Immedi- ataly ⁷³ Pn850 0 Number of Latch Sequence Count Immediately Sequence Count Pn851 0 Continuous Latch Sequence Count Immediately Immediately Pn852 0000h Latch Sequence 5 to 8 Set- tings Immediately Immediately Pn860 0000h SVCMD_IO Input Signal Monitor Allocations 2 Immediately Pn862 0000h SVCMD_IO Input Signal Monitor Allocations 2 Immediately Pn863 0000h SVCMD_IO Output Signal Monitor Allocations 2 Immediately Pn864 0000h SVCMD_IO Output Signal Monitor Allocations 3 Immediately Pn863 0000h SVCMD_IO Output Signal Monitor Allocations 3 Immediately Pn864 0000h SVCMD_IO Output Signal M		Default Setting		Enabled
Pn842 U Speed 1 antexture antexture Pn844 0 Second Origin Approach Acceleration/Deceleration Acceleration Acceleratio	Pn840	100		
Pn844 0 Speed 2 ately*3 Pn846 0 POSING Command Scurve Acceleration/Deceleration Rate Immediately Pn850 0 Number of Latch Sequences Immediately Pn851 0 Continuous Latch Sequence Count Immediately Pn852 0000h Latch Sequence 1 to 4 Set- tings Immediately Pn853 0000h Latch Sequence 5 to 8 Set- tings Immediately Pn860 0000h SVCMD_IO Input Signal Monitor Allocations 1 Immediately Pn861 0000h SVCMD_IO Input Signal Monitor Allocations 3 Immediately Pn862 0000h SVCMD_IO Input Signal Monitor Allocations 1 Immediately Pn863 0000h SVCMD_IO Unput Signal Monitor Allocations 3 Immediately Pn863 0000h SVCMD_IO Unput Signal Monitor Allocations 1 Immediately Pn864 0000h SVCMD_IO Unput Signal Monitor Allocations 3 Immediately Pn868 0000h SVCMD_IO Unput Signal Monitor Allocations 1 Immediately Pn868 0000h SVCMD_IO Unput Signal Monitor Allocations 2	Pn842	0		
Pn846 0 Acceleration/Deceleration Immediately attely** Pn850 0 Number of Latch Sequences Immediately Pn851 0 Continuous Latch Sequence Count Immediately Pn852 0000n Latch Sequence 1 to 4 Set Ings Immediately Pn853 0000n Latch Sequence 5 to 8 Set- Ings Immediately Pn860 0000n SVCMD_IO Input Signal Monitor Allocations 1 Immediately Pn861 0000n SVCMD_IO Input Signal Monitor Allocations 3 Immediately Pn862 0000n SVCMD_IO Input Signal Monitor Allocations 3 Immediately Pn863 0000n SVCMD_IO Input Signal Monitor Allocations 4 Immediately Pn863 0000n SVCMD_IO Unput Signal Monitor Allocations 4 Immediately Pn864 0000n SVCMD_IO Unput Signal Monitor Allocations 4 Immediately Pn868 0000n SVCMD_IO Unput Signal Monitor Allocations 5 Immediately Pn869 0000n SVCMD_IO Output Signal Monitor Allocations 5 Immediately Pn869 0000n SVCMD_IO Output Signal Monitor Alloca	Pn844	0	Second Origin Approach Speed 2	
PR650 0 Sequences Immediately PR851 0 Continuous Latch Sequence Count Immediately PR852 0000h Latch Sequence 1 to 4 Set- tings Immediately PR853 0000h Latch Sequence 5 to 8 Set- tings Immediately PR860 0000h SVCMD_IO Input Signal Monitor Allocations 1 Immediately PR861 0000h SVCMD_IO Input Signal Monitor Allocations 2 Immediately PR862 0000h SVCMD_IO Input Signal Monitor Allocations 3 Immediately PR863 0000h SVCMD_IO Input Signal Monitor Allocations 3 Immediately PR863 0000h SVCMD_IO Unput Signal Monitor Allocations 1 Immediately PR863 0000h SVCMD_IO Unput Signal Monitor Allocations 3 Immediately PR864 0000h SVCMD_IO Unput Signal Monitor Allocations 3 Immediately PR860 - Station Address Monitor (for maintenance, read only) - PR861 - Station Address Monitor (for maintenance, read only) - PR862 - Station Address Monitor (for maintenance, read only)	Pn846	0	Acceleration/Deceleration	
Priosition0Sequence CountInitializationPn8520000hLatch Sequence 1 to 4 Set tingsImmediatelyPn8530000hLatch Sequence 5 to 8 Set immediatelyImmediatelyPn8600000hSVCMD_IO Input Signal Monitor Allocations 1ImmediatelyPn8610000hSVCMD_IO Input Signal Monitor Allocations 2ImmediatelyPn8620000hSVCMD_IO Input Signal Monitor Allocations 3ImmediatelyPn8630000hSVCMD_IO Input Signal Monitor Allocations 4ImmediatelyPn8640000hSVCMD_IO Unput Signal Monitor Allocations 4ImmediatelyPn8680000hSVCMD_IO Output Signal Monitor Allocations 4ImmediatelyPn8690000hSVCMD_IO Output Signal Monitor Allocations 2ImmediatelyPn860-Station Address MonitorImmediatelyPn880-Set Transmission Byte Count Monitor Allocations 3ImmediatelyPn881-Set Transmission Cycle Setting Monitor Allocations Cycle-Pn882-Transmission Cycle Setting Monitor Allocations Cycle-Pn883-Communications Cycle-Pn884000hCommunications Cycle-Pn8840Communications Cycle Setting Monitor Allocations Cycle-Pn8840Communications Cycle Setting Monitor Allocations Cycle-Pn8840Communications Cycle Monitor during AlarmWaring (for maintenance, read only)-Pn8840 <t< td=""><td>Pn850</td><td>0</td><td>Sequences</td><td>Immediately</td></t<>	Pn850	0	Sequences	Immediately
PR652O000htingsInfiniteduatelyPn8530000hLatch Sequence 5 to 8 Set- tingsImmediatelyPn8600000hSVCMD_IO Input Signal Monitor Allocations 1ImmediatelyPn8610000hSVCMD_IO Input Signal Monitor Allocations 3ImmediatelyPn8620000hSVCMD_IO Input Signal Monitor Allocations 3ImmediatelyPn8630000hSVCMD_IO Input Signal Monitor Allocations 4ImmediatelyPn8680000hSVCMD_IO Output Signal Monitor Allocations 4ImmediatelyPn8690000hSVCMD_IO Output Signal Monitor Allocations 2ImmediatelyPn8690000hSVCMD_IO Output Signal Monitor Allocations 2ImmediatelyPn860-Station Address Monitor (for maintenance, read only)-Pn880-Station Address Monitor (for maintenance, read only)-Pn881-Set Transmission Byte Count Monitor [Vol.25 µs] (for maintenance, read only)-Pn883-Set Transmission Cycle Setting Monitor [x 0.25 µs] (for maintenance, read only)-Pn8840000hCommunications CycleImmediatelyPn8840Error Counter Monitor (for maintenance, read only)-Pn8840Error Counter Monitor (for maintenance, read only)-Pn8840hError Counter Monitor (for maintenance, read only)-Pn8840hError Counter Monitor (for maintenance, read only)-Pn8840hError Counter Monitor (for main	Pn851	0	Sequence Count	Immediately
PrisosOcountingsInimediatelyPn8600000hSVCMD_IO Input Signal Monitor Allocations 1ImmediatelyPn8610000hSVCMD_IO Input Signal Monitor Allocations 2ImmediatelyPn8620000hSVCMD_IO Input Signal Monitor Allocations 3ImmediatelyPn8630000hSVCMD_IO Input Signal Monitor Allocations 4ImmediatelyPn8630000hSVCMD_IO Output Signal Monitor Allocations 4ImmediatelyPn8680000hSVCMD_IO Output Signal Monitor Allocations 1ImmediatelyPn8690000hSVCMD_IO Output Signal Monitor Allocations 2ImmediatelyPn860-SVCMD_IO Output Signal Monitor Allocations 3ImmediatelyPn861-Station Address Monitor (for maintenance, read only)-Pn881-Set Transmission Byte Count Monitor follocations 2-Pn882-Transmission Cycle Setting Monitor (tor maintenance, read only)-Pn883-Communications Cycle Setting Monitor (transmis- sion cycle) (for mainte- nance, read only)-Pn8840Communications Cycle Setting Monitor (transmis- maintenance, read only)-Pn8840Communications Cortols 2ImmediatelyPn8840Communications (for maintenance, read only)-Pn8840hCommunications (for maintenance, read only)-Pn8840hCommunications (for maintenance, read only)-Pn8850hResponse Data Monitor <td>Pn852</td> <td>0000h</td> <td>tings</td> <td>Immediately</td>	Pn852	0000h	tings	Immediately
Pri600OCOUNMonitor Allocations 1InfinitediatelyPn8610000hSVCMD_IO Input Signal Monitor Allocations 2ImmediatelyPn8620000hSVCMD_IO Input Signal Monitor Allocations 4ImmediatelyPn8630000hSVCMD_IO Input Signal Monitor Allocations 4ImmediatelyPn8680000hSVCMD_IO Output Signal Monitor Allocations 4ImmediatelyPn8680000hSVCMD_IO Output Signal Monitor Allocations 1ImmediatelyPn8690000hSVCMD_IO Output Signal Monitor Allocations 2ImmediatelyPn8690000hSVCMD_IO Output Signal Monitor Allocations 2ImmediatelyPn860-Station Address Monitor (for maintenance, read only)-Pn880-Set Transmission Byte Count Monitor fyels (for maintenance, read only)-Pn881-Set Transmission Cycle Setting Monitor (for maintenance, read only)-Pn883-Communications Cycle-Pn8840000hCommunications CycleImmediatelyPn8840Communications Cycle-Pn8840Communications CycleImmediatelyPn8840Command Data Monitor maintenance, read only)-Pn8840hCommand Data Monitor maintenance, read only)-Pn8840hCommand Data Monitor maintenance, read only)-Pn8840hCommand Data Monitor maintenance, read only)-Pn8850hResponse Data Monitor during Alarm/War	Pn853	0000h	tings	Immediately
Pn861 0000h Monitor Allocations 2 Infinediately Pn862 0000h SVCMD_IO Input Signal Monitor Allocations 3 Immediately Pn863 0000h SVCMD_IO Output Signal Monitor Allocations 1 Immediately Pn868 0000h SVCMD_IO Output Signal Monitor Allocations 1 Immediately Pn868 0000h SVCMD_IO Output Signal Monitor Allocations 1 Immediately Pn869 0000h SVCMD_IO Output Signal Monitor Allocations 2 Immediately Pn860 - SVCMD_IO Output Signal Monitor Allocations 2 Immediately Pn860 - SVCMD_IO Output Signal Monitor Allocations 2 Immediately Pn880 - Station Address Monitor (for maintenance, read only) - Pn881 - Set Transmission Cycle Setting Monitor [kytes] (for maintenance, read only) - Pn883 - Communications Cycle Setting Monitor [transmis- sion cycles] (for mainte- nance, read only) - Pn884 0000h Communications Controls 2 Immediately Pn884 0 MeCHATROLINK Receive Error Counter Monitor (for maintenance, read only) - Pn884 0h MecHATROLINK Receive Error Counter Monitor (Pn860	0000h	Monitor Allocations 1	Immediately
Pn862 0000h Monitor Allocations 3 Infinitediately Pn863 0000h SVCMD_IO Input Signal Monitor Allocations 4 Immediately Pn868 0000h SVCMD_IO Output Signal Monitor Allocations 1 Immediately Pn869 0000h SVCMD_IO Output Signal Monitor Allocations 2 Immediately Pn869 0000h SVCMD_IO Output Signal Monitor Allocations 2 Immediately Pn860 - SVCMD_IO Output Signal Monitor Allocations 2 Immediately Pn880 - Station Address Monitor (for maintenance, read only) - Pn881 - Set Transmission Byte Count Monitor [bytes] (for maintenance, read only) - Pn882 - Transmission Cycle Setting Monitor [transmis- sion cycles] (for mainte- nance, read only) - Pn883 - Communications Cycle Setting Monitor [transmis- sion cycles] (for mainte- nance, read only) - Pn884 0000h Communications Controls 2 Immediately Pn884 0 MECHATROLINK Receive Error Counter Monitor (for maintenance, read only) - Pn886 0h Command Data Monitor during Alarm/Warning (for maintenance, read only) - Pn886 0h <	Pn861	0000h	Monitor Allocations 2	Immediately
PrisosOutonMonitor Allocations 4InfinediatelyPn8680000hSVCMD_1O Output Signal Monitor Allocations 1ImmediatelyPn8690000hSVCMD_1O Output Signal Monitor Allocations 2ImmediatelyPn8690000hSVCMD_1O Output Signal Monitor Allocations 3ImmediatelyPn860-Station Address Monitor (for maintenance, read only)-Pn881-Set Transmission Byte Count Monitor [bytes] (for maintenance, read only)-Pn882-Transmission Cycle Setting Monitor [v 0.25 µs] (for maintenance, read only)-Pn883-Communications Cycle Setting Monitor [V 0.25 µs] (for maintenance, read only)-Pn8840000hCommunications Cycle Setting Monitor [V 0.25 µs] (for maintenance, read only)-Pn8840Communications Cycle Setting Monitor [V or Communications Cycles] (for maintenance, read only)-Pn8840Communications Controls 2ImmediatelyPn8840Communications Controls 2ImmediatelyPn8850hCommand Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8850hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8860hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8860hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8860hResponse Data Monitor during Alarm/Warning (for maintenan	Pn862	0000h	Monitor Allocations 3	Immediately
PrisosO000hMonitor Allocations 1InfinediatelyPn8690000hSVCMD_IO Output Signal Monitor Allocations 3ImmediatelyPn86A0000hSVCMD_IO Output Signal Monitor Allocations 3ImmediatelyPn860-Station Address Monitor (for maintenance, read only)-Pn881-Set Transmission Byte Count Monitor [bytes] (for maintenance, read only)-Pn882-Transmission Cycle Setting Monitor [x 0.25 µs] (for maintenance, read only)-Pn883-Communications Cycle Setting Monitor [x 0.25 µs] (for maintenance, read only)-Pn8840000hCommunications Cycle Setting Monitor [ransmis- sion cycles] (for mainte- nance, read only)-Pn8840000hCommunications Coult Monitor [ransmis- sion cycles] (for mainte- nance, read only)-Pn884000hCommunications Counter Monitor maintenance, read only)-Pn8840Communications Counter Monitor maintenance, read only)-Pn8840Command Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8850hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8860hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8000Number of Parameter BanksAfter restartPn90100Number of Parameter Bank MembersAfter restart	Pn863	0000h	Monitor Allocations 4	Immediately
P18690000hMonitor Allocations 2InfinitediatelyPn86A0000hSVCMD_IO Output Signal Monitor Allocations 3ImmediatelyPn880-Station Address Monitor (for maintenance, read only)-Pn881-Set Transmission Byte Count Monitor [bytes] (for maintenance, read only)-Pn882-Transmission Cycle Setting Monitor [transmission Cycle Setting Monitor [transmission Cycle Setting Monitor [transmission cycles] (for maintenance, read only)-Pn883-Communications Cycle Setting Monitor [transmis- sion cycles] (for mainte- nance, read only)-Pn8840000hCommunications Controls 2ImmediatelyPn8840MECHATROLINK Receive Erro Counter Monitor (for maintenance, read only)-Pn8840hCommand Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8840hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8850hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8860hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8860hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn89010Number of Parameter BanksAfter restartPn9010ImmediatelyAfter restart	Pn868	0000h	Monitor Allocations 1	Immediately
PriseAOUCONMonitor Allocations 3InfinitedatelyPn880-Station Address Monitor (for maintenance, read only)-Pn881-Set Transmission Byte Count Monitor [bytes] (for maintenance, read only)-Pn882-Transmission Cycle Setting Monitor [x 0.25 µs] (for maintenance, read only)-Pn883-Communications Cycle Setting Monitor [transmis- sion cycles] (for mainte- nance, read only)-Pn8840000hCommunications Controls 2ImmediatelyPn8840000hCommunications Controls 2ImmediatelyPn8840MECHATROLINK Receive Error Counter Monitor (for maintenance, read only)-Pn8860hCommunications Controls 2ImmediatelyPn8860hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8870hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8000Number of Parameter BanksAfter restartPn9010Number of Parameter Bank MembersAfter restart	Pn869	0000h	Monitor Allocations 2	Immediately
Pn880-(for maintenance, read only)-Pn881-Set Transmission Byte Count Monitor [bytes] (for maintenance, read only)-Pn882-Transmission Cycle Setting Monitor [x 0.25 µs] (for maintenance, read only)-Pn883-Communications Cycle Setting Monitor [ransmis- sion cycles] (for mainte- nance, read only)-Pn8840000hCommunications Controls 2ImmediatelyPn8840Communications Controls 2ImmediatelyPn8840Communications Controls 2ImmediatelyPn8840Communications Controls 2ImmediatelyPn8840Communications Controls 2ImmediatelyPn8840Response Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8860hResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8850hAfter restartPn9000Number of Parameter BanksAfter restartPn9010Number of Parameter Bank MembersAfter restart	Pn86A	0000h	Monitor Allocations 3	Immediately
Pn881-Count Monitor [bytes] (for maintenance, read only)Pn882-Transmission Cycle Setting Monitor [x 0.25 µs] (for maintenance, read only)Pn882-Communications Cycle Setting Monitor [transmis- sion cycles] (for mainte- nance, read only)Pn883-Communications Cycle Setting Monitor [transmis- sion cycles] (for mainte- nance, read only)Pn8840000hCommunications Controls 2Pn8840MECHATROLINK Receive Error Counter Monitor (for maintenance, read only)Pn8840Command Data Monitor during Alarm/Warning (for maintenance, read only)Pn8860hResponse Data Monitor during Alarm/Warning (for maintenance, read only)Pn886 to Pn8860hResponse Data Monitor during Alarm/Warning (for maintenance, read only)Pn890 to Pn8860hAfter restart BanksPn9010Number of Parameter Bank MembersAfter restart	Pn880	_	(for maintenance, read only)	-
Pn882-Monitor [x 0.25 µs] (for maintenance, read only)-Pn883-Communications Cycle Setting Monitor [transmis- sion cycles] (for mainte- nance, read only)-Pn8840000hCommunications Controls 2ImmediatelyPn88A0MECHATROLINK Receive Error Counter Monitor (for maintenance, read only)-Pn88A0MECHATROLINK Receive Error Counter Monitor (for maintenance, read only)-Pn890 to Pn8A6OhResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8A8 to Pn8BEOhResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn8000Number of Parameter BanksAfter restartPn9010ImmediatelyNumber of Parameter BanksAfter restart	Pn881	_	Count Monitor [bytes] (for	_
Pn883-Setting Monitor [transmission cycles] (for maintenance, read only)-Pn8840000hCommunications Controls 2ImmediatelyPn88A0MECHATROLINK Receive Error Counter Monitor (for maintenance, read only)-Pn890 to Pn8A60hCommand Data Monitor during Alarm/Warning (for maintenance, read only)-Pn890 to Pn8A60hResponse Data Monitor 	Pn882	-	Monitor [× 0.25 µs] (for	-
Pn88A0MECHATROLINK Receive Error Counter Monitor (for maintenance, read only)Pn890 to Pn8A60hCommand Data Monitor during Alarm/Warning (for maintenance, read only)Pn8A8 to Pn8BE0hResponse Data Monitor during Alarm/Warning (for maintenance, read only)Pn800 to Pn8A8 to Pn8BE0hAfter restart BanksPn9000Number of Parameter BanksAfter restartPn9010After restart	Pn883	-	Setting Monitor [transmis- sion cycles] (for mainte-	_
Pn88A0Error Counter Monitor (for maintenance, read only)Pn890 to Pn8A60hCommand Data Monitor during Alarm/Warning (for 	Pn884	0000h		Immediately
Pn890 to Pn8A6Ohduring Alarm/Warning (for maintenance, read only)-Pn8A6 to Pn8BEOhResponse Data Monitor during Alarm/Warning (for maintenance, read only)-Pn800OhNumber of Parameter BanksAfter restartPn901ONumber of Parameter Bank MembersAfter restart	Pn88A	0	Error Counter Monitor (for maintenance, read only)	-
Pn8BEOhduring Alarm/Warning (for maintenance, read only)-Pn9000Number of Parameter BanksAfter restartPn9010Number of Parameter Bank MembersAfter restart		Oh	during Alarm/Warning (for	_
Pn900 0 Banks After restart Pn901 0 Number of Parameter Bank Members After restart		Oh	during Alarm/Warning (for	_
Physical Members After restart	Pn900	0		After restart
Continued on payt page	Pn901	0	Members	After restart

Parameter No.	Default Setting	Name	When Enabled
Pn902 to Pn910	0000h	Parameter Bank Member Definition	After restart
Pn920 to Pn95F	0000h	Parameter Bank Data (Not saved in nonvolatile mem- ory.)	Immediately
01 PnA02	_	Encoder Type Selection (read only)	-
02 PnA04	_	Motor Type Selection (read only)	-
03 PnA06	_	Semi-closed/Fully-closed Selection (read only)	-
04 PnA08	_	Rated Motor Speed (read only)	-
05 PnA0A	-	Maximum Output Speed (read only)	-
06 PnA0C	_	Speed Multiplier (read only)	-
07 PnA0E	-	Rated Torque (read only)	-
08 PnA10	-	Maximum Output Torque (read only)	-
09 PnA12	-	Torque Multiplier (read only)	-
0A PnA14	-	Resolution (read only)	-
0B PnA16	0	Scale Pitch	After restart
0C PnA18	_	Pulses per Scale Pitch (read only)	-
21 PnA42	16	Electronic Gear Ratio (Numerator)	After restart
22 PnA44	1	Electronic Gear Ratio (Denominator)	After restart
23 PnA46	0	Absolute Encoder Origin Offset	Immedi- ately ^{*2}
24 PnA48	65535	Multiturn Limit Setting	After restart
25 PnA4A	0000h	Limit Setting	After restart
26 PnA4C	1073741823	Forward Software Limit	Immediately
27 PnA4E	0	Reserved (Do not change.)	Immediately
28 PnA50	-1073741823	Reverse Software Limit	Immediately
29 PnA52	0	Reserved (Do not change.)	Immediately
41 PnA82	Oh	Speed Unit Selection	After restart
42 PnA84	0	Speed Base Unit Selection	After restart
43 PnA86	Oh	Position Unit Selection	After restart

14

	Continued from previous page.			
Parameter No.	Default Setting	Name	When Enabled	
44 PnA88	0	Position Base Unit Selec- tion	After restart	
45 PnA8A	Oh	Acceleration Unit Selection	After restart	
46 PnA8C	4	Acceleration Base Unit Selection	After restart	
47 PnA8E	1h	Torque Unit Selection	After restart	
48 PnA90	0	Torque Base Unit Selection	After restart	
49 PnA92	0601011Fh	Supported Unit Systems (read only)	_	
61 PnAC2	40000	Speed Loop Gain	Immediately	
62 PnAC4	20000	Speed Loop Integral Time Constant	Immediately	
63 PnAC6	40000	Position Loop Gain	Immediately	
64 PnAC8	0	Feedforward Compensation	Immediately	
65 PnACA	0	Position Loop Integral Time Constant	Immediately	
66 PnACC	7	Positioning Completed Width	Immediately	
67 PnACE	1073741824	Near Signal Width	Immediately	
81 PnB02	0	Exponential Acceleration/ Deceleration Time Constant	Immedi- ately ^{*3}	
82 PnB04	0	Movement Average Time	Immedi- ately ^{*3}	
83 PnB06	100	External Positioning Final Travel Distance	Immediately	
84 PnB08	\times 5,000h reference units/s converted to 10^{-3} min ⁻¹	Origin Approach Speed	Immediately	
85 PnB0A	× 500h reference units/s converted to 10 ⁻³ min ⁻¹	Origin Return Creep Speed	Immediately	
86 PnB0C	100	Final Travel Distance for Origin Return	Immediately	
87 PnB0E	1h	Fixed Monitor Selection 1	Immediately	
88 PnB10	Oh	Fixed Monitor Selection 2	Immediately	
89 PnB12	Oh	SEL_MON (CMN1) Monitor Selection 1	Immediately	
8A PnB14	Oh	SEL_MON (CMN2) Monitor Selection 2	Immediately	
8B PnB16	10	Origin Detection Width	Immediately	
8C PnB18	100	Forward Torque Limit	Immediately	
8D PnB1A	100	Reverse Torque Limit	Immediately	

Parameter No.	Default Setting	Name	When Enabled	
8E PnB1C	20000	Zero Speed Detection Range	Immediately	
8F PnB1E	10000	Speed Coincidence Signal Detection Width	Immediately	
90 PnB20	0FFF3F3Fh	Servo Command Control Field Enable/Disable Selec- tions (read only)	-	
91 PnB22	0FFF3F33h	Servo Status Field Enable/ Disable Selections (read only)	-	
92 PnB24	01FF01F0h	Output Bit Enable/Disable Selections (read only)	-	
93 PnB26	FF0FFEFEh	Input Bit Enable/Disable Selections (read only)	-	

*1. The enable timing depends on the digit that is changed. Refer to the following section for details.

 $\ast 2.$ The parameter setting is enabled after SENS_ON command execution is completed.

*3. Change the setting when the reference is stopped (i.e., while DEN is set to 1). If you change the setting during operation, the reference output will be affected.

14

Appendices

The appendix provides information on interpreting panel displays, and tables of corresponding SERVOPACK and SigmaWin+ function names.

15

15.1	Interp	reting Panel Displays15-2
	15.1.2 15.1.3 15.1.4	Interpreting Status Displays15-2Alarm and Warning Displays15-2Hard Wire Base Block Active Display15-2Overtravel Display15-2Forced Stop Display15-2
15.2	Corresp	onding SERVOPACK and SigmaWin+ Function Names 15-3
		Corresponding SERVOPACK Utility Function Names

15.1.1 Interpreting Status Displays

15.1 Interpreting Panel Displays

You can check the Servo Drive status on the panel display of the SERVOPACK. Also, if an alarm or warning occurs, the alarm or warning number will be displayed.

15.1.1 Interpreting Status Displays


The status is displayed as described below.

Display	Meaning	Display	Meaning
	/TGON (Rotation Detection) Signal Display Lit if the Servomotor speed is higher than the setting of Pn502 or Pn581 and not lit if the speed is lower than the setting. (The default set- ting is 20 min ⁻¹ or 20 mm/s.)		Reference Input Display Lit while a reference is being input.
	Base Block Display Lit during the base block state (servo OFF). Not lit while the servo is ON.		Control Power Supply ON Display Lit while the control power is being supplied

15.1.2 Alarm and Warning Displays

If there is an alarm or warning, the display will change in the following order.

Example: Alarm A.E60



15.1.3 Hard Wire Base Block Active Display

If a hard wire base block (HWBB) is active, the display will change in the following order.

15.1.4 Overtravel Display

If overtravel has occurred, the display will change in the following order.

◎ Forward Overtravel (P-OT)
 ② Reverse Overtravel (N-OT)
 ③ Forward and Reverse Overtravel
 ◆ Status Display → P → n

15.1.5 Forced Stop Display

During a forced stop, the following display will appear.

Status
$$\longrightarrow$$
 Not lit. $\longrightarrow F \longrightarrow$ Not lit. $\longrightarrow 5 \longrightarrow$ Not lit. $\longrightarrow E \longrightarrow$ Not lit. $\longrightarrow P \longrightarrow$ Not lit. $\longrightarrow P \longrightarrow$ Not lit.

15.2.1 Corresponding SERVOPACK Utility Function Names

15.2 Corresponding SERVOPACK and SigmaWin+ Function Names

This section gives the names and numbers of the utility functions and monitor display functions used by the SERVOPACKs and the names used by the SigmaWin+.

15.2.1 Corresponding SERVOPACK Utility Function Names

	SigmaWin+	SERVOPACK		
Button in Menu Dialog Box	Function Name	Fn No.	Function Name	
	Initialize	Fn005	Initializing Parameters	
	Software Reset	Fn030	Software Reset	
	Setup Wizard	-	-	
Daala Euroa	I/O Signal Allocation	-	-	
Basic Func- tions		Fn011	Display Servomotor Model	
		Fn012	Display Software Version	
	Product Information	Fn01E	Display SERVOPACK and Servomotor IDs	
		Fn01F	Display Servomotor ID from Feedback Option Module	
	Reset Absolute Encoder	Fn008	Reset Absolute Encoder	
	Multi-turn Limit Setup	Fn013	Multiturn Limit Setting after Multiturn Limit Disagreement Alarm	
Encoder	Search Origin	Fn003	Origin Search	
Setting	Zero Point Position Setting	Fn020	Set Absolute Linear Encoder Origin	
	Polarity Detection	Fn080	Polarity Detection	
	Motor Parameter Scale Write	-	-	
		Fn000	Display Alarm History	
	Display Alarm	Fn006	Clear Alarm History	
Trouble-		Fn014	Reset Option Module Configuration Error	
shooting	Alarm Trace	-	-	
	Reset Motor Type Alarm	Fn021	Reset Motor Type Alarm	
Ora anatiana	Jog	Fn002	Jog	
Operation	Program JOG Operation	Fn004	Jog Program	
	Trace	_	-	
N 4	Real Time Trace	-	-	
Monitor	Monitor	_	-	
	Life Monitor	_	-	
	Tuning - Autotuning without Host Refer- ence	Fn201	Advanced Autotuning without Reference	
	Tuning - Autotuning with Host Reference	Fn202	Advanced Autotuning with Reference	
	Tuning - Custom Tuning	Fn203	One-Parameter Tuning	
Tuning	Tuning - Custom Tuning - Adjust Anti-resonance Control	Fn204	Adjust Anti-resonance Control	
	Tuning - Custom Tuning - Vibration Suppression	Fn205	Vibration Suppression	
	System Tuning	-	-	
	Response Level Setting	Fn200	Tuning-less Level Setting	
	Edit Online Parameters	-	-	

15

15.2.1 Corresponding SERVOPACK Utility Function Names

Continued from previous page.

SigmaWin+		SERVOPACK		
Button in Menu Dialog Box	Function Name	Fn No.	Function Name	
	Mechanical Analysis	_	-	
Diagnostic	Easy FFT	Fn206	Easy FFT	
Diagnostic	Ripple Compensation	-	-	
	Online Vibration Monitor	-	-	
	Adjust the Analog Monitor Output	Fn00C	Adjust Analog Monitor Output Offset	
		Fn00D	Adjust Analog Monitor Output Gain	
	Adjust the Motor Current Detec- tion Offsets	Fn00E	Autotune Motor Current Detection Signal Offset	
		Fn00F	Manually Adjust Motor Current Detection Signal Offset	
Others	Initialize Vibration Detection Level	Fn01B	Initialize Vibration Detection Level	
	Parameter Converter	-	-	
	SERVOPACK Axis Name Setting	-	-	
	Write Prohibited Setting	Fn010	Write Prohibition Setting	
	Motor Parameter SERVOPACK Write	_	-	

15.2.2 Corresponding SERVOPACK Monitor Display Function Names

15.2.2 Corresponding SERVOPACK Monitor Display Function Names

	SigmaWin+		SERVOPACK
Button in Menu Dialog Box	Name [Unit]	Un No.	Name [Unit]
	Motor Speed [min ⁻¹]	Un000	Motor Speed [min ⁻¹]
	Speed Reference [min ⁻¹]	Un001	Speed Reference [min ⁻¹]
	Torque Reference [%]	Un002	Torque Reference [%] (percentage of rated torque)
	 Rotary Servomotors: Rotational Angle 1 [encoder pulses] (number of encoder pulses from origin within one encoder rotation) Linear Servomotors: Electrical Angle 1 [linear encoder pulses] (linear encoder pulses from the polarity origin) 	Un003	 Rotary Servomotors: Rotational Angle 1 [encoder pulses] (number of encoder pulses from origin within one encoder rotation displayed in decimal) Linear Servomotors: Electrical Angle 1 [linear encoder pulses] (linear encoder pulses from the polarity origin displayed in decimal)
	 Rotary Servomotors: Rotational Angle 2 [deg] (electrical angle from origin within one encoder rotation) Linear Servomotors: Electrical Angle 2 [deg] (electrical angle from polarity ori- gin) 	Un004	 Rotary Servomotors: Rotational Angle 2 [deg] (electrical angle from polarity origin) Linear Servomotors: Electrical Angle 2 [deg] (electrical angle from polarity origin)
	Input Reference Pulse Speed [min ⁻¹]	Un007	Input Reference Pulse Speed [min ⁻¹] (displayed only during position control)
Motion	Position Deviation [reference units]	Un008	Position Error Amount [reference units] (displayed only during position control)
Monitor	Accumulated Load Ratio [%]	Un009	Accumulated Load Ratio [%] (percentage of rated torque: effective torque in cycles of 10 seconds)
	Regenerative Load Ratio [%]	Un00A	Regenerative Load Ratio [%] (percentage of processable regenerative power: regenerative power consumption in cycles of 10 seconds)
	Input Reference Pulse Counter [ref- erence units]	Un00C	Input Reference Pulse Counter [reference units]
	Feedback Pulse Counter [encoder pulses]	Un00D	Feedback Pulse Counter [encoder pulses]
	Fully-closed Loop Feedback Pulse Counter [external encoder resolu- tion]	Un00E	Fully-closed Loop Feedback Pulse Counter [external encoder resolution]
	Upper Limit Setting of Motor Maxi- mum Speed/Upper Limit Setting of Encoder Output Resolution	Un010*1	Upper Limit Setting of Motor Maximum Speed/ Upper Limit Setting of Encoder Output Resolu- tion
	Total Operation Time [100 ms]	Un012	Total Operation Time [100 ms]
	Feedback Pulse Counter [reference units]	Un013	Feedback Pulse Counter [reference units]
	Overheat Protection Input [0.01 V]	Un02F	Overheat Protection Input [0.01 V]
	Current Backlash Compensation Value [0.1 reference units]	Un030	Current Backlash Compensation Value [0.1 reference units]
	Backlash Compensation Value Set- ting Limit [0.1 reference units]	Un031	Backlash Compensation Value Setting Limit [0.1 reference units]

Appendices

15

15.2.2 Corresponding SERVOPACK Monitor Display Function Names

Continued from previous page.

SigmaWin+			SERVOPACK		
Button in Menu Dialog Box	Name [Unit]	Un No.	Name [Unit]		
	Power Consumption [W]	Un032	Power Consumption [W]		
	Consumed Power [0.001 Wh]	Un033	Consumed Power [0.001 Wh]		
Motion	Cumulative Power Consumption [Wh]	Un034	Cumulative Power Consumption [Wh]		
	Energy Consumption of the Dynamic Brake Resistor [%]	Un03B	Dynamic Brake Resistor energy consumption [%] (Percentage of Pn601 (Dynamic Brake Resistor Allowable Energy Consumption))		
Monitor	Absolute Encoder Multiturn Data	Un040	Absolute Encoder Multiturn Data		
	Position within One Rotation of Absolute Encoder [encoder pulses]	Un041	Position within One Rotation of Absolute Encoder [encoder pulses]		
	Lower Bits of Absolute Encoder Position [encoder pulses]	Un042	Lower Bits of Absolute Encoder Position [encoder pulses]		
	Upper Bits of Absolute Encoder Position [encoder pulses]	Un043	Upper Bits of Absolute Encoder Position [encoder pulses]		
	Polarity Sensor Signal Monitor	Un011	Polarity Sensor Signal Monitor		
Status Monitor	Active Gain Monitor	Un014	Effective Gain Monitor (gain settings $1 = 1$, gain settings $2 = 2$)		
	Safety I/O Signal Monitor	Un015	Safety I/O Signal Monitor		
Input Sig- nal Moni- tor	Input Signal Monitor	Un005	Input Signal Monitor		
Output Signal Monitor	Output Signal Monitor	Un006	Output Signal Monitor		
	Installation Environment Monitor – SERVOPACK	Un025	SERVOPACK Installation Environment Monitor [%]		
	Installation Environment Monitor – Servomotor ^{*2}	Un026	Servomotor Installation Environment Monitor [%]		
Quarter	Service Life Prediction Monitor – Built-in Fan	Un027	Built-in Fan Remaining Life Ratio [%]		
Service Life Moni- tor	Service Life Prediction Monitor – Capacitor	Un028	Capacitor Remaining Life Ratio [%]		
	Service Life Prediction Monitor – Surge Prevention Circuit	Un029	Surge Prevention Circuit Remaining Life Ratio [%]		
	Service Life Prediction Monitor – Dynamic Brake Circuit ^{*3}	Un02A	Dynamic Brake Circuit Remaining Life Ratio [%]		
	Service Life Prediction Monitor – Built-in Brake Relay	Un036	Built-in Brake Relay Remaining Life Ratio [%]		
Product Informa- tion	Motor – Resolution	Un084	Linear Encoder Pitch (Scale pitch = Un084 \times 10 ^{Un085} [pm])		
		Un085	Linear Encoder Pitch Exponent (Scale pitch = Un084 × 10 ^{Un085} [pm])		
	-	Un020	Rated Motor Speed [min-1]		
_	-	Un021	Maximum Motor Speed [min ⁻¹]		
		1			

*1. You can use Un010 to monitor the upper limit setting for the maximum motor speed or the upper limit setting for the encoder output resolution.

You can monitor the upper limit of the encoder output resolution setting (Pn281) for the current maximum motor speed setting (Pn385), or you can monitor the upper limit of the maximum motor speed setting for the current Select which signal to monitor with Pn080 = $n.X\square\square\square$ (Calculation Method for Maximum Speed or Encoder Output Pulses).

*2. This applies to the following motors. The display will show 0 for all other models.

SGM7J, SGM7A, and SGM7G

*3. With SGD7S-210D, -260D, -280D, and -370D SERVOPACKs, you cannot check the remaining life ratio with the Service Life Prediction Monitor and Un02A because these SERVOPACKs are not equipped with a built-in dynamic brake circuit.

\langle Index angle

Symbols

/BK	6-33
/BK (Brake) signal	6-33
/CLT	
/CLT (Torque Limit Detection) signal	7-31
/COIN	
/COIN (Positioning Completion) signal	7-11
/HWBB1	4-37
/HWBB2	
/N-CL	7-28
/N-CL (Reverse External Torque Limit) signal	
/NEAR	
/NEAR (Near) signal	
/P-CL	7-28
/P-CL (Forward External Torque Limit) signal	
/S-RDY	
/S-RDY (Servo Ready) signal	
/TGON	
/TGON (Rotation Detection) signal	
/V-CMP	
/V-CMP (Speed Coincidence Detection) signal -	
/VLT	
/VLT (Speed Limit Detection) signal	
/WARN	
/WARN (Warning) signal	7-8

Α

A.CC07-38
absolute encoder 7-32
origin offset6-50
resetting6-47
wiring4-20
additional adjustment functions9-66
alarm reset possibility 13-5
ALM7-7
ALM (Servo Alarm) signal
Analog Monitor Connector 4-39
analog monitor factors 10-11
anti-resonance control9-51
automatic detection of connected motor 6-14
automatic gain switching 9-67
automatic notch filters 9-32
autotuning with a host reference 9-35
autotuning without a host reference 9-24

В

backlash compensation 9-7	5
base block (BB)	/i

battery

replacement13-3
block diagram 2-7
brake operation delay time
brake release delay time

С

CCW
clearing alarm history 13-46
CN1
CN2
CN3
CN5
CN6A
CN6B
CN7
CN8
coasting
coasting to a stop
coefficient of speed fluctuation 2-6
compatible adjustment functions
Computer Connector
connecting a safety function device 12-14
countermeasures against noise 4-5
current control mode selection9-74
current gain level setting
custom tuning9-42
CW

D

DC power supply input4-12
DC Reactor
terminals
wiring
DC reactor
wiring
decelerating to a stop6-37
detection timing for Overload Alarms (A.720)6-41
detection timing for Overload Warnings (A.910)6-40
diagnostic output circuits
diagnostic tools9-97
displaying alarm history13-45
dynamic brake applied
Dynamic Brake Resistor
allowable energy consumption 5-9
connections 5-7
resistance 5-9
dynamic brake stopping

Ε

EasyFFT9-99
EDM112-10
EDM1 (External Device Monitor) signal 12-10

electronic gear 6-42
encoder divided pulse output 7-19, 11-7
setting 7-24
signals 7-19
encoder resolution 6-43, 7-24
estimating the moment of inertia 9-16
External Regenerative Resistor 6-53
external torque limits 7-28

F

feedback pulse counter 6-22
feedforward9-33, 9-93
feedforward compensation 9-93
forcing the motor to stop 7-57
forward direction 11-6
forward rotation 6-15
friction compensation 9-33, 9-70
fully-closed system 11-2

G

gain switching 9-66
gravity compensation 9-72
grounding 4-8
group 1 alarms 6-38
group 2 alarms 6-39
G-SEL 9-67

н

hard wire base block (HWBB)	12-3
HWBB input signal specifications	12-7
hard wire base block (HWBB) state	12-5
detecting errors in HWBB signal	12-7
resetting	12-6
holding brake	6-32
HWBB 12-3,	12-5
detecting errors in HWBB signal	12-7
HWBB input signal specifications	12-7
HWBB state	
resetting	12-6

L

J

- - - - - - 8-7

- -

jogging - - - - -

- - -

L
limiting torque7-27
linear encoder
feedback resolution 6-44
scale pitch setting 6-16
wiring example 4-20
Linear Servomotor vi
line-driver output circuits 4-35
list of alarms 13-5
list of MECHATROLINK-III common parameters 14-48
list of parameters 14-2
MECHATROLINK-III common parameters 14-48
list of warnings 13-51

Μ

Main Circuit Cable vi
manual gain switching 9-67
manual tuning9-82
mechanical analysis9-97
mode switching
(changing between proportional and PI control) 9-93
Momentary Power Interruption Hold Time 7-15
monitor factors 10-11
motor current detection signal
automatic adjustment 7-53
manual adjustment
offset 7-53
motor direction setting 6-15
motor maximum speed 7-18
motor overload detection level 6-40
multiturn limit
Multiturn Limit Disagreement

Ν

Noise Filter 4-6
Noise Filter connection precautions 4-7
N-OT 6-27
N-OT (Reverse Drive Prohibit) signal 6-27
notch filters 9-85

0

operation for momentary power interruptions 7-15
origin search 8-18
output phase form7-20
overheat protection input 4-29
overload warnings6-40
overtravel 6-27
release method selection
warnings 6-30

Ρ

R

reactors
DC reactor connection terminal 4-11
DC reactor wiring 4-18
reference unit 6-42
Regenerative Resistor
connection 4-18
regenerative resistor6-53
regenerative resistor capacity 6-53
resetting alarms 13-43
resetting alarms detected in Option Modules 13-47
reverse direction 11-6
risk assessment 12-4
Rotary Servomotor vi

S

Safety Function Signals 4-36
safety functions 12-2
application examples 12-11
precautions
verification test 12-13
safety input circuits 4-36
scale pitch 6-16
selecting the phase sequence
for a Linear Servomotor 6-21
selecting torque limits 7-27
SEMI F47 function7-16
Serial Communications Connector 4-39

Serial Converter Unit6-16
Servo Drive vi
servo gains9-82
servo lockvi
servo OFFvi
servo ON vi
Servo Systemvi
Servomotor vi
Servomotor stopping method for alarms
SERVOPACK vi
inspections and part replacement
part names 1-4
ratings 2-2
specifications 2-4
status displays15-2
setting the origin
setting the position deviation overflow alarm level 9-8
setting the position deviation overflow alarm level
at servo ON
setting the vibration detection level9-10
setup parameters 6-4
SG4-30
SigmaWin+vi
signal allocations 7-4
sink circuits
software limits7-26
software reset
source circuits
speed detection method selection 9-75
speed limit during torque control
speed loop gain9-84
speed loop integral time constant9-84
Status Monitor10-3
stopping by applying the dynamic brake 6-37
stopping method for servo OFF 6-38
storage humidity 2-4
storage temperature 2-4
surrounding air humidity 2-4
surrounding air temperature 2-4
switching condition A

Т

test without a motor8-20
TH
three-phase, 400-VAC power supply input4-11
torque reference filter
trial operation
MECHATROLINK-III communications
troubleshooting alarms
troubleshooting warnings 13-53
tuning parameters 6-5
tuning-less

load level 9-14	
rigidity level 9-14	ł
tuning-less function 9-12	2
V vibration suppression 9-56	5
	ĺ
W	
writing parameters 6-17	1
Z	
zero clamping 6-37	7
ZONE output 7-60)
ZONE table 7-60)
ZONE N 7-60)
ZONE P 7-60)
ZONE signals 7-60)

Revision History

The revision dates and numbers of the revised manuals are given on the bottom of the back cover.

MANUAL NO. SIEP S800002 14B <1>-1 Web revision number Published in Japan May 2016 Date of publication

Date of Publication	Rev. No.	Web Rev. No.	Section	Revised Contents
September 2022	<14>	-	7.1.2, 7.1.6, 7.1.10, 9.12.1, 9.12.4, 13.2.1, 13.2.2, 13.2.4, 14.1.2	Partly revised.
			Back cover	Revision: Address
February 2022	<13>	0	Preface, 6.16.4, 6.17.2, 7.8.9, 7.12.1, 7.12.2, 14.2.2	Partly revised.
			Back cover	Revision: Address
September 2021	<12>	0	All chapters	Partly revised.
August 2020	<11>	0	Preface, 3.7, 6.15.1, 7.5.2, 9.5, 11.3.4, 14.1.2	Partly revised.
February 2020	<10>	0	4.4.3, 6.15.1, 6.17.2	Addition: Information on Linear Encoder from Canon Precision Inc.
November 2019	<9>	0	All chapters	Partly revised.
			Back cover	Revision: Address
February 2019	<8>	0	6.1.4, 8.6.3	Revision: Information in table of restrictions
	10.2.2, 10.2.3, 13.2.6, 13.2.7, 15.2.1Partly revised.13.2.3Addition: Reset prov Back coverBack coverRevision: Address		13.2.6, 13.2.7,	Partly revised.
		Addition: Reset procedure with the SigmaWin+		
			Back cover	Revision: Address
September 2018	<7>	0	All chapters	Partly revised.
			4.4.3, 6.15.1	Addition: Absolute linear encoder from Fagor Automation S. Coop.
			13.2.2	Revision: A.C90
			Back cover	Revision: Address
June 2018	<6>	0	All chapters	Partly revised.
October 2017	<5>	0	Preface	Revision: Information on UL standards and EU directives
			Chapter 5	Addition: Information on dynamic brake
			All chapters	Partly revised.
			Back cover	Revision: Address
January 2017	<4>	4> 0	1.4.1, 1.5.1, 1.5.2, 2.1.1, 2.1.2, 2.1.3, 2.2.1, 2.2.2, 2.3.1, 3.3, 3.4.2, 4.3.1, 4.3.2, 4.3.4, 5.12	Addition: Information on SGD7S-210D to -370D
			4.4.3	Addition: Specifications for diodes to prevent reverse current flow
			5.11.3, 6.13.2	Deletion: Torque from the parameter table for Pn406
			Back cover	Revision: Address
October 2016	<3>	0	All chapters	Partly revised.
June 2016	<2>	0	2.1.1	Revision: Value of continuous output current (Model: SGD7S-170D)

Date of Publication	Rev. No.	Web Rev. No.	Section	Revised Contents
May 2016	<1>	0	1.5.1, 1.5.2, 2.1.1, 2.1.2, 2.3.2, 3.3, 3.4.2, 4.3.4, 5.13, 13.1.2	Addition: Information on SGD7S-170D
			1.3, 1.4.1, 2.1.2, 4.2, 4.3.1, 4.4.4, 5.11.3, 5.11.5, 13.1.2, 14.1.2	Addition: Information on Servomotor brake control
			All chapters	Partly revised.
March 2016	-	-	-	First edition

Σ -7-Series AC Servo Drive Σ -7S SERVOPACK with 400 V-Input Power and MECHATROLINK-III **Communications References RJ-45** Connectors FT/EX Specification ZONE Outputs Product Manual

IRUMA BUSINESS CENTER (SOLUTION CENTER)

480, Kamifujisawa, Iruma, Saitama, 358-8555, Japar Phone: +81-4-2962-5151 Fax: +81-4-2962-6138 www.yaskawa.co.jp

YASKAWA AMERICA, INC.

2121, Norman Drive South, Waukegan, IL 60085, U.S.A. Phone: +1-800-YASKAWA (927-5292) or +1-847-887-7000 Fax: +1-847-887-7310 www.yaskawa.com

YASKAWA ELÉTRICO DO BRASIL LTDA.

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil Phone: +55-11-3585-1100 Fax: +55-11-3585-1187 www.yaskawa.com.br

YASKAWA EUROPE GmbH

Hauptstraße 185, 65760 Eschborn, Germany Phone: +49-6196-569-300 Fax: +49-6196-569-398 www.yaskawa.eu.com E-mail: info@yaskawa.eu.com

YASKAWA ELECTRIC KOREA CORPORATION

18F, Hi Investment & Securities Building, 66 Yeoui-daero, Yeongdeungpo-gu, Seoul, 07325, Korea Phone: +82-2-784-7844 Fax: +82-2-784-8495 www.yaskawa.co.kr

YASKAWA ASIA PACIFIC PTE. LTD. 30A, Kallang Place, #06-01, 339213, Singapor Phone: +65-6282-3003 Fax: +65-6289-3003 www.yaskawa.com.sg

YASKAWA ELECTRIC (THAILAND) CO., LTD. 59, 1F-5F, Flourish Building, Soi Ratchadapisek 18, Ratchadapisek Road, Huaykwang, Bangkok, 10310, Thailand Phone: +66-2-017-0099 Fax: +66-2-017-0799 www.yaskawa.co.th

YASKAWA ELECTRIC (CHINA) CO., LTD.

22F, Link Square 1, No.222, Hubin Road, Shanghai, 200021, China Phone: +86-21-5385-2200 Fax: +86-21-5385-3299 www.yaskawa.com.cn

YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE

Room 1011, Tower W3 Oriental Plaza, No.1, East Chang An Avenue, Dong Cheng District, Beijing, 100738, China Phone: +86-10-8518-4086 Fax: +86-10-8518-4082

YASKAWA ELECTRIC TAIWAN CORPORATION

12F, No. 207, Section 3, Beishin Road, Shindian District, New Taipei City 23143, Taiwan Phone: +886-2-8913-1333 Fax: +886-2-8913-1513 or +886-2-8913-1519 www.yaskawa.com.tw



VASKAWA ELECTRIC CORPORATION

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply. Specifications are subject to change without notice for ongoing product modifications and improvements

© 2016 YASKAWA ELECTRIC CORPORATION

MANUAL NO. SIEP S800002 140 <14>-0 Published in Japan September 2022 22-4-18 Original instructions